### **OWNER'S MANUAL**

Operation Maintenance Specifications

All information in this Owner's Manual is current at the time of publication. However, Genesis reserves the right to make changes at any time so that our policy of continual product improvement may be carried out.

This manual applies to all Genesis Branded Vehicle models and includes descriptions and explanations of optional as well as standard equipment.

As a result, you may find material in this manual that does not apply to your specific vehicle.

# CAUTION: MODIFICATIONS TO YOUR GENESIS BRANDED VEHICLE

Your Genesis Branded Vehicle should not be modified in any way. Such modifications may adversely affect the performance, safety or durability of your Genesis Branded Vehicle and may, in addition, violate conditions of the limited warranties covering the vehicle. Certain modifications may also be in violation of regulations established by the U.S. Department of Transportation and other federal or state agencies.

### TWO-WAY RADIO INSTALLATION

Your vehicle is equipped with a Tire Pressure Monitoring System, Passenger Occupant Classification System and other CAN bus systems. It is possible for an improperly installed/adjusted high powered two-way radio to adversely affect electronic systems. For this reason, we recommend that you carefully follow the radio manufacturer's instructions if you choose to install one of these devices.

#### SAFETY AND VEHICLE DAMAGE WARNING

This manual includes information titled as DANGER, WARNING, CAUTION and NOTICE.

These titles indicate the following:



### **DANGER**

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.



### WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.



### CAUTION

CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

### NOTICE

NOTICE indicates a situation which, if not avoided, could result in vehicle damage.

# GENESIS BRANDED VEHICLE OWNER PRIVACY POLICY

Your Genesis Branded Vehicle may be equipped with technologies and services that use information collected, generated, recorded or stored by the vehicle. Genesis Branded Vehicle has created a Vehicle Owner Privacy Policy to explain how these technologies and services collect use and share this information.

You may read our Vehicle Owner Privacy Policy on the GenesisMotorsUSA.com website at:

http://www.genesismotorsusa.com/privacy-policy.html
If you would like to receive a hard copy of our Vehicle Owner Privacy Policy,
please contact our Genesis Customer Care at:

Genesis Customer Care PO BOX 20650 Fountain Valley, CA 92728 844-340-9741

Genesis Customer Care representatives are available Monday through Friday, between the hours of 5:00 AM and 7:00 PM PST and Saturday and Sunday between 6:30 AM and 3:00 PM PST (English).

For Genesis Customer Care assistance in Spanish or Korean, representatives are available Monday through Friday between 6:30 AM and 3:00 PM PST.

# **Table of contents**

Introduction / Starting Your Electric Vehicle	1
Vehicle Information, Consumer Information, and Reporting Safety Defects	2
Seats and Safety System	3
Instrument Cluster	4
Convenience Features	5
Driving Your Vehicle	6
Driver Assistance System	7
Emergency Situations	8
Maintenance	9
Index	1

# 1. Introduction / Starting Your Electric Vehicle

Understanding Your Electric Venicle	-/
Characteristics of Your Electric Vehicles	1-7
Precautions when Using the High Voltage Battery	1-8
Using EV Mode Functions	1-9
Checking the EV Mode Screen Configuration	
Checking Energy Information	
Setting the Next Departure Time	
Setting Scheduled Charging and Climate	
Setting Battery Discharging Limit when Using Vehicle to Load (V2L)	
Setting Electric Vehicle Specialized Functions	
Setting the target battery charge level	
Setting the charging current	
Setting battery conditioning mode	
Setting utility mode	
, , ,	
Using V2L Function	
Safety Precautions when Using the V2L	
Using Electricity Outside the Vehicle	
Solving V2L Problems	
•	
Using Aux. Battery Saver+	
Charging Your Electric Vehicle	
Checking Basic Information on Charging Your Electric Vehicle	
Checking charging type and charging time	
Checking the charging status	
Checking the high voltage charging indicator	
Checking information on the charging label	
Setting charging connector locking mode	
Safety Precautions for Charging Your Electric Vehicle	
Using an AC Charger	
Using a DC Charger	
Using a Portable Charger (ICCB: In-Cable Control Box)	
Using the Scheduled Charging Function	
Checklist when Charging Does Not Start	

Driving Your Electric Vehicle	1-49
Starting Your Vehicle	1-49
Stopping Your Vehicle	
Virtual Engine Sound System	
Checking Electric Vehicle Driving Information	1-53
Countermeasures for Accidents or Fire	1-60 1-61
Turning off the High Voltage Battery	1-61

### INTRODUCTION

Congratulations, and thank you for choosing this Genesis Branded Vehicle. We are pleased to welcome you to the growing number of discerning people who drive the Genesis Branded Vehicle. We are very proud of the advanced engineering and high-quality construction of each Genesis Branded Vehicle we build.

Your Owner's Manual will introduce you to the features and operation of your new Genesis Branded Vehicle. To become familiar with your new Genesis Branded Vehicle, so that you can fully enjoy it, read this Owner's Manual carefully before driving your new vehicle.

This manual contains important safety information and instructions intended to familiarize you with your vehicle's controls and safety features so you can safely operate your vehicle.

This manual also contains information on maintenance designed to enhance safe operation of the vehicle. It is recommended that all service and maintenance on your car be performed by an authorized retailer of Genesis Branded products. Retailers of Genesis Branded products are prepared to provide high-quality service, maintenance and any other assistance that may be required.

This Owner's Manual should be considered a permanent part of your vehicle, and should be kept in the vehicle so you can refer to it at any time. The manual should stay with the vehicle if you sell it to provide the next owner with important operating, safety and maintenance information.

### **GENESIS CUSTOMER CARE**



### **CAUTION**

Severe vehicle damage may result from the use of poor quality fuels and lubricants that do not meet Genesis Branded Vehicle specifications. You must always use high quality lubricants that meet the specifications listed on Page 2-11 in the Vehicle Specifications section of the Owner's Manual.

Copyright 2022 Genesis Customer Care. All rights reserved. No part of this publication may be reproduced, stored in any retrieval system or transmitted in any form or by any means without the prior written permission of Genesis Customer Care.


1-3

#### **GUIDE TO GENESIS PARTS**

What are Genesis Parts?
 Genesis Parts are the same parts
 used by HYUNDAI Motor Company
 to manufacture vehicles. They are
 designed and tested for the optimum
 safety, performance, and reliability to
 our customers.



2. Why should you use Genesis Parts? Genesis Parts are engineered and built to meet rigid manufacturing requirements. Damage caused by using imitation, counterfeit or used salvage parts is not covered under the Genesis Branded New Vehicle Limited Warranty or any other Genesis Branded Vehicle warranty. In addition, any damage to or failure of Genesis Part caused by the installation or failure of an imitation, counterfeit or used salvage part is not covered by any Genesis Branded Vehicle Warranty.



3. How can you tell if you are purchasing Genesis Parts?

Look for the Genesis Parts Logo on the package. Genesis Parts exported to the U.S. are packaged with labels written only in English. Genesis Parts are only sold through an authorized retailer of Genesis Branded products.



### **HOW TO USE THIS MANUAL**

We want to help you get the greatest possible driving pleasure from your vehicle. Your Owner's Manual can assist you in many ways. We strongly recommend that you read the entire manual. In order to minimize the chance of death or injury, you must read the WARNING and CAUTION sections in the manual.

Illustrations complement the words in this manual to best explain how to enjoy your vehicle. By reading your manual, you will learn about features, important safety information, and driving tips under various road conditions.

The general layout of the manual is provided in the Table of Contents. Use the index when looking for a specific area or subject; it has an alphabetical listing of all information in your manual.

Sections: This manual has nine chapters plus an index. Each section begins with a brief list of contents so you can tell at a glance if that section has the information you want.

#### **SAFETY MESSAGES**

Your safety, and the safety of others, is very important. This Owner's Manual provides you with many safety precautions and operating procedures. This information alerts you to potential hazards that may hurt you or others, as well as damage your vehicle.

Safety messages found on vehicle labels and in this manual describe these hazards and what to do to avoid or reduce the risks.

Warnings and instructions contained in this manual are for your safety. Failure to follow safety warnings and instructions can lead to serious injury or death.

Throughout this manual DANGER, WARNING, CAUTION, NOTICE and the SAFETY ALERT SYMBOL will be used.



This is the safety alert symbol. It is used to alert you to potential physical injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death. The safety alert symbol precedes the signal words DANGER, WARNING and CAUTION.



DANGER indicates a hazardous situation that, if not avoided, will result in death or serious injury.



WARNING indicates a hazardous situation that, if not avoided, could result in death or serious injury.



CAUTION indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

### NOTICE

NOTICE indicates a situation that, if not avoided, could result in vehicle damage.

#### **VEHICLE MODIFICATIONS**

- This vehicle should not be modified. Modification of your vehicle could affect its performance, safety or durability and may even violate governmental safety and emissions regulations.
  - In addition, damage or performance problems resulting from any modification may not be covered under warranty.
- If you use unauthorized electronic devices, it may cause the vehicle to operate abnormally, wire damage, battery discharge and fire. For your safety, do not use unauthorized electronic devices.

### NOTICE

Some vehicle interior sounds (including welcome sound, navigation alerts, or warning sound) may be generated from the interior speakers and amplifier. Do not replace these components with anything other than the genuine Genesis factory parts. Any unauthorized product may cause a malfunction of the vehicle interior sounds that may affect the intended operation of the vehicle.

#### VEHICLE DATA COLLECTION AND EVENT DATA RECORDERS

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an airbag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less. The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating;
- Whether or not the driver and passenger safety belts were buckled/ fastened;
- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and,
- How fast the vehicle was traveling.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur.

NOTE: EDR data are recorded by your vehicle only if a non-trivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (for example, name, gender, age, and crash location) are recorded. However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

#### UNDERSTANDING YOUR ELECTRIC VEHICLE

Electric vehicles are driven using a battery and an electric motor. While general vehicles use an internal combustion engine and gasoline as fuel, electric vehicles use electrical energy that is charged inside the high voltage battery. As a result, electric vehicles are eco-friendly in that they do not require fuel and do not emit exhaust gases.

# Characteristics of Your Electric Vehicles

- Electric vehicles are driven using the electrical energy that is charged inside the high voltage battery. This method prevents air pollution since fuel, like gasoline, is not required, negating the emission of exhaust gases.
- A high performance electric motor is used in the vehicle as well. Compared to standard, internal combustion engine vehicles, engine noise and vibrations are much more minimal when driving.
- When decelerating or driving downhill, regenerative braking is utilized to charge the high voltage battery. This minimizes energy loss and increases the distance to empty.
- When the battery charge is not sufficient, AC charge, DC charge and trickle charge are available. (Refer to the "Charging Your Electric Vehicle" section in this chapter for details.)

### *i* Information

What does regenerative braking do? It uses an electric motor when decelerating and braking and transforms kinetic energy to electrical energy in order to charge the high voltage battery. (Torque is applied in the opposite direction when decelerating to generate braking force and electric energy.)

#### **Battery information**

- High voltage battery (high-capacity):
   Drives the motor and operates the air-conditioner. It can be charged via an AC charger, DC charger, or portable charger.
- 12 V auxiliary battery: Operates all lamps, wipers, and audio system.
   The 12 V battery charge can also be maintained by the high voltage battery at parked condition at certain conditions.

# Main components of your electric vehicle

- On-Board Charger (OBC): A device that charges the high voltage battery by converting AC power of the power grid to DC power.
- Inverter: Transforms direct current into alternating current to supply power to the motor, and transforms alternating current into direct current to charge the high voltage battery.
- Low Voltage DC-DC Converter (LDC): Transforms power from the high voltage battery to low voltage (12 V) to supply power to the vehicle (DC-DC).
- Vehicle Control Unit (VCU): Control the various controls on the vehicle.
- Motor: Uses electrical energy stored inside the high voltage battery to drive the vehicle (functions like an engine in a standard vehicle).
- Gear: Delivers rotational force of the motor to the tires at appropriate speeds and torque.
- High voltage battery (Lithium-ion battery): Stores and supplies power necessary for the electric vehicle to operate (12 V auxiliary battery provides power to the vehicle features such as lights and wipers).

### **MARNING**

- Do not intentionally remove or disassemble high voltage components and high voltage battery connectors and wires. Also, be careful not to damage high voltage components and the high voltage battery. It may cause serious injury and significantly impact the performance and durability of the vehicle.
- When inspection and maintenance is required for high voltage components and the high voltage battery, contact an authorized retailer of Genesis Branded products.

### High voltage battery warmer system

The high voltage battery warmer system prevents reduction of battery output when battery temperature is low. If the charging connector is connected, the warmer system automatically operates according to the battery temperature. Charging time may shorten compare to vehicles without the high voltage battery warmer system. However, electricity charge may increase because of high voltage battery warmer system operation.



#### Information

The high voltage battery warmer system operates when the charging connector is connected to the vehicle. However, the high voltage warmer system may not operate when battery temperature drops below -31 °F (-35 °C).

### Precautions when Using the High Voltage Battery

- Keep the gauge of the high voltage battery from going below L (Low).
   Storing the vehicle while the battery level is low for a long time may damage the battery or reduce the battery's capacity, resulting in needing a battery replacement.
- If a collision occurs, have the vehicle inspected by an authorized retailer of Genesis Branded products to check the battery connection status.
- Using the V2L function may reduce the driving distance due to the use of high voltage battery energy, and repeated use of the V2L function may decrease high voltage battery life.
- Frequent use of DC charging may impact battery life.
- The high voltage battery level may reduce naturally even if the vehicle is not driven.
- Storing the vehicle in temperatures that are too hot or cold may degrade the battery performance.
- The distance to empty or power output may differ depending on the driving conditions, such as the outside temperature. Driving at high speeds or uphill may increase battery consumption, resulting in reducing the distance to empty.

- If you use the air conditioning or heating, which is powered by the high voltage battery, the distance to empty may reduce. Maintain proper temperature when using the air conditioner or heater.
- Natural degradation may occur with the high voltage battery depending on the number of years the vehicle is used.
- If you do not use the vehicle for a long time, charge the high voltage battery once every three months to prevent it from discharging. When the battery level is low, immediately charge the vehicle.
- Using AC charging as much as possible can help keep the battery in optimal condition. Fully charging the battery when it is 20 % or lower helps keep the battery in optimal condition. (Charging once a month or more is recommended.)
- The charging level value displayed on the instrument cluster may decrease according to the charging conditions (charger status, outside temperature, battery temperature, etc.). For longer battery life and safety, after a certain charging level is reached, the charging current is gradually lowered to fully charge the battery.

#### USING EV MODE FUNCTIONS



EV mode provides driving information and high voltage battery information. You can set various electronic vehicle functions in EV mode.



### Information


The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

# **Checking the EV Mode Screen Configuration**

Follow the instructions below to enter EV mode and check the screen configuration.

- On the infotainment system, swipe the Home screen to the left to display the All menus screen.
- 2. On the All menus screen, select EV.
  - The EV mode screen appears.

### The details of the EV mode screen is as follows:



No.	Name	Description
(1)	Energy information	You can check the distance to empty, total battery power remaining, and expected charging time for each charge type.
(2)	Next departure time	You can set anticipated departure time for scheduled charging and target temperature.
(3)	Scheduled charging and climate control	You can set the date and time of when to charge the battery and the climate control temperature. Also, you may select the time to start charging using the off-peak time setting.
(4)	Vehicle to Load (V2L) setting	You can set the battery discharging limit (%) for the high voltage battery for driving.
(5)	EV setting	You can set various electric vehicle specialized functions. For more information, refer to the "Setting Electric Vehicle Specialized Functions" section in this chapter.

### **Checking Energy Information**

Check the distance to empty, State of Charge (SOC), and expected charging time and charge the vehicle if necessary.

- For more information about charging the vehicle, refer to the "Charging Your Electric Vehicle" section on page 1-26.
- On the infotainment system, swipe the Home screen to the left to display the All menus screen.



- 2. On the All menus screen, select **EV** and select the vehicle image.
- 3. On the Energy Information screen, select each item to check the vehicle energy information.

### Checking the battery status



On the Energy Information screen, select **Battery Status**.

- You can check the current charge level, expected distance to empty, and charging time for each charge type.
- For more information about setting target battery charge level, refer to the "Setting the Target Battery Charge Level" section in this chapter.

### *i* Information

- The distance to empty is calculated based on the electric energy economy history and outside temperature while driving. The distance may change if the driving pattern changes.
- The distance to empty may vary depending on the change of the driving pattern even if the same target battery charge level is set.

#### Checking electricity use

On the Energy Information screen, select **Electricity Use**.

• You can check the current energy consumption for each vehicle system.



OJKEVQ012047L

- Drivetrain: Shows the percentage of instantaneous and regenerative energy consumed by the motor to drive the vehicle.
- (2) Climate: Shows the power and energy consumption used by the air conditioner or heater.
- (3) Electronics: Shows the power and energy consumption used by the vehicle system, including the instrument cluster, infotainment system (speaker and navigation), headlight, vehicle control unit, etc.
- (4) Battery Care: Shows the momentary power and energy consumption used when increasing and cooling down the battery temperature to maintain optimal battery performance.

# Checking the electric energy economy history

On the Energy Information screen, select **EV Economy History**.

 You can check the history of electric energy economy with the date and distance of previous driving.

### **Setting the Next Departure Time**

You can set an anticipated departure time for scheduled charging and target temperature.



### Information

- Scheduled charging and climate will be activated based on the departure time.
- To use scheduled charging and climate function, the vehicle must be connected to the charger at the scheduled time.
- The scheduled climate function directly uses the power of the connected charger. It can maintain a pleasant environment and enhance vehicle performance by controlling the temperature of the vehicle and the battery without using the high voltage battery power.
- On the infotainment system, swipe the Home screen to the left to display the All menus screen.



On the All menus screen, select EV > Next Departure Time.



OJKEVQ012012L

3. Set the anticipated departure schedule.



- 4. Set anticipated time (1) the vehicle will departure after charging.
- 5. At **Repeat** option (2), select the day of the week to activate scheduled charging and target temperature for the departure time.

### **Setting Scheduled Charging and** Climate



You can set the date and time of when to charge the battery and the climate control temperature. Also, you may select the time to start charging using the off-peak time setting.



- Scheduled charging and climate can be activated based on the departure time.
- To use scheduled charging and climate function, the vehicle must be connected to the charger at the scheduled time.
- The scheduled climate function. directly uses the power of the connected charger. It can maintain a pleasant environment and enhance vehicle performance by controlling the temperature of the vehicle and the battery without using the high voltage battery power

### Setting scheduled charging

Follow the instructions below to set the off-peak time and scheduled charging option.

 On the infotainment system, swipe the Home screen to the left to display the All menus screen.



OJKEVQ012015L

On the All menus screen, select EV > Scheduled Charging and Climate > Scheduled Charging.



3. Set the off-peak hours at **Start Time** (1) and **End Time** (2).

- 4. Select the charging option (3).
  - Prioritize Off-peak Charging:
     Charging is activated during the off-peak time. It may keep on charging pass off-peak time to reach the target battery charge level.
  - Charge ONLY during Off-peak:
     Charging is activated only during the off-peak time. It may not be able to reach the target battery charge level.
  - For more information about setting the target battery charge level, refer to the "Setting the Target Battery Charge Level" section in this chapter

#### Setting a scheduled climate

Follow the instructions below to set the scheduled climate control temperature.

- On the infotainment system, swipe the Home screen to the left to display the All menus screen.
- On the All menus screen, select EV > Scheduled Charging and Climate > Scheduled Charging.



- 3. Set the desired temperature (1).
  - The air conditioning system is activated at the departure time.
  - For more information about setting the departure time, refer to the "Setting a next departure time" section in this chapter.

### Setting Battery Discharging Limit when Using Vehicle to Load (V2L)

Setting battery discharging limit (%) can prevent the battery from discharging when operating home appliances or electric devices using the high voltage battery.

 For more information about V2L function, refer to the "Using V2L Function" section in this chapter.

### **Information**

V2L provides AC power using the high voltage battery to operate electric devices. You can operate home appliances and electric devices, or charge another electric vehicle in emergency while camping or doing other outdoor activities.

- On the infotainment system, swipe the Home screen to the left to display the All menus screen.
- On the All menus screen, select EV > EV Charge Transfer.



- 3. Set the desired battery discharging limit (%).
  - The battery discharging limit can be set below the current high voltage battery level.
  - When the high voltage battery level reaches the set battery discharging limit, V2L function automatically cuts off electrical supply.

### Setting Electric Vehicle Specialized Functions

You can set various EV specialized functions such as target battery charge level, charging current, battery conditioning mode, and utility mode from the EV Settings screen.

### Setting the target battery charge level

Follow the instructions below to set the target battery charge level when charged with an AC charger or a DC charger.

 On the infotainment system, swipe the Home screen to the left to display the All menus screen.



UJKEVQUIZUZO

- On the All menus screen, select EV >
   (EV Settings) > Max. % Charge.
- Set each of the target battery charge level for AC charging and DC charging.
  - The charging level can be changed by 10 %.
  - If the target battery charge level is lower than the current high voltage battery charge level, the battery will not be charged.

### Setting the charging current

Follow the instructions below to set the charging current when using an AC charger or a portable charger.

 On the infotainment system, swipe the Home screen to the left to display the All menus screen.



- On the All menus screen, select EV >
   (EV Settings) > Charging Current.
  - If the charging stops before reaching the target battery charge level while charging with an AC charger or a portable charger, reduce the size of the input current and retry charging.
  - The charging time may differ depending on which charging current is selected.

### Setting battery conditioning mode

The Battery conditioning mode is efficient during the winter time when the high voltage battery temperature is low. This mode is recommended to improve driving and DC charging performances during winter by raising the battery temperature to an adequate level.

 On the infotainment system, swipe the Home screen to the left to display the All menus screen.



On the All menus screen, select EV > ♥ (EV Settings) > Battery Conditioning Mode.

### *i* Information

- The driving distance may be reduced as the energy is required to increase battery temperature.
- If the battery temperature is low during driving or when the scheduled air conditioner/heater is activated, this mode is operated to improve driving performance. However, the mode is not operated to ensure driving distance when the battery level is low.
- If you set the DC charging station as your destination while using the battery conditioning mode, the battery temperature is optimized for charging and you can shorten the charging time after you arrive and start charging.
- Battery conditioning mode is available for vehicles equipped with the battery heater.

### Setting utility mode

Utility mode allows the high voltage battery to be used instead of the 12 V auxiliary battery for purposes other than driving. You can use the audio and lights of your vehicle without discharging the 12 V auxiliary battery and even use the indoor V2L feature.

### *i* Information

- You cannot drive the vehicle while the utility mode is activated, and the gear can only be shifted to P (Park).
- You can use every electric device in the vehicle while the utility mode is activated.
- When the utility mode is activated, the Electronic Parking Brake (EPB) is applied automatically.

Follow the instructions below to set the utility mode.

- Check the operation conditions of the utility mode.
  - The **READY** indicator is displayed on the instrument cluster.
  - The gear is shifted to P (Park).
- 2. On the infotainment system, swipe the Home screen to the left to display the All menus screen.



- On the All menus screen, select EV > (EV Settings) > Utility Mode and select Activate Utility Mode to activate the function (Utility Mode: ON).
  - The READY indicator turns off and the UTIL indicator illuminates on the instrument cluster and the EPB is applied.
  - The utility mode can be deactivated by pressing the Start/Stop button to the OFF position.
  - If you want to utilize V2L function in the vehicle while the utility mode is activated, refer to the "Using Electricity Inside the Vehicle" section in this chapter.



### Information

If the utility mode is not activated when the vehicle is in the ready mode (**READY** indicator on) mode and the gear is shifted to P (Park), check the operation status of EPB.

# Searching for nearby charging stations

You can search for a charging station along your current route, near your current location, near your destination, or at a specific charging station.

- On the infotainment system, swipe the Home screen to the left to display the All menus screen.
- On the All menus screen, select EV and select the charging station icon (\*) next to the vehicle image.



- 3. Choose a searching option from the list on the left side of the screen.
  - You can choose among Along Route, Near Current Position, Near Destination, Near Center of Map and Favorite Station.
  - The direction (arrow) and distance, charger type, address, and location on the map of the charging stations corresponding to the selected option are displayed on the right side of the screen.

### **USING V2L FUNCTION (IF EQUIPPED)**

Using the Vehicle to Load (V2L) feature, you can turn on electric devices by connecting them to the high voltage battery.

# Safety Precautions when Using the V2L

Before using the V2L function, read and comply with all the safety information below. Failure to do so may cause electric shock or fire and result in serious injury, death, vehicle malfunction, or property damage.

Precautions when using the V2L function



- Do not use the V2L function if the V2L connector, charging inlet, power plug, or cable is damaged, corroded, or rusted.
- Do not touch the V2L connector, charging inlet, or power plug with wet hands.
- Do not use the V2L function if the connection part of the V2L connector and the charging inlet is loose.
- Check if there is no water, dust, or other contaminants before connecting the connector and the power plug. They may cause electric shock or fire.
- Do not put metal objects or touch the V2L connector or charging inlet with bare hands.

- For electric devices used outdoors in a vehicle, use a product that is waterproof or use it in a waterproof environment. If rain or humidity intrude into electric devices, multioutlets, extension cords, etc., it may cause electric shock or damage the vehicle or devices.
- If there is a risk of lightning, do not use the V2L function outside the vehicle.
- Do not use an electric heating appliances such as an electric kettle, toaster, or iron in the vehicle. Doing so may result in a fire and injury.

Precautions when the cooling fan operate



### ! WARNING



When using the V2L, the cooling fan in the vehicle motor compartment can operate automatically even if the vehicle is turned off. Do not put your hand near the cooling fan when the V2L is operating.

### Precautions for handling and using the V2L connector

### **CAUTION**

 Do not modify or disassemble the V2L connector. It may cause fire, electric shock, or injury. Damage to your vehicle caused by modification and disassembling is not covered by warranty.



Be careful when connecting or disconnecting the power plug to the V2L connector or when opening or closing the V2L connector cover. You may scratch your hand.

- Do not place objects on the V2L connector. It may damage the cable and cause electric shock or fire.
- Do not drop the V2L connector or apply any impact on it. Keep it clean in a dry place without water or humidity.

### NOTICE

- Be sure to disconnect the V2L connector from the vehicle when you are finished using the V2L function.
- Do not charge the vehicle using the V2L connector. If you charge the vehicle by modifying the power cable of the connector, etc., it may damage the vehicle

### Precautions when using electric/ electronic products




### **CAUTION**

- Before using the product, check the precautions and how to use the product referring to the product manual.
- Only use products that have obtained national safety certification.
- Only use an electric device that does not exceed the maximum power capacity that the vehicle can supply. However, some of the electric devices may not operate normally even if the product has power consumption less than the maximum power capacity provided by the vehicle.
  - Electric devices that require high power during initial operation.
  - Measuring devices that need to process accurate data.
  - Electric devices that are sensitive to inverter type AC charger.
- Do not use products that require a continuous power supply, such as medical equipment. The power supply may be interrupted depending on the vehicle's condition.
- The V2L discharging mode is blocked automatically in case of overheating. When the discharging mode is blocked, check whether the V2L connector or power plug is contaminated, worn, corroded or broken.
  - If the temperature falls to a proper level after it is left unattended, you can use it again.
  - If overheating repeats when using a certain electric device, do not use the electric device.

- Do not connect more than two extension cords or multi-outlet. Also, when using the extension cable, ensure that the cable is not twisted. Heat from the overlapped cable may cause fire.
- Do not hang home appliances on the wire.
- Do not use if the insulation of home appliance cables is damaged or broken.
- Fully insert the power plug when connecting it to the power.
- Only use qualified power plug with ground connection that meets the standard. Do not use worn, corroded, or broken power plug or improper power plug that does not meet the standard.

# Using Electricity Outside the Vehicle

Follow the instructions below to connect the V2L connector to the charging inlet on the vehicle and supply power to an electronic product.



- 1. Open the cover of the V2L connector.
- 2. Close the cover after connecting home appliances and electric devices to the power outlet.

### **MARNING**

Some types of plugs may not fit into the outlet cover of the V2L connector, causing incomplete closing of the cover.

Do not use the V2L connector on a rainy or snowy day if the outlet cover is not completely closed. There is a risk of fire and/or injury.

- 3. Open the charging door and connect the V2L connector to the charging inlet on the vehicle.
  - Connect the V2L connector to the charging inlet within 60 seconds after opening the charging door.
- 4. Press the power switch (A) of the V2L connector.
  - The power is supplied and the indicator (B) on the V2L connector is turned on.

### *i* Information

- When the V2L connector is connected to the charging inlet of the vehicle, all doors and connectors are automatically locked to prevent theft. To disconnect the V2L connector, unlock the door and pull the connector with the release button pressed.
- Before using the V2L function, deactivate the scheduled climate setting. Refer to the "Setting scheduled charging and climate" section. The V2L function may be cut off depending on the scheduled climate setting.
- To check and change the V2L setting, refer to the "Setting Battery Discharging Limit when Using Vehicle to Load (V2L)" section.
- If an electric device that exceeds the maximum power capacity is connected, a warning message appears on the instrument cluster and the power supply shuts off immediately.

# Using Electricity Inside the Vehicle



You can connect home appliances or electric devices to the power outlet inside the vehicle.



### WARNING

Do not use an electric heating appliances such as electric kettle, toaster, or iron in the vehicle. It may cause a fire or injury.

- Press the Start/Stop button to the ON position or activate the utility mode.
  - For more information about the utility mode, refer to the "Setting Utility Mode" section in this chapter.



Use the smart key to unlock the power outlet cover.

3. Open the power outlet cover by sliding it to the left and connect the power plug of the electric device to the power socket.

### *i* Information

• The indicator on the power outlet indicates the operation status.



- Blue: Standby
- Red: The power outlet is connected but no power is supplied.
- Green: The power outlet is connected, and the power is supplied normally.
- V2L discharging mode shuts off if the vehicle turns off while using indoor V2L when the vehicle is on.
- Opening the charging door or connecting the V2L connector to the charging inlet, the V2L discharging mode shuts off.
- If you want to use the indoor and outdoor V2L simultaneously, first connect the V2L connector to the charging inlet and then use the indoor V2L.

- When the high voltage battery charge level reaches the set discharging limit (%), the operation stops, and a warning message appears on the instrument cluster. If you want V2L operation, set the discharging limit (%) lower than the current battery charge.
  - For more information about the discharging limit, refer to the "Setting Battery Discharging Limit when Using Vehicle to Load (V2L)" section in this chapter.
  - For more information about warnings, refer to the "Warning and Indicator Lights" section in this chapter.

### **Solving V2L Problems**

If a problem occurs while using the V2L function, the V2L stops operating and related messages appears on the instrument cluster.

Check the cause of the message and take appropriate measures referring to the following table.

	Tollowing table.				
Message	Cause	Measure			
V2L has ended. Battery level has reached the set value  ONE1Q011077L  V2L has ended. Battery level has reached the set value	The high voltage battery level reaches the discharging limit set level.	To use the V2L continuously, make the discharging limit set level lower than the present battery level. (Refer to the "Setting Battery Discharging Limit when Using Vehicle to Load (V2L)" section in this chapter.)			
V2L stopped due to excessive power use  ONE1Q011078L  V2L stopped due to excessive power use	An electrical appliance that exceeds the maximum power output the vehicle can supply is connected.	Check the total power consumption of the electrical appliance and replace it with a product that is within the V2L maximum power output.			
V2L conditions not met  OJKEVQ012117N  V2L conditions not met	V2L is stopped for the following reasons: - V2L connector switch is off - V2L connector is overheated - Opening the charging door while using the V2L indoor outlet	Make sure there are no problems with the V2L connector and the vehicle indoor outlet.			

### **USING AUX. BATTERY SAVER+**

The Aux. Battery Saver+ is a function that monitors the charging status of the 12 V auxiliary battery. If the auxiliary battery level is low, the main high voltage battery charges the auxiliary battery.

### $\overline{i}$ In

### Information

- The Aux. Battery Saver+ function cannot prevent battery discharge if the auxiliary battery is damaged, worn out, used as a power supply or unauthorized electronic devices are
- If the Aux. Battery Saver+ function was activated, the high voltage battery level may have decreased.

### A

### **WARNING**

When this function is activating, the indicator lamp illuminates and the high voltage electricity flows into the vehicle. Do not touch the high voltage electric wire, connector, or any electrical components and devices. This may cause an electric shock and lead to injuries. Also, do not modify your vehicle in any way. This may affect your vehicle performance and lead to an accident.

#### CHARGING YOUR ELECTRIC VEHICLE

### Checking Basic Information on Charging Your Electric Vehicle Checking charging type and charging time

The charge types for electric vehicle are as follows:

- AC Charge: The electric vehicle is charged by plugging into a AC charger installed at your home or a public charging station.
- DC Charge: You can charge at high speed at public charging stations. Refer to the respective company's charger app or online information that is provided for each DC charger type.
  - Battery performance and durability may be impacted if the DC charger is used constantly.
- Portable Charge: The Electric vehicle can be charged by using household electricity.
  The electrical outlet at your home must comply with regulations and can safely
  accommodate the Voltage / Current (Amps) / Power (Watts) ratings specified on the
  portable charge.

Category	AC Charge	DC Charge	Portable Charge
Charging Inlet (Vehicle)	ORG3EVQ011029	ORG3EVQ011030	ORG3EVQ011029
Charging Connector	ORG3EVQ011090	OAEEQ016079N	ORG3EVQ011090
Charging Outlet	OLFPOQ4057N	OAEEQ016023	ONX4EPHQ011019L
How to Charge	Use AC charger installed at home or public charging stations	Use the DC charger at public charging stations	Use household current

 Actual charger image and charging method may differ depending on the charger manufacturer.



Type 3R enclosure satisfies the requirements of UL 50E standard when the charging connector is connected to the vehicle side charging inlet. An additional Type 3R enclosure should be provided in the end installation of the vehicle side charging inlet. The "Type 3R" marking can be found on the charging inlet.

 What is type 3R?: Performance requirement for enclosures intended for outdoor use that provides a degree of protection against falling dirt, rain, sleet, and/or snow.

### **CAUTION**

- Risk of electric shock, do not disconnect under load.
- Suitable for use on a circuit capable of delivering not more than 5000 rms symmetrical amperes, 120 volts AC maximum.
- Suitable for use on a circuit capable of delivering not more than 30000 rms symmetrical amperes, 1000 volts DC maximum.

The estimated charging time for each charging type is as follows:

Charging Type	Standard Battery Type	
AC charge	Takes about 7 hours and 5 minutes at room temperature when charged to 100 %.	
	350 kW charger	Takes about 18 minutes at room temperature when charged from 10 % to 80 %. Can be charged to 100 %.
DC charge	50 kW charger	Takes about 1 hour and 13 minutes at room temperature when charged from 10 % to 80 %. Can be charged to 100 %.
Portable charge (ICCB: In-Cable Control Box)	Takes about 68 hours at room temperature when charged to 100 %.	

### *i* Information

- The DC charging time may be longer at cold temperature below 20 °F (-17 °C).
- Depending on the condition and durability of the high voltage battery, charger specifications, and ambient temperature, the time required for charging the high voltage battery may vary.

### Checking the charging status

Check the State of Charge (SOC) of the high voltage battery via the charge indicator lamp inside the charging door.

- With the vehicle door unlocked, press the open indicator on the charging door to open the charging door.
- 2. Check the charge indicator lamp inside the charging door.
  - SOC is indicated in 4 levels.



### (1) Charging Status

Lamp Status	Details	
yellow	High voltage battery level very low	
green	High voltage battery level low	
green	High voltage battery level middle	
B	High voltage battery level high	
green	•	

### (2) Immediate charging

Lamp Status	Details
OFF	Scheduled charging deactivation button. Press 2 seconds to charge immediately.

# Checking the high voltage charging indicator



The high voltage indicator is located on top of the dashboard. When the 12 V auxiliary battery is discharged, it is charged from the high voltage battery of the vehicle. When the high voltage electricity flows in the vehicle, the color of the indicator changes to amber and turns off after charging is finished.

### **!** WARNING

When the function is activating, the Charging Indicator will turn on and high voltage electricity will be flowing in the vehicle. Do not touch the high voltage electric wire (orange), connector, and all electric components and devices. This may cause electric shock and lead to injuries. Also, do not modify your vehicle in any way. This may affect your vehicle performance and lead to an accident.

# Checking information on the charging label



You can find the charging label when the charging door is opened.



- (1) Warning for high voltage: Indicates a device with a risk of electric shock.
- (2) Warning/Caution symbol: Indicates a device that may cause property damage, serious injury or death if not operated carefully.
- (3) Rated voltage and maximum charging current: Indicates a device that may cause property damage, serious injury or death if not operated carefully.



Risks of failure, fire, injury, etc., are expected when using the charging connector with unmatched symbol.

# Setting charging connector locking mode



You can lock the charging connector during AC charging to prevent unintended detachment of the charging connector from the vehicle.

On the infotainment system, select EV > (EV Settings) > Lock Charging Cable to set the locking mode of the charging connector.

### Information

- The charging inlet is locked during DC charging regardless of the charging connector locking mode setting. After charging is completed, the locked charging inlet is unlocked.
- The charging inlet locks when the V2L connector is connected, regardless of the charging connector locking mode setting.
   After use, the lights can be turned off by pressing the switch on the V2L connector, and the charging inlet can be unlocked by pressing the vehicle door unlock button.

#### When the Charging Connector Is Locked

	Always	Lock While Charging	Do Not Lock
Before charging	Yes	No	No
While charging	Yes	Yes	No
Finished charging	Yes	No	No

#### Always mode:

The connector locks when the charging connector is plugged into the charging inlet. The connector is locked until all doors are unlocked by the driver. This mode can be used to prevent portable charging cable theft.

- The charging connector unlocks when all doors are unlocked. If the charging cable is not disconnected within 15 seconds, it is automatically locked again.
- If the charging connector is unlocked when all doors are unlocked, but all doors are locked again immediately, the connector is automatically locked again.

#### Lock while charging mode:

The connector locks when charging starts. The connector unlocks when charging is complete. This mode can be used when charging in a public charging station so that other customers can use the charger after your vehicle finishes charging.

Do not lock mode (if equipped):

The connector unlocks regardless of the state of charging. Press the charging connector release button to disconnect the connector.

Be careful of portable charging cable theft.

# Disconnecting the charging connector in an emergency



If the charging connector does not disconnect from the charging inlet due to battery discharge and failure of electric wires, open the hood and slightly pull the emergency cable. The charging connector is disconnected from the charging inlet.

### Safety Precautions for Charging Your Electric Vehicle

Before charging your electric vehicle, read and comply with all the safety information below. Failure to do so may cause electric shock or fire and result in a serious injury, death, vehicle malfunction, or property damage.

# Precautions for electric medical devices



#### WARNING

Electromagnetic waves that are generated from the charger can seriously impact medical electric devices such as an implantable cardiac pacemaker.

If you are fitted with any electronic medical implants (for example, cardiac pacemaker), make sure to ask the medical team and manufacturer whether charging your electric vehicle will impact the operation of electronic medical implants.

# Basic safety precautions for charging



### WARNING

- Before charging, apply the Electronic Parking Brake (EPB) with the brake pedal pressed, shift to P (Park) and turn off the vehicle. Movement of the vehicle while charging may result in death, serious injury, or property damage.
- Use specified electric vehicle charger only. Failure to do so may damage the charger, charging cable, or vehicle.
   Also, it may lead to safety hazards, such as fire, explosion, etc.
- To avoid death, serious injury, or property damage from electric shock and fire, follow the instructions below:
  - Do not touch the charging connector, charging plug, or the charging inlet when connecting the cable to the charger and the charging inlet on the vehicle.
  - Do not touch the charging connector and charging plug with wet hands, or when standing in water or snow while connecting the charging cable.
  - When connecting or removing the charging cable, you must hold the charging connector handle and charging plug.
  - Use a waterproof charger. Do not charge the vehicle in a place where rainwater may come in contact with the joints of the charging cable connector and the charging plug.
  - Ensure there is no water, dust, or other contaminants on the charging cable connector and the charging plug.
  - Immediately stop charging if you feel abnormal conditions, such as odor or smoke.
  - Do not charge the vehicle if there is a risk of lightning.

# *i* Information

- While charging, the gear cannot be shifted from P (Park) to any other gear.
- Ensure the vehicle door is unlocked before disconnecting the charging connector. The unlock button on the charging connector does not work when the vehicle door is locked.
- To control the temperature of the high voltage battery while charging or when the battery temperature is high, the air conditioner is used to cool down the battery. It may generate noise or vibration from operation of the air conditioner compressor and cooling fan, but this is a normal condition when charging the highvoltage battery.
- The cooling system may be operated when using the air conditioner during charging. This may degrade the air conditioner's performance temporarily.
- Depending on the condition and durability of the high voltage battery, charger specifications, and ambient temperature, the time required for charging the battery may vary.
- In rare cases, you might hear high-frequency noise (a small beeping sound) outside the vehicle when charging with a 400 V DC charger that has deteriorated or has long communication delay. The high-frequency noise can be generated only when the vehicle tries to reduce its own electromagnetic waves to keep DC charging as stable as possible. This beep sound does not affect the charging performance or the vehicle itself.

# Precautions when the cooling fan operates



#### **WARNING**

Do not put your hand near the cooling fan in the motor compartment while charging. It may operate automatically to control the battery temperature, even if the vehicle is turned off.

# Precautions for operating the charging door

Before operating the charging door, read and comply with all the safety information below.

### NOTICE

- Before opening the charging door, check in which direction the door opens and ensure that there is no interference with nearby objects when opening or closing the charging door.
- If you cannot open the charging door due to freezing weather, lightly tap or remove any ice near the charging door.
- Do not try to forcibly open the charging door. It may cause damage to the charging door or cause a malfunction.

# Precautions when using the charging cable



#### CAUTION

- To prevent electric shock, replace the charging cable if the insulation or the connector is damaged.
- Do not modify or disassemble the charging cable. Doing so may result in fire, electric shock, or injury.
- Do not pull or twist the charging cable excessively, and ensure that the cable is not twisted. Power cuts or damage to the cable's insulation sheath may result in electric shock or fire.
- Do not drag the charging cable on the floor or place objects on it. Damage to the insulation of the cable may result in electric shock or fire.
- Do not use the charging cable near a heat source or heating appliance.
- Do not drop or subject the charging cable to a strong impact. Also, ensure no water or liquid comes in contact with the cable.
- Use the charging cable only when there are no children around.
- If there is any sign of damage, corrosion, or rust on the charging connector and power plug, or if the connection of the charging connector and power plug seems loose, do not use the cable. Have the vehicle inspected by an authorized retailer of Genesis Branded products.

# Precautions when handling and storing the portable charging cable



#### CAUTION

- Always keep the charging connector and plug dry and clean.
- Ensure that the connectors, power plugs, and control box (portable charger) of the charging cable are not submerged or in contact with water.
- Keep the charging cable free from water or moisture, and keep it in the cargo storage compartment.
- Do not keep the charging cable near heat source or heating appliances.
- Keep the charging cable away from children.
- If there is dust or contaminants inside the charging connector or power plug, remove it using an air gun.
- If the charging cable is contaminated, completely disconnect the cable from the charger or power, and remove the contaminants.
  - Wipe the charging cable lightly with the soft cloth soaked with a 3 % neutral detergent aqueous solution, then use a clean cloth to completely remove moisture and dry the cable in a well-ventilated shade
  - When removing contaminants, ensure the charging connector and charging plug are not in contact with water.
  - Do not use organic solvents, such as benzene, paint thinner, or detergent. Doing so may cause deformation, discoloration, or malfunction of the charging cable.
  - When using a vehicle decontamination agent, ensure that the product does not contain organic solvents, such as benzene, paint thinner, or detergent.

# Using an AC Charger

How to connect AC charger

- 1. Parking brake is applied automatically when shifting to P (Park).
- 2. Shift to P (Park), and turn OFF the vehicle.

If charging is initiated without the gear in P (Park), the charging starts after the gear is automatically shifted to P (Park).



- Push the charging door where the triangle symbol (1) is located to open. The charging door opens only when the vehicle is unlocked.
- 4. Remove the inlet cover (2).
- Check to confirm there is no dust or foreign substances inside the charging connector and charging inlet.
- 6. Hold the charging connector handle and connect it to the vehicle charging inlet. Push the charging connector all the way in until the connector clicks into place. If the charging connector and charging inlet are not connected properly, this may cause a fire and charging may not start.
- Connect the charging plug to the electric outlet at an AC charging station to start charging.

8. Check if the Charging ( ) indicator light of the high voltage battery on the instrument cluster is turned ON. Charging is not active when the Charging ( ) indicator light is OFF. If the charging connector is not connected to the vehicle charging inlet properly, charging may not start. In this case, try reconnecting the charging connector to the vehicle charging inlet again.



### Information

If the charging connector locking mode is set to **Always** or **Lock while charging**, unlock the door by pressing the button on the smart key or the button on the driver's door, and disconnect the charging connector from the charging inlet.

For more information, refer to the "Setting Charging Connector Locking Mode" section in this chapter.



ORG3EVQ011034

 After charging has started, the estimated charging time is displayed on the cluster display for about 1 minute.

If you open the driver's door while charging, the estimated charging time is also displayed on the cluster display for about 1 minute. When scheduled charging or scheduled air conditioning/heating is set, the estimated charging time is displayed as "--".



- Even though charging is possible with the Start/Stop button in the ON/ START position, for your safety, start charging when the Start/Stop button is in the OFF position and the vehicle shifted to P (Park). After charging has started, you can use electrical components such as the radio by pressing the Start/Stop button to the ACC or ON position.
- During AC charging, the radio reception may be poor.

## Checking charging status

When charging the high voltage battery, the charge level can be checked from outside the vehicle.

For more information, refer to the "Checking the Charging Status" section in this chapter.

#### How to disconnect AC charger

1. When charging is complete, remove the charging plug from the electrical outlet of the AC charging station.



Press release button (1), then remove the charging connector from the vehicle inlet.



To prevent portable charging cable theft, the charging connector cannot be disconnected from the charging inlet when the doors are locked or the charging connector is in the **Always** mode. Unlock all doors to disconnect the charging connector from the charging inlet.

However, if the vehicle is in the charging connector **Lock while charging** mode, the charging connector automatically unlocks from the charging inlet when charging is completed.

If you attempt to disconnect the charging connector without pressing the release button, the charging connector and the charging inlet may be damaged. For more information, refer to the "Setting Charging Connector Locking Mode" in this chapter.

If the release button does not work even after the all doors are unlocked, pull the emergency cable in the motor room and press the release button on the charging connector to disconnect it from the vehicle. If the release button still does not work, consult an authorized retailer of Genesis Branded products.



### Information

Some charging connectors installed in public charging stations stops charging by pressing the release button while the charging connector is locked, and the connector can be disconnected. If the release button does not stop the charger, use the charger control panel or smartphone app to stop the charger.

- 3. Make sure to completely close the charging door.
- Close the protection caps of the charging connector and the charging plug to protect them from foreign substances.
- 5. If a personal charging connector is used, store the charging connector in the cable compartment.

### Using a DC Charger

You can charge at high speed at public charging stations. Refer to the respective company's app or website for manual or instructions that is provided for each DC charger type.

Battery performance and durability may be impacted if the DC charger is used constantly.



### Information

If you use a DC charger when the vehicle is already fully charged, some DC chargers may send out an error message. When the vehicle is fully charged, do not charge the vehicle.

#### How to connect a DC charger

- 1. Parking brake is applied automatically when shifting to P (Park).
- 2. Shift to P (Park), and turn OFF the vehicle.



- 3. Push the charging door where the triangle symbol (1) is located to open. The charging door opens only when the vehicle is unlocked.
- 4. Remove the inlet cover (2).
- 5. Check to confirm there is no dust or foreign substances inside the charging connector and charging inlet.
- 6. Hold the charging connector handle and connect it to the vehicle charging inlet. Push the charging connector all the way in until the connector clicks into place. If the charging connector and charging inlet are not connected properly, this may cause a fire and charging may not start.

Refer to each respective DC charger instructions for details about how to use the DC charger.

7. Check if the charging indicator light (<) of the high voltage battery on the instrument cluster is turned ON. Charging is not active when the charging indicator light (5) is OFF. If the charging connector is not connected to the vehicle charging inlet properly, charging may not start. In this case, try reconnecting the charging connector to the vehicle charging inlet again.

During severe cold weather, DC charging may not be available to prevent high voltage battery degradation.



8. After charging has started, the estimated charging time is displayed on the cluster display for about 1 minute.

If you open the driver's door while charging, the estimated charging time is also displayed on the cluster display for about 1 minute.



## Information

Even though charging is possible with the Start/Stop button in the ON/START position, for your safety, start charging when the Start/Stop button is in the OFF position and the vehicle shifted to P (Park). After charging has started, you can use electrical components such as the radio by pressing the Start/Stop button to the ACC or ON position.

#### Checking charging status

When charging the high voltage battery, the charge level can be checked from outside the vehicle.

For more information, refer to the "Checking the Charging Status" section in this chapter.

#### How to disconnect DC charger

- 1. Press release button and then remove charging connector when DC charging is completed, or after you stop charging using the DC charger. If the release button does not stop the DC charger, use the charger control panel or smartphone app to stop the charger. Refer to each respective DC charger instructions for details about how to disconnect the charging connector.
- 2. Make sure to completely close the charging door.

### **Using a Portable Charger** (ICCB: In-Cable Control Box)



- (1) Power plug and cord (cord set)
- (2) Control box
- (3) Charging cable and charging connector

Portable charger may be used with household electricity when AC or DC charger is not available.

#### How to set the charge level of the portable charger (ICCB: In-Cable Control Box)



ONF1041060N

- 1. Check the rated current of the electric outlet prior to connecting the plug to the outlet.
- 2. Connect the plug to a household electric outlet.
- 3. Check the display window on the control box.



- 4. Press the button (1) on the front of the control box for 2 to 8 seconds to adjust the charge level. (Refer to charging cable type and example for setting the charge level.)
- 5. The charge level on the display window of the control box changes every time you press the button (1).
- 6. When setting the charge level is complete, start charging according to the portable charger instructions.

\* Example for setting the ICCB charge level


The example is only for reference and may vary according to the surrounding environment.

Outlet Current	ICCB Charge Level	Control Box Display Window
14-16 A	12 A	
13-12 A	10 A	
11-10 A	8 A	
9-8 A	6 A	ORG3EVQ011076

## NOTICE

Make sure that charge level selection matches the capacity of your circuit breaker to avoid blown fuse.

# How to connect portable charger (ICCB: In-Cable Control Box)



1. Connect the plug to a household electric outlet.



- 2. Check if the power lamp (green) illuminates on the control box.
- 3. Depress the brake pedal and apply the parking brake.
- Turn OFF all switches, shift to P (Park), and turn OFF the vehicle.

If charging is initiated without the gear in P (Park), the charging will start after the gear is automatically shifted to P (Park).



- Push the charging door where the triangle symbol (1) is located to open. The charging door opens only when the vehicle is unlocked.
- Open the protection caps of the charging connector and the charging plug. Check if there are any foreign substances or dust.
- Hold the charging connector handle and connect it to the vehicle charging inlet. Push the connector all the way in until the connector clicks into place. If the charging connector and charging inlet are not connected properly, this may cause a fire and charging may not start.



8. Charging starts automatically (Charging indicator light illuminates).

9. Check if the Charging (s) indicator light of the high voltage battery on the instrument cluster is turned ON. Charging is not active when the Charging (s) indicator light is OFF. If the charging connector is not connected to the vehicle charging inlet properly, charging may not start. In this case, try reconnecting the charging connector to the vehicle charging inlet again.



If the charging connector locking mode is set to **Always** or **Lock while charging**, unlock the door by pressing the button on the smart key or the button on the driver's door, and disconnect the charging connector from the charging inlet.

For more information, refer to the "Setting Charging Connector Locking Mode" section in this chapter.



ORG3EVQ011054L

10. After charging has started, the estimated charging time is displayed on the cluster display for about 1 minute.

If you open the driver's door while charging, the estimated charging time is also displayed on the cluster display for about 1 minute. When scheduled charging or scheduled air conditioner/heater is set, the estimated charging time is displayed as "--".

# i

#### Information

Even though charging is possible with the Start/Stop button in the ON/START position, for you safety, start charging when the Start/Stop button is in the OFF position and the vehicle shifted to P (Park). After charging has started, you can use electrical components such as the radio by pressing the Start/Stop button to the START or ON position.

### Checking charging status

When charging the high voltage battery, the charge level can be checked from outside the vehicle.

For more information, refer to the "Checking the Charging Status" section in this chapter.

## Charging status indicator lamp for portable charger

Indi	cator	Details					
POWER	FCI: POWER	On: Power on					
CHARGE	<b>[4]</b> CHARGE	On: Charge Blink: Current temperature	Blink: Current limit due to high plug temperature or high internal				
FAULT	() FAULT	Blink: Charging interrupted					
		On: Err	or while charging/ E	rror during self-diagnosis			
		Error code	Item	Cause			
		E1	Control pilot communication	Vehicle communication error			
		E2		Current leakage			
		E3	Leakage	Charger error			
		E4	Plug temperature	Plug overtemperature warning			
		E5		Plug temperature failure			
		E6		Charger error			
		E7	Overcurrent	Charging overcurrent warning			
		E8	Internal	Charger overheating			
	88.	E9	temperature	Charger error			
Error code		F1	Relay fusion	Charger error			
		F2	Ground Monitoring/ Interrupt	Poor grounding of outlet			
		F3	Switched mode	Switched mode power supply error (voltage failure)			
		F4	power supply power failure	Switched mode power supply error (abnormal voltage)			
		F5	Control pilot	Control Pilot (-) voltage error			
		F6	voltage error	Control Pilot (+) voltage error			
		F7	Temperature	Plug temperature sensor error			
		F8	sensor error	PCB internal temperature sensor error			

Ind	icator	Details
	88.	12 A
	<i>E</i> <b>E</b> .	10 A
CHARGE	08	8 A
LEVEL	<i>0</i> 8	6 A
	button (1) is p	g current changes whenever the pressed for less than 1 sec with plugged into an electrical outlet ehicle.

ORG3EVQ011075

### Status / Diagnosis / Countermeasure



- Charging connector plugged into vehicle (POWER Green ON)
- Plug connected to an electric outlet (POWER Green ON)

Contact an authorized retailer of Genesis Branded products.



#### While charging

- Charge indicator (POWER Green ON / CHARGE Blue ON)
- · Charging current



Before plugging charging connector into vehicle (POWER Green ON, FAULT Red blink)

- · Abnormal temperature
- ICCB (In-Cable Control Box) failure

Contact an authorized retailer of Genesis Branded products.



Plugged into vehicle (POWER Green ON, FAULT Red Blink)

- · Diagnostic device failure
- · Current leakage
- · Abnormal temperature

Contact an authorized retailer of Genesis Branded products.



- Leakage current failure (POWER Green ON, FAULT Red Blink)
- After disconnecting and reconnecting the power plug, press and release the button for 2 seconds or longer to clear the error.

Contact an authorized retailer of Genesis Branded products.



Power saving mode

 7-segment display is turned off if there is no status change for more than 1 minute.

# How to disconnect portable charger (ICCB: In-Cable Control Box)



 Press the release button (1), then remove the charging connector from the vehicle inlet.




To prevent charging cable theft, the charging connector cannot be disconnected from the charging inlet when the doors are locked or the charging connector is in the **Always** mode. Unlock all doors to disconnect the charging connector from the charging inlet.

However, if the vehicle is in the charging connector **Lock while charging** mode, the charging connector automatically unlocks from the charging inlet when charging is completed.



2. Make sure to completely close the charging door.



- Disconnect the plug from the household electric outlet. Do not pull the cable when disconnecting the plug.
- 4. Close the protection caps of the charging connector and the charging plug to protect them from foreign substances.
- If a personal charging connector is used, store the connector in the cable compartment.

# Precautions for Portable Charger (ICCB: In-Cable Control Box)

- Use the portable charger that is certified by Genesis Branded Vehicle.
- Do not try to repair, disassemble, or adjust the portable charger.
- Do not use an extension cord or adapter.
- Stop using immediately when failure occurs.
- Do not touch the plug and charging connector with wet hands.
- Do not touch the terminal part of the AC charging connector and the AC charging inlet on the vehicle.
- Do not connect the charging connector to voltage that does not comply with regulations.
- Do not use the portable charger if it is worn out, exposed, or there exists any type of damage on the portable charger.
- If the ICCB case and AC charging connector is damaged, cracked, or the wires are exposed in any way, do not use the portable charger.
- Do not let children operate or touch the portable charger.
- · Keep the control box free of water.
- Keep the normal charging connector or plug terminal free of foreign substances.
- Do not step on the cable or cord. Do not pull the cable or cord and do not twist or bend it.
- Do not charge when there is lightning.
- Do not drop the control box or place a heavy object on the control box.
- Do not place an object that can generate high temperatures near the charger when charging.
- Charging with the worn out or damaged household electric outlet can result in a risk of electric shock. If you have doubts about the condition of a household electric outlet, have it checked by a licensed electrician.

 Stop using the portable charger immediately if the household electric outlet or any components is overheated or you notice burnt odors.

# Using the Scheduled Charging Function (if equipped)

- You can set-up a charging schedule for your vehicle using the Infotainment system or Genesis Connected Service application. Refer to the infotainment system manual or the Genesis Connected Service for detailed information about setting scheduled charging.
- Scheduled charging can only be done when using a AC charger or the portable charger (ICCB: In-Cable Control Box).



When scheduled charging is set and the AC charger or the portable charger (ICCB: In-Cable Control Box) is connected for charging, the indicator lamp illuminates (1) for 3 minutes to indicate that scheduled charging is set.

 When scheduled charging is set, charging is not initiated immediately when the AC charger or portable charger (ICCB: In-Cable Control Box) is connected. When immediate charging is required, use the infotainment system or Genesis Connected Service application to deactivate the scheduled charge setting or press schedule charging deactivation button (2) for 2 seconds.  If you press the scheduled charging deactivation button (2) to immediately charge the battery, charging must be initiated 3 minutes after the charging cable has been connected.

When you press the scheduled charging deactivation button (2) for immediate charging, the scheduled charge setting is not completely deactivated. If you need to completely deactivated the scheduled charge setting, use the Infotainment system or Genesis Connected Service application to finalize the deactivation.

Refer to the "Using an AC Charger" or "Using a Portable Charger (ICCB: In-Cable Control Box)" section for details about connecting the AC charger and the portable charger (ICCB: In-Cable Control Box).

### **Checklist when Charging Does Not Start**

When the high voltage battery does not charge, check the followings:

- Check the charging setting for the vehicle. Refer to "Charge Management", in
  this chapter (for example, If target battery charge level is lower than high voltage
  battery charge level or when scheduled charging is set, charging is not initiated
  immediately when the AC charger or portable charger (ICCB: In-Cable Control Box)
  is connected.)
- 2. Check the operation status of AC charger, portable charger and DC charger. (Charging Status Indicator Lamp for Portable Charger, refer to "Checking Charging Status" for trickle charge in this chapter.)
- \* Actual method for indicating the charging status may vary in accordance with the charger manufacturer.
- 3. When the vehicle does not charge and a warning message appears on the cluster display, check the corresponding message. Refer to the "Cluster Display Messages" section in this chapter.
- 4. If the vehicle is properly charged when charged with another normally working charger, contact the charger manufacturer.
- 5. If the vehicle does not charge when charged with another normally working charger, contact an authorized retailer of Genesis Branded products for inspection.
- 6. If charging fails and the Service () warning light is illuminated on the instrument cluster, contact an authorized retailer of Genesis Branded products.

### **DRIVING YOUR ELECTRIC VEHICLE**

### **Starting Your Vehicle**



#### CAUTION

- Always fasten the seat belt before starting the vehicle.
- Check if the Electronic Parking Brake (EPB) is applied before starting the vehicle.
- 1. Holding the smart key, sit in the driver's seat.
- 2. Turn off all electrical devices.
- 3. Make sure the gear is in P (Park).
- 4. Press the Start/Stop button while depressing the brake pedal.
  - The READY indicator illuminates on the instrument cluster.
  - If the **READY** indicator does not illuminate, start the vehicle again.
- 5. Depress and hold the brake pedal and shift to the desired position.
- Release the parking brake and slowly release the brake pedal. Check if the vehicle slowly moves forward, then depress the accelerator pedal.

## **Stopping Your Vehicle**

- 1. Hold down the brake pedal while the vehicle is stopped.
- 2. Shift the gear to P (Park) while depressing the brake pedal.
- 3. Apply the Electronic Parking Brake (EPB).
- 4. Press the Start/Stop button and turn off the vehicle while depressing the brake pedal.
  - The READY indicator turns off on the instrument cluster.



### CAUTION

Always check if the **READY** indicator is turned off on the instrument cluster.

If the **READY** indicator is illuminated and the gear is in any other position than P (Park), unexpected vehicle movement may occur resulting in a collision.

### **Virtual Engine Sound System**

The Virtual Engine Sound System (VESS) generates engine sound to make pedestrians aware of the approaching vehicle when driving.


- If the vehicle is in the ready mode (READY indicator is on) and the gear is not in P (Park), the virtual engine sound is operated.
- When the gear is shifted to R (Reverse), an additional warning sound is heard.

# **CAUTION**

- This vehicle is much quieter than conventional gasoline powered vehicles. Always check the surroundings and drive your vehicle safely.
- When parking your vehicle or while waiting at a traffic light, check whether any children or obstacles exist around your vehicle.
- Check whether anything exists behind your vehicle while driving in reverse.
   Pedestrians may not hear the sound of your vehicle.

# **Checking Electric Vehicle Driving Information**

Distance to empty



B 40 16 20 MPH 20 35 €

OJKEV042073N

The distance to empty is the estimated distance the vehicle can be driven with the remaining electric energy.

#### When destination is not set

- On average, a vehicle can drive about 236 miles (380 km).
- Under certain circumstances where the air conditioner/heater is ON, the distance to empty is impacted, resulting in a possible distance range from 186 miles (300 km). When using the heater during cold weather or driving at high speed, the high voltage battery consumes a lot more electricity. This may reduce the distance to empty significantly.

- After '0 mile' has been displayed, the vehicle may stop soon. Immediately drive to a safe place and stop your vehicle.
- Distance to empty that is displayed on the instrument cluster after completing a recharge may vary significantly depending on previous operating patterns.
  - When previous driving patterns include high speed driving, resulting in the high voltage battery using more electricity than usual, the estimated distance to empty is reduced. When the high voltage battery uses little electricity in ECO mode, the estimated distance to empty increases.
- Distance to empty may depend on many factors such as the charge amount of the high voltage battery, weather, temperature, durability of the battery, geographical features, and driving style. When the ambient temperature is low such as in winter, the actual driving distance may reduce due to degradation of the battery.
- Natural degradation may occur with the high voltage battery depending on the number of years the vehicle is used. This may reduce the distance to empty.

#### When destination is set

When the destination is set, the distance to empty may change. The distance to empty is recalculated using the information of the destination. However, the distance to empty may vary significantly based on traffic conditions, driving habits, and condition of the vehicle.

#### Tips for improving driving range

 If you operate the air conditioner / heater too much, the driving battery uses too much electricity. This may reduce the distance to empty. Therefore, it is recommended that you set the cabin temperature to 72 °F (22 °C) AUTO. This setting has been certified by various assessment tests to maintain optimal energy consumption rates while keeping the temperature fresh.

Turn OFF the heater and air conditioner if you do not need them.

- When the heater or air conditioning system is on, the energy consumption is reduced if recirculation mode is selected instead of selecting the fresh mode. The fresh mode requires large amount of energy consumption as the outside air has to be re-heated or cooled.
- When using the heater or air conditioning system, use the DRIVER ONLY or scheduled air conditioner/ heater function.
- Depress and hold the accelerator pedal to maintain speed and drive economically.
- Gradually depress and release the accelerator pedal when accelerating or decelerating.
- Always maintain specified tire pressures.
- Do not use unnecessary electrical components while driving.
- Do not load unnecessary items in the vehicle.
- Do not mount parts that may increase air resistance.

#### Power/Charge gauge





The Power/Charge gauge shows the energy consumption and recovery status of the electric motor.

#### · POWER:

The discharging status of the electric motor is shown when the vehicle is accelerating or driving on an uphill road. As the electric energy discharged increases, the gauge level also increases.

#### · CHARGE:

The charging status of the electric motor is shown when the vehicle is decelerating or driving on a downhill road (being charged by the regenerative brakes). As more electric energy charges, the lower the gauge level.

### State Of Charge (SOC) gauge for high voltage battery





- The SOC gauge shows the charging status of the high voltage battery.
- The 'L' on the indicator indicates that there is not enough energy in the high voltage battery. 'H' indicates that the driving battery is fully charged.
- When driving on highways, make sure to check in advance if the high voltage battery is charged enough.





When the remaining battery is lower than 10 % on the SOC gauge, the High Voltage Battery Level ( warning light illuminates to alert you of the battery level.

When the High Voltage Battery Level (( ) warning light illuminates, the vehicle can drive an additional 12-25 miles (20-40 km) depending on the driving speed, heater/air conditioner, weather, driving style, and other factors. Charging is required.



### **CAUTION**

When the high voltage battery level is low, the Power Down () indicator light illuminates and the vehicle power is limited.

Charge the battery immediately since your vehicle may not be driven, or may roll back on a slope with the indicator light illuminated.

# Checking the Warning and Indicator Lights (related to electric vehicle)

Ready indicator light

**READY** 

#### This indicator illuminates:

When the vehicle is ready to be driven.

- ON: Normal driving is possible.
- OFF: Normal driving is not possible, or a problem has occurred.
- Blinking: Emergency driving.

When the **READY** indicator goes off or blinks, there is a problem with the system. In this case, have your vehicle inspected by an authorized retailer of Genesis Branded products.

#### Service warning light



#### This warning light illuminates:

- When the Start/Stop button is in the ON position. The Service warning light illuminates for 3 seconds and then goes off.
- When there is a problem with related parts of the electric vehicle control system, such as sensors, etc.

When the warning light illuminates while driving, or does not go off after starting the vehicle, have your vehicle inspected by an authorized retailer of Genesis Branded products.

#### Power down indicator light



This indicator light illuminates:

When the power is limited for the safety of the high-powered parts of an electric vehicle. The power is limited for the following reasons:

- The high voltage battery level is too low or voltage is decreasing
- The temperature of the high voltage battery is too high or too low
- The temperature of the motor is high

### NOTICE

- Do not accelerate or start the vehicle suddenly when the power down indicator light is illuminated.
- When the power is limited for the safety of high-powered parts of an electric vehicle, the power down indicator light illuminates. Your vehicle may not be driven, or may roll back on a slope with the indicator light illuminated due to the limitation of vehicle power.

# **Information**

Unless both the Service warning light and Power Down indicator light illuminate at the same time, it is not a failure.

# Charging connector indicator light



This warning light indicates the connection status of the charging connector. When the charging connector is connected to the vehicle, the green light illuminates for about 1 minute.

# High voltage battery level warning light



This warning light illuminates:

When the high voltage battery level is low.

Charge the high voltage battery as soon as possible.

# Regenerative brake warning light



This warning light illuminates:

When the regenerative brake does not operate and the brake does not perform well. This causes the Brake Warning light (red) and Regenerative Brake Warning Light (yellow) to illuminate simultaneously.

In this case, drive safely and have your vehicle inspected by an authorized retailer of Genesis Branded products.

The operation of the brake pedal may be more difficult than normal and the braking distance can increase.


## Cluster Display Messages Shift to P to charge



This message is displayed if you connect the charging cable without the gear in the P (Park) position.

Shift to P (Park) before connecting the charging cable.

#### Remaining Time



[A]: AC charge, [B]: DC charge

This message displays how much time remains until the battery is charged to the selected target battery charge level.

#### Unplug vehicle to start



This message is displayed when you start the vehicle without unplugging the charging cable. Unplug the charging cable, and then turn on the vehicle.

#### **Charging Door Open**



This message is displayed when the vehicle is driven with the charging door opened. Close the charging door and then start driving.

# Charging Stopped. Check the charger



This warning message is displayed when charging is stopped for the following reasons:

- There is a problem with the external AC charger or DC charger
- The external AC charger stops charging

Genesis Branded products.

- The charging cable is damaged
In this case, check to confirm there is
no problem with the external AC or DC
charger and charging cable.
If the same problem occurs when
charging the vehicle with a normally
operating AC charger or genuine Genesis
portable charger, have your vehicle
inspected by an authorized retailer of

# Charging Stopped. Check the cable connection



This warning message is displayed when charging is stopped because the charging connector is not correctly connected to the charging inlet

In this case, separate the charging connector and reconnect it and check to confirm there is no problem (external damage, foreign substances, etc.) with the charging connector and charging inlet.

If the same problem occurs when charging the vehicle with a replaced charging cable or genuine Genesis portable charger, have your vehicle inspected by an authorized retailer of Genesis Branded products.

## Check regenerative brakes



This warning message is displayed when the regenerative brake system does not work properly. In this case, have the vehicle inspected by an authorized retailer of Genesis Branded products.

#### Low EV battery



When the high voltage battery level reaches below about 10 %, this warning message is displayed.

The High Voltage Battery Level () warning light illuminates simultaneously. Charge the high voltage battery immediately.

#### Charge immediately. Power limited



When the high voltage battery level reaches below about 5 %, this warning message is displayed.

The High Voltage Battery Level () warning light illuminates simultaneously.

The vehicle's power will be reduced to minimize the energy consumption of the high voltage battery. Charge the battery immediately.

# Power limited due to low EV battery temperature. Charge battery



Both warning messages are displayed to protect electric vehicle system when outside temperature is low. If the high voltage battery charging level is low and parked outside in low temperature for a long time, vehicle power may be limited. Charging the battery before driving helps

Charging the battery before driving helps increase power.

## NOTICE

If these warning messages are still displayed even after the ambient temperature has increased, have the vehicle inspected by an authorized retailer of Genesis Branded products.

#### EV Battery Overheated! Stop vehicle



ORG3EVO011050L

This warning message is displayed to protect battery and electric vehicle system when the high voltage battery temperature is too high.

Turn off the Start/Stop button and stop the vehicle so that the battery temperature decreases.

#### **Power limited**



This warning message is displayed to ensure the safety of high-powered components of electric vehicles. The power is limited for the following reasons:

- The high voltage battery level is too low or voltage is decreasing
- The temperature of the high voltage battery is too high or too low
- The temperature of the motor is high

## NOTICE

- When this warning message is displayed, do not accelerate or start the vehicle suddenly.
- When the power is limited for the safety of high-powered parts of an electric vehicle, the warning message is displayed. Your vehicle may not be driven, or may roll back on a slope with the warning message displayed due to the limitation of vehicle power.



### Information

Unless both the Service warning light and Power Down indicator light illuminate at the same time, it is not a failure.

# Stop vehicle and check power supply



This warning message is displayed when a failure occurs in the power supply system.

In this case, park the vehicle in a safe location and have your vehicle towed to the nearest authorized retailer of Genesis Branded products and have the vehicle inspected.

### **Check Virtual Engine Sound System**



This message is displayed when there is a problem with the Virtual Engine Sound System (VESS).

In this case, have the vehicle inspected by an authorized retailer of Genesis Branded products.

#### Check electric vehicle system



This warning message is displayed when there is a problem with the electric vehicle control system.

Refrain from driving when the warning message is displayed.

In this case, have the vehicle inspected by an authorized retailer of Genesis Branded products.

#### **COUNTERMEASURES FOR ACCIDENTS OR FIRE**

#### If an Accident Occurs

# **MARNING**



- When a vehicle accident occurs, move the vehicle to a safe place, turn OFF the vehicle and disconnect the high voltage cut-off switch from the auxiliary battery (12 V) to prevent high voltage electricity from flowing.
- If electric wires are exposed from inside or outside the vehicle, do not touch the wires.

Also, do not touch the high voltage electric wire (orange), connector, and all electric components and devices. This may cause electric shock and lead to injuries.

# **WARNING**

- When a vehicle accident occurs and the high voltage battery is damaged, harmful gas and electrolytes may leak. Be careful not to touch the leaked liquid.
- When you suspect leakage of inflammable gas and other harmful gases, open the windows and evacuate to a safe location. If any leaked fluid comes in contact with your eyes or skin, immediately clean the affected area thoroughly with tap water or saline solution and have doctors inspect it as soon as possible.


# **⚠** WARNING

- If a small scale fire occurs, use a fire extinguisher (ABC, BC) that is meant for electrical fires. If it is impossible to extinguish the fire in the early stage, maintain a safe distance from the vehicle and immediately call your local fire emergency responders. Also, advise them that an electric vehicle is involved.
- If the fire spreads to the high voltage battery, large amount of water is needed to put out the fire. Using small amount of water or fire extinguishers not meant for electrical fires could cause serious injury or death from electrical shocks.

# **⚠** WARNING

- If you cannot put out the fire immediately, the high voltage battery may explode. Evacuate to a safe place and do not let other people approach the site.
  - Contact the fire department and notify them of an electric vehicle fire.
- If the vehicle is flooded with water, immediately turn off the vehicle and evacuate to a safe place. Contact the fire department or an authorized retailer of Genesis Branded products.

# **MARNING**



[1]: Dollies

- If towing is required, it must be towed with a wheel lift and dollies or flatbed equipment with all the wheels off the ground. Towing with the wheels on the ground can damage the vehicle's motor components.
- When a vehicle fire occurs because of the high voltage battery, there is a risk of a secondary fire. Contact the fire department when towing the vehicle.

# Other Precautions for Electric Vehicle

- When you paint or apply heat treatment to the vehicle as a result of an accident, the performance of the high voltage battery can be reduced.
- If heat treatment is required, contact an authorized retailer of Genesis Branded products.
- When you clean the motor compartment, do not use high pressure water. This may cause an electric shock due to a discharge in high voltage electricity, or damage the vehicle's electric system.

 Use or install genuine Genesis part or the equivalent (of the genuine part) specified for your vehicle.

# Turning off the High Voltage Battery

In case disconnecting the high voltage cut-off switch is required in an emergency, follow the instructions below:



Pull the yellow label in the high voltage cut-off switch to shut down the high voltage battery.



Never disconnect the high voltage cut-off switch except in an emergency situation.

### NOTICE

Do not put excessive force to the switch while shutting down the high voltage battery. Doing so may damage the high voltage cut-off switch.

# 2. Vehicle Information, Consumer Information, and Reporting Safety Defects

Exterior Overview (Front View)	2-2
Exterior Overview (Rear View)	2-3
Interior Overview	
Center Console Overview	2-5
Steering Wheel Control Overview	2-6
Motor Compartment Overview	2-7
Dimensions	2-8
Electric Vehicle Specifications	2-8
Bulb Wattage	2-9
Tires and Wheels	2-10
Air Conditioning System	2-11
Vehicle Weight and Luggage Volume	2-11
Recommended Lubricants and Capacities	2-11
Vehicle Identification Number (VIN)	2-12
Vehicle Certification Label	2-12
Tire Specification and Pressure Label	2-12
Motor Number	2-13
Air Conditioner Compressor Label	2-13
Refrigerant Label	2-13
Open Source Software Notice	2-14
Consumer Information	2-14
Reporting Safety Defects	2-15

## **EXTERIOR OVERVIEW (FRONT VIEW)**



(1)	Hood	5-68
(2)	Headlight	9-52
(3)	Tires and wheels	9-24
(4)	Side view mirror	.5-57

(5)	Panoramic sunroof	5-64
(6)	Front windshield wiper blades	.9-18
(7)	Windows	5-60
(8)	Front radar	7_/


## **EXTERIOR OVERVIEW (REAR VIEW)**



1)	Door5-30	C
2)	Rear combination light9-52	2
3)	Liftgate 5-7	1
4)	Liftgate open/close button5-73	3
5)	High mounted stop light9-53	3

(6)	Rear window wiper blades	9-19
7)	Antenna5	-132
(8)	Wide-rear view camera	7-118
9)	Reverse light	9-52


### **INTERIOR OVERVIEW**



(1)	Inside door handle5-88	8
(2)	Integrated memory system5-40	Э
(3)	Side view mirror control switch5-5	7
(4)	Side view mirror folding button5-58	8
(5)	Central door lock switch5-3	1
(6)	Power window switches5-6	1
(7)	Power window lock button/5-65 Electronic child safety lock button 5-34	
(8)	Instrument panel illumination control switch4-:	5

(9)	DBC (Downhill Brake Control) button6-44
(10)	ESC (Electronic Stability Control) OFF button
(11)	Power liftgate open/close button5-73
(12)	EPB (Electronic Parking Brake) switch6-30
(13)	Hood release lever5-68
(14)	Steering wheel tilt/telescopic switch. 5-45
(15)	Steering wheel 5-44
(16)	Seat 3-3


## **CENTER CONSOLE OVERVIEW**



(1)	Instrument cluster4-4	(12)	USB charger
(2)	Horn5-46	(13)	Wireless charging syst
(3)	Driver's front airbag3-48	(14)	Cup holder
(4)	Start/Stop button6-5	(15)	Rotary shifter
(5)	Infotainment system4-35, 5-132	(16)	Auto Hold button
(6)	Automatic climate control system 5-96	(17)	Drive mode button
(7)	Hazard warning flasher button 8-2	(18)	Parking/View button
(8)	Passenger's front airbag3-48	(19)	Parking Safety button.
(9)	Glove box5-119	(20)	Rear seat climate cont
(10)	Wireless charging system indicator 5-124	(21)	Rear seat USB charger
(11)	USB port5-132	(22)	Boost button

2)	USB charger	5-123
3)	Wireless charging system pad	5-124
4)	Cup holder	5-121
5)	Rotary shifter	.6-10
6)	Auto Hold button	6-34
7)	Drive mode button	6-53
8)	Parking/View button	7-119
9)	Parking Safety button	7-139
20)	Rear seat climate control	5-96
21)	Rear seat USB charger	5-123
22)	Boost button	6-55

### STEERING WHEEL CONTROL OVERVIEW



6)	Wiper and washer control lever	5-93
7)	Cluster display control	4-26
8)	Lane Driving Assist button	.7-30
9)	Driving Assist button	.7-55
10)	Vehicle Distance button	7-80

Q\_17

## **MOTOR COMPARTMENT OVERVIEW**



(1) Coolant reservoir ......9-12 (2) Brake fluid reservoir.....9-14 (3) Windshield washer fluid reservoir ...... 9-15 (4) Fuse box ...... 9-37

(5)	Cabin air filter9	-17
(6)	Front trunk5-	69
(7)	Jump-start negative (chassis)	
	A	

## **DIMENSIONS**

Items		in (mm)		
Overall length		185.6 (4,715)		
Overall width		75.2 (1,910)		
Overall height		64.0 (1,625)		
Trood	Tire size	Front	Rear	
Tread	265/45 R20	64.7 (1,643) 65.2 (1,657)		
Wheelbase		113.2 (	2,875)	

## **ELECTRIC VEHICLE SPECIFICATIONS**

	AWD	
	Max. output (kW)	160 (180) *1
Motor	Max. torque (Nm)	350
	Capacity (kWh)	77.4
Battery (Lithium-ion)	Power output (kW)	394
(Eltinam fort)	Voltage (V)	697
Charger (OBC)	Max. output (kW)	10.9

OBC: On-Board Battery Chargers
\*1: if equipped with boost mode

## **BULB WATTAGE**

Light Bulb			Bulb Type	Wattage
	Headlight	Low	LED	LED
		High	LED	LED
	Turn signal light		LED	LED
Front	Parking light		LED	LED
FIOIIL	Side marker		LED	LED
	Daytime Running	g Light (DRL)	LED	LED
	Puddle light		LED	LED
	Side repeater lig	ht	LED	LED
	Stop light		LED	LED
	Tail light		LED	LED
	Turn signal light		LED	LED
Rear	Reverse light		LED	LED
	Side marker		LED	LED
	License plate ligi	nt	LED	LED
	High mounted st	op light	LED	LED
	Map lamp		LED	LED
	Room lamp (with	nout sunroof)	LED	LED
	Personal lamp (v	vith sunroof)	LED	LED
	Vanity mirror lam	np	LED LED	
Interior	Glove box lamp		LED	LED
	Inner door handl Door courtesy la	e lamp/Mood lamp/ mp	LED	LED
	Cargo area lamp		LED	LED
	Front trunk lamp		LED	LED

### **TIRES AND WHEELS**

	Tire Size		Inflation Pressure psi (kPa)				
Items		Wheel Size	Normal Load		Maximum Load		Wheel Bolt Torque [lbf·ft (kgf·m, N·m)]
			Front	Rear	Front	Rear	
Full size tire	265/45R20	8.5J x 20	33 (230)	39 (270)	33 (230)	39 (270)	101-116 (14-16, 137-157)

## NOTICE

- It is permissible to add 3 psi (20 kPa) to the standard tire pressure specification if colder temperatures are expected soon. Tires typically lose 1 psi (7 kPa) for every 12 °F (7 °C) temperature drop. If extreme temperature variations are expected, recheck your tire pressure as necessary to keep them properly inflated.
- Tire inflation pressures may vary depending on changes in elevation. If driving
  in areas of higher or lower elevation, be sure to check and adjust for proper tire
  inflation.
- Do not exceed the maximum inflation pressure, as found on the sidewall of the tire(s).

# **A** CAUTION

When replacing tires, ALWAYS use the same size, type, brand, construction and tread pattern supplied with the vehicle. If not, it can damage the related parts or make it work irregularly.

## **AIR CONDITIONING SYSTEM**

Item	Weight of Volume	Classification
Refrigerant	32 oz. (900 g)	R-1234yf
Compressor lubricant	6.3 oz. (180 g)	POE

Contact an authorized retailer of Genesis Branded products dealer for more informations.

## **VEHICLE WEIGHT AND LUGGAGE VOLUME**

Gross Vehicle Weight	Luggage Volume
6,041 lbs. (2,740 kg)	17.8 cu ft (503 ℓ)

## RECOMMENDED LUBRICANTS AND CAPACITIES

To help achieve proper vehicle performance and durability, use only lubricants of the proper quality.

These lubricants and fluids are recommended for use in your vehicle.

Lubricant		Volume	Classification	
Gear fluid	Front	3.2 US qt. (2.9 ℓ)	HK ATF 65 SP4M-1	
Gear Hulu	Rear	3.0 US qt. (2.8 l)	HK ATF 00 SP4WI-I	
Coolant	Motor and gear system	4.87 US qt. (4.61 l)	Mixture of antifreeze and water (Phosphate-based Ethylene glycol coolant for aluminum radiator)	
Coolant	Battery system	12.86 US qt. (12.17 ℓ)		
Brake fluid		As required	SAE J1704 DOT-4 LV, FMVSS 116 DOT-4, ISO 4925 CLASS-6	

# VEHICLE IDENTIFICATION NUMBER (VIN)



The VIN is also on a plate attached to the top of the left side dashboard. The number on the plate can easily be seen through the windshield from outside.

# VEHICLE CERTIFICATION LABEL



The vehicle certification label attached on the driver's (or front passenger's) side center pillar gives the vehicle identification number (VIN).

# TIRE SPECIFICATION AND PRESSURE LABEL



The tires supplied on your new vehicle are chosen to provide the best performance for normal driving.

The tire label located on the driver's side center pillar gives the tire pressures recommended for your vehicle.

## **MOTOR NUMBER**



The motor number are stamped as shown in the drawing.

# AIR CONDITIONER COMPRESSOR LABEL



A compressor label informs you the type of compressor your vehicle is equipped with such as model (1), serial number (2), supplier part number (3), lot number (4), refrigerant oil (5) and refrigerant (6).

# REFRIGERANT LABEL (IF EQUIPPED)



You can find out which air conditioning refrigerant is applied to your vehicle on the label located inside of the hood.

### **OPEN SOURCE SOFTWARE NOTICE**

This vehicle contains software with open source licenses.

Open source software information including the source code, copyright notices and referred license terms may be obtained on the website

https://www.genesis.com/worldwide/en/opensource.html

Hyundai Motor Company will provide the open source code to you in storage medium such as CD-ROM for minimum charge covering the cost of performing source distribution upon email request to <a href="mailto:opensource@genesis.com">opensource@genesis.com</a> within a period of 3 years from the date of product purchase.

### **CONSUMER INFORMATION**

This consumer information has been prepared in accordance with regulations issued by the National Highway Traffic Safety Administration of the U.S. Department of Transportation. Your retailer of Genesis Branded products will help answer any questions you may have as you read this information. Genesis Branded Vehicles are designed and manufactured to meet or exceed all applicable safety standards.

For your safety, however, we strongly urge you to read and follow all directions in this Owner's Manual, particularly the information under the headings "NOTICE", "CAUTION" and "WARNING".

### REPORTING SAFETY DEFECTS

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Genesis Customer Care.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Genesis Customer Care.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to http://www.safercar.gov;

download the SaferCar mobile application; or write to: Administrator, NHTSA.

1200 New Jersey Ave, SE., Washington, DC. 20590.

You can also obtain other information about motor vehicle safety from http://www.safercar.gov.

# 3. Seats and Safety System

Important Safety Precautions	3-2
Always Wear Your Seat Belt	3-2
Restrain All Children	
Airbag Hazards	
Driver Distraction	3-2
Control Your Speed	3-2
Keep Your Vehicle In Safe Condition	3-2
Seats	3-3
Safety Precautions	3-6
Front Seats	
Rear Seats	
Head Restraint	
Seat Warmers	3-20
Front Seat Warmers	
Rear Seat Warmers	
Operating Rear Seat Warmer from the Front Seat	3-2
Air Ventilation Seats	3-23
Front Air Ventilation Seats	
Rear Air Ventilation Seats	
Operating Rear Air Ventilation Seat from Front Seat	
Seat Belts	3-26
Seat Belt Safety Precautions	
Seat Belt Warning Light	
Seat Belt Restraint System	
Pre-Active Seat Belt (PSB)	
Additional Seat Belt Safety Precautions	3-35
Care of Seat Belts	
Child Restraint System (CRS)	3-38
Our Recommendation: Children Always In the Rear	3-38
Selecting a Child Restraint System (CRS)	
Installing a Child Restraint System (CRS)	
Airbag - Supplemental Restraint System	3-46
Where are the Airbags?	
How Does the Airbag System Operate?	
What to Expect After an Airbag Inflates	3-54
Occupant Classification System (OCS)	3-5
Why Didn't My Airbag Go Off In a Collision?	3-6
SRS Care	3-66
Additional Safety Precautions	3-67
Airbag Warning Labels	

### IMPORTANT SAFETY PRECAUTIONS

You will find many safety precautions and recommendations throughout this section, and throughout this manual. The safety precautions in this section are among the most important.

### **Always Wear Your Seat Belt**

A seat belt is your best protection in all types of accidents. Airbags are designed to supplement seat belts, not replace them. So even though your vehicle is equipped with airbags, ALWAYS make sure you and your passengers wear your seat belts, and wear them properly.

### Restrain All Children

All children under age 13 should ride in your vehicle properly restrained in a rear seat, not the front seat. Infants and small children should be restrained in an appropriate Child Restraint System. Larger children should use a booster seat with the lap/shoulder belt until they can use the seat belt properly without a booster seat.

## **Airbag Hazards**

While airbags can save lives, they can also cause serious or fatal injuries to occupants who sit too close to them, or who are not properly restrained. Infants, young children, and short adults are at the greatest risk of being injured by an inflating airbag. Follow all instructions and warnings in this manual.

### **Driver Distraction**

Driver distraction presents a serious and potentially deadly danger, especially for inexperienced drivers. Safety should be the primary concern when behind the wheel and drivers need to be aware of the wide array of potential distractions, such as drowsiness, reaching for objects, eating, personal grooming, other passengers, and using mobile phones.

Drivers can become distracted when they take their eyes and attention off the road or their hands off the wheel to focus on activities other than driving. To reduce your risk of distraction and an accident:

- ALWAYS set up your mobile devices (for example, MP3 players, phones, navigation units, etc.) when your vehicle is parked or safely stopped.
- ONLY use your mobile device when allowed by laws and conditions permit safe use. NEVER text or email while driving. Most states have laws prohibiting drivers from texting. Some states and cities also prohibit drivers from using handheld phones.
- NEVER let the use of a mobile device distract you from driving. You have a responsibility to your passengers and others on the road to always drive safely, with your hands on the wheel as well as your eyes and attention on the road.

## **Control Your Speed**

Excessive speed is a major factor in crash injuries and deaths. Generally, the higher the speed, the greater the risk, but serious injuries can also occur at lower speeds. Never drive faster than is safe for current conditions, regardless of the maximum speed posted.

# Keep Your Vehicle In Safe Condition

Having a tire blowout or a mechanical failure can be extremely hazardous. To reduce the possibility of such problems, check your tire pressures and condition frequently, and perform all regularly scheduled maintenance.


## **SEATS**



### Front seat

- (1) Seat sliding forward or rearward/ Seat cushion tilt/ Seat cushion height
- (2) Seatback angle
- (3) Seat cushion extension/ Seat cushion support
- (4) Lumbar support

- (5) Seatback bolster
- (6) Comfortable stretch
- (7) Seat warmer/Air ventilation seat
- (8) Head restraint
- (9) Walk-in seat switch
- (10) Rear adjustment



## Rear seat

- (11) Seatback angle (Manual)
- (12) Head restraint
- (13) Armrest

- (14) Seat warmer
- (15) Remote seatback release handle



Infotainment system

Select **Setup > Vehicle > Seat** from the Settings menu in the infotainment system, you may use various convenience functions.

- Seat Position Change Alert: Seat change information is displayed.
- Seat Switch Alerts: Detailed information of the seat switch and image is displayed when the switch is touched or the switch is moved.
- Warmer/Ventilation Features
  - Automatic Controls Linked to Climate Control Settings: The seat temperature is automatically controlled.
  - Seat Warmer Balance: When the seat heater is on, you may lower the seat heater (warmer) setting, or may turn the seat heater off for either the seatback or seat cushion.
- Seating Easy Access
  - Steering Easy Access: Moves the steering wheel when the driver enters or leaves the vehicle.
  - Driver Seat Easy Access: The distance (Normal/Extended/Off) the seat automatically moves when the driver enters or leaves the vehicle may be selected.
- Ergo-Motion Seat
  - Comfortable Stretch: The operation intensity and operation time for Comfortable Stretch may be selected.
  - Smart Posture Assist: The seat is adjusted to assist the driver's posture after driving for an hour.
  - Smart Support: The driver's seat bolster is increased when SPORT mode is selected or when driving at high speed.

## *i* Information

- The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.
- The information provided may differ depending on which functions are applicable to your vehicle.

## **Safety Precautions**

Adjusting the seats so that you are sitting in a safe, comfortable position plays an important role in driver and passenger safety, together with seat belts and airbags, in an accident.

# ! WARNING

Do not use a cushion that reduces friction between the seat and the passenger. The passenger's hips may slide under the lap portion of the seat belt during an accident or a sudden stop. Serious or fatal internal injuries could result because the seat belt cannot operate properly.

## **Airbags**

You can take steps to reduce the risk of being injured by an inflating airbag. Sitting too close to an airbag greatly increases the risk of injury in the event the airbag inflates.

The National Highway Traffic Safety Administration (NHTSA) recommends that drivers allow at least 10 inches (25 cm) between the center of the steering wheel and their chest.

# ⚠ WAI

## WARNING

To reduce the risk of serious injury or death from an inflating airbag, take the following precautions:

- Adjust the driver's seat as far to the rear as possible maintaining the ability to control the vehicle.
- Adjust the front passenger seat as far to the rear as possible.
- Hold the steering wheel by the rim with hands at the 9 o'clock and 3 o'clock positions to minimize the risk of injuries to your hands and arms.
- NEVER place anything or anyone between you and the airbag.
- Do not allow the front passenger to place feet or legs on the dashboard to minimize the risk of leg injuries.

#### Seat belts

Always fasten your seat belt before starting any trip. At all times, passengers should sit upright and be properly restrained. Infants and small children must be restrained in appropriate Child Restraint Systems. Children who have outgrown a booster seat and adults must be restrained using the seat belts.

## A

## **WARNING**

Take the following precautions when adjusting your seat belt:

- NEVER use one seat belt for more than one occupant.
- Always position the seatback upright with the lap portion of the seat belt snug and low across the hips.
- NEVER allow children or small infants to ride on a passenger's lap.
- Do not route the seat belt across your neck, across sharp edges, or reroute the shoulder strap away from your body.
- Do not allow the seat belt to become caught or jammed.

### **Front Seats**

The front seat can be adjusted by using the control switches located on the outside of the seat cushion. Before driving, adjust the seat to the proper position so that you can easily control the steering wheel, foot pedals and controls on the instrument panel.



### WARNING

Take the following precautions when adjusting your seat:

- NEVER attempt to adjust the seat while the vehicle is moving. The seat could respond with unexpected movement and may cause loss of vehicle control resulting in an accident.
- Do not place anything under the front seats. Loose objects in the driver's foot area could interfere with the operation of the foot pedals, causing an accident.
- Do not allow anything to interfere with the normal position and proper locking of the seatback.
- Do not place a cigarette lighter on the floor or seat. When you operate the seat, gas may exit out of the lighter causing a fire.
- Use extreme caution when picking up small objects trapped under the seats or between the seat and the center console. Your hands might be cut or injured by the sharp edges of the seat mechanism.
- If there are occupants in the rear seats, be careful while adjusting the front seat position.
- Make sure that the seat is locked in place after the adjustment. If not, the seat might move unexpectedly resulting in an accident.

## $\triangle$

## CAUTION

To prevent injury:

- Do not adjust your seat while wearing your seat belt. Moving the seat cushion forward may cause strong pressure on your abdomen.
- Do not allow your hands or fingers to get caught in the seat mechanisms while the seat is moving.



## WARNING

NEVER allow children in the vehicle unattended. The power seats are operable when the vehicle is turned off.

## NOTICE

To prevent damage to the seats:

- Always stop adjusting the seats when the seat has been adjusted as far forward or rearward as possible.
- Do not adjust the seats longer than necessary when the vehicle is turned off. This may result in unnecessary battery drain.
- Do not operate two or more seats at the same time. This may result in an electrical malfunction.

### Forward and rearward adjustment



To move the seat forward or rearward:

- 1. Push the control switch forward or rearward.
- 2. Release the switch once the seat reaches the desired position.

## Seat cushion tilt/height adjustment



### Seat cushion tilt (1)

To change the angle of the front part of the seat cushion:

Push the front portion of the control switch up to raise or down to lower the front part of the seat cushion.

Release the switch once the seat reaches the desired position.

### Seat cushion height (2)

To change the height of the seat cushion:

Push the rear portion of the control switch up to raise or down to lower the height of the seat cushion.

Release the switch once the seat reaches the desired position.

## Seatback angle adjustment



OJKEV031008

To recline the seatback:

- 1. Push the control switch forward or rearward.
- 2. Release the switch once the seatback reaches the desired position.

### Reclining seatback

Sitting in a reclined position when the vehicle is in motion can be dangerous. Even when buckled up, the protections of your restraint system (seat belts and airbags) is greatly reduced by reclining your seatback.



## WARNING

NEVER ride with a reclined seatback when the vehicle is moving.

Riding with a reclined seatback increases your chance of serious or fatal injuries in the event of a collision or sudden stop.

Driver and passengers should always sit well back in their seats with the seatbacks upright and should be belted properly.

Seat belts must be snug against your hips and chest to work properly. When the seatback is reclined, the shoulder belt cannot do its job because it will not be snug against your chest. Instead, it will be in front of you. During an accident, you could be thrown into the seat belt, causing neck or other injuries.

The more the seatback is reclined. the greater chance the passenger's hips will slide under the lap belt or the passenger's neck will strike the shoulder belt.

### Seat cushion extension adjustment (for driver's seat) (if equipped)



To move the front part of the cushion forward or rearward:

- 1. Push the control switch forward or rearward.
- 2. Release the switch once the seat cushion reaches the desired length.

# Seat cushion support adjustment (for driver's seat) (if equipped)



### To adjust cushion support:

- Push the control switch up to increase cushion support or down to decrease cushion support.
- 2. Release the switch once the seat cushion support reaches the desired position.

### Lumbar support (if equipped)



### To adjust the lumbar support:

- Press the front portion of the switch (1) to increase support or the rear portion of the switch (2) to decrease support.
- 2. Press switch (3) or (4) to move the support position up or down.
- 3. Release the switch once the lumbar support reaches the desired position.

# Seat bolster adjustment (for driver's seat) (if equipped)



### To adjust seat bolster:

- Push the adjustment lever clockwise, the seatback bolster will be adjusted inward. Push the switch counterclockwise, the seatback bolster will be adjusted outward.
- 2. Release the lever once the bolster reaches the desired position.

# Ergo-motion seat (for driver's seat) (if equipped)



Select **Ergo-Motion Seat** from the infotainment system's Settings menu to select and set up supplemental functions for the driver.



Before actually using each function, try the functions with the vehicle parked.

#### Comfortable stretch

Comfortable stretch is a function that helps relieve fatigue of the driver's pelvis and lower back due to driving.



Every time you press the button, you may select a mode or turn off the function in the following order.

- Pelvic stretching: The cushion portion moves, helping the left and right movement of the pelvis.
- Lumbar stretching: The seatback portion moves, helping back and forth movement of the lower back.
- Whole Body stretching: The cushion and seatback moves in sequence, helping the whole body reduce fatigue.
- Off: Turns off Comfortable Stretch.

Also, you can change the operation intensity and operation time from the Settings menu in the infotainment system.

- Intensity: Setup > Vehicle > Seat > Ergo-Motion Seat > Comfortable Stretch > Strong/Normal
- Time: Setup > Vehicle > Seat > Ergo-Motion Seat > Comfortable Stretch > Session Length > Short(10s)/ Long(20s)

### **Smart posture assist**

After driving for an hour, Smart posture assist automatically adjusts the pelvis and back portion of the driver's seat to assist the driver's posture.

You can activate or deactivate Smart posture assist function from the Settings menu in the infotainment system.

Select: Setup > Vehicle > Seat > Ergo-Motion Seat > Smart Posture Assist

#### **Smart support**

The driver's seat bolster support increases when SPORT mode is selected for Drive Mode and when driving at high speed.

You can activate or deactivate Posture Assist function from the Settings menu in the infotainment system.

Select: Setup > Vehicle > Seat > Ergo-Motion Seat > Smart Support



### Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

## Walk-in switch (if equipped)



The rear seat passenger may use the switches to control the front passenger seat.

- Sliding forward or rearward:
   Press the switch (1) or (2) to move the front passenger seat forward or rearward.
- Seatback angle:
   Press the switch (3) or (4) to recline the front passenger seatback forward or rearward.



The rear passenger should not adjust the front seat when a passenger is seated.

## Seatback pocket



The seatback pocket is provided on the back of the front seatbacks.



## CAUTION

Do not put heavy or sharp objects in the seatback pockets. In an accident they could come loose from the pocket and injure occupants.

### **Rear Seats**



### **WARNING**

Take the following precautions:

- Adjusting the seats
  - NEVER attempt to adjust the seat while the vehicle is moving. The seat may suddenly move and may injure the passenger.
  - Make sure that the seat is locked in place after the adjustment. If not, the seat might move unexpectedly resulting in an accident.
- · Folding the seats
  - Do not fold the seatback when the seat is occupied (for example, passenger, pets or luggage). It may injure the passenger or pet, or damage the luggage.
  - Never allow passengers to sit on top of the folded down seatback while the vehicle is moving. This is not a proper seating position and no seat belts are available for use. This could result in serious injury or death in case of an accident or sudden stop.
  - Objects carried on the folded down seatback should not extend higher than the top of the front seatbacks.
     This could allow cargo to slide forward and cause injury or damage during sudden stops.

- When returning the rear seatback from a folded to an upright position, hold the seatback and return it slowly. Ensure that the seatback is completely locked into its upright position by pushing on the top of the seatback. In an accident or sudden stop, the unlocked seatback could allow cargo to move forward with great force and enter the passenger compartment, which could result in serious injury or death.
- · Loading cargo
  - Make sure the vehicle is off, the gear shifted to P (Park), and the parking brake is securely applied whenever loading or unloading cargo. Failure to take these steps may allow the vehicle to move if the shift button or shift dial is inadvertently pressed or rotated to another position.
  - When cargo is loaded through the rear passenger seats, ensure the cargo is properly secured to prevent it from moving while driving.
- Do not place objects in the rear seats, since they cannot be properly secured and may hit vehicle occupants in a collision causing serious injury or death.



## CAUTION

Do not allow your hands or fingers to get caught in the seat mechanisms while adjusting the seats.

## NOTICE

To prevent damage to the vehicle:

- · Rear seat belts
  - Before folding the seatback, insert the seat belt buckle in the holder between the seatback and cushion. And insert the seat belt webbing in the guide to prevent the seat belt from being damaged.
- Cargo

Be careful when loading cargo through the rear passenger seats to prevent damage to the vehicle interior.

### Manual adjustment



### Seatback angle

To recline the seatback:

- 1. Pull up the seatback recline lever.
- 2. Hold the lever and adjust the seatback of the seat to the position you desire.
- Release the lever and make sure the seatback is locked in place. The lever MUST return to its original position for the seatback to lock.



The seatbacks can be folded with the seatback recline lever.

### Folding the rear seats

The rear seatbacks can be folded to facilitate carrying long items or to increase the luggage capacity of the vehicle.

To fold down the rear seatback:

 Set the front seatback to the upright position and if necessary, slide the front seat forward.



2. Lower the rear head restraints to the lowest position.



Route the seat belt webbing through the rear seat belt guides to prevent the belts from being trapped behind or under the seats.





4. Pull up the seatback folding lever, then fold the seat toward the front of the vehicle. When you return the seatback to its upright position, always be sure it has locked into position by pushing on the top of the seatback.



- 5. To use the rear seat, lift and unfold the seatback to the upright position by pulling up the folding lever. Push the seatback firmly until it clicks into place. Make sure the seatback is locked in place.
- 6. Return the rear seat belt to the proper position.

# Remote seatback release handle (Cargo area)



Pull the remote seatback release handle located on either side in the rear cargo area.

### **Armrest**



The armrest is located in the center of the rear seat. Pull the armrest down from the seatback to use it.

### **Head Restraint**

The vehicle's front and rear seats have adjustable head restraints. The head restraints provide comfort for passengers, but more importantly they are designed to help protect passengers from whiplash and other neck and spinal injuries during an accident, especially in a rear impact collision.

## **⚠** WAI

## WARNING

To help reduce the risk of serious injury or death in an accident, take the following precautions when adjusting your head restraints:

- Always properly adjust the head restraints for all passengers BEFORE starting the vehicle.
- NEVER let anyone ride in a seat with the head restraint removed or reversed.



Adjust the head restraints so the middle of the head restraint is at the same height as the height of the top of the eyes.

- NEVER adjust the head restraint position of the driver's seat when the vehicle is in motion.
- Adjust the head restraint as close to the passenger's head as possible. Do not use a seat cushion that holds the body away from the seatback.
- Make sure the head restraint locks into position after adjusting it.

## **MARNING**



When sitting on the rear seat, do not adjust the height of the head restraint to the lowest position.



When there is no occupant in the rear seats, adjust the height of the head restraint to the lowest position. The rear seat head restraint can reduce the visibility of the rear area.

## NOTICE

To prevent damage, NEVER hit or pull on the head restraints.

### Front seat head restraints



The driver's and front passenger's seats are equipped with adjustable head restraints for the passengers safety and comfort.



Adjusting the height up and down To raise the head restraint:

1. Pull it up to the desired position (1).

To lower the head restraint:

- 1. Push and hold the release button (2) on the head restraint support.
- 2. Lower the head restraint to the desired position (3).

## NOTICE



If you recline the seatback towards the front with the head restraint and seat cushion raised, the head restraint may come in contact with the sunvisor or other parts of the vehicle.



Removal

To remove the head restraint:

- 1. Recline the seatback (2) with the seatback angle switch (1).
- 2. Raise the head restraint as far as it can go.
- Press the head restraint release button (3) while pulling the head restraint up (4).

## **MARNING**

NEVER allow anyone to travel in a seat with the head restraint removed.



### Reinstallation

To reinstall the head restraint:

- 1. Recline the seatback.
- 2. Put the head restraint poles (2) into the holes while pressing the release button (1).
- 3. Adjust the head restraint to the appropriate height.
- 4. Recline the seatback (4) with the seatback angle switch (3).



Always make sure the head restraint locks into position after reinstalling and adjusting it properly.

### Rear seat head restraints



The rear seats are equipped with head restraints in all the seating positions for the passenger's safety and comfort.



Adjusting the height up and down To raise the head restraint:

1. Pull it up to the desired position (1).

To lower the head restraint:

- 1. Push and hold the release button (2) on the head restraint support.
- 2. Lower the head restraint to the desired position (3).



### Removal/Reinstallation

To remove the head restraint:

- 1. Raise the head restraint as far as it can go.
- Press the head restraint release button

   (1) while pulling the head restraint up
   (2).

To reinstall the head restraint:

- Put the head restraint poles into the holes (3) while pressing the release button (1).
- 2. Adjust the head restraint to the appropriate height.

## **SEAT WARMERS (IF EQUIPPED)**

Seat warmers are provided to warm the seats during cold weather.

During mild weather or under conditions where the operation of the seat warmer is not needed, keep the seat warmers off.

#### **Front Seat Warmers**



- Press next to the desired seat from the climate control screen while the vehicle is on (READY indicator on).
  - · Seat warmer is turned on to 'High'
- 2. Press ∨ to lower and ∧ to raise the temperature.
  - Press and hold \( \sim \) or \( \sim \) to turn
     off the seat warmer, or press \( \sim \)
     multiple times until the seat warmer
     is turned off.
  - The seat warmer is automatically turned off if the seat temperature goes above a certain level. The seat warmer turns on again if the temperature is low.
  - To turn on the seat warmer when the seat ventilation is turned on, press \( \times\) until the seat warmer is turned on. (if equipped)
  - The seat warmer temperature is lowered automatically after a certain time to prevent low temperature burns. Press or from the climate control screen to adjust the temperature again. The temperature is adjusted automatically after a certain time after the temperature level is manually selected.

 Automatic Controls Linked to Climate Control Settings (for driver's seat)

The seat warmer automatically controls the seat temperature depending on the ambient temperature when the vehicle is on (READY indicator on).

To use this function, it can be enabled from the Settings menu in the infotainment system.

Select: Setup > Vehicle > Seat > Warmer/ Ventilation Features > Automatic Controls Linked to Climate Control Settings > Driver Seat Warmer/ Ventilation

Seat Warmer Balance

You may lower the seat warmer setting, or may turn the seat warmer off for either the seatback or seat cushion when the seat warmer is on.

To use this function, it can be enabled from the Settings menu in the infotainment system.

Select: Setup > Vehicle > Seat > Warmer/Ventilation Features > Seat Warmer Balance

 The seat warmer defaults to the OFF position whenever the Start/ Stop button is pressed to the ON position. However, if the Automatic Controls Linked to Climate Control Settings function is on, the driver's seat warmer turns on and off depending on the ambient temperature.

### **Rear Seat Warmers**



While the vehicle is on (**READY** indicator on), press the button on the center console to select the desired temperature level.

- The temperature can be set to HIGH/ MEDIUM/LOW. The seat temperature changes from high, medium, low, and to off each time the button is pressed.
- Press and hold the button to turn off the seat warmer.
- The seat warmer temperature is lowered automatically after a certain time to prevent low temperature burn.
- The seat warmer defaults to the OFF position whenever the Start/Stop button is pressed to the ON position.

# Operating Rear Seat Warmer from the Front Seat





Rear seat warmers can be turned on or off from the front seat.

- Press 'REAR' from the upper area of the climate control screen while the vehicle is on (READY indicator on).
  - The climate control screen for the rear seat is displayed.
- 2. Press \( \cap \) next to the desired seat from the climate control screen.
  - · Seat warmer is turned on to 'HIGH'.

- 3. Press ∧ to raise and ∨ to lower the temperature.
  - Press and hold \( \simes \) or \( \simes \) to turn
    off the seat warmer, or press \( \simes \)
    multiple times until the seat warmer
    is turned off.
  - The seat warmer automatically turns off if the seat temperature goes above a certain level. The seat warmer turns on again if the temperature is low.
  - To turn on the seat warmer when the seat ventilation is turned on, press until the seat warmer is turned on. (if equipped)

## **M** WARNING

The seat warmers may cause serious burns, even at low temperatures and especially if used for long periods of time.

Passengers must be able to feel if the seat is becoming too warm so they can turn it off, if needed.

People who cannot detect temperature change or pain to the skin should use extreme caution, especially the following types of passengers:

- Infants, children, elderly or disabled persons, or hospital outpatients.
- People with sensitive skin or who burn easily.
- Fatigued individuals.
- · Intoxicated individuals.
- People taking medication that may cause drowsiness or sleepiness.

Never place anything on the seat that insulates against heat when the seat warmer is operating, such as blanket or seat cushion.



## Information

Low temperature burn occurs when the skin is exposed to relatively low temperature (104-122 °F (40-50 °C)). The passenger may get burns before feeling any heat or pain. Be careful not to use the seat warmers for a long time.

## NOTICE

To prevent damage to the seat warmers and seats:

- Never use a solvent such as paint thinner, benzene, alcohol, or gasoline to clean the seats.
- Avoid spilling liquids on the surface of the seats and seatbacks.
- Do not place heavy or sharp objects on seats equipped with seat warmers.
- · Do not change the seat cover.
- Refrain from using the seat warmers while the vehicle is turned off to prevent the battery from being discharged.
- Turn off the seat warmers and turn on the air ventilation seats to switch from one function to another, or vice versa. Frequently shifting from one to another may cause a malfunction or performance degradation.

## AIR VENTILATION SEATS (IF EQUIPPED)

The air ventilation seats cool the front seats by blowing air through small vent holes on the surface of the seat cushions and seatbacks.

When air ventilation is not desired, keep the switches in the OFF position.

### Front Air Ventilation Seats



- 1. Press \( \cap \) next to the desired seat from the climate control screen while the vehicle is on (READY indicator on).
  - The air ventilation seat is turned on to 'HIGH'.
- 2. Press  $\wedge$  to raise and  $\vee$  to lower the fan speed.
  - Press and hold ∨ or ∧ to turn off the air ventilation seat, or press ∧ multiple times until the air ventilation seat is turned off.
  - · The air ventilation seat automatically turns off if the seat temperature goes below a certain level. The seat ventilator turns on again if the temperature rises.

### **Rear Air Ventilation Seats**



While the vehicle is on (READY indicator on), press the button on the center console to select the desired temperature level.

- The airflow speed can be set to HIGH/ MEDIUM/LOW. The airflow speed will change from high, medium, low, and to off each time the button is pressed.
- · Press and hold the button to turn off the air ventilation seats.

## Operating Rear Air Ventilation Seat from Front Seat



Air ventilation seats can be turned on or off from the front seat.

OJKEV032032N

- Press 'REAR' from the upper part of the climate control screen while the vehicle is on (READY indicator on).
  - The climate control screen for the rear seat is displayed.
- 2. Press ∨ next to the desired seat from the climate control screen.
  - Air ventilation seat is turned on to 'HIGH'.
- - Press and hold ∨ or ∧ to turn off the air ventilation seat, or press ∨ multiple times until it turns off.
  - The air ventilation seat automatically turns off once the seat temperature falls below the a certain temperature, and turns on again when the temperature rises.

- If the air ventilation seat is position to 'HIGH', fan speed increases depending on the vehicle speed and driving time.
- After the seat ventilator is turned on, it takes 3-5 minutes for the passengers to notice the temperature change.
- Use the air ventilation seat with the air conditioning on for more effective ventilation.
- Automatic Controls Linked to Climate Control Settings (for driver's seat) The air ventilation seat automatically controls the seat temperature depending on the ambient temperature when the vehicle is on (READY indicator on). To use this function, it can be enabled from the Settings menu in the infotainment system.

Select: Setup > Vehicle > Seat > Warmer/ Ventilation Features > Automatic Controls Linked to Climate Control Settings > Driver Seat Warmer/Ventilation

 The air ventilation seats default to the OFF position whenever the Start/Stop button is pressed to the ON position. However, if the Automatic Controls Linked to Climate Control Settings function is on, the driver's air ventilation seat turns on and off depending on the ambient temperature.

## NOTICE

To prevent damage to the air ventilation seats:

- Never use a solvent such as paint thinner, benzene, alcohol, or gasoline to clean the seats.
- Avoid spilling liquids on the surface of the front seats and seatbacks.
   This may cause the air vent holes to become blocked and not to work properly.
- Do not place materials such as plastic bags or newspapers under the seats.
   They may block the air intake causing the air vents not to work properly.
- Do not obstruct the intake vent behind the seatbacks. The ventilation performance may decrease.
- · Do not change the seat covers.
- Refrain from using the air ventilation seats while the vehicle is turned off to prevent the battery from being discharged.
- Turn off the air ventilation seats and turn on the seat warmers to switch from one function to another, or vice versa. Frequently shifting from one to another may cause a malfunction or performance degradation.

### **SEAT BELTS**

This section describes how to use the seat belts properly. It also describes some of the things not to do when using seat belts.

### **Seat Belt Safety Precautions**

Always fasten your seat belt and make sure all passengers have fastened their seat belts before starting any trip.
Airbags are designed to supplement the seat belt as an additional safety device, but they are not a substitute. Most states require all occupants of a vehicle to wear seat belts.

## A

### WARNING

Seat belts must be used by ALL passengers whenever the vehicle is moving. Take the following precautions when adjusting and wearing seat belts:

- Children under the age of 13 should be properly restrained in the rear seats.
- Never allow children to ride in the front passenger seat, unless the airbag is deactivated. If a child is seated in the front passenger seat, move the seat as far back as possible and the child must always be restrained in the seat properly.
- NEVER allow an infant or child to be carried on an occupant's lap.
- NEVER ride with the seatback reclined when the vehicle is moving.
- Do not allow children to share a seat or seat belt.
- Do not wear the shoulder belt under your arm or behind your back.

- Never wear a seat belt over fragile objects. If there is a sudden stop or impact, the seat belt can damage it.
- Do not use the seat belt if it is twisted.
   A twisted seat belt will not protect you properly in an accident.
- Do not use a seat belt if the webbing or hardware is damaged.
- Do not latch the seat belt into the buckles of other seats.
- NEVER unfasten the seat belt while driving. This may cause loss of vehicle control resulting in an accident.
- Make sure there is nothing in the buckle interfering with the seat belt latch mechanism, because any materials in the buckle can cause the seat belt not to be fastened securely.
- No modifications or additions should be made by the user which will either prevent the seat belt adjusting devices from operating to remove slack, or prevent the seat belt assembly from being adjusted to remove slack.



### WARNING

Damaged seat belts and seat belt assemblies will not operate properly. Always replace:

- Frayed, contaminated, or damaged webbing.
- · Damaged hardware.
- The entire seat belt assembly after it has been worn in an accident, even if damage to webbing or assembly is not apparent.

## Seat Belt Warning Light Driver's seat belt warning



As a reminder to the driver, the seat belt warning light will illuminate for about 6 seconds each time the Start/Stop button is in the ON position regardless of belt fastening.

If the seat belt is not fastened, when vehicle speed is between 5.5 mph (9 km/h) and 12 mph (20 km/h) the warning light will continue to illuminate and warning chime will sound until the seat belt is fastened.

If the seat belt is not fastened, when vehicle speed is above 12 mph (20 km/h), the warning light will blink and warning chime will sound for about 100 seconds (warning chime will sound in three stages).

### Front passenger's seat belt warning

As a reminder to the front passenger, the front passenger's seat belt warning light will illuminate for about 6 seconds each time the Start/Stop button is in the ON position regardless of belt fastening.

If the seat belt is not fastened, when vehicle speed is between 5.5 mph (9 km/h) and 12 mph (20 km/h) the warning light will continue to illuminate and warning chime will sound until the seat belt is fastened.

If the seat belt is not fastened, when vehicle speed is above 12 mph (20 km/h), the warning light will blink and warning chime will sound for about 100 seconds (warning chime will sound in three stages).



## WARNING

Riding in an improper position adversely affects the front passenger's seat belt warning system. It is important for the driver to instruct the passenger to be seated properly as instructed in this manual.



### Information

- Although the front passenger seat is not occupied, the seat belt warning light will blink or illuminate for 6 seconds.
- The front passenger's seat belt warning may operate when luggage is placed on the front passenger seat.

#### Rear passenger's seat belt warning



#### Rear seatbelt

With the Start/Stop button in the ON position, if the rear seat passenger's seat belt is not fastened, the corresponding seat belt warning light will illuminate for 70 seconds. But, if the seatbelt is fastened after 6 seconds, the corresponding seat belt warning light will immediately turn off.

If the seat belt is fastened, and then unfastened while driving below 12 mph (20 km/h), the corresponding seat belt warning light will illuminate.

If the seat belt is fastened, and then unfastened while driving above 12 mph (20 km/h), the corresponding seat belt warning light will blink and the warning chime will sound for about 35 seconds.

#### **Seat Belt Restraint System**





Improperly positioned seat belts may increase the risk of serious injury in an accident. Take the following precautions when adjusting the seat belt:

- Position the lap portion of the seat belt as low as possible across your hips, not on your waist, so that it fits snugly. This allows your strong pelvic bones to absorb the force of the crash, reducing the chance of internal injuries.
- Position one arm under the shoulder belt and the other over the belt, as shown in the illustration.
- Always position the shoulder belt anchor into the locked position at the appropriate height.
- Never position the shoulder belt across your neck or face.

## Driver's Seat Belt – 3-point system with emergency locking retractor



#### To fasten your seat belt:

Pull it out of the retractor and insert the metal tab (1) into the buckle (2). An audible "click" sounds when the tab locks into the buckle. Make sure the seat belt is not twisted.



Place the lap belt (1) portion across your hips and the shoulder belt (2) portion across your chest.

The seat belt automatically adjusts to the proper length after the lap belt portion is adjusted manually so that it fits snugly around your hips. If you lean forward in a slow, easy motion, the belt extends and moves with you.

If there is a sudden stop or collision, the belt is locked in place. It also locks if you try to lean forward too quickly.

### i


#### Information

If you cannot smoothly pull the seat belt out from the retractor, firmly pull the seat belt out and release it. After release, the belt may be pulled out smoothly.

#### Height adjustment

You can adjust the height of the shoulder belt anchor to one of the four different positions for maximum comfort and safety.

The shoulder portion should be adjusted so it lies across your chest and midway over your shoulder nearest the door, not over your neck.



To adjust the height of the seat belt anchor, lower or raise the height adjuster into an appropriate position.

To raise the height adjuster, pull it up (1). To lower it, push it down (3) while pressing the height adjuster button (2). Release the button to lock the anchor into position. Try sliding the height adjuster to make sure that it has locked into position.



To release your seat belt:

Press the release button (1) in the locking buckle.

The belt should automatically draw back into the retractor. If this does not happen, check the belt is not twisted, then try again.

## Rear Seat Belts - 3-point system with convertible locking retractor

This type of seat belt combines both an emergency locking retractor and an automatic locking retractor. Convertible retractor type seat belts are installed in the rear seat positions to help accommodate the installation of child restraint systems.

A convertible retractor is also installed in the front passenger seat position, children should always be seated in the rear and never place any infant/child restraint system in the front seat.

#### To fasten your seat belt:

Pull the seat belt out of the retractor and insert the metal tab into the buckle. An audible "click" sounds when the tab locks into the buckle. Pull the shoulder portion of the belt to snug the belt across your hips and remove slack. Make sure the seat belt is not twisted.

When not securing a child restraint, the seat belt automatically adjusts to the proper length only after the lap belt portion of the seat belt is adjusted manually so that it fits snugly across your hips.

When the seat belt has been fully extended from the retractor to allow for the installation of a child restraint system, the seat belt operation changes to allow the belt to retract, but not to extend (Automatic Locking Retractor Type). Refer to the "Using a Child Restraint System" section in this chapter.



To release your seat belt:

Press the release button (1) in the locking buckle.

The belt should automatically draw back into the retractor. If this does not happen, check the belt is not twisted, then try again.

### *i* Information

- The emergency locking mode allows seated passengers to move freely in their seats while keeping some tension on the belt. During a collision or sudden stop, the retractor automatically locks the belt to help restrain the passengers.
- To deactivate the automatic locking mode, unbuckle the seat belt and allow the belt to fully retract.

## Rear center seatbelt (3-point rear center seat belt)



Insert the tongue plate (1) into the buckle until an audible "click" is heard, indicating the latch is locked. Pull the shoulder portion of the belt to snug the belt across your hips and remove slack.

Make sure the seat belt is not twisted.

When using the rear center seat belt, use the buckle with the "CENTER" mark.



#### Information

If you cannot pull out the safety belt from the retractor, firmly pull the belt out and release it. After release, pull out the belt smoothly.



#### WARNING

Make sure that the seatback is locked in place when using the rear center seat belt.

If not, the seatback may move when there is a sudden stop or collision, which could result in serious injury.

#### Pre-tensioner seat belt



Your vehicle is equipped with driver's and front passenger's and rear passengers Pre-tensioner Seat Belts (Retractor Pre-tensioner). The purpose of the pre-tensioner is to make sure the seat belts fit tightly against the occupant's body in certain frontal or side collision(s). The pre-tensioner seat belts may be activated in crashes where the frontal or side collision(s) is severe enough, together with the airbags.

When the vehicle stops suddenly, or if the occupant tries to lean forward too quickly, the seat belt retractor will lock into position.

In certain frontal collisions, the pretensioner will activate and pull the seat belt into tighter contact against the occupant's body.

If the system senses excessive tension on the driver or passenger's seat belt when the pre-tensioner system activates, the load limiter inside the retractor pre-tensioner will release some of the pressure on the affected seat belt (if equipped with load limiter).

### **WARNING**

- Always wear your seat belt and sit properly in your seat.
- Do not use the seat belt if it is loose or twisted. A loose or twisted seat belt will not protect you properly in an accident.
- Do not place anything near the buckle. This may adversely affect the buckle and cause it to function improperly.
- Always replace your pre-tensioners after activation or an accident.
- NEVER inspect, service, repair or replace the pre-tensioners by yourself. Have the pre-tensioners inspected, serviced, repaired or replaced by an authorized retailer of Genesis Branded products.
- · Do not hit the seat belt assemblies.


### **MARNING**

Do not touch the pre-tensioner seat belt assemblies for several minutes after they have been activated. When the pre-tensioner seat belt mechanism deploys during a collision, the pre-tensioner can become hot and can burn you.

### **CAUTION**

Body work on the front area of the vehicle may damage the pre-tensioner seat belt system. Therefore, have the system serviced by an authorized retailer of Genesis Branded products.





The Pre-Tensioner Seat Belt System consists mainly of the following components. Their locations are shown in the illustration above:

- (1) SRS airbag warning light
- (2) Retractor pre-tensioner
- (3) SRS control module
- (4) Rear Retractor pre-tensioner (if equipped)

#### NOTICE

The sensor that activates the SRS control module is connected with the pre-tensioner seat belts. The SRS airbag warning light on the instrument cluster will illuminate for about 3-6 seconds after the Start/Stop button is in the ON position, and then it should turn off.

If the pre-tensioner is not working properly, the warning light will illuminate even if the SRS airbag is not malfunctioning. If the warning light does not illuminate, stays illuminated or illuminates when the vehicle is being driven, have the pre-tensioner seat belts and/or SRS control module inspected by an authorized retailer of Genesis Branded products as soon as possible.



- Pre-tensioner seat belts may activate in certain frontal or side collisions or rollover situations.
- When the pre-tensioner seat belts are activated, a loud noise may be heard and fine dust, which may appear to be smoke, may be visible in the passenger compartment. These are normal operating conditions and are not hazardous.
- Although it is non-toxic, the fine dust may cause skin irritation and should not be inhaled for prolonged periods. Wash all exposed skin areas thoroughly after an accident in which the pre-tensioner seat belts were activated.



#### WARNING

- Fasten your seat belt while sitting properly in an upright position to maximize the effectiveness of the pretensioner seat belt system.
- A pre-tensioner seat belt system is designed to activate only once. Replace the pre-tensioner seat belt system, if it was activated in an accident.

## Pre-Active Seat Belt (PSB) (if equipped)

The purpose of the Pre-Active Seat Belt is to tighten the seat belt when a collision is sensed during emergency braking, or when a loss of control is sensed.

#### NOTICE

Pre-Active Seat Belt is a supplementary system. Pre-Active Seat Belt activates only when the passenger is wearing his/her seat belt.

#### Pre-Active Seat Belt operation

In order to maximize the safety of the passenger, Pre-Active Seat Belt system operates as below.

· Full retraction

The seat belt is tightened when:

- Emergency braking situation occurs
- Losing control of the vehicle
- The vehicle detects a collision
- The vehicle detects driving on a frozen road
- Driving on a rough road with severe impact
- Unstable rolling of the vehicle occurs
- Slack removal

Tightens a loose seat belt if vehicle speed is over 9 mph (15 km/h).

Belt parking

Tightens a loose seat belt when the seat belt is unfastened.

#### Warning message



#### **Check Pre-Active Seat Belt**

The Pre-Active Seat Belt warning message will appear if there is a problem with your Pre-Active Seat Belt.

Have the system checked by an authorized retailer of Genesis Branded products if the warning message comes on while the vehicle is in motion. When the Pre-Active Seat Belt warning message disappears, the master (A) warning light illuminates.

## Additional Seat Belt Safety Precautions

#### Seat belt use during pregnancy

The seat belt should always be used during pregnancy. The best way to protect your unborn child is to protect yourself by always wearing the seat belt.

Pregnant women should always wear a lap-shoulder seat belt. Place the shoulder belt across your chest, routed between your breasts and away from your neck. Place the lap belt below your belly so that it fits SNUGLY across your hips and pelvic bone, under the rounded part of the belly.

### **MARNING**

- Pregnant woman are more vulnerable to any impacts on the abdomen during an abrupt stop or accident. If you are in an accident while pregnant, consult your doctor.
- To reduce the risk of serious injury or death to an unborn child during an accident, pregnant women should NEVER place the lap portion of the seat belt above or over the area of the abdomen where the unborn child is located.

#### Seat belt use and children

#### Infant and small children

All 50 states have child restraint laws which require children to travel in approved child restraint devices, including booster seats. The age at which seat belts can be used instead of child restraints differs among states, so you should be aware of the specific requirements in your state, and where you are travelling. Infant and child restraints must be properly placed and installed in a rear seat. For more information refer to the "Child Restraint Systems" section in this chapter.

#### **WARNING**

ALWAYS properly restrain infants and small children in a Child Restraint System appropriate for the child's height and weight.

To reduce the risk of serious injury or death to a child and other passengers, NEVER hold a child in your lap or arms when the vehicle is moving. The violent forces created during an accident will tear the child from your arms and throw the child against the interior of the vehicle.

Small children are best protected from injury in an accident when properly restrained in the rear seat by a child restraint system that meets the requirements of the Federal Motor Vehicle Safety Standards. Before buying any child restraint system, make sure that it has a label certifying that it meets Federal Motor Vehicle Safety Standard FMVSS 213. The restraint must be appropriate for your child's height and weight. Check the label on the child restraint for this information. Refer to the "Child Restraint Systems" section in this chapter.

#### Larger children

Children under age 13 who are too large for a booster seat should always occupy the rear seat and use the available lap/ shoulder belts. A seat belt should lie across the upper thighs and be snug across the shoulder and chest to restrain the child safely. Check belt fit periodically. A child's squirming could put the belt out of position. In the event of an accident, children are afforded the best safety restrained by a proper Child Restraint System in the rear seats.

If a larger child over age 13 must be seated in the front seat, the child must be securely restrained by the available lap/shoulder belt and the seat should be placed in the rearmost position.

If the shoulder belt portion slightly touches the child's neck or face, try placing the child closer to the center of the vehicle. If the shoulder belt still touches their face or neck, they need to be returned to an appropriate booster seat in the rear seat.

### **MARNING**

- Always make sure larger children's seat belts are worn and properly adjusted.
- NEVER allow the shoulder belt to contact the child's neck or face.
- Do not allow more than one child to use a single seat belt.

#### Seat belt use and injured people

A seat belt should be used when an injured person is being transported. Consult a physician for specific recommendations.

#### One person per belt

Two people (including children) should never attempt to use a single seat belt. This could increase the severity of injuries in case of an accident.

#### Do not lie down

Sitting in a reclined position when the vehicle is in motion can be dangerous. Even when buckled up, the protections of your restraint system (seat belts and/or airbags) is greatly reduced by reclining your seatback.

Seat belts must be snug against your hips and chest to work properly.

During an accident, you could be thrown into the seat belt, causing neck or other injuries.

The more the seat back is reclined, the greater the chance for the passenger's hips to slide under the lap belt or the passenger's neck to strike the shoulder belt.

### ∕!\ w

#### WARNING

- NEVER ride with a reclined seatback when the vehicle is moving.
- Riding with a reclined seatback increases your chance of serious or fatal injuries in the event of a collision or sudden stop.
- Driver and passengers should always sit well back in their seats with the seatbacks upright and should be belted properly.

#### **Care of Seat Belts**

Seat belt systems should never be disassembled or modified. In addition, care should be taken to assure that seat belts and belt hardware are not damaged by seat hinges, doors or other abuse.

#### Periodic inspection

All seat belts should be inspected periodically for wear or damage of any kind. Any damaged parts should be replaced as soon as possible.

#### Keep belts clean and dry

Seat belts should be kept clean and dry. If belts become dirty, they can be cleaned by using a mild soap solution and warm water. Bleach, dye, strong detergents or abrasives should not be used because they may damage and weaken the fabric.

#### When to replace seat belts

The entire seat belt assembly or assemblies should be replaced if the vehicle has been involved in an accident. This should be done even if no damage is visible. Consult an authorized retailer of Genesis Branded products.

#### **CHILD RESTRAINT SYSTEM (CRS)**

## Our Recommendation: Children Always In the Rear



#### **WARNING**

Always properly restrain children in the rear seats of the vehicle.

Children of all ages are safer when restrained in the rear seat. A child riding in the front passenger seat can be forcefully struck by an inflating airbag resulting in SERIOUS INJURY or DEATH.

Children under age 13 must always ride in the rear seats and must always be properly restrained to minimize the risk of injury in an accident, sudden stop or sudden maneuver. According to accident statistics, children are safer when properly restrained in the rear seats than in the front seat. Even with airbags, children can be seriously injured or killed. Children too large for a child restraint must use the seat belts provided.

All 50 states have child restraint laws which require children to travel in approved child restraint devices. The laws governing the age or height/weight restrictions at which seat belts can be used instead of child restraints differs among states, so you should be aware of the specific requirements in your state, and where you are travelling.

Child restraint systems must be properly placed and installed in the rear seat. You must use a commercially available child restraint system that meets the requirements of the Federal Motor Vehicle Safety Standards (FMVSS 213).

Child restraint systems are generally designed to be secured in a vehicle seat by lap belt portion of a lap/shoulder belt, or by a LATCH system in the rear seats of the vehicle.

#### Child restraint system (CRS)

Infants and younger children must be restrained in an appropriate rear-facing or forward-facing CRS that has first been properly secured to the rear seat of the vehicle. Read and comply with the instructions for installation and use provided by the manufacturer of the child restraint.



#### WARNING

An improperly secured child restraint can increase the risk of SERIOUS INJURY or DEATH in an accident. Always take the following precautions when using a child restraint system:

- NEVER install a child or infant restraint in the front passenger's seat.
- Always properly secure the child restraint to a rear seat of the vehicle.
- Always follow the child restraint system manufacturer's instructions for installation and use.
- Always properly restrain your child in the child restraint.
- If the vehicle head restraint prevents proper installation of a child seat (as described in the child restraint system manual), the head restraint of the respective seating position shall be readjusted or entirely removed.
- Do not use an infant carrier or a child safety seat that "hooks" over a seatback, it may not provide adequate protection in an accident.
- After an accident, have retailer of Genesis Branded products check the child restraint system, seat belts, tether anchors and lower anchors.

## Selecting a Child Restraint System (CRS)

When selecting a Child Restraint System for your child, always:

- Make sure the CRS has a label certifying that it meets applicable Federal Motor Vehicle Safety Standards (FMVSS 213).
- Select a Child Restraint System based on your child's height and weight. The required label or the instructions for use typically provide this information.
- Select a Child Restraint System that fits the vehicle seating position where it will be used.
- Read and comply with the warnings and instructions for installation and use provided with the Child Restraint System.

#### Child Restraint System types

There are three main types of Child Restraint Systems: rearward-facing, forward-facing and booster Child Restraint Systems.

They are classified according to the child's age, height and weight.

### **WARNING**

NEVER install a child or infant restraint in the front passenger's seat.

Placing a rear-facing child restraint in the front seat can result in SERIOUS INJURY or DEATH if the child restraint is struck by an inflating airbag.



#### Rear-facing child seats

A rear-facing child seat provides restraint with the seating surface against the back of the child. The harness system holds the child in place, and in an accident, acts to keep the child positioned in the seat and reduce the stress to the neck and spinal cord.

All children under age one must always ride in a rear-facing infant child restraint.

Convertible and 3-in-1 child seats typically have higher height and weight limits for the rear-facing position, allowing you to keep your child rearfacing for a longer period of time.

Continue to use a rear-facing child seat for as long as your child will fit within the height and weight limits allowed by the child seat manufacturer. It's the best way to keep them safe. Once your child has outgrown the rear-facing child restraint, your child is ready for a forward-facing child restraint with a harness.



#### Forward-facing Child Restraint System

A forward-facing Child Restraint System provides restraint for the child's body with a harness. Keep children in a forward-facing Child Restraint System with a harness until they reach the top height or weight limit allowed by your Child Restraint System's manufacturer.

Once your child outgrows the forwardfacing Child Restraint System, your child is ready for a booster seat.

#### **Booster seats**

A booster seat is a Child Restraint System designed to improve the fit of the vehicle's seat belt system. A booster seat positions the seat belt so that it fits properly over the stronger parts of your child's body. Keep your children in booster seats until they are big enough to fit in a seat belt properly.

For a seat belt to fit properly, the lap belt must lie comfortable across the upper thighs, not the stomach. The shoulder belt should lie comfortable across the shoulder and chest and not across the neck or face. Children under age 13 must always be properly restrained to minimize the risk of injury in an accident, sudden stop or sudden maneuver.

## Installing a Child Restraint System (CRS)



#### WARNING

Before installing your Child Restraint System always:

- Read and follow the instructions provided by the manufacturer of the child restraint.
- Read and follow the instructions regarding Child Restraint Systems in this manual.

Failure to follow all warnings and instructions could increase the risk of the SERIOUS INJURY or DEATH if an accident occurs.



#### WARNING

If the vehicle head restraint prevents proper installation of a child seat as described in the child seat system manual, the head restraint of the respective seating position shall be readjusted or entirely removed.

After selecting a proper child seat for your child, check to make sure it fits properly in your vehicle. Follow the instructions provided by the manufacturer when installing the child seat. Note these general steps when installing the seat to your vehicle:

- Properly secure the child restraint to the vehicle. All child restraints must be secured to the vehicle with the lap part of a lap/shoulder belt or with the LATCH system.
- Make sure the child restraint is firmly secured. After installing a child restraint to the vehicle, push and pull the seat forward-and-back and side-to-side to verify that it is securely attached to the seat. A child restraint secured with a seat belt should be installed as firmly as possible. However, some side-to-side movement can be expected.
- Secure the child in the Child Restraint System. Make sure the child is properly strapped in the Child Restraint System according to the Child Restraint System manufacturer's instructions.



#### **CAUTION**

A Child Restraint System in a closed vehicle can become very hot. To prevent burns, check the seating surface and buckles before placing your child in the Child Restraint System.

#### Lower Anchors and Tether for Children (LATCH System)

The LATCH system holds a child restraint during driving and in an accident. This system is designed to make installation of the child restraint easier and reduce the possibility of improperly installing your child restraint. The LATCH system uses anchors in the vehicle and attachments on the child restraint. The LATCH system eliminates the need to use seat belts to secure the child restraint to the rear seats.

Lower anchors are metal bars built into the vehicle. There are two lower anchors for each LATCH seating position that will accommodate a child restraint with lower attachments.

To use the LATCH system in your vehicle, you must have a child restraint with LATCH attachments.

The child seat manufacturer will provide you with instructions on how to use the child seat with its attachments for the LATCH lower anchors.



LATCH anchors have been provided in the left and right outboard rear seating positions. Their locations are shown in the illustration. There are no LATCH anchors provided for the center rear seating position.

### **MARNING**

Do not attempt to install a child restraint system using LATCH anchors in the rear center seating position. There are no LATCH anchors provided for this seat. Using the outboard seat anchors can damage the anchors which may break or fail in a collision resulting in serious injury or death.



[A]: Lower Anchorage Position Indicator, [B]: Lower Anchorage

The lower anchor position indicator symbols are located on the left and right rear seat backs to identify the position of the lower anchors in your vehicle (see arrows in illustration).

The LATCH anchors are located between the seatback and the seat cushion of the rear seat left and right outboard seating positions.

## Securing a child restraint with the LATCH anchors system

To install a LATCH-compatible child restraint in either of the rear outboard seating positions:

- 1. Move the seat belt buckle away from the lower anchors.
- Move any other objects away from the anchors that could prevent a secure connection between the child restraint and the lower anchors.
- Place the child restraint on the vehicle seat, then attach the seat to the lower anchors according to the instructions provided by the child restraint manufacturer.
- Follow the child restraint instructions for properly adjusting and tightening the lower attachments on the child restraint to the lower anchors.

## **MARNING**

Take the following precautions when using the LATCH system:

- Read and follow all installation instructions provided with your child restraint system.
- To prevent the child from reaching and taking hold of unretracted seat belts, buckle all unused rear seat belts and retract the seat belt webbing behind the child. Children can be strangled if a shoulder belt becomes wrapped around their neck and the seat belt tightens.
- NEVER attach more than one child restraint to a single anchor. This could cause the anchor or attachment to come loose or break.
- Always have the LATCH system inspected by an authorized retailer of Genesis Branded products after an accident. An accident can damage the LATCH system and may not properly secure the child restraint.

#### NOTICE

Make sure that the combined weight of the child and the child restraint system is less than 65 lbs. (30 kg) for each LATCH system.

#### Securing a child restraint seat with "Tether Anchor" system



First secure the child restraint with the LATCH lower anchors or the seat belt. If the child restraint manufacturer recommends that the top tether strap be attached, attach and tighten the top tether strap to the top tether strap anchor.

Child restraint hook holders are located on the rear of the seatbacks.



#### WARNING

Take the following precautions when installing the tether strap:

- Read and follow all installation instructions provided with your child restraint system.
- NEVER attach more than one child restraint to a single tether anchor. This could cause the anchor or attachment to come loose or break.
- Do not attach the tether strap to anything other than the correct tether anchor. It may not work properly if attached to something else.
- Do not use the tether anchors for adult seat belts or harnesses, or for attaching other items or equipment to the vehicle.



To install the tether anchor:

- Route the child restraint tether strap over the child restraint seatback. Route the tether strap under the head restraint and between the head restraint posts, or route the tether strap over the top of the vehicle seatback. Make sure the strap is not twisted.
- Connect the tether strap hook to the tether anchor, then tighten the tether strap according to the child seat manufacturer's instructions to firmly secure the child restraint to the seat.
- Check that the child restraint is securely attached to the seat by pushing and pulling the seat forwardand-back and side-to-side.

#### Securing a child restraint with lap/ shoulder belt

When not using the LATCH system, all child restraints must be secured to a vehicle rear seat with the lap part of a lap/shoulder belt.

## **MARNING**

ALWAYS place a rear-facing child restraint in the rear seat of the vehicle.

Placing a rear-facing child restraint in the front seat can result in serious injury or death if the child restraint is struck by an inflating airbag.

#### Automatic locking mode

Since all passenger seat belts move freely under normal conditions and only lock under extreme or emergency conditions (emergency locking mode), you must manually pull the seat belt all the way out to shift the retractor to the "Automatic Locking" mode to secure a child restraint.

The "Automatic Locking" mode will help prevent the normal movement of the child in the vehicle from causing the seat belt to loosen and compromise the child restraint system. To secure a child restraint system, use the following procedure.

To install a child restraint system on the rear seats, do the following:

 Place the child restraint system on a rear seat and route the lap/ shoulder belt around or through the child restraint, following the restraint manufacturer's instructions. Be sure the seat belt webbing is not twisted.

### i

#### Information

When using the rear center seat belt, you should also refer to the "Rear Seat Belts – 3-point system with convertible locking retractor" section in this chapter.



Fasten the lap/shoulder belt latch into the buckle. Listen for the distinct "click" sound.

### *i* Information

Position the release button so that it is easy to access in case of an emergency.



- Pull the shoulder portion of the seat belt all the way out. When the shoulder portion of the seat belt is fully extended, it will shift the retractor to the "Automatic Locking" (child restraint) mode.
- 4. Slowly allow the shoulder portion of the seat belt to retract and listen for an audible "clicking" or "ratcheting" sound. This indicates that the retractor is in the "Automatic Locking" mode. If no distinct sound is heard, repeat steps 3 and 4.

- Remove as much slack from the belt as possible by pushing down on the child restraint system while feeding the shoulder belt back into the retractor.
- Push and pull on the child restraint system to confirm that the seat belt is holding it firmly in place. If it is not, release the seat belt and repeat steps 2 through 6.
- 7. Double check that the retractor is in the "Automatic Locking" mode by attempting to pull more of the seat belt out of the retractor. If you cannot, the retractor is in the "Automatic Locking" mode.

If your CRS (child restraint system) manufacturer instructs or recommends you to use a tether anchor with the lap/ shoulder belt, refer to the previous pages for more information.

## i

#### Information

When the seat belt is allowed to retract to its fully stowed position, the retractor will automatically switch from the "Automatic Locking" mode to the emergency lock mode for normal adult usage.



#### WARNING

If the retractor is not in the "Automatic Locking" mode, the child restraint can move when your vehicle turns or stops suddenly. A child can be seriously injured or killed if the child restraint is not properly anchored in the car, including manually pulling the seat belt all the way out to shift the retractor to the "Automatic Locking" mode.

To remove the child restraint, press the release button on the buckle and then pull the lap/shoulder belt out of the restraint and allow the seat belt to retract fully.

#### **AIRBAG - SUPPLEMENTAL RESTRAINT SYSTEM**



- (1) Driver's front airbag
- (2) Passenger's front airbag
- (3) Side airbag

- (4) Curtain airbag
- (5) Driver's knee airbag
- (6) Front center side airbag

Your vehicle is equipped with a Supplemental Airbag System for the driver's seat and front passenger's seats.

The front airbags are designed to supplement the three-point seat belts. For these airbags to provide protection, the seat belts must be worn at all times when driving.

You can be severely injured or killed in an accident if you are not wearing a seat belt. Airbags are designed to supplement seat belts, but do not replace them. Also, airbags are not designed to deploy in every collision. In some accidents, the seat belts are the only restraint protecting you.



#### AIRBAG SAFETY PRECAUTIONS

ALWAYS use seat belts and Child Restraint Systems - every trip, every time, everyone! Even with airbags, you can be seriously injured or killed in a collision if you are improperly belted or not wearing your seat belt when the airbag inflates.

NEVER place a child in any Child Restraint System or booster seat in the front passenger seat, unless the airbag is deactivated.

An inflating airbag could forcefully strike the infant or child causing serious or fatal injuries.

ABC - Always Buckle Children under age 13 in the back seat. It is the safest place for children of any age to ride. If a child age 13 or older must be seated in the front seat, he or she must be properly belted and the seat should be moved as far back as possible.

All occupants should sit upright with the seatback in an upright position, centered on the seat cushion with their seat belt on, legs comfortably extended and their feet on the floor until the vehicle is parked and the vehicle is turned off. If an occupant is out of position during an accident, the rapidly deploying airbag may forcefully contact the occupant causing serious or fatal injuries.

You and your passengers should never sit or lean unnecessarily close to the airbags or lean against the door or center console.

Move your seat as far back as possible from front airbags, while still maintaining control of the vehicle. The U.S. National Highway Traffic Safety Administration (NHTSA) recommends that drivers allow at least 10 inches (25 cm) between the center of the steering wheel and the chest.

# Where are the Airbags? Driver's and passenger's front airbags







[A]: Driver's front airbag, [B]: Driver's knee airbag, [C]: Passenger's front airbag

Your vehicle is equipped with a Supplemental Restraint System (SRS) and lap/shoulder belts at both the driver and passenger seating positions.

The SRS consists of airbags which are located in the center of the steering wheel, in the driver's side lower dashboard below the steering wheel, and the passenger's side front panel pad above the glove box.

The airbags are labeled with the letters "AIRBAG" embossed on the pad covers.

The purpose of the SRS is to provide the vehicle's driver and front passengers with additional protection than that offered by the seat belt system alone in case of a frontal impact of sufficient severity.

### ⚠ W


#### **WARNING**

To reduce the risk of serious injury or death from inflating front airbags, take the following precautions:

- Seat belts must be worn at all times to help keep occupants positioned properly.
- Move your seat as far back as possible from front airbags, while still maintaining control of the vehicle.
- Never lean against the door or center console.
- Do not allow the front passenger to place their feet or legs on the dashboard.
- Never place any objects (such as dashboard cover, mobile phone holder, cup holder, perfume or stickers) over or near the airbag modules on the steering wheel, instrument panel, windshield glass, and the front passenger's panel above the glove box. Such objects may cause harm if the vehicle is in a collision severe enough to cause the airbags to deploy.
- Do not attach any objects on the front windshield and inside mirror.

## Side airbags and front center side airbag (if equipped)





[A]: Side airbag,

[B]: Front center side airbag (Driver's seat)

Your vehicle is equipped with a side airbag in each front seat. Additionally, a front center side airbag is provided in the inboard side of the driver seatback. The purpose of the airbag is to provide the vehicle's additional protection than that offered by the seat belt alone.

The side airbags and front center side airbag are designed to deploy during certain side impact collisions, depending on the crash severity.

For vehicles equipped with a rollover sensor the front center side airbag, side and/or curtain airbags and pretensioners on both sides of the vehicle may deploy if a rollover or possible rollover is detected.

The side airbags and front center side airbag are not designed to deploy in all side impact or rollover situations.

### $\Lambda$

#### **!** WARNING

To reduce the risk of serious injury or death from an inflating side airbag and front center side airbag, take the following precautions:

- Seat belts must be worn at all times to help keep occupants positioned properly.
- Do not allow passengers to lean their heads or bodies onto doors, put their arms on the doors, stretch their arms out of the window, or place objects between the doors and seats.
- Hold the steering wheel at the 9
  o'clock and 3 o'clock positions, to
  minimize the risk of injuries to your
  hands and arms.
- Do not use any accessory seat covers.
   This could reduce or prevent the effectiveness of the system.
- Do not hang objects over the airbags. In an accident it may cause vehicle damage or personal injury especially when airbag is inflated.

- Do not place any objects over the airbag or between the airbag and yourself. Also, do not attach any objects around the area the airbag inflates such as the door, side door glass, front and rear pillar.
- Do not place any objects between the door and the seat. They may become dangerous projectiles if the side airbag inflates.
- Do not install any accessories on the side or near the side airbags.
- Do not impact the doors when the Start/Stop button is in the ON or START position as this may cause the side airbags to inflate.
- If the seat or seat cover is damaged, have the system serviced by an authorized retailer of Genesis Branded products.

#### Curtain airbags





Curtain airbags are located along both sides of the roof rails above the front and rear doors.

They are designed to help protect the heads of the front seat occupants and the rear outboard seat occupants in certain side impact collisions.

The curtain airbags are designed to deploy during certain side impact collisions, depending on the crash severity.

For vehicles equipped with a rollover sensor the side and/or curtain airbags and pre-tensioners on both sides of the vehicle may deploy if a rollover or possible rollover is detected.

The curtain airbags are not designed to deploy in all side impact or rollover situations.



#### **WARNING**

To reduce the risk of serious injury or death from an inflating curtain airbag, take the following precautions:

- All occupants must wear seat belts at all times to help keep occupants positioned properly.
- Properly secure Child Restraint System as far away from the door as possible.
- Do not place any objects over the airbag. Also, do not attach any objects around the area the airbag inflates such as the door, side door glass, front and rear pillar, roof side rail.
- Do not hang other objects, especially hard or breakable objects.
  - In an accident, it may cause vehicle damage or personal injury.
- Do not allow passengers to lean their heads or bodies onto doors, put their arms on the doors, stretch their arms out of the window, or place objects between the doors and seats.
- Do not attempt to open or repair the side curtain airbags yourself. If necessary, have the airbag inspected by an authorized retailer of Genesis Branded products.

## How Does the Airbag System Operate?



The SRS consists of the following components:

- (1) Driver's front airbag module
- (2) Passenger's front airbag module
- (3) Front center side airbag module
- (4) Side airbag modules
- (5) Curtain airbag modules
- (6) Front retractor pre-tensioner
- (7) Airbag warning light
- (8) SRS control module (SRSCM) / Rollover sensor
- (9) Front impact sensors
- (10) Side impact sensors (acceleration)
- (11) Side impact sensors (pressure)
- (12) Driver's knee airbag module
- (13) Occupant classification system
- (14) Driver's and front passenger's seat belt buckle sensors



#### SRS warning light

The SRS (Supplemental Restraint System) airbag warning light on the instrument panel displays the airbag symbol depicted in the illustration. The system checks the airbag electrical system for malfunctions. The light indicates that there is a potential problem with your airbag system, which could include your side and/or curtain airbags used for rollover protection.



#### **WARNING**

If your SRS malfunctions, the airbag may not inflate properly during an accident, increasing the risk of serious injury or death.

If any of the following conditions occur, your SRS is malfunctioning:

- The light does not turn on for about three to six seconds when the Start/ Stop button is in the ON position.
- The light stays on after illuminating for about three to six seconds.
- The light comes on while the vehicle is in motion.
- The light blinks when the vehicle is on (READY indicator on).

Have an authorized retailer of Genesis Branded products inspect the SRS as soon as possible if any of these conditions occur. During a moderate to severe frontal collision, sensors will detect the vehicle's rapid deceleration. If the rate of deceleration is high enough, the control unit will inflate the front airbags, at the time and with the force needed.

The front airbags help protect the driver and front passenger by responding to frontal impacts in which seat belts alone cannot provide adequate restraint. The side airbags help provide protection in certain side impacts or rollover accidents by supporting the side upper body area.

- Airbags are activated (able to inflate if necessary) only when the Start/Stop button is in the ON or START position and it can be activated within about 3 minutes after the vehicle is turned off.
- Airbags inflate in the event of certain frontal or side collisions to help protect the occupants from serious physical injury.
- There is no single speed at which the airbags will inflate. Generally, airbags are designed to inflate based upon the severity of a collision and its direction. These two factors determine whether the sensors produce an electronic deployment/inflation signal.
- The front airbags will completely inflate and deflate in an instant. It is virtually impossible for you to see the airbags inflate during an accident. It is much more likely that you will simply see the deflated airbags hanging out of their storage compartments after the collision.

 In addition to inflating in serious side collisions, vehicles equipped with a rollover sensor, side and/or curtain airbags and front center side airbag will inflate if the sensing system detects a rollover.

When a rollover is detected, curtain airbags will remain inflated longer to help provide protection from ejection, especially when used in conjunction with the seat belts.

 To help provide protection, the airbags must inflate rapidly. The speed of airbag inflation is a consequence of extremely short time in which to inflate the airbag between the occupant and the vehicle structures before the occupant impacts those structures. This speed of inflation reduces the risk of serious or lifethreatening injuries and is thus a necessary part of airbag design.

However, the rapid airbag inflation can also cause injuries which can include facial abrasions, bruises and broken bones because the inflation speed also causes the airbags to expand with a great deal of force.

 There are even circumstances under which contact with the airbag can cause fatal injuries, especially if the occupant is positioned excessively close to the airbag.

You can take steps to reduce the risk of being injured by an inflating airbag. The greatest risk is sitting too close to the airbag. An airbag needs space to inflate. It is recommended that drivers sit as far as possible between the center of the steering wheel and the chest while still maintaining control of the vehicle.



When the SRSCM detects a sufficiently severe impact to the front of the vehicle, it will automatically deploy the front airbags.



Upon deployment, tear seams molded directly into the pad covers will separate under pressure from the expansion of the airbags. Further opening of the covers allows full inflation of the airbags.

A fully inflated airbag, in combination with a properly worn seat belt, slows the driver's or the front passenger's forward motion, reducing the risk of head and chest injury.





After complete inflation, the airbag immediately starts deflating, enabling the driver to maintain forward visibility and the ability to steer or operate other controls.

### **⚠** WARNING

To prevent objects from becoming dangerous projectiles when the passenger's airbag inflates:

- Do not install or place any objects (drink holder, CD holder, stickers, etc.) on the front passenger's panel above the glove box where the passenger's airbag is located.
- Do not install a container of liquid air freshener near the instrument cluster or on the instrument panel surface.

## What to Expect After an Airbag Inflates

After a frontal or side airbag inflates, it will deflate very quickly. Airbag inflation will not prevent the driver from seeing out of the windshield or being able to steer. Curtain airbags may remain partially inflated for some time after they deploy.



### **WARNING**

After an airbag inflates, take the following precautions:

- Open your windows and doors as soon as possible after impact to reduce prolonged exposure to the smoke and powder released by the inflating airbag.
- Do not touch the airbag storage area's internal components immediately after an airbag has inflated. The parts that come into contact with an inflating airbag may be very hot.
- Always wash exposed skin areas thoroughly with cold water and mild soap.
- Have an authorized retailer of Genesis Branded products replace the airbag immediately after deployment. Airbags are designed to be used only once.

## Noise and smoke from inflating airbag

When the airbags inflate, they make a loud noise and may produce smoke and powder in the air inside of the vehicle. This is normal and is a result of the ignition of the airbag inflator. After the airbag inflates, you may feel substantial discomfort in breathing because of the contact of your chest with both the seat belt and the airbag, as well as from breathing the smoke and powder. The powder may aggravate asthma for some people. If you experience breathing problems after an airbag deployment, seek medical attention immediately.

Though the smoke and powder are nontoxic, they may cause irritation to the skin, eyes, nose, throat, etc. If this is the case, wash and rinse with cold water immediately and seek medical attention if the symptoms persist.

## Occupant Classification System (OCS)



Your vehicle is equipped with an Occupant Classification System (OCS) in the front passenger's seat.

## Main components of the Occupant Classification System

- A detection device located within the front passenger seat cushion.
- Electronic system to determine whether the passenger airbag systems should be activated or deactivated.
- An indicator light located on the overhead console which illuminates the words "PASSENGER AIRBAG OFF" indicating the front passenger airbag system is deactivated.
- The instrument cluster airbag indicator light is interconnected with the OCS.

The OCS is designed to help detect the presence of a properly-seated front passenger and determine if the passenger's front airbag should be enabled (may inflate) or not.

The purpose is to help reduce the risk of injury or death from an inflating airbag to certain front passenger seat occupants, such as children, by requiring the airbag to be automatically turned off.

For example, if a child restraint of the type specified in the regulations is on the seat, the occupant classification sensor can detect it and cause the airbag to turn off

Front passenger seat adult occupants who are properly seated and wearing the seat belt properly, should not cause the passenger airbag to be automatically turned off. For smaller adults it may turn off. However, if the occupant does not sit in the seat properly (for example, by not sitting upright, by sitting on the edge of the seat, or by otherwise being out of position), this could cause the sensor to turn the airbag off.

You will find the "PASSENGER AIRBAG OFF" indicator overhead console panel. This system detects the conditions 1-4 in the following table and activates or deactivates the front passenger airbag based on these conditions.

Always be sure that you and all vehicle occupants are seated properly and wearing the seat belt properly for the most effective protection by the airbag and the seat belt.

The OCS may not function properly if the passenger takes actions which can affect the classification system. These include:

- · Failing to sit in an upright position.
- Leaning against the door or center console.
- Sitting towards the sides of the front of the seat.
- Putting their legs on the dashboard or resting them on other locations which reduce the passenger weight on the front seat.
- · Wearing the seat belt improperly.
- · Reclining the seatback.
- Wearing thick clothing like ski wear or hip protection wear.
- Putting an additional thick cushion on the seat.
- Putting electrical devices (for example, notebook, satellite radio) on the seat with inverter charging.

#### Condition and operation in the front passenger Occupant Classification System

Condition Detected by the Occupant Classification System	Indicator/Warning Light		Devices
	"PASSENGER AIRBAG OFF" Indicator Light	SRS Warning Light	Front Passenger Airbag
1. Adult *1	Off	Off	Activated
2. Infant *2 or child restraint system with 12 months old *3 *4	On	Off	Deactivated
3. Unoccupied	On	Off	Deactivated
4. Malfunction in the system	Off	On	Activated

<sup>\*1:</sup> The system judges a person of adult size as an adult. When a smaller adult sits in the front passenger seat, the system may recognize him/her as a child depending on his/her physique and posture.

<sup>\*2:</sup> Do not allow children to ride in the front passenger seat. When a larger child who has outgrown a child restraint system sits in the front passenger seat, the system may recognize him/her as an adult depending upon his/her physique or sitting position.

<sup>\*3:</sup> Never install a child restraint system on the front passenger seat.

<sup>\*4:</sup> The PASSENGER AIRBAG "OFF" indicator may turn on or off when a child above 12 months to 12 years old (with or without child restraint system) sits in the front passenger seat. This is a normal condition.

## **MARNING**

Riding in an improper position or placing weight on the front passenger's seat when it is unoccupied by a passenger adversely affects the OCS. To reduce the risk of serious injury or death:



 NEVER put a heavy load in the front seat or seatback pocket, or hang any items on the front passenger seat.



NEVER place your feet on the front passenger seatback.



NEVER sit with your hips shifted towards the front of the seat.



 NEVER ride with the seatback reclined when the vehicle is moving.



NEVER place your feet or legs on the dashboard.



 NEVER lean on the door or center console or sit on one side of the front passenger seat.



 Do not sit on the passenger seat wearing heavily padded clothes such as ski wear or hip protector.



 Do not use car seat accessories such as thick blankets and cushions which cover up the car seat surface.



- Do not place electronic devices such as laptops, DVD player, or conductive materials such as water bottles on the passenger seat.
- Do not use electronic devices such as laptops and satellite radios which use inverter chargers.



 If a large quantity of liquid has been spilled on the passenger seat, the airbag warning light may illuminate or malfunction.

Therefore, make sure the seat has been completely dried before driving the vehicle.

- Do not place sharp objects on the front passenger seat. These may damage the
  occupant detection system, if they puncture the seat cushion.
- · Do not place any items under the front passenger seat.
- When replacing the seat, use genuine Genesis parts. The OCS has been developed
  using genuine Genesis parts car seats. Altering or changing the authentic parts
  may result in system malfunction and increase risk of injury when in a collision. Any
  of the above could interfere with the proper operation of the OCS sensor thereby
  increasing the risk of an injury in an accident.



**Proper seated position for OCS** If the "PASSENGER AIRBAG OFF" indicator is on when an adult is seated in the front passenger seat, place the Start/Stop button in the OFF position and ask the passenger to sit properly (sitting upright with the seat back in an upright position, centered on the seat cushion with their seat belt on, legs comfortably extended and their feet on the floor). Restart the vehicle and have the person remain in that position. This will allow the system to detect the person and to enable the passenger airbag. If the "PASSENGER AIRBAG OFF" indicator is still on, ask the passenger to move to the rear seat.



NEVER allow an adult passenger to ride in the front passenger seat when the "PASSENGER AIRBAG OFF" indicator is illuminated. During a collision, the airbag will not inflate if the indicator is illuminated. Have your passenger reposition themselves in the seat. If the "PASSENGER AIRBAG OFF" indicator remains illuminated after the passenger repositions themselves properly and the vehicle is restarted, have the passenger move to the rear seat because the airbag will not inflate.

#### NOTICE

The "PASSENGER AIRBAG OFF" indicator generally illuminates for about 4 seconds after the Start/Stop button is in the ON position or after the READY (ready indicator) is displayed on the instrument cluster. But, if the Start/Stop button is turned to the ON position within 3 minutes after vehicle OFF, the indicator does not illuminate. If the front passenger seat is occupied, the OCS will then classify the front passenger after several more seconds.

## Do Not Install a Child Restraint in the Front Passenger's Seat



OH1039193 Ough your vehicle is equipped

Even though your vehicle is equipped with the OCS, never install a child restraint in the front passenger's seat. An inflating airbag can forcefully strike a child or child restraint resulting in serious or fatal injury.

### **MARNING**

- NEVER place a rear-facing or frontfacing child restraint in the front passenger's seat of the vehicle.
- An inflating frontal airbag could forcefully strike a child resulting in serious injury or death.
- Always properly restrain children in an appropriate child restraint in the rear seat of the vehicle.

## Why Didn't My Airbag Go Off In a Collision?

There are certain types of accidents in which the airbag would not be expected to provide additional protection. These include rear impacts, second or third collisions in multiple impact accidents, as well as low speed impacts. Damage to the vehicle indicates collision energy absorption, and is not an indicator of whether or not an airbag should have inflated.

#### Airbag collision sensors



#### WARNING

To reduce the risk of an airbag deploying unexpectedly and causing serious injury or death:

- Do not hit or allow any objects to impact the locations where airbags or sensors are installed.
- Do not perform maintenance on or around the airbag sensors. If the location or angle of the sensors is altered, the airbags may deploy when they should not or may not deploy when they should.
- Do not install bumper guards or replace the bumper with a nongenuine Genesis part. This may adversely affect the collision and airbag deployment performance.
- Press the Start/Stop button to the OFF or ACC position and wait for 3 minutes, when the vehicle is being towed to prevent inadvertent airbag deployment.
- Have all airbag repairs performed by an authorized retailer of Genesis Branded products.



- (A) SRS control module/Rollover sensor
- (B) Front impact sensor
- (C) Side impact sensor (Pressure)
- (D) Side impact sensor (Acceleration)
- (E) Side impact sensor (Acceleration)

#### Airbag inflation conditions



Front airbags

Front airbags are designed to inflate in a frontal collision depending on the severity of impact of the front collision.





Side and curtain airbags and front center side airbag

Side and curtain airbags and the front center side airbag are designed to inflate when an impact is detected by side collision sensors depending on the severity of impact resulting from a side collision.

Although the driver's and front passenger's airbags are designed to inflate in frontal collisions, they also may inflate in other types of collisions if the front impact sensors detect a sufficient impact. Side and curtain airbags and the front center side airbag are designed to inflate in side impact collisions, but they may inflate in other collisions if the side impact sensors detect a sufficient impact.

Also, the side and curtain airbags and the front center side airbag are designed to inflate when a rollover is detected by a rollover sensor (if equipped with rollover sensor).

If the vehicle chassis is impacted by bumps or objects on unimproved roads, the airbags may deploy. Drive carefully on unimproved roads or on surfaces not designed for vehicle traffic to prevent unintended airbag deployment.

# Airbag non-inflation conditions



In certain low-speed collisions the airbags may not deploy. The airbags are designed not to deploy in such cases because they may not provide benefits beyond the protection of the seat belts.



Front airbags are not designed to inflate in rear collisions, because occupants are moved backward by the force of the impact. In this case, inflated airbags would not provide any additional benefit.



Front airbags may not inflate in side impact collisions, because occupants move in the direction of the collision, and thus in side impacts, front airbag deployment would not provide additional occupant protection.

However, side and curtain airbags and the front center side airbag may inflate depending on the severity of impact.



In an angled collision, the force of impact may direct the occupants in a direction where the airbags would not be able to provide any additional benefit, and thus the sensors may not deploy any airbags.



Just before impact, drivers often brake heavily. Such heavy braking lowers the front portion of the vehicle causing it to "ride" under a vehicle with a higher ground clearance. Airbags may not inflate in this "underride" situation because deceleration forces that are detected by sensors may be significantly reduced by such "underride" collisions.



Airbags may not inflate if the vehicle collides with objects such as utility poles or trees, where the point of impact is concentrated and the collision energy is absorbed by the vehicle structure.



Front airbags may not inflate in rollover accidents because front airbag deployment would not provide additional occupant protection.

The side and curtain airbags and the front center side airbag may inflate in a rollover situation, when it is detected by the rollover sensor.

#### **SRS Care**

The SRS is virtually maintenance-free and there are no parts you can safely service by yourself. If the SRS airbag warning light does not illuminate when the Start/Stop button is in the ON position, or continuously remains on, have the system immediately inspected by an authorized retailer of Genesis Branded products.

Any work on the SRS system, such as removing, installing, repairing, or any work on the steering wheel, the front passenger's panel, front seats and roof rails be performed by an authorized retailer of Genesis Branded products. Improper handling of the SRS system may result in serious personal injuries.

# **WARNING**

To reduce the risk of serious injury or death, take the following precautions:

- Do not attempt to modify or disconnect the SRS components or wiring, including the addition of any kind of badges to the pad covers or modifications to the body structure.
- Do not place objects over or near the airbag modules on the steering wheel, instrument panel, and the front passenger's panel above the glove box.
- Clean the airbag pad covers with a soft cloth moistened with plain water.
   Solvents or cleaners could adversely affect the airbag covers and proper deployment of the system.
- Always have inflated airbags replaced by an authorized retailer of Genesis Branded products.
- If components of the airbag system must be discarded, or if the vehicle must be scrapped, certain safety precautions must be observed.
   Consult an authorized retailer of Genesis Branded products for the necessary information. Failure to follow these precautions could increase the risk of personal injury.

# **Additional Safety Precautions**

Passengers should not move out of or change seats while the vehicle is moving. A passenger who is not wearing a seat belt during a crash or emergency stop can be thrown against the inside of the vehicle, against other occupants, or be ejected from the vehicle.

Do not use any accessories on seat belts. Devices claiming to improve occupant comfort or reposition the seat belt can reduce the protection provided by the seat belt and increase the chance of serious injury in a crash.

#### Do not modify the front seats.

Modification of the front seats could interfere with the operation of the supplemental restraint system sensing components or side airbags.

Do not place items under the front seats. Placing items under the front seats could interfere with the operation of the supplemental restraint system sensing components and wiring harnesses.

**Do not cause impact to the doors.** Impact to the doors when the Start/Stop button is in the ON or START position may cause the airbags to inflate.

Modifications to accommodate disabilities. If you require modification to your vehicle to accommodate a disability, contact Genesis Customer Care at 844 340-9741.

# Adding equipment to or modifying your airbag equipped vehicle

If you modify your vehicle by changing your vehicle's frame, bumper system, front end or side sheet metal or ride height, this may affect the operation of your vehicle's airbag system.

# Airbag Warning Labels



Airbag warning labels, required by the U.S. National Highway Traffic Safety Administration (NHTSA), are attached to alert the driver and passengers of potential risks of the airbag system. Be sure to read all of the information about the airbags that are installed on your vehicle in this Owners Manual.

# 4. Instrument Cluster

Instrument Cluster Control	4-5
Instrument panel illumination	4-5
Gauges and Meters	4-5
Speedometer	4-5
Power/Charge Gauge	4-6
State of Charge (SOC) Gauge for High Voltage Battery	4-6
Outside temperature gauge	4-7
Odometer	4-8
Distance to empty	4-8
Energy economy (for 12.3-inch 3D cluster)	4-9
Gear Shift Indicator	4-9
Regenerative braking level indicator	4-10
Warning and Indicator Lights	4-10
Ready indicator light	4-10
Service warning light	
Power down indicator light	4-11
Charging connector indicator light	4-11
High voltage battery level warning light	4-11
Seat belt warning light	4-11
Airbag warning light	4-12
Regenerative brake warning light	4-12
Parking brake & brake fluid warning light	4-12
Anti-lock Brake System (ABS) warning light	4-13
Electronic Brake Force Distribution (EBD) system warning light	
MDPS (Motor Driven Power Steering)	
Master warning light	
Electronic Parking Brake (EPB) warning light	4-15
Low tire pressure warning light	
Forward safety warning light	
Lane safety indicator light	
LED headlight warning light	
All Wheel Drive (AWD)warning light	4-16
Icy road warning light	4-17
Electronic Stability Control (ESC) indicator light	
Electronic Stability Control (ESC) OFF indicator light	
Immobilizer indicator light	
Turn signal indicator light	
High beam indicator light	
Low beam indicator light	4-18
Light ON indicator light	4-18
High Beam Assist indicator light	4-19
AUTO HOLD indicator light	


Instrument Cluster......4-4

Cluster Display Messages	4 10
Shift to P	
Vehicle is in N. Press START button and shift to P	4-19
Low key battery	
Press START button while turning wheel	
Press brake pedal to start vehicle	
Key not in vehicle	
Key not detected	
Press START button again	
Press START button with key	
Check BRAKE SWITCH fuse	
Shift to P to start vehicle	4-20
Battery discharging due to external electrical devices	4-20
Door, Hood, Liftgate open indicator	4-21
Low tire pressure	
Lights	4-21
Wiper	
Low washer fluid	4-22
Check haptic steering wheel system	4-22
Check headlight LED	4-22
Shift to P to charge	4-22
Remaining Time	
Unplug vehicle to start	4-22
Charging Door Open	
Charging Stopped. Check the charger	
Charging Stopped. Check the cable connection	
Check regenerative brakes	
Low EV battery	
Charge immediately. Power limited	
Power limited due to low EV battery temperature. Charge battery	
EV battery Overheated! Stop vehicle	
Power limited	
Stop vehicle and check power supply	
Check Virtual Engine Sound System	
Check electric vehicle system	
Check electric verificie system	+-23

# **4.Instrument Cluster**

Cluster Display	4-26
Cluster Display Control	4-26
View Modes	4-26
Driving Assist view	4-27
Turn By Turn (TBT) view	4-27
Utility view	4-27
Additional information display	4-30
Option Menu	4-30
Service messages	4-31
3D cluster (for 12.3-inch 3D cluster)	4-31
Head-up display	4-31
Driver Assistance settings	4-31
Speed unit	4-32
3D Instrument Cluster (for 12.3-inch 3D Cluster)	4-32
3D cluster setting	4-32
Recommendations to optimize the 3D effect	4-32
Vehicle Settings (Infotainment System)	4-35
Setting Your Vehicle	4-35
5	

# **INSTRUMENT CLUSTER**



- (1) Speedometer
- (2) Power/Charge gauge
- (3) Distance to empty
- (4) Warning and indicator lights
- (5) Cluster display
- (6) Battery SOC (State of Charge) gauge
- (7) Smart regeneration system

# **Instrument Cluster Control**

Instrument panel illumination



When the vehicle's parking lights or headlight are on, press the illumination control switch to adjust the brightness of the instrument panel illumination.

When pressing the illumination control switch, the interior switch illumination intensity is also adjusted.



Never adjust the instrument panel illumination while driving to prevent death, serious injury, or vehicle damage.



- The brightness of the instrument panel illumination is displayed.
- When the brightness setting reaches either the minimum or maximum level, a chime sounds.

# **Gauges and Meters**

Speedometer





The speedometer indicates the speed of the vehicle and is calibrated in miles per hour (MPH) and/or kilometers per hour (km/h).

# Power/Charge Gauge





The Power/Charge gauge shows the energy consumption and recovery status of the electric motor.

#### POWFR:

The discharging status of the electric motor is shown when the vehicle is accelerating or driving on an uphill road. As the electric energy discharged increases, the gauge level also increases.

#### CHARGE:

The charging status of the electric motor is shown when the vehicle is decelerating or driving on a downhill road (being charged by the regenerative brakes). As more electric energy charges, the lower the gauge level.

# State of Charge (SOC) Gauge for High Voltage Battery





OJKEV042015N

- The SOC gauge shows the charging status of the high voltage battery.
- The 'L' on the indicator indicates that there is not enough energy in the high voltage battery. 'H' indicates that the high voltage battery is fully charged.
- When driving on highways, make sure to check in advance if the high voltage battery is charged enough.





- When the remaining battery is lower than 10 % on the SOC gauge, the High Voltage Battery Level ( warning light illuminates to alert you of the battery level.
- 2. When the High Voltage Battery Level (() warning light illuminates, the vehicle can drive an additional 12-25 miles (20-40 km) depending on the driving speed, heater/air conditioner, weather, driving style, and other factors. Charging is required.

# NOTICE

When the high voltage battery level is low, the Power Down () indicator light illuminates and the vehicle power is limited.

Charge the battery immediately since your vehicle may not be driven, or may roll back on a slope with the indicator light illuminated.

### Outside temperature gauge





OJKEV042011N

The temperature reads in Fahrenheit or Celsius depending on the units selected from the Settings menu in the infotainment system.

The temperature indicated on the instrument cluster may not change as quickly as the outside temperature.

# Select: Setup > General > Units > Temperature Unit > °F/°C


Both the temperature unit on the instrument cluster and climate control screen is changed.



# Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

#### **Odometer**



3.4 300m OJKEV042006N

The odometer indicates the total distance that the vehicle has been driven and should be used to determine when periodic maintenance is required.

# Distance to empty





- The distance to empty is the
- estimated distance the vehicle can be driven with the remaining electric energy. The distance to empty differs
- depending on which drive mode (ECO/COMFORT/SPORT) is selected.

For more information, refer to the "Distance to Empty" section in chapter 1.



# Information

- The distance to empty may differ from the actual driving distance because it is only an estimate as it is an estimate of the available driving distance.
- · The distance to empty may differ significantly based on driving conditions, driving habits, and condition of the vehicle.
- If the vehicle is not on level ground or the battery power has been interrupted, the distance to empty function may not operate correctly.

# Energy economy (for 12.3-inch 3D cluster)



The instant energy economy (1) and instant fuel economy (2) is displayed at the bottom of the instrument cluster.

#### **Automatic reset**

To automatically reset the average fuel economy, select between "After Ignition" or "After Recharging" from the Settings menu in the infotainment system.



For 8-inch instrument cluster, you can check the fuel economy in the Utility view on the cluster.

For more information, refer to the "View modes" section in this chapter.

# **Gear Shift Indicator**





The Gear Shift Indicator indicates the current gear or P (Park).

### Regenerative braking level indicator





The selected regenerative braking level is displayed on the instrument cluster. Also, the Smart Regenerative System's operation status is displayed.

For more information, refer to the "Regenerative Braking System" section in chapter 6.

# **Warning and Indicator Lights**



# Information

Make sure that all warning lights are OFF after starting the vehicle. If any light is still ON, this indicates a situation that needs attention.

# Ready indicator light

READY

### This indicator illuminates:

When the vehicle is ready to be driven.

- ON: Normal driving is possible.
- OFF: Normal driving is not possible, or a problem has occurred.
- Blinking: Emergency driving.

When the **READY** indicator goes off or blinks, there is a problem with the system. In this case, have your vehicle inspected by an authorized retailer of Genesis Branded products.

# Service warning light



#### This warning light illuminates:

- When the Start/Stop button is in the ON position. The Service warning light illuminates for 3 seconds and then goes off.
- When there is a problem with related parts of the electric vehicle control system, such as sensors, etc.

When the warning light illuminates while driving, or does not go off after starting the vehicle, have your vehicle inspected by an authorized retailer of Genesis Branded products.

#### Power down indicator light



This indicator light illuminates:

When the power is limited for the safety of the high-powered parts of an electric vehicle. The power is limited for the following reasons:

- The high voltage battery level is too low or voltage is decreasing
- The temperature of the high voltage battery is too high or too low
- The temperature of the motor is high

# NOTICE

- Do not accelerate or start the vehicle suddenly when the power down indicator light is illuminated.
- When the power is limited for the safety of the high-powered parts of an electric vehicle, the power down indicator light illuminates. Your vehicle may not be driven, or may roll back on a slope with the indicator light illuminated due to the limitation of vehicle power.

# *i* Information

Unless both the Service Warning Light and Power Down Indicator Light illuminate at the same time, it is not a failure.

# Charging connector indicator light



This warning light indicates the connection status of the charging connector. When the charging connector is connected to the vehicle, the green light illuminates for about 1 minute.

# High voltage battery level warning light



This warning light illuminates:

When the high voltage battery level is low.

Charge the high voltage battery as soon as possible.

# Seat belt warning light



This warning light informs the driver that the seat belt is not fastened.

For more information, refer to the "Seat Belts" section in chapter 3.

#### Airbag warning light



### This warning light illuminates:

- When the Start/Stop button is in the ON position. The Airbag warning light illuminates for 3-6 seconds and then goes off.
- When there is a malfunction with the SRS

If the Airbag warning light remains illuminated while driving, have the vehicle inspected by an authorized retailer of Genesis Branded products.

# Regenerative brake warning light





#### This warning light illuminates:

When the regenerative brake does not operate and the brake does not perform well. This causes the Parking Brake Warning light (red) and Regenerative Brake Warning Light (yellow) to illuminate simultaneously.

In this case, drive safely and have your vehicle inspected by an authorized retailer of Genesis Branded products.

The operation of the brake pedal may be more difficult than normal and the braking distance can increase.

# Parking brake & brake fluid warning light



## This warning light illuminates:

- When the Start/Stop button is in the ON position. The Parking Brake warning light illuminates for about 3 seconds and then goes off once the parking brake is released.
- Whenever the parking brake is applied.
- Whenever the brake fluid level in the reservoir is low.
  - If the warning light illuminates with the parking brake released, it indicates the brake fluid level in the reservoir is low.
- When the regenerative brake does not operate.

# If the brake fluid level in the reservoir is low:

- 1. Drive carefully to the nearest safe location and stop your vehicle.
- 2. With the motor stopped, check the brake fluid level immediately and add fluid as required (For more information, refer to the "Brake Fluid" section in chapter 9). After adding brake fluid, check all brake components for fluid leaks. If a brake fluid leak is found, or if the warning light remains on, or if the brakes do not operate properly, do not drive the vehicle. Have the vehicle inspected by an authorized retailer of Genesis Branded products.

### **Dual-diagonal braking system**

Your vehicle is equipped with the dual diagonal braking system. This means you still have braking on two wheels even if one of the dual systems fails.

With only one of the dual systems working, more than normal pedal travel and greater pedal force are required to stop the vehicle.

Also, the vehicle does not stop in a short distance if only a portion of the braking system is working.



# **WARNING**

If the Parking Brake & Brake Fluid warning light illuminates with the parking brake released, it indicates that the brake fluid level is low. Have the vehicle inspected by an authorized retailer of Genesis Branded products.

Anti-lock Brake System (ABS) warning light



#### This warning light illuminates:

- When the Start/Stop button is in the ON position. The ABS warning light illuminates for about 3 seconds and then goes off.
- Whenever there is a malfunction with the ABS.

The hydraulic braking system still operates even if there is a malfunction with the ABS.

If the ABS warning light remains illuminated while driving, have the vehicle inspected by an authorized retailer of Genesis Branded products.

Electronic Brake Force Distribution (EBD) system warning light





When the ABS warning and Parking Brake warning lights are on simultaneously, it may indicate a problem with the Electronic Brake Force Distribution system.

If both the ABS warning light and the Parking Brake warning light remain illuminated while driving, have the vehicle inspected by an authorized retailer of Genesis Branded products.

# ! WARNING

When both ABS and Parking Brake & Brake Fluid warning lights are on, the braking system does not work normally and you may experience an unexpected and dangerous situation during sudden

Avoid high speed driving and abrupt braking.

Have the vehicle inspected by an authorized retailer of Genesis Branded products as soon as possible.



### Information

When the ABS warning light is on or both ABS and Parking Brake & Brake Fluid warning lights are on, the speedometer, odometer, or tripmeter may not work. Also, the MDPS warning light may illuminate and the steering effort may increase or decrease.

# MDPS (Motor Driven Power Steering)



This warning light illuminates:

- · When the Start/Stop button is in the ON position. The Motor Driven Power Steering warning light illuminates for about 3 seconds and then goes off.
- Whenever there is a malfunction with the Motor Driven Power Steering. If the MDPS warning light remains illuminated while driving, have the vehicle inspected by an authorized retailer of Genesis Branded products.

### Master warning light



This warning light illuminates:

If a malfunction is detected in any of the following:

- Forward Collision-Avoidance Assist malfunction
- Forward Collision-Avoidance Assist radar blocked
- Blind-Spot Collision-Avoidance Assist malfunction
- Blind-Spot Collision-Avoidance Assist radar blocked
- LED headlight malfunction
- High Beam Assist malfunction
- Smart Cruise Control malfunction
- Smart Cruise Control radar blocked
- Tire Pressure Monitoring System (TPMS) malfunction

If the issue is resolved, the Master Warning Light turns off.

# Electronic Parking Brake (EPB) warning light



# Low tire pressure warning light



This warning light illuminates:

- When the Start/Stop button is in the ON position. The EPB warning light illuminates for about 3 seconds and then goes off.
- Whenever there is a malfunction with FPR

If the EPB warning light remains illuminated while driving, have the vehicle inspected by an authorized retailer of Genesis Branded products.



#### Information

The Electronic Parking Brake (EPB) warning light may illuminate when the Electronic Stability Control (ESC) indicator light comes on to indicate that ESC is not working properly. This does not indicate malfunction of EPB.

#### This warning light illuminates:

- When the Start/Stop button is in the ON position. The low tire pressure warning light illuminates for about 3 seconds and then goes off.
- When one or more tires are significantly underinflated. (The location of the underinflated tire appears on the cluster display.)

For more information, refer to the "Tire Pressure" section in chapter 8.

This warning light remains ON after blinking for about 60 seconds, or repeatedly blinks ON and OFF in 3 second intervals:

When there is a malfunction with the TPMS.

If this occurs, have the vehicle inspected by an authorized retailer of Genesis Branded products as soon as possible.

For more information, refer to the "Tire Pressure Monitoring System (TPMS)" section in chapter 8.



# WARNING

- The TPMS cannot alert you to severe and sudden tire damage caused by external factors.
- If you notice any vehicle instability, immediately take your foot off the accelerator pedal, apply the brakes gradually with light force, and slowly move to a safe position off the road.

### Forward safety warning light



## This warning light illuminates:

- When the Start/Stop button is in the ON position. The Forward Safety warning light illuminates for about 3 seconds and then goes off.
- When Forward Collision-Avoidance Assist is turned off by:
  - Selecting **Off** for Forward Safety from the Settings menu.
  - Turning off ESC (press and hold the ESC button)
- Whenever a malfunction with Forward Collision-Avoidance Assist is detected.

If this occurs, have the vehicle inspected by an authorized retailer of Genesis Branded products.

For more information, refer to the "Forward Collision-Avoidance Assist (FCA)" section in chapter 7.

### Lane safety indicator light



#### This indicator light illuminates:

- Green: When Lane Keeping Assist operating conditions are met.
- Grey: When Lane Keeping Assist operating conditions are not met.
- Yellow: Whenever a malfunction with Lane Keeping Assist is detected.
   If this occurs, have the vehicle inspected by an authorized retailer of Genesis Branded products.

For more information, refer to the "Lane Keeping Assist (LKA)" section in chapter 7.

# LED headlight warning light (if equipped)



#### This warning light illuminates:

- When the Start/Stop button is in the ON position. The LED headlight warning light illuminates for about 3 seconds and then goes off.
- Whenever there is a malfunction with the LED headlight.

If the LED headlight warning light remains illuminated while driving, have the vehicle inspected by an authorized retailer of Genesis Branded products.

## This warning light blinks:

Whenever there is a malfunction with a LED headlight related part.

If this occurs, have the vehicle inspected by an authorized retailer of Genesis Branded products.

# NOTICE

Continuous driving with the LED Headlight warning light on or blinking can reduce LED headlight life.

# All Wheel Drive (AWD) warning light (if equipped)



#### This warning light illuminates:

Whenever a malfunction with the AWD system is detected.

If this occurs, have the vehicle inspected by an authorized retailer of Genesis Branded products.

For more information, refer to the "All Wheel Drive (AWD)" section in chapter 6.

# Icy road warning light (if equipped)



This indicator light illuminates:

To warn the driver the road may be icy. When the outside temperature on the temperature gauge is below 40 °F (4 °C), a single chime sounds, both the outside temperature gauge and Icy Road Warning indicator blink several times, and then they remain illuminated.

You can activate or deactivate lcy Road Warning function from the Settings menu in the infotainment system.

Select: Setup > Vehicle > Cluster > Content Selection > Icy Road Warning



### Information

- If the Icy Road warning light appears while driving, avoid speeding, rapid acceleration, sudden braking, or sharp turning.
- The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

# Electronic Stability Control (ESC) indicator light



This indicator light illuminates:

- When the Start/Stop button is in the ON position. The Electronic Stability Control indicator light illuminates for about 3 seconds and then goes off.
- Whenever there is a malfunction with ESC system.
  - If this occurs, have the vehicle inspected by an authorized retailer of Genesis Branded products.

This indicator light blinks:

While ESC is operating.

For more information, refer to the "Electronic Stability Control (ESC)" section in chapter 6.

# Electronic Stability Control (ESC) OFF indicator light



This indicator light illuminates:

- When the Start/Stop button is in the ON position. The ESC OFF indicator light illuminates for about 3 seconds and then goes off.
- When you deactivate ESC system by pressing the ESC OFF button.

For more information, refer to the "Electronic Stability Control (ESC)" section in chapter 6.

#### Immobilizer indicator light



This indicator light illuminates for up to 30 seconds:

When the vehicle detects the smart key in the vehicle with the Start/Stop button in the ACC or ON position.

- At this time, you can start the vehicle.
- The indicator light goes off after starting the vehicle.

This indicator light blinks for a few seconds:

When the smart key is not in the vehicle, you cannot start the vehicle.

This indicator light illuminates for 2 seconds and goes off:

If the smart key is in the vehicle and the Start/Stop button is ON, but the vehicle cannot detect the smart key, have the vehicle inspected by an authorized retailer of Genesis Branded products.

#### This indicator light blinks:

Whenever there is a malfunction with the immobilizer system, have the vehicle inspected by an authorized retailer of Genesis Branded products.

## Turn signal indicator light



This indicator light blinks:
When you operate the turn signal lever.

If any of the following occur, there may be a malfunction with the turn signal system.

- The turn signal indicator light illuminates but does not blink.
- The turn signal indicator light blinks rapidly.
- The turn signal indicator light does not illuminate at all.

If any of these occur, have the vehicle inspected by an authorized retailer of Genesis Branded products.

## High beam indicator light



This indicator light illuminates:

- When the headlights are on and in the high beam position.
- When the turn signal lever is pulled into the Flash-to-Pass position.

# Low beam indicator light



This indicator light illuminates: When the headlights are on.

# Light ON indicator light



This indicator light illuminates: When the parking lights or headlights are on.

# High Beam Assist indicator light (if equipped)



This indicator light illuminates:

When the high beam is on with the light switch in the AUTO position.

- White: When High Beam Assist is ready to operate.
- Green: When High Beam Assist is operating.

If your vehicle detects oncoming vehicles in front of you, High Beam Assist switches the high beam to low beam automatically.

For more information, refer to the "High Beam Assist (HBA)" section in chapter 5.

#### **AUTO HOLD indicator light**



This indicator light illuminates:

- Green: When you activate Auto Hold by pressing the AUTO HOLD switch.
- Grey: When you stop the vehicle completely by depressing the brake pedal with Auto Hold activated.
- Yellow: Whenever a malfunction with the Auto Hold is detected.
   If the AUTO HOLD indicator light remains YELLOW while driving, have the vehicle inspected by an authorized retailer of Genesis Branded products.

For more information, refer to the "Electronic Parking Brake (EPB)" section in chapter 6.

# **Cluster Display Messages**

Shift to P

This message is displayed if you try to turn off the vehicle without the gear in the P (Park) position.

If this occurs, the Start/Stop button turns to the ACC position.

# Vehicle is in N. Press START button and shift to P

This message is displayed if you try to turn off the vehicle with the gear in N (Neutral).

To turn off the vehicle:

- 1. Press the Start/Stop button. The button will change to the ON position.
- 2. Press the P button to shift to P (Park).
- 3. Press the Start/Stop button again, then the vehicle will turn off.

# Low key battery

When the Start/Stop button is pressed to the OFF position, a message may appear, indicating the internal battery of the Smart Key is low.

Replace the Smart Key battery.

# Press START button while turning wheel (if equipped)

This message is displayed if the steering wheel does not unlock normally when the Start/Stop button is pressed.

You should press the Start/Stop button while turning the steering wheel right and left.

### Press brake pedal to start vehicle

This message is displayed if the Start/ Stop button changes to the ACC position twice by pressing the button repeatedly without depressing the brake pedal.

You can start the vehicle by depressing the brake pedal and then pressing the Start/Stop button.

### Key not in vehicle

This message is displayed if the smart key is not in the vehicle when you leave the vehicle with the Start/Stop button in the ON or Start position.

Always turn off the vehicle before leaving your vehicle.

# Key not detected

This message is displayed if the smart key is not detected when you press the Start/Stop button.

# Press START button again

If you cannot start the vehicle after the Start/Stop button is pressed, attempt to start the vehicle by pressing the Start/Stop button again.

If the warning message appears each time you press the Start/Stop button, have the vehicle inspected by an authorized retailer of Genesis Branded products.

# Press START button with key

This message is displayed and the immobilizer indicator blinks if you press the Start/Stop button while the warning message, "Key not detected" appears.

#### Check BRAKE SWITCH fuse

This message is displayed if the brake switch fuse is disconnected.

Replace the fuse with a new one before starting the vehicle.

If that is not possible, you can start the vehicle by pressing the start button for 10 seconds in the ACC position.

### Shift to P to start vehicle

This message is displayed if you try to start the vehicle in any other position except P (Park).



# Information

You can start the vehicle with the gear in N (Neutral). But, for your safety, start the vehicle with the gear shifted to P (Park).

# Battery discharging due to external electrical devices

This message is displayed if the 12 V battery voltage is low or if a current draw is detected that could drain the vehicle battery.

Do not connect any external electronic devices to the battery system or battery discharge may occur.

If this message appears on the cluster and there are no other external electronic devices connected to the vehicle, have the vehicle inspected by an authorized retailer of Genesis Branded products.

# Door, Hood, Liftgate open indicator



This warning is displayed if any door or hood or liftgate is left open. The warning indicates which door is open on the cluster display



# **CAUTION**

Before driving the vehicle, confirm the door, hood, and liftgate are fully closed. Also, check there are no door, hood, and liftgate open warning lights or messages displayed on the instrument cluster.

# Low tire pressure



This warning message is displayed if the tire pressure is low. The corresponding tire on the vehicle illuminates.

For more information, refer to the "Tire Pressure Monitoring System (TPMS)" section in chapter 8.

### Lights



This indicator displays which exterior light is selected using the lighting control.

You can activate or deactivate Wiper/ Lights display function from the Settings menu in the infotainment system.

Select: Setup > Vehicle > Cluster > **Content Selection > Wiper/Lights** Display

# Wiper



This indicator displays which wiper speed is selected using the wiper control.

You can activate or deactivate Wiper/ Lights display function from the Settings menu in the infotainment system.

Select: Setup > Vehicle > Cluster > **Content Selection > Wiper/Lights** Display



# The infotainment system may change after software updates. For more information, refer to the user's manual

provided in the infotainment system and the quick reference guide.

### Low washer fluid (if equipped)

This message is displayed if the washer fluid level in the reservoir is nearly empty. Have the washer fluid reservoir refilled.

### Check haptic steering wheel system

This message is displayed if there is a problem with the haptic steering wheel system. Have the vehicle inspected by an authorized retailer of Genesis Branded products.

# Check headlight LED (if equipped)


This message is displayed if there is a problem with the LED headlight. Have the vehicle inspected by an authorized retailer of Genesis Branded products.

# Shift to P to charge

This message is displayed if you connect the charging cable without the gear in the P (Park) position.

Shift to P (Park) before connecting the charging cable.

# Remaining Time



[A]: AC charge, [B]: DC charge

This message is displayed to notify the remaining time to charge the battery to the selected target battery charge level.

# Unplug vehicle to start

This message is displayed when you start the vehicle without unplugging the charging cable. Unplug the charging cable, and then turn on the vehicle.

# Charging Door Open

This message is displayed when the vehicle is driven with the charging door opened. Close the charging door and then start driving.

# Charging Stopped. Check the charger

This warning message is displayed when charging is stopped for the following reasons:

- There is a problem with the external AC charger or DC charger
- The external AC charger stops charging
- The charging cable is damaged In this case, check whether there is any problem with the external AC or DC charger and charging cable.

If the same problem occurs when charging the vehicle with a normally operating AC charger or genuine Genesis portable charger, have your vehicle inspected by an authorized retailer of Genesis Branded products.

# Charging Stopped. Check the cable connection

This warning message is displayed when charging is stopped because the charging connector is not correctly connected to the charging inlet

In this case, separate the charging connector and reconnect it and check whether there is any problem (external damage, foreign substances, etc.) with the charging connector and charging inlet.

If the same problem occurs when charging the vehicle with a replaced charging cable or genuine Genesis portable charger, have your vehicle inspected by an authorized retailer of Genesis Branded products.

# Check regenerative brakes



These warning messages are displayed when the regenerative brake system does not work properly.

In this case, have the vehicle inspected by an authorized retailer of Genesis Branded products.

# Low EV battery



When the high voltage battery level reaches below about 10 %, this warning message is displayed.

The High Voltage Battery Level () warning light illuminates simultaneously.

Charge the high voltage battery immediately.

# Charge immediately. Power limited



When the high voltage battery level reaches below about 5 %, this warning message is displayed.

The High Voltage Battery Level (ﷺ) warning light illuminates simultaneously.

The vehicle's power will be reduced to minimize the energy consumption of the high voltage battery. Charge the high voltage battery immediately.

# Power limited due to low EV battery temperature. Charge battery



Both warning messages are displayed to protect electric vehicle system when outside temperature is low. If the high voltage battery charging level is low and parked outside in low temperature for a long time, vehicle power may be limited. Charging the battery before driving helps increase power.

# NOTICE

If these warning messages are still displayed even after the ambient temperature has increased, have the vehicle inspected by an authorized retailer of Genesis Branded products.

# EV battery Overheated! Stop vehicle

This warning message is displayed to protect battery and electric vehicle system when the high voltage battery temperature is too high.

Turn off the Start/Stop button and stop the vehicle so that the battery temperature decreases.

#### Power limited

This warning message is displayed to ensure the safety of high-powered components of electric vehicles. The power is limited for the following reasons:

- The high voltage battery level is too low or voltage is decreasing
- The temperature of the high voltage battery is too high or too low
- The temperature of the motor is high

# NOTICE

- When this warning message is displayed, do not accelerate or start the vehicle suddenly.
- When the power is limited for the safety of high-powered parts of the electric vehicle, the warning message is displayed. Your vehicle may not be driven, or may roll back on a slope with the warning message displayed due to the limitation of vehicle power.

# *i* Information

Unless both the Service Warning Light and Power Down Indicator Light illuminate at the same time, it is not a failure.

# Stop vehicle and check power supply

This warning message is displayed when a failure occurs in the power supply system.

In this case, park the vehicle in a safe location and tow your vehicle to the nearest authorized retailer of Genesis Branded products and have the vehicle inspected.

# **Check Virtual Engine Sound System**

This message is displayed when there is a problem with the Virtual Engine Sound System (VESS).

In this case, have the vehicle inspected by an authorized retailer of Genesis Branded products.

## Check electric vehicle system

This warning message is displayed when there is a problem with the electric vehicle control system.

Refrain from driving when the warning message is displayed.

In this case, have the vehicle inspected by an authorized retailer of Genesis Branded products.

# **CLUSTER DISPLAY**

# **Cluster Display Control**



The cluster display modes can be changed by using the control switches.

Switch	Operation	Function
ョ	Press	MODE button for changing View modes
<u></u>	Press	UP, DOWN switch for changing items in Utility view and Option menu
ОК	Press	SELECT/RESET switch for entering Option menu
	Press and hold	SELECT/RESET switch for retrieving assist information or resetting the selected item

## **View Modes**

View modes	Explanation	
Driving Assist	Driving Assist view displays the status of the vehicle's Driver Assistance systems.	
Turn by Turn	Turn By Turn view displays the state of the navigation.	
Utility Utility view displays driving information such as the trip electric energy economy and etc.		

The information provided may differ depending on which features are available to your vehicle.

# **Driving Assist view**



OJKEV041023

The status of Smart Cruise Control, Lane Following Assist, Highway Driving Assist, etc., is displayed when Driving Assist view is selected.

For more information, refer to the each function information section in chapter 7.


# Turn By Turn (TBT) view



Turn-by-turn navigation, distance/time to destination information is displayed when Turn by Turn view is selected.

### Utility view

In the Utility view, using the  $\wedge$ ,  $\vee$  (UP, DOWN) switch, you may change through items in the following order.



#### Drive info

This display shows the trip distance, the average energy consumption, and the total driving time.

The information is combined for each ignition cycle.


To manually reset the information, press and hold the **OK** button when viewing the Drive Info. The trip distance, the average energy consumption, and total driving time will reset simultaneously.

The driving information will continue to be counted while the vehicle is on (READY indicator is on) (for example, when the vehicle is in traffic or stopped at a stop light.).




# Information

The vehicle must be driven for a minimum of 0.19 miles (300 meters) since the last ignition key cycle before the accumulated driving information is recalculated.



#### **After Recharging**

Trip distance, total driving time and average energy consumption after the vehicle has been recharged are displayed. To reset manually, press the **OK** button on the steering wheel for more than 1 second when 'After recharging' is displayed.



#### Accumulated info

This display shows the accumulated trip distance, the average energy consumption, and the total driving time.

The information is accumulated starting from the last reset.

To manually reset the information, press and hold the **OK** button when viewing the Accumulated driving info. The trip distance, the average energy consumption, and total driving time will reset simultaneously.

The accumulated driving information will continue to be counted while the vehicle is on (**READY** indicator is on) (for example, when the vehicle is in traffic or stopped at a stop light).



# Information

The vehicle must be driven for a minimum of 0.19 miles (300 meters) since the last ignition key cycle before the accumulated driving information is recalculated.



240000

## Tire pressure

The tire pressure of each tire is displayed. For more information, refer to the "Tire Pressure Monitoring System (TPMS)" section in chapter 8.



**Energy flow / Driving force distribution (if** 

equipped)

• The electric vehicle system informs

- the drivers its energy flow in various operating modes.
- The distribution status of the driving power of the front and rear wheels are displayed when Auto AWD mode is activated.


For more information, refer to the "All Wheel Drive (AWD)" section in chapter 6.

#### Select contents

You can select the items to be displayed in Utility view.



1. Press and hold the **OK** button on the steering wheel.



- Use the \( \frac{1}{2}, \) (UP, DOWN) switch to change items, and press the **OK** button to select or deselect the item.
- 3. After selecting the items to be displayed in the Utility view, press the (MODE) button to exit the 'Select Contents' display.

# Additional information display



# **Driving assist information**

The current operation conditions of Manual Speed Limit Assist, Smart Cruise Control, Lane Following Assist, Highway Driving Assist, etc., is displayed.

# **Option Menu**

Press the **OK** button to enter Option menu.



# ! WARNING

To avoid driver distractions, do not adjust the setting while driving which may lead to an accident.



# Information

The information provided may differ depending on which functions are available to your vehicle.

Menu	Explanation
Service messages	To check vehicle warning messages.
3D cluster (for 12.3-inch 3D cluster)	To activate or deactivate 3D effect.
Head-up display	To activate or deactivate head-up display.
Driver Assistance settings	To directly display the "Driver Assistance" menu on the infotainment system.
Speed unit	To set speed unit between MPH and km/h.

## Service messages



OJKEV042041L

When Service Messages menu is selected, press the **OK** button on the steering wheel to check vehicle warning messages.

# 3D cluster (for 12.3-inch 3D cluster)



O IKEV042042I

When 3D Cluster menu is selected, press the **OK** button on the steering wheel. You may select or deselect 3D cluster effect by pressing the **OK** button.

# Head-up display (if equipped)



OJKEV042043E

When Head-Up Display menu is selected, press the **OK** button on the steering wheel. You may select or deselect headup display by pressing the **OK** button.

### **Driver Assistance settings**



O IKEV042044E

When Driver Assistance Settings menu is selected, press the **OK** button on the steering wheel. The 'Driver Assistance' menu will be displayed on the infotainment system.

cluster.

## Speed unit (if equipped)



When the Speed Unit menu is selected, press the **OK** button on the steering wheel. You can change the speed unit setting between MPH and km/h for the

# 3D Instrument Cluster (for 12.3-inch 3D Cluster)

3D cluster setting

To use the 3D cluster, press the Start/ Stop button to the ON position, and then select **Setup > Vehicle > Cluster > 3D Cluster Depth > Medium/Light** in the infotainment system.


To use the cluster 2D, select Off.



# **Information**

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

# Recommendations to optimize the 3D effect



- Adjust the height of the seat and steering wheel so that the instrument cluster and camera module can be seen at a glance.
- The optimal distance to maximize the 3D effect is 30 inches (75 cm). Adjust the distance between the driver's seat and the instrument cluster.
- Hold the steering wheel with both hands and drive in an upright position.

## *i* Information

- When your face gets too close or far to the instrument cluster, or the camera on the instrument cluster is blocked by the steering wheel or other objects, the 3D cluster changes to 2D automatically. However if the object blocking the camera is removed, the cluster changes back to 3D automatically.
- If the outside temperature is below 39 °F (4 °C), it may change to 2D for about 1 to 10 minutes.
- Two red lights may appear on the camera in the following conditions when:
  - The outside brightness is dim or driving at night
  - The vehicle drives inside a building, such as a basement parking lot
  - The camera case of the instrument cluster is partially damaged

### **CAUTION**

- It may sometimes be difficult to read information on the 3D cluster in the following situations. You must change the cluster to 2D for safe driving when:
  - The driver is wearing sunglasses, special glasses, infrared cutoff glasses, refracting glasses or thick glasses
  - The driver has heavy eye makeup (eyeliner, mascara, color makeup, false eyelash) or eye piercing
  - The driver's view is blocked by his/ her hair, etc.

- The driver is winking or wearing an eye patch on one eye
- The driver's face is covered partially by a mask, muffler, hood, etc.
- The driver's view is blocked by incoming light from outside of the vehicle
- Light from outside, sunlight or infrared LED light of the camera is reflected on the glasses or sunglasses
- The driver turns or lowers his/her head so that the face or an eye is hidden from the camera
- The driver shakes his/her head up and down, or adverse road conditions cause excessive vehicle vibrations while driving
- The driver is too tall or short
- More than two people are looking at the instrument cluster simultaneously from the driver's seat
- The driver's eyesight of both eyes are severely different
- The driver has a severe headache
- Do not look toward the camera within 8 inches (20 cm) for longer than a minute.
- If you use the 3D cluster while your vehicle is stopped, it can cause eye strains or dizziness.
- We recommend people who are pregnant, elderly or has motion sickness, avoid using the cluster in 3D.

## **MARNING**

- You should not use the 3D cluster if you or any of your family members or relatives has a history of epilepsy, convulsions, etc. Flashing or flickering lights or specific or regular patterns shown on the cluster may stimulate epilepsy, convulsions, etc.
- You should not use the 3D effect immediately if you feel any of the following symptoms: Haziness, unconsciousness, disorientation, nausea, headache, fatigue, dizziness, etc.

# **MARNING**

While replacing the instrument cluster by yourself, be cautious of the heat from the top and backside of the instrument cluster.

#### NOTICE



[A]: Interior view camera

- Do not apply any impact on the surface of the instrument cluster, interior view camera or around the area of the interior view camera. If the interior view camera is damaged, the system may not operate properly.
- Do not place a mobile phone or an object in front of the interior view camera. The surface of the instrument cluster or interior view camera might be damaged due to an impact while driving.
- Do not place anything on the interior view camera or in front of interior view camera while driving. Interior view camera may not operate properly.
- When cleaning the instrument cluster
  or interior view camera, wipe with
  a soft and clean cloth to prevent
  damages on the surface of the
  cluster or interior view camera lens.
  In addition, you should not use sharp
  tools near the cluster or interior view
  camera, or use chemicals to clean the
  cluster or interior view camera.
- Always keep the interior view camera clean and dry.

#### **VEHICLE SETTINGS (INFOTAINMENT SYSTEM)**



Vehicle Settings in the infotainment system provides user options for the settings including door lock/unlock features, convenience features, driver assistance settings, etc.

#### Vehicle Settings menu


- Driver Assistance
- Drive Mode
- Active Sound Design
- Head-Up Display
- Cluster
- Climate
- Seat
- Lights
- Door/Liftgate
- Digital key
- Convenience

The information provided may differ depending on which functions are available to your vehicle.



Do not adjust the Vehicle Settings while driving. You may be distracted from the driving task and could crash.

#### **Setting Your Vehicle**



 Press the SETUP button on the main keyboard.



2. Select **Vehicle** to change the Vehicle Settings.



The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

# 5. Convenience Features

Using Smart Key	
Immobilizer System	5-1
Genesis Digital Key	
Digital Key (Smartphone)	
Digital Key (Card Key)	
Personalized Profile and Vehicle Settings	
Used Vehicle/Digital Key Maintenance	
Limitations of the System	
Fingerprint Authentication System	5-26
Fingerprint Authentication System Settings	5-26
Fingerprint Authentication System Operation	
Limitations of the System	
When Purchasing a Used Vehicle	
Remotely Starting the Vehicle	
Door Locks	
Operating Door Locks from Outside the Vehicle	
Operating Door Locks from Inside the Vehicle	
Automatic Door Lock and Unlock Features	
Child-protector Rear Door Locks	
Electronic Child Safety Lock	5-34
Theft-alarm System	
Advanced Rear Occupant Alert (ROA)	5-37
Advanced Rear Occupant Alert Settings	
Advanced Rear Occupant Alert Operation	
Advanced Rear Occupant Alert Precautions	
Declaration of Conformity	5-39
Integrated Memory System	5-40
Storing Memory Positions	
Recalling Memory Positions	
Resetting the System	
Seat Easy Access	5-42
Smart Posture Care System	5-43
Steering Wheel	5-44
MDPS (Motor Driven Power Steering)	5-44
Tilt/Telescopic Steering	
Horn	
Heated Steering Wheel	5-46

Mirrors         5-4           Inside Rearview Mirror         5-           Side View Mirrors         5-           Reverse Parking Aid         5-	-48 -57
Windows	
Panoramic Sunroof       5-         Power Sunshade       5-         Tilt Open/Close       5-         Slide Open/Close       5-         Automatic Reversal       5-         Resetting the Sunroof       5-         Sunroof Open Warning       5-	-64 -65 -65 -66 -67
Hood	-68
Front Trunk	-69
Power Liftgate 5 Power Liftgate Operation Condition 5 Operating the Power Liftgate 5 Setting the Power Liftgate 5 Resetting the Power Liftgate 5 Emergency Liftgate Safety Release 5	5-71 -73 -75 -76
Smart Liftgate	-77 -78
Charging Door	-79
Head-up Display	-80 -80


# 5. Convenience Features

Exterior Lights	
Lighting Control	
High Beam Operation	
Turn Signals and Lane Change Signals	
Battery Saver Function	
Headlight Delay Function	
Headlight Leveling Device	
Headlight Moisture Removal Function	
Reverse Guide Light	
Interior Lights	5-86
Interior Light AUTO Cut	5-86
Front Lamps	
Rear Lamps	
Vanity Mirror Lamp	
Glove Box Lamp	
Door Handle Lamp/Mood Lamp/Door Courtesy Lamp	
Cargo Area Lamp	
Puddle Light	
Welcome System	
High Beam Assist (HBA)	
High Beam Assist Setting	
High Beam Assist Operation	
High Beam Assist Malfunction and Limitations	5-92
Wipers and Washers	5-93
Front Windshield Wipers	
Front Windshield Washers	5-94
Rear Window Wiper and Washer	5-95
Automatic Climate Control System	
Automatic Temperature Control Mode	
Manual Temperature Control Mode	
System Operation	
System Maintenance	
•	
Windshield Defrosting and Defogging  To Defog Inside Windshield	
To Defrost Outside Windshield	
Defogging Logic	
Rear Window Defroster	
1 COI ** 11 10 C V C C C C C C C C C C C C C C C C C	J II-

Climate Control Additional Features  Auto Defogging System  A/C Automatic Drying  Auto Dehumidify  Recirculating Air when Washer Fluid is Used	5-115 5-116 5-117
Automatic Controls Linked to Climate Control Settings (for driver's seat)	5-118
Storage Compartment  Center Console Storage  Glove Box  Sunglass Holder  Mobile Phone Holder	5-119 5-119 5-120
Interior Features	
Sunvisor	5-122
Power OutletUSB Charger	5-123
Wireless Smartphone Charging System Vehicle to Load (V2L)	
Clock	5-127
Coat HookFloor Mat Anchor(s)	
Rear Side Window Sunshades	5-128
Cargo Security Screen	
Exterior Features Roof Side Rails.	
Infotainment System	
USB PortAntenna	
Steering Wheel Remote Controls	
Infotainment System	
Voice Recognition	
Lexicon Premium Sound System	

#### **ACCESSING YOUR VEHICLE**

#### **Using Smart Key**



Your Genesis Branded Vehicle uses a smart key that can be used to lock or unlock the doors, liftgate, and start the vehicle.

- 1. Door lock
- 2. Door unlock
- 3. Liftgate open/close
- 4. Panic
- 5. Remote Start
- 6. Light on
- 7. Forward/Backward (if equipped)

#### Locking your vehicle



To lock your vehicle using the door handle touch sensor or the Smart Key:

- 1. Close all doors, hood, and liftgate.
- 2. Have the smart key with you.
- 3. Touch the outer part of the door handle on or near the handle detent for about 1 second or press the Door Lock button (1) on the smart key. The hazard warning lights blink.
- 4. Make sure the doors are locked by pulling the door handle.

# *i* Information

 The side view mirror will fold if 'Enable on Door Unlock' is selected from the Settings menu in the infotainment system.

Select: Setup > Vehicle > Lights > Welcome Mirror/Light > Enable on Door Unlock

 The door handle touch sensor only operates when the smart key is within 28-40 inches (0.7-1 m) from the outside door handle.

- If you lock the doors using the door handle touch sensor, the doors are not locked under the following circumstances:
  - The Smart Key is in the vehicle.
  - The Start/Stop button is from ACC or ON position.
  - Any door is open (except for the liftgate).

If this occurs, a chime sounds for about 3 seconds. Check the vehicle before attempting to lock the vehicle again.

# **MARNING**

Do not leave the Smart Key in your vehicle with children that are unattended or unsupervised.

Children could unintentionally press the Start/Stop button or could operate the power windows or other vehicle controls or even cause the vehicle to move. This may result in serious injury or death.

#### Unlocking your vehicle



To unlock your vehicle using the door handle touch sensor or the Smart Key:

- 1. Have the smart key with you.
- Grab the door handle to activate the door unlock touch sensor or press the Door Unlock button (2) on the smart key. The chime sounds and hazard warning lights blink two times.

• If you unlock the doors using the passenger side door handle, all the doors are unlocked. If you unlock the doors using the driver side door handle, either the driver's side door is unlocked or all the doors are unlocked depending on the setting for the Two Press Unlock feature. Change the Driver Door unlock mode by referring to "Setting the Two Press Unlock feature".

### Information

 The side view mirror will unfold if 'Enable on Door Unlock' is selected from the Settings menu in the infotainment system.

Select: Setup > Vehicle > Lights > Welcome Mirror/Light > Enable on Door Unlock

- The door handle button or touch sensor only operates when the smart key is within 28-40 inches (0.7-1 m) from the outside door handle.
- If you do not open the door after unlocking within 30 seconds, it returns to the lock mode.

#### Setting the Two Press Unlock feature

You can activate or deactivate the Two Press Unlock feature from the Settings menu in the infotainment system.

Select: Setup > Vehicle > Door > Two Press Unlock



#### Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

# Setting the door lock/unlock prevention feature

The doors may lock or unlock if the touch sensor of the outside door handle is recognized while washing your vehicle or due to heavy rain.

To prevent unintentional door lock or unlock:

Press the lock button on the smart key and immediately press the unlock button along with the lock button for more than 4 seconds. The hazard warning lights blink four times. At this time, the doors do not lock or unlock even though the touch sensor is touched on the outside door handle.

To deactivate the function, press the door lock or unlock button on the smart key.



#### Information

During a car wash or rain, in order to minimize unintentional operation of the touch sensor, the touch sensor may become insensitive. This is not a malfunction.

#### Opening the liftgate



To open the liftgate:

- 1. Have the smart key with you.
- Press the liftgate open/close button on the vehicle or press and hold the Liftgate Open button (3) on the smart key for more than one second. The hazard warning lights blink twice and the liftgate is opened.



#### Information

The liftgate open/close button only operates when the smart key is within 28 inches (0.7 m) from the liftgate.

#### Remotely starting the vehicle

To start the vehicle remotely:

- Press the door lock button on the smart key. You must be within about 32 feet (10 m) from the vehicle.
- Press and hold the Remote Start button (5) on your smart key. You must press the button within 4 seconds from when you have pressed the door lock button. The hazard warning lights blink and the vehicle starts (READY indicator on).
- 3. To turn off the vehicle, press the Remote Start button (5) once.



- The vehicle must be in P (Park) for the remote start function to start.
- The vehicle turns off (READY indicator off) if you get inside the vehicle without a registered smart key.
- The vehicle turns off if you do not get on the vehicle within 10 minutes after remotely starting the vehicle.
- The Remote Start button may not operate if the smart key is not within 32 feet (10 m) from the vehicle.
- The vehicle does not remotely start if the hood or liftgate is open.

#### Turning on the lights

If the Light On button (6) is pushed, the headlights and tail lights are turned on. However, it works only when the following conditions are satisfied:

- The vehicle is turned off.
- · The doors are locked.
- The light control switch is in the AUTO headlight position (The headlights and tail lights turn on when it is dark) or in the headlight position.

# Remotely moving the vehicle forward or backward (if equipped)

Some models are equipped with the Remote Smart Parking Assist feature.

With the smart key, the vehicle can be moved forward or backward remotely to enter or exit a tight parking space.

For more information, refer to the "Remote Smart Parking Assist (RSPA)" section in chapter 7.

#### Using panic alarm

The horn sounds and the hazard warning lights blink for about 30 seconds if this button (4) is pressed for more than 1 second. To stop the horn and lights, press any button on the smart key.

#### Starting the vehicle

Your vehicle is equipped with a Start/ Stop button instead of a key cylinder. You can leave your smart key in your pocket or purse when you start your vehicle.

For more information, refer to the "Start/ Stop Button" section in chapter 6.

## *i* Information

If the smart key is not moved for some time, the detection function for smart key operation will pause. Lift the smart key to activate the detection again.

#### NOTICE

To prevent damaging the smart key:

- Keep the smart key in a cool, dry place to avoid damage or malfunction.
   Exposure to moisture or high temperature may cause the internal circuit of the smart key to malfunction which may not be covered under warranty.
- Avoid dropping or throwing the smart key.
- Protect the smart key from extreme temperatures.

#### Using mechanical key

If the Smart Key does not operate normally, you can lock or unlock the driver's door by using the mechanical key.

To remove the mechanical key from the smart key:



1. Place a soft cloth over the slot (A), and using a flat-head screw driver slightly open the smart key cover.



- Press the mechanical key and remove it from the smart key.
- 3. After use, reinstall the mechanical key and smart key cover.

#### Loss of a smart key

A maximum of two Smart Keys can be registered to a single vehicle. If you happen to lose your smart key, immediately take the vehicle and remaining keys to your authorized retailer of Genesis Branded products or tow the vehicle, if necessary.

#### Smart key precautions

The smart key may not work if any of the following occur:

- The smart key is close to a radio transmitter such as a radio station or an airport which can interfere with normal operation of the transmitter.
- The smart key is near a mobile two way radio system or a mobile phone.
- Another vehicle's smart key is being operated close to your vehicle.

If the smart key does not work correctly, open and close the door with the mechanical key. If you have a problem with the smart key, contact an authorized retailer of Genesis Branded products.

If the smart key is in close proximity to your mobile phone, the signal could be blocked by your mobile phone's normal operational signals. This is specifically relevant when the phone is active such as making and receiving calls, text messaging, and/or sending/receiving emails. If possible, avoid keeping the smart key and your mobile phone in the same location such as pants or jacket pocket to avoid interference between the two devices.

#### NOTICE

- Keep the smart key away from electromagnetic materials that blocks electromagnetic waves to the key surface.
- Always have the smart key with you when leaving the vehicle. If the smart key is left near the vehicle, the vehicle battery may be discharged.



#### Information

This device complies with Part 15 of the FCC rules. Operation is subject to the following three conditions:

- 1. This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

#### Replacing the battery

If the Smart Key is not working properly, try replacing the battery with a new one.

Battery Type: CR2032 To replace the battery:



 Place a soft cloth over the slot (A), and using a flat-head screwdriver slightly open the smart key cover.



- 2. Remove battery cover using a phillips screwdriver.
- 3. Remove the old battery and insert the new battery. Make sure the battery position is correct.
- 4. Reinstall the battery cover and smart key cover.

If you suspect your smart key might have sustained some damage, or you feel your smart key is not working correctly, contact an authorized retailer of Genesis Branded products.



#### WARNING

This product contains a button battery. If swallowed, a lithium button battery can cause severe or fatal injuries within 2 hours.

Keep batteries out of reach of children. If you think batteries may have been swallowed or placed inside any part of the body, seek immediate medical attention.



#### Information



An inappropriately disposed battery can be harmful to the environment and human health. Dispose of the battery according to your local law(s) or regulations.

#### **Immobilizer System**

The immobilizer system protects your vehicle from theft. If an improperly coded key (or other device) is used, the vehicle is disabled.

When the Start/Stop button is pressed to the ON position, the immobilizer system indicator should come on briefly, then go off. If the indicator starts to blink, the system does not recognize the coding of the key. Press the Start/Stop button to the OFF position, then press the Start/Stop button to the ON position again.

In some circumstances, the vehicle may not recognize your smart key if another smart key device is nearby or a metal object such as a key chain is causing interference with the smart key.

If this occurs, your vehicle may not start. Remove any metal objects or additional keys near the smart key before attempting to start the vehicle again.

If the system repeatedly does not recognize the coding of the key, contact your retailer of Genesis Branded products.

Do not attempt to alter this system or add other devices to it. Electrical problems could result that may make your vehicle inoperable.



#### **!** WARNING

In order to prevent theft of your vehicle, do not leave spare keys anywhere in your vehicle. Your immobilizer password is a customer unique password and should be kept confidential.

#### NOTICE

The transponder in your key is an important part of the immobilizer system. It is designed to give years of trouble-free service, however you should avoid exposure to moisture, static electricity and rough handling. Immobilizer system malfunction could occur.



#### Information

This device complies with Part 15 of the FCC rules. Operation is subject to the following three conditions:

- 1. This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

#### **GENESIS DIGITAL KEY**

Genesis digital key provides convenience to the driver, which the driver can use to lock or unlock the driver and passenger doors or the trunk and turn on the vehicle.

#### Digital Key (Smartphone) How to register Digital Key (Smartphone)

To use the smartphone as a digital key follow the following procedure.

This service is only available for Android smartphones that passed the internal usability test. The smartphone must meet the following requirements:

- Android operating system version 7.0 or newer.
- Bluetooth (BLE) 4.0 or newer.
- Near Field Communication (NFC)

In case of iPhone, Apple does not assist any of the NFC services. (Services are expected to be provided according to policy change.)

#### **Genesis Digital Key App**

- Search 'Genesis digital key' from the Google Play Store and download the app. Please refer to the detailed manual of the digital key app or Genesis website. The option can be found under the following app menu: Menu > Application Info > Tutorial. Please note the manual before using the app.
- 2. After downloading the app, sign up for a Genesis account and service.

#### Smartphone set up

- The driver can use the Digital Key NFC (Near Field Communication) feature after enabling it on the smartphone's setting menu. To change the NFC setting of the smartphone, refer to the smartphone manual or contact the customer service center of smartphone manufacturers.
- The driver should unlock and turn on the smartphone screen.

#### **Smartphone registration**

- Turn the vehicle on with the Smart key and make sure to keep the smart key inside the vehicle during digital key registration.
- Open Genesis Digital Key App in the vehicle owner's smartphone and activate the digital key registration screen after selecting the vehicle to register.



OJKEV052276N

 From the infotainment system settings menu, select Setup > Vehicle > Digital Key > Enable digital keys.



[A]: In-vehicle authentication pad (Wireless charging pad)

 After 'Enabling digital keys' is selected, place the backside of the smartphone on the in-vehicle authentication pad.



OJKEV052281N

- Select Smartphone key > Save menu on the infotainment system. The saving process will begin automatically.
- 6. When the digital key (smartphone) is saved, a message will appear on the infotainment system.
- Remove the smartphone from the pad and complete the saving process under the guidance of the smartphone screen.

# **information**

Vehicle

When there is a digital key (smartphone) already saved in the vehicle, the 'Save' menu is disabled. If you want to save a digital key again, refer to "How to delete Digital Key (Smartphone)" and follow the deleting procedure first before saving a digital key.

Smartphone

The digital key cannot be saved again while the vehicle's digital key is saved in the owner's smartphone. Save the digital key after deleting the digital key from the Digital Key App.

- During the digital key saving process, the process will cancel when:
  - The smartphone is removed from the in-vehicle authentication pad (wireless charging pad)
  - Changing the infotainment system or instrument cluster screen
  - The vehicle is turned off
  - The gear is shifted
  - Saving digital key that does not belong to the vehicle owner
  - The smartphone screen is locked or turned off
  - NFC setting of your smartphone is off (saving process will not begin)
  - There is no smart key (saving process will not begin)

# How to Use the Digital Key (Smartphone)

**Smartphone touch control** 

The driver can lock and unlock the door by touching the smartphone on the door handle without opening the Digital Key App. Also, the vehicle can be started by placing the smartphone on the in-vehicle authentication pad (wireless charging pad).



[A]: Door handle authentication pad.

[B]: NFC antenna (Backside of the smartphone) (The antenna position differs depending on models.)

#### Locking/Unlocking the doors

- If the driver touches the smartphone NFC antenna to the driver's or passenger's door handle authentication pad for more than 2 seconds, the door will lock or unlock.
- If Two Press Unlock function is set, only the driver's door will be unlocked by touching the smartphone on the driver's door handle. Touch the smartphone once more within 4 seconds to unlock all doors.
- After unlocking the doors, the doors will automatically re-lock after 30 seconds unless a door is opened.
- If the smartphone digital key does not operate, move the smartphone more than 4 inches (0.1 m) from the door handle authentication pad and try it again.

Note that you cannot lock your vehicle using the smartphone NFC antenna if any of the following occur:

- The Smart Key is in the vehicle
- The Start/Stop button is in ACC or ON position
- Any of the doors are open except for the hood or trunk

#### · Starting the vehicle

- After placing your registered smartphone on the in-vehicle authentication pad (wireless charging pad), depress the brake pedal and press the Start/ Stop button.
- 2. After starting the vehicle, the digital key data will be automatically updated. It will take 5 to 20 seconds. After that, the smartphone will automatically go into the wireless charging mode. Once the vehicle is started, you can remove the smartphone from the pad.

For more information, refer to the "Start/Stop Button" section in chapter 6.

# *i* Information

To lock/unlock the doors and/or start the vehicle with the smartphone Digital Key, always turn on and unlock the smartphone screen.

# *i* Information

- After the battery has been reconnected or the battery has been recharged, it will take time for the digital key (smartphone) to operate due to remote security update. When locking or unlocking the door with the smartphone NFC antenna, touch and hold the smartphone on the door handle until the door(s) is locked or unlocked.
- If the mobile data connection of the smartphone is weak, remote security information update may fail. At this time, use the card key to lock or unlock the doors, or start the vehicle. When you are in a place where the mobile data connection of your smartphone is available, place your smartphone on the invehicle authentication pad (wireless charger pad) and start your vehicle, or touch the digital key on the door handle to lock or unlock the door, the remote security information will be automatically updated. Even though the vehicle is not started, wait until the remote security information is updated and the in-vehicle authentication pad (wireless charging pad) changes to charging mode.

# **MARNING**

The vehicle can be started when the registered smartphone is placed on the in-vehicle authentication pad (wireless charging pad). Therefore, do not leave unsupervised children or people who are not aware of the system since it can result in serious injury or death. In addition, always have the registered smartphone with you to prevent vehicle theft when leaving the vehicle.

#### Digital key App remote control

Various control functions such as Door Lock/Unlock, Remote Start, Panic and Trunk Open/Close are available using the Digital Key App. To use the Digital Key App functions, the smartphone's Bluetooth must be activated, and must be about within 32 feet (10 m) from the vehicle.

- Connecting Digital Key App with the vehicle
- 1. Open the Genesis Digital Key App in the smartphone. Select the vehicle you want to control from the vehicle list in the App.
- Approach the vehicle with the Genesis Digital Key App opened. The Digital Key App will automatically connect with the vehicle.
- 3. When the connection is complete, the icons in the Digital Key App will become active.

#### Controlling the vehicle with Digital Key App



Press the icons to remotely control the vehicle.

- 1. Lock Doors
- 2. Unlock Doors
- 3. Panic On
- 4. Panic Off
- 5. Remote vehicle On
- 6. Remote vehicle Off
- 7. Liftgate HOLD
- 8. RSPA (if equipped)

For more information on how to use Remote Parking, refer to the "Remote Smart Parking Assist (RSPA)" section in chapter 7. The icon will be highlighted or an alarm and vibration will also be provided when the selected icon function is being performed.

After the Digital Key App and vehicle are connected, if Digital Key App remote control is not used over 5 minutes, the connection between the app and vehicle will disconnect automatically.

### i

#### Information

You cannot lock your vehicle if:

- The Start/Stop button is in the ACC or ON position.
- Any door is open.
- Remotely starting the vehicle with the Digital Key App
- 1. Press the Door Lock button in Genesis Digital Key App.
- 2. Press the Remote vehicle On icon within 4 seconds.
- 3. The hazard warning lights will blink and the vehicle will start.
  - Unless the driver puts the registered digital key (smartphone) on the in-vehicle authentication pad (wireless charging pad) when the Remote Start function is on, the vehicle will turn off.
  - If the driver does not get in the vehicle within 10 minutes after the vehicle is remotely started, the vehicle will turn off.

#### ↑ CAUTION

- If the vehicle windows are tinted with a film containing metallic substances, it may cause poor Bluetooth connection and poor performance of the Digital Key App.
- If multiple users use the digital key at the same time, the functions of the Digital Key App may not work properly. Only the necessary user should operate the Digital Key App remote control.
- When using the Digital Key App remote control, the driver (the remote control user) should leave the vehicle after checking that the doors are locked. When the doors are locked. the chime will sound and the hazard warning lights will blink once.
- The remote functions of the Digital Key App enable the vehicle to be controlled when the user is within operating range. If the digital key is out of the operating range, the remote control function may not operate properly.
- If the smartphone are moved away from the vehicle while the smartphone and the vehicle is connected, Digital Key App remote control may not operate properly.

- When using Digital Key App remote control via Bluetooth, communication may be slow or the operating range may be reduced in the following circumstances:
  - Smartphone mobile data is weak
  - Bluetooth connection is weak due to many Bluetooth devices
  - There is an object such as metal or concrete between the vehicle and smartphone
  - The smartphone is wrapped in your hand or other electronic devices that cause interference is placed near the smartphone
- If you use a smartphone cover that uses wireless communication or is made of metal, the digital key NFC function may not work properly. Remove the smartphone cover before using the digital key NFC function.
- If Digital Key App remote control does not operate properly, use the smartphone's NFC function to lock and unlock the doors.

# How to delete Digital Key (Smartphone)



OJKEV052278N

- Turn the vehicle on with the smart key and make sure to keep the smart key inside the vehicle during the digital key (smartphone) deleting process.
- From the infotainment system settings menu, select Setup > Vehicle > Digital Key > Smartphone key > Delete. The 'Delete' menu will be disabled if there is no digital key (smartphone) saved.
- When the digital key (smartphone) is deleted, a message will appear on the infotainment screen or cluster.
- Go to 'Initialize Digital Key' menu in the Digital Key App and select the vehicle to delete the digital key information.

# What to do when user changes smartphone or deletes app

If the driver changes his/her smartphone or has deleted the Genesis Digital Key App, refer to the following to set up the Genesis Digital Key App again.

#### Smartphone change

Follow the procedure below to use the digital key in your new smartphone.

- Install the Genesis Digital Key App and log in.
- From the infotainment system settings menu, first delete the previous digital key (Digital Key > Smartphone key > Delete), and then save the digital key again.
- 3. If you have shared the digital key with others, you will need to re-share the digital key.

#### Smartphone reset/App delete & reinstall/ App data delete

Follow the procedure below to use the digital key when the smartphone was reset, the app was deleted and then reinstalled, or the app data was deleted.

- Install the Genesis Digital Key App and log in.
- 2. Input the PIN number for user verification. If PIN is correct, digital key data will be downloaded to the user's smartphone and you can use the digital key without any further registration or sharing procedure.

#### Smartphone operability with Digital Key

The Digital Key App may not be available on some smartphones. Check for available smartphone models on the Genesis website. The smartphone NFC antenna location guide can be confirmed on the Genesis website or contact the smartphone manufacturer's customer service center.

#### Digital Key (Card Key)

How to register Digital Key (Card Key)

To use the card key as a digital key, follow the following procedure.

#### For Android smartphones

- Install Genesis digital key app in main user's smartphone and register the digital key (smartphone). Please refer to the registration method of the digital key (smartphone).
  - 1-1. Activate Genesis digital key app and then select Menu > Settings > Card Key Enroll Authentication. Please follow the digital key authentication procedure according to the app.
    - Bluetooth authentication:
      Before starting the process, the
      driver needs to make sure to
      check whether the Bluetooth
      connection is working properly.
      To enroll the card key, please
      select Menu > Settings > Card
      Key Enroll Authentication
      in the top right corner of the
      digital key app. The card saving
      process should be completed
      within 5 minutes after the
      authentication process is done
      in the vehicle.
    - NFC authentication: After selecting NFC authentication, please contact the smartphone on the driver's or passenger's outside door handle.
  - 1-2. Get in the vehicle with the smart key.

#### **Except Android smartphones**

Get in the vehicle with two smart keys.



[A]: In-vehicle authentication pad (Wireless charging pad)

2. Place the NFC card key on the invehicle authentication pad.



OJKEV052279N

- From the infotainment system settings menu, select Setup > Vehicle > Digital Key > Card key > Save. The saving process will begin automatically.
- 4. When the digital key (card key) is saved, a message will appear on the infotainment system.

### *i* Information

- When there is a digital key (card key) already saved in the vehicle, the 'Save' menu is disabled. If you want to save a digital key again, refer to "How to delete Digital Key (Card key)" and follow the deleting procedure first before saving a digital key.
- When registering a digital key (card key), authentication is required once through a smartphone. Complete the registration within 5 minutes after authentication.
- To register the digital key (card key), the smart key must be in the vehicle.
- The registered digital key (card key) cannot be used for another vehicle.
- The previously saved digital key (card key) can be not used if a new digital key (card key) is registered.

#### How to use the Digital key (Card key)

#### Card key touch control

The driver can lock and unlock the door by touching the card key on the door handle. Also, the vehicle can be started by placing the card key on the in-vehicle authentication pad (wireless charging pad).



[A]: Door handle authentication pad, [B]: Card key NFC antenna

#### · Locking/Unlocking the doors

- If the driver touches the card key on the driver's or passenger's door handle authentication pad for more than 2 seconds, the door will lock or unlock.
- If Two Press Unlock function is set, only the driver's door will be unlocked by touching the card key on the driver's door handle. Touch the card key once more within 4 seconds to unlock all doors.
- After unlocking the doors, the doors will automatically re-lock after 30 seconds unless a door is opened.

# *i* Information

- You cannot lock your vehicle if:
  - The Smart Key is in the vehicle.
  - The Start/Stop button is in the ACC or ON position.
  - Any door is open (except for the liftgate).
  - The vehicle battery is discharged.

A chime sounds for about 3 seconds. Move the smartphone more than 4 inches away from the door handle sensor and then try again.

#### · Starting the vehicle

After placing your registered card key on the in-vehicle authentication pad (wireless charger pad), depress the brake pedal and press the Start/ Stop button.

For more information, refer to the "Start/ Stop Button" section in chapter 6.

# **MARNING**

The vehicle can be started when the registered card key is placed on the in-vehicle authentication pad (wireless charging pad). Therefore, do not leave unsupervised children or people who are not aware of the system since it can result in serious injury or death. In addition, always have the registered card key with you to prevent vehicle theft when leaving the vehicle.

# **A** CAUTION

- The digital key (card key) may not work under the following conditions:
  - The card key is not touching the center of the door handle authentication pad or in-vehicle authentication pad (wireless charging pad) correctly.
  - The card key is used overlapped with NFC-enabled cards such as credit card or smartphone.
  - If the card key does not work, move the card key about 4 inches (10 cm) away from the authentication pad and then touch it again.
- The card key can be damaged by impacts. If the key is damaged, replace the card key with a new one and register it again.
- Long-time exposure to high temperature may cause the card key to malfunction. Be careful not to expose the key to direct sunlight or high temperature.
- The card key is consumable and it is not covered by your warranty. Therefore, the result of misuse by customers such as breakage or loss is not guaranteed.
- Always have the card key with you when leaving the vehicle. If the authenticated phone has a dead battery, or it is lost or stolen, you may be locked out of the vehicle.

#### How to delete Digital Key (Card key)

 Turn the vehicle on with the smart key and make sure to keep the smart key inside the vehicle during the digital key (card key) deleting process.



- From the infotainment system settings menu, select Setup > Vehicle > Digital Key > Card key > Delete. The 'Delete' menu will be disabled if there is no digital key (card key) saved.
- 3. When the digital key (card key) is deleted, a message will appear on the infotainment screen or cluster.

# Personalized Profile and Vehicle Settings

When the registered digital key is linked with user profile, the vehicle will automatically operate (door lock/unlock with digital key, etc.) according to the user profile setting. User profile linking and personalization are available for a total of two drivers.

#### Linking / Unlinking profile

#### How to link user profile

- Select Setup > User Profile >
   Profile Settings > Link Digital Key
   (Smartphone) on the infotainment
   system settings menu.
- Unlock the smartphone, enable the NFC feature, and place it on the invehicle authentication pad (wireless charging pad) according to the message on the infotainment system.
- 3. User profile linking will start with the message 'Linking... Pressing any button will cancel linking the Digital Key'.
- 4. If you select 'Link', the registered phone number's digital key and the user profile will link. Select 'Link' according to the instruction.
- When the process is complete, the message 'Digital Key Link Complete.' will appear on the infotainment system.

#### How to unlink user profile

- Unlink digital key in the User Profile settings. Unlinking is possible only when user profile is linked.
- When unlinking is complete, the message 'Digital key is unlinked.' will appear on the infotainment system.

# *i* Information

- User profile cannot be linked to both Driver 1 and Driver 2 that are connected to a single smartphone.
   Personalization will operate with the recently linked user profile, and the previously linked user profile will be automatically canceled.
- User profile can be linked when digital key is enabled (Setup > Vehicle > Digital Key > Enable digital keys).
   The linked user profile information is maintained even when the digital key function is disabled. User profile can be linked to a smartphone with the Digital Key App installed.
- User profile can be linked when a digital key is registered on the smartphone and the vehicle. The smartphone with another vehicle's digital key cannot be linked.
- If you remove the smartphone from the in-vehicle authentication pad (wireless charging pad) before completing the user profile link, the linking process will not be completed normally.
- To unlink the user profile, the smartphone does not need to be on the in-vehicle authentication pad (wireless charging pad).
- Once the user profile linked digital key in the smartphone is deleted, the digital key should be re-registered and personalized by linking the user profile again.

#### Vehicle personalization operation

The personalization function linked with digital key works under the following conditions:

- Touch the driver's door handle with the profile linked smartphone to lock or unlock the doors (Personalization does not operate when locking or unlocking the front passenger door.).
- When the remote door unlock with the profile linked smartphone digital key app works, the user profile linked with digital key can be changed manually from the infotainment system settings.

# *i* Information

User profile operation according to door lock/unlock system is as follows.

Item	Personalization operation	
Initial value	Guest	
Profile linked smartphone key	Linked profile	
Profile unlinked smartphone key	Recently activated	
NFC card key	profile	
Smart key		

- The personalization function using the digital key can be operated after linking the digital key in the infotainment system profile menu.
- The personalization function works only when the vehicle is OFF or when the vehicle is started remotely. If the vehicle is not started remotely, personalization function does not work with the digital key.

#### Vehicle personalization with digital key

The available personalization function in the vehicle is as follows.

System	Personalization Item		
	Head Up Display (HUD)	Position adjustment of image, Information display selection	
	Lamp	Blink number of one-touch signal lamps	
Vehicle Settings	Cluster	Information display on the cluster, Voice volume, Welcome sound	
	Vehicle Settings Seat/Mirror/ Steering wheel Door	Seat position, Side view mirror position, Steering wheel position, Easy Access	
		Smart heating wire/ventilation On/Off	
		Automatic door lock/unlock, Two Press Unlock	
	Smartphone wireless charging	Wireless charging On/Off	
	Air conditioning	Setting up temperature unit, Block air inflow/ Automatic ventilation/Window defroster On/Off	
	Wiper	Auto rear wiper (in R)	
	Navigation	Preferred volume of the navigation system	
Infatainna ant	Inavigation	Recent destination	
Infotainment system	User preset	My menu list settings, Radio preset	
System	Phone connectivity	Bluetooth preferential connection	
		CarPlay/Android Auto	
Air conditioning	Operating condition	Latest operation setup of the following functions: Temperature (AUTO), air flow direction, air volume, air conditioner, air intake control, SYNC, Front windshield defroster, OFF	



#### Information

For more information of personalization, refer to the user's manual provided in the infotainment system and the quick reference guide.



#### **CAUTION**

If you leave the digital key in the vehicle after locking or unlocking the doors or starting the vehicle with the smart key, the doors can be locked with the central door lock. Have the digital key with you at all times.

# Used Vehicle/Digital Key Maintenance

#### Purchasing used vehicle

If any of the digital key devices (smartphone key, card key) are registered in the vehicle, the message 'Digital key(s) active' will appear on the instrument cluster once when the vehicle is turned on after unlocking the vehicle door. When purchasing a used car, be sure to check the message and delete the smartphone key and card key registered by the previous user. Please let us know the purchase of a used vehicle through Genesis Customer Care. Check whether the card key that came with the used vehicle operates properly. If the card key does not work properly, delete the card key and register the smartphone key, and then re-register the card key.

#### Digital Key Maintenance

If you need to have your Digital Key System repaired or replaced, the registered smart key/card key can be deleted. In this case, you should delete the digital key on the smartphone and re-register the key.

#### **Limitations of the System**

- Genesis Digital Key App on the smartphone and card key may not work if any of the following occurs:
  - The Digital Key App in the smartphone is deleted (reinstall the app)
  - Account log information of Genesis Digital Key App is expired (required to re-log in)
  - When you try to log in from another smartphone instead of the registered smartphone with same user account - Smartphone rooting or app hacking is detected
  - Smartphone battery or the vehicle battery is discharged
  - Smartphone's screen is off or locked
  - NFC or Bluetooth is turned off in the smartphone settings
  - Smartphone's mobile network setting is off or airplane mode is activated
  - A credit card is overlapped in the back of your smartphone, or metal or thick smartphone case is used
  - Using the card key with other cards, or using it in a wallet or card holder
  - There is electronic interference by other vehicles, objects, etc.
- The vehicle may not be controlled by the smartphone if any of the following occurs:
  - Basic and necessary functions of the smartphone are operating (general call, urgent call, audio or NFC payment)
  - Using wireless earphone

#### FINGERPRINT AUTHENTICATION SYSTEM (IF EQUIPPED)

Fingerprint Authentication system allows you to start the vehicle, have access to personal information, unlock profile, and exit valet mode with a registered fingerprint.

A fingerprint must be registered in the User Profile Settings from the infotainment system to use the system.

The maximum of two fingerprints can be registered. Driver 1 and Driver 2 can register one fingerprint each.

### **information**

If no fingerprint is registered in the infotainment system, Fingerprint Authentication system does not operate.

# Fingerprint Authentication System Settings

You can set or delete a fingerprint through the infotainment system. Follow the following procedure.

#### Registering fingerprint



[A]: Fingerprint sensor

1. Have both of your smart keys with you in the vehicle.

- Turn on the vehicle and select Setup > User Profile > Driver 1 > Fingerprint Identification from the infotainment system.
- After entering the profile password, select Set/Delete Fingerprint > Set.
- 4. Place your finger that you wish to register on the fingerprint sensor according to the instruction.
- 5. Following the instructions, place several parts of your fingerprint until the scanning process is complete. When scanning is complete, the "Saving fingerprint...." appears and the fingerprint registering process is proceeded.

### *i* Information

- Remove all substances including protection film on the fingerprint sensor, and then register your fingerprint.
- Starting the vehicle with fingerprint is available when your vehicle is equipped with the Genesis Digital Key system.
- The fingerprint registering process is canceled when the following condition occurs:
  - The infotainment system screen is altered
  - The Start/Stop button turns on or off
  - The gear is shifted, and the vehicle is driven

#### Deleting fingerprint

- Have one of your smart key with you in the vehicle.
- Turn on the vehicle and select Setup > User Profile > Driver 1 > Fingerprint Identification from the infotainment system.
- After entering the profile password, select Set/Delete Fingerprint > Delete.
- Delete the registered fingerprint according to the message "Delete all Driver 1 fingerprints?".



#### **CAUTION**

Do not participate in duplicating your fingerprint with anyone.

#### Fingerprint Authentication System Operation

Using features with touch control

The convenience features such as starting the vehicle, accessing personal information, unlocking profile, and exiting valet mode are available with the fingerprint authentication system.

When the fingerprint shape appears on the infotainment system, you should place your finger on the fingerprint sensor in the vehicle according to the instruction message for authorization and then you can operate the linked features without entering the password.

If the Fingerprint Authentication system does not work, pull your finger away from the fingerprint sensor and then try again.

Fingerprint linked features can be turned on or off from the Settings menu.

#### Select:

 Setup > User Profile > Driver 1 (or Driver 2) > Fingerprint Identification

Fingerprint Linked Features	Characteristic	
Starting vehicle	Start vehicle with fingerprint but without smart key	
Personal information access	Use features with	
Profile unlock	fingerprint but without a password	
Valet mode exit	without a password	



#### Information

- The same fingerprint cannot be registered for Driver 1 and Driver 2.
   The personalization function works with the recently linked profile, and the previously linked profile is automatically canceled.
- The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

#### Starting the vehicle



Place your finger on the fingerprint sensor (1) to verify your fingerprint. After it is successfully verified, start the vehicle by pressing the Start/Stop button (2) within 30 seconds.

# Message on the cluster display when starting the vehicle

Fingerprint Authentication Status	Light Color	Message On Cluster Display
Standby	White	-
Succeed	Blue	"Authenticated. The vehicle can now be started"
Fail	Yellow	-
Restricted due to consecutive failure	Red	"Fingerprint authorization is locked out. Try again in XX min"   * Restricted for 1 minute, 3 minutes or 5 minutes when failed every 5 times.

## *i* Information

- If you are in the vehicle for an extended period without starting the vehicle, the fingerprint sensor may turn off. If this occurs, depress the brake pedal and verify your fingerprint again when the fingerprint sensor illuminates.
- For more information on how to start your vehicle with the Start/ Stop button, refer to the "Start/Stop Button" section in chapter 6.

#### **Limitations of the System**

- Fingerprint Authentication system may not work when:
  - Fingerprint authentication is performed with an unregistered fingerprint.
  - The fingerprint is not placed on the center of the fingerprint sensor.
  - The fingerprint sensor or fingerprint is wet or dirty.
  - The film on the sensor is not removed.
  - The registered fingerprint is wounded or swollen.
  - The hand is overly dry.
  - The sensor is touched shortly.
- If fingerprint authentication fails repeatedly, fingerprint recognition is temporarily restricted. You should try it later or try other methods such as inputting your password.
- If the vehicle does not start due to fingerprint sensor malfunction, have the system inspected by an authorized retailer of Genesis Branded products.

- All registered fingerprints may be deleted during repair due to a malfunction of the fingerprint authentication system or related parts. Have your smart key when you visit an authorized retailer of Genesis Branded products.
- You cannot use the fingerprint sensor when the vehicle is discharged.
- If Start Vehicle is deselected from the vehicle settings menu for Driver 1 and Driver 2, the fingerprint sensor will not operate when the vehicle is off.
- Gently place your finger on the fingerprint sensor. Fingerprint authentication attempts with excessive force may fail.
- If the vehicle is turned on or off during the fingerprint authentication process, your fingerprint may not be verified properly.

# **WARNING**

Do not register children's fingerprints in the vehicle.

If you register children's fingerprints and leave them in the vehicle, unexpected accidents may occur.

#### When Purchasing a Used Vehicle

If you purchase a used vehicle, you should confirm and delete all of the registered fingerprints in Driver 1 and Driver 2 profile.

#### **Remotely Starting the Vehicle**


If **Start Vehicle** is selected from the Driver 1 or Driver 2 User Profile settings menu, and the door is unlocked with the Genesis Digital Key App or the Genesis Connected Service App while the vehicle is remotely started, the vehicle turns off if the fingerprint sensor does not verify your fingerprint.

To remotely start the vehicle with the Genesis Digital Key App, refer to the "Genesis Digital Key" section in this chapter. And for Genesis Connected Service App, see additional information in separately supplied manual.

#### **DOOR LOCKS**

#### Operating Door Locks from Outside the Vehicle

Using mechanical key



[A]: Lock, [B]: Unlock

- 1. Pull the door handle.
- Insert the mechanical key into the key cylinder and rotate (2) clockwise to unlock the vehicle and counterclockwise to lock the vehicle.
   Once the doors are unlocked, they can be opened by pulling the door handle.



#### Information

Only the driver's door can be locked/unlocked using the mechanical key.

#### NOTICE

- If the key cylinder cover freezes and cannot be removed easily, lightly tap on the cover or try to warm the cover by placing your hands around it and blowing warm air on it.
- Do not apply excessive force to the door and door handle.

#### Using smart key

For more information, refer to the "Using Smart Key" section in this chapter.

# i

#### Information

- In cold and wet climates, door lock and door mechanisms may not work properly due to freezing conditions.
- If the door is locked/unlocked multiple times in rapid succession with either the vehicle key or door lock switch, the system may stop operating temporarily in order to protect the circuit and prevent damage to system components.

#### In case of an emergency



Doors without an outside key hole can be locked as follows:

- 1. Open the door.
- Insert the key into the emergency door lock hole and turn the key to the lock position.
- 3. Close the door securely.



#### Information

If the electrical power to door lock switch is not operating (e.g. discharged vehicle battery) and the liftgate is closed, you cannot open the liftgate until power is restored.

#### Operating Door Locks from Inside the Vehicle

With the inside door handle



#### Front door

If the inner door handle is pulled when the door is locked, the door is unlocked and opened.

#### Rear door - Two pull operation

If the inner door handle is pulled once when the door is locked, the door is unlocked. If the inner door handle is pulled once more, the door is opened.

#### With the central door lock switch





[A]: Driver's door, [B]: Front passenger's door

Driver and passenger door central door lock switch

When pressing the  $(\frac{1}{1})$  portion (1) on the switch, all vehicle doors are locked.

- If any door is opened, the doors are not locked even though the lock switch (1) of the door is pressed.
- If the smart key is in the vehicle and any door is opened, the doors are not locked even though the lock switch (1) of the door is pressed. When pressing the (1) portion (2) on the switch, all vehicle doors are unlocked. When all vehicle doors are locked, the indicator lights on the driver's door and passenger's door turn on. If any door is unlocked, the indicator turns off.



#### Rear door

When the lock switch (1) is pressed (door indicator light ON), all vehicle doors are locked.

When the unlock switch (2) is pressed, all vehicle doors are unlocked.

### *i* Information

If all doors are locked with the rear door lock button, and the electronic child safety lock button (if equipped) in the driver's seat is turned ON (indicator light ON), the rear doors cannot be opened. If you want to open the rear doors:

- Unlock the door with the smart key from outside.
- Unlock the door with Genesis Connected Service using your smartphone.
- Press the electronic child safety lock button on the driver's door to turn it off (indicator light OFF), then unlock the doors with the driver's or passenger's central door lock switch. (Electronic child lock OFF > Door unlocked)
- Press the electronic child safety lock button on the driver's door to turn it off (indicator light OFF), then pull the rear inner door handle twice.

# **MARNING**

- Always close and lock the doors while the vehicle is moving. If the doors are unlocked, the risk of being thrown from the vehicle in a collision increases.
- Do not pull the inner door handle of the driver's or passenger's door while the vehicle is moving.

## **MARNING**

Do not leave the elderly, children, or animals unattended in your vehicle. An enclosed vehicle can become extremely hot and the elderly, unattended children or animals who cannot escape the vehicle may be seriously injured or killed.

# **MARNING**

Always park your vehicle properly. Depress the brake pedal, change the gear to P (Park), apply the parking brake, press the Start/Stop button to the OFF position, close all windows, lock all doors, and always take the keys with you.

# **MARNING**

Be careful when opening doors and watch for vehicles, motorcycles, bicycles, or pedestrians approaching the vehicle to prevent serious injury or death.

# *i* Information

To exit the vehicle if the power door lock does not function:

- Operate the door unlock feature repeatedly (both electronic and manual) while simultaneously pulling on the door handle.
- Operate the other door locks and handles.
- Lower the driver's front window and use the mechanical key to unlock the door from outside.

# Automatic Door Lock and Unlock Features

Your vehicle is equipped with features that will automatically lock or unlock your vehicle based on settings you select in the infotainment system.

#### Auto LOCK Enable on driving

When this feature is set in the infotainment system, all the doors will be locked automatically when the vehicle exceeds 9 mph (15 km/h).

#### Auto UNLOCK Upon Vehicle off

When this feature is set in the infotainment system, all the doors will be unlocked automatically when the vehicle is turned off.

# **Information**

For more information, refer to the user's manual provided in the infotainment system and the guick reference guide.

# Additional unlock safety feature airbag deployment

As an additional safety feature, all doors will be automatically unlocked when an impact causes the airbags to deploy.

# Child-protector Rear Door Locks (if equipped)



The child safety lock is provided to help prevent children seated in the rear from accidentally opening the rear doors. The rear door safety locks should be used whenever children are in the vehicle.

The child safety lock is located on the edge of each rear door. When the child safety lock is in the lock position, the rear door will not open if the inner door handle is pulled.

To lock the child safety lock, insert a small flat blade tool (like a screwdriver or similar) (1) into the slot and turn it to the lock position as shown.

To allow a rear door to be opened from inside the vehicle, unlock the child safety lock.



Never allow children to open the rear doors while the vehicle is moving. They may fall out of the vehicle. Be sure to use the rear door safety locks whenever children are in the vehicle.

## **Electronic Child Safety Lock (if** equipped)



When the electronic child safety lock button is pressed and the indicator light on the button illuminates, the rear doors cannot be opened from inside the vehicle.

- The rear door window cannot be opened or closed while the electronic child safety lock button is in the LOCK position (indicator light ON). For more information, refer to the "Windows" section in this chapter.
- · Electronic child safety lock does not automatically turn on unless the driver presses the electronic child safety lock button.
- If 3 minutes passes after the Start/ Stop button is pressed to the OFF or ACC, the indicator on the button turns off, and the driver cannot turn off electronic child safety lock by pressing the button. To turn off the function, press the Start/Stop button to the ON position, and then press the electronic child safety lock button.

- If the power is supplied again after removing the battery or battery is discharged while the electronic child safety lock button is in the LOCK position, press the button once more to match the state of the indicator on the electronic child safety lock button and actual status of the electronic child safety lock function.
- If the airbag is activated while the electronic child safety lock button is in the LOCK position (indicator light ON), the rear doors will unlock automatically.
- Vehicles equipped with the electronic child safety lock feature is not provided with a manual child safety lock.

## ! WARNING

Never allow children to open the rear doors while the vehicle is moving. They may fall out of the vehicle. Be sure to use the electronic child safety lock whenever children are in the vehicle.

## NOTICE

#### Child safety lock failure



When electronic child safety lock does not work even though the button is pressed, the message will be displayed and an alarm will sound. Have the vehicle inspected by an authorized retailer Genesis Branded products.

# Safe Exit Assist (if equipped with electronic child safety lock)

Safe Exit Assist prevents the rear occupant from opening the rear door. When an approaching vehicle from the rear area is detected after the vehicle stops, the rear doors will not unlock even when the driver tries to unlock the rear doors using the electronic child safety lock button.

For more information, refer to the "Safe Exit Assist (SEA)" section in chapter 7.

## **THEFT-ALARM SYSTEM**

This system helps to protect your vehicle and valuables. The horn will sound and the hazard warning lights will blink continuously if any of the following occur:

- A door is opened without using the smart key.
- The liftgate is opened without using the smart key.
- The vehicle hood is opened.

The alarm continues for 30 seconds, then the system resets. To turn off the alarm, unlock the doors with the smart key.

The Theft Alarm System automatically sets 30 seconds after you lock the doors and the liftgate. For the system to activate, you must lock the doors and the liftgate from outside the vehicle with the smart key or by touching the touch sensor on the outside of the door handle with the smart key in your possession.

The hazard warning lights will blink and the chime will sound once to indicate the system is armed.

Once the security system is set, opening any door, the liftgate, or the hood without using the smart key will cause the alarm to activate.

The Theft Alarm System will not set if the hood, the liftgate, or any door is not fully closed. If the system will not set, check the hood, the liftgate, or the doors are fully closed.

Do not attempt to alter this system or add other devices to it.

## i

## Information

- Do not lock the doors until all passengers have left the vehicle. If the remaining passenger leaves the vehicle when the system is armed, the alarm will be activated.
- If the vehicle is not disarmed with the smart key, open the doors by using the mechanical key and start the vehicle by directly pressing the Start/ Stop button with the smart key.
- If the system is disarmed by unlocking the vehicle, but neither a door or the liftgate is opened within 30 seconds, the doors will relock and the system will rearm automatically.

## ADVANCED REAR OCCUPANT ALERT (ROA) (IF EQUIPPED)

Advanced Rear Occupant Alert is provided to prevent a driver from leaving a vehicle with a passenger left in the vehicle.

## Advanced Rear Occupant Alert Settings

To use Rear Occupant Alert, it can be enabled from the Settings menu in the infotainment system.

Select: Setup > Vehicle > Convenience > Rear Occupant Alert (ROA)



### Information

- Deselect 'Rear Occupant Alert (ROA)' from the settings menu to turn the system off.
- The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

# Advanced Rear Occupant Alert Operation

· First alert

When you turn off the vehicle and open the driver's door after opening and closing the rear door or liftgate, the 'Check rear seats' or the 'Check rear seat for passengers and belongings' warning message appears on the instrument cluster.

· Second alert

After the first alert, the second alert operates when any movement is detected in the vehicle after the driver's door is closed and all the doors are locked. The horn sounds about 25 seconds. Also, a text message is sent to members of Genesis Connected Services (if available). If the system continues to detect a movement, the alert operates up to 8 times.

To stop the alert:

- Unlock the doors with the smart key
- Turn it off from the Genesis Connected Services App (if available)
- The system detects movement in the vehicle for 10 minutes after the door is locked.

## *i* Information

- The second alert is available for vehicles equipped with the ROA sensor.
- The second alert is activated only after the prior activation of the first alert.
- Rear Occupant Alert also activates when movement is detected in the cargo area.



[A]: Cluster, [B]: Steering wheel

If you do not want to use Rear Occupant Alert, press the OK button on the steering wheel when the first alert appears and the second alert is deactivated once.

• If the vehicle is started remotely (if equipped with Remote Start), inside movement detection stops.

# Advanced Rear Occupant Alert Precautions



- Make sure that all the windows are closed. If any window is open, the alert may occur when the sensor has detected any movement (e.g. wind or bugs).
- The alert may occur if any movement is detected in the driver's or passenger's seat.
- If all doors are locked with a passenger in the vehicle, the alert may occur.
- The alert may occur if there is an impact on the vehicle.
- If boxes or objects are stacked in the vehicle, the system may not detect passengers. The alert may occur if the boxes or objects fall off or move.
- The alert may occur with the doors locked if the vehicle is pushed or shaken, or washed, or if there is sufficient external vibration or noise.
- The alert may occur when there are metallic or liquid objects in the vehicle.

## **WARNING**

Even if your vehicle is equipped with Advanced Rear Occupant Alert (ROA), always check the rear seats or cargo area before you leave the vehicle.

Advanced Rear Occupant Alert (ROA) may not operate when:

- Movement does not continue for a certain period of time or the movement is small.
- A child is not seated in a child restraint system.
- The detection signal is weak because the signal is obscured by a seat or CRS (e.g. child is restrained in the forwardfacing CRS).
- Movement is detected in areas other than the rear seats.
- The rear passenger is covered with a fabric made of metallic substance such as a blanket.
- The sensor is dirty or blocked with foreign substances.
- An animal at the rear seat is not large enough to be detected by the sensor or there is hardly any movement.
- Attaching objects or modifying the interior ceiling, or the interior ceiling is deformed or damaged.
- There are electronic interference around the vehicle.
- The external environment and other conditions are detected.

## **Declaration of Conformity**

The radio frequency components (ROA Radar Sensor) complies:

For USA



#### FCC ID: NSZVITA001

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

#### **CAUTION TO USERS**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

OANATEL323

#### For Canada

Model: VitaSense IC: 3019A-VITA001

This device complies with Industry Canada licenceexempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée

aux deux conditions suivantes:
(1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

OANATEL324

## **INTEGRATED MEMORY SYSTEM (IF EQUIPPED)**



Integrated Memory System for the driver's seat is provided to store and recall the following memory settings with a simple button operation.

- · Driver's seat position
- Steering wheel position (power adjustment)
- Side view mirror position
- Head-up Display position (if equipped)

## **MARNING**

Never attempt to operate the integrated memory system while the vehicle is moving.

## Information

- If the battery is disconnected, the memory settings will be erased.
- If integrated memory system does not operate normally, have the system inspected by an authorized retailer of Genesis Branded products.

## **Storing Memory Positions**

- 1. Shift to P (Park) while the Start/Stop button is in the ON position.
- Adjust the driver's seat position, side view mirror position, steering wheel position and head-up display height to the desired position.
- Press the SET button. The system will beep once and notify you 'Press button to save settings' on the cluster display.
- 4. Press one of the memory buttons (1 or 2) within 4 seconds. The system will beep twice when the memory has been successfully stored.
- 5. 'Driver 1 (or 2) settings saved' will appear on the cluster display. The message appears only for the driver's seat position memory setting.

## **Recalling Memory Positions**

- 1. Shift to P (Park) while the Start/Stop button is in the ON position.
- Press the desired memory button (1 or 2). The system will beep once, and then the driver's seat position, side view mirror position, steering wheel position and head-up display height will automatically adjust to the stored positions.
- 3. 'Driver 1(or 2) settings applied' will appear on the cluster display.

## i In

## Information

- If you press the SET button or the corresponding button which the setting is being recalled, the setting will temporarily deactivate. If you press the other buttons, the setting of the pressed button will activate.
   For example, if you press the SET button or number 1 button with the number 1 setting in operation, the setting will temporarily deactivate. If you press the number 2 button, the number 2 setting will activate.
- If you adjust the seat, side view mirror, steering wheel or head-up display while recalling the stored positions, the preset settings will become ineffective.

### Resetting the System

Take the following procedures to reset integrated memory system, when it does not operate properly.

# Resetting integrated memory system

- Stop the vehicle and open the driver's door with the Start/Stop button in the ON position and the vehicle shifted to P (Park).
- 2. Adjust the driver's seat and seatback to the foremost position.
- 3. Press the **SET** button and push forward the driver's seat movement switch over 2 seconds simultaneously.

# While resetting integrated memory system

- 1. Resetting starts with a notification sound.
- 2. The driver's seat and seatback is adjusted to the rearward position with the notification sound.
- The driver's seat and seatback is re-adjusted to the default position (central position) with the notification sound.

However, in the following cases, the resetting procedure and the notification sound may stop.

- The memory button is pressed.
- The seat control switch is operated.
- The gear is shifted out of P (Park).
- The driving speed exceeds 2 mph (3 km/h).
- The driver's door is closed.

## NOTICE

- While integrated memory system is being reset, if the resetting and notification sound stops incompletely, restart the resetting procedure again.
- Make sure that there is no objects around the driver's seat in advance of resetting the integrated memory system.
- After resetting the integrated memory system, the adjustment for the driver seat must be stored again to recall the memory position.

## **Seat Easy Access**

Seat easy access will move the driver's seat and steering wheel automatically as follows:

· Exiting the vehicle:

The driver's seat, steering wheel and seat bolster will move as follows when the Start/Stop button is in the OFF position with the gear in P (Park) and the driver's door open.

- Driver seat: Moves rearward depending on the distance selected from the Settings menu in the infotainment system.
- Steering wheel: Moves upward
- Seat bolster (if equipped): Adjusted to the default position.

However, the driver's seat may not move rearward if there is not enough space between the driver's seat and the rear seats.

Also, on a regular basis, the steering wheel will also move forward to adjust its location by itself.

· Entering the vehicle:

The driver's seat, steering wheel and seat bolster will move as follows when the Start/Stop button is pressed to the ACC, ON or START position or while carrying the smart key, the driver's door is closed with the Start/Stop button in the OFF position.

- Driver seat: Moves back to its original position.
- Steering wheel: Moves back to its original position.
- Seat bolster (if equipped): Adjusted to the default position.
- You can set the Seat Easy Access function from the Settings menu in the infotainment system.

#### Select:

- Driver seat

Setup > Vehicle > Seat > Seating Easy Access > Driver Seat Easy Access > Normal/Extended/Off

- Steering wheel

Setup > Vehicle > Seat > Seating Easy Access > Steering wheel easy access



## Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

## **SMART POSTURE CARE SYSTEM (IF EQUIPPED)**

The Smart Posture Care system automatically provides a healthy posture (position) for the driver's back, and sets the steering wheel, side view mirrors, head-up display positions according to the driver's body measurements.



### Information

If the Seat Posture Care system does not operate normally, have the system checked by an authorized retailer of Genesis Branded products.



- Check that the gear is in P (Park) while the vehicle Start/Stop button is in the ON position.
- Select Setup > Vehicle > Seat >
   Smart Posture Care > Enter Driver's Information from the Settings menu in the infotainment system.
  - Or press the SET button on the driver's door. With a beep sound the Smart Posture Care menu will be displayed on the infotainment system.
- 3. Enter information (Height, Sitting height, Weight) in the infotainment system.
- After entering the driver's information, press Posture Analysis > Adjust Posture > Save Current Posture. The driver's seat, steering wheel, side view mirror and head-up display will be adjusted.
- 5. Save the adjusted seat position in 'Settings 1' or 'Settings 2'.



### Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

#### STEERING WHEEL

# MDPS (Motor Driven Power Steering)

The system assists you with steering the vehicle. If the vehicle is turned off or if the power steering system becomes inoperative, you may still steer the vehicle, but it will require increased steering effort.

If you notice any change in the effort required to steer during normal vehicle operation, have the system checked by an authorized retailer of Genesis Branded products.



### CAUTION

If the MDPS does not operate normally, the o! warning light and the message 'Check motor driven power steering' will illuminate on the instrument cluster. You may steer the vehicle, but it will require increased steering efforts. Take the vehicle to an authorized retailer of Genesis Branded products and have the system checked as soon as possible.



## Information

During normal vehicle operation:

- The steering effort may be high immediately after pressing the Start/Stop button to the ON position.
  - This happens as the system performs the MDPS system diagnostics. When the diagnostics are completed, the steering wheel effort returns to its normal condition.
- When the 12 V battery voltage is low, you may have to use more effort to steer. This is a temporary condition and returns to normal after charging the battery.
- A noise may be heard from the MDPS relay after the Start/Stop button is in the ON or OFF position.
- Motor noise may be heard when the vehicle is at a stop or at a low speeds.
- When you operate the steering wheel in low temperatures, abnormal noise may occur. If the temperature rises, the noise disappears.
- When an error is detected from MDPS, the steering effort assist function is not activated. Instrument cluster warning lights may illuminate or the steering effort may be high. If these symptoms occur, drive the vehicle to a safe location as soon as possible. Have the system inspected by an authorized retailer f Genesis Branded products as soon as possible.

## **Tilt/Telescopic Steering**

When adjusting the steering wheel to a comfortable position, adjust the steering wheel so that it points toward your chest, not toward your face. Make sure you can see the instrument cluster warning lights and gauges. After adjusting, push the steering wheel both up and down to be certain it is locked in position.

Always adjust the position of the steering wheel before driving.



## **WARNING**

NEVER adjust the steering wheel while driving. This may cause loss of vehicle control resulting in an accident.

#### Manual adjustment



To adjust the steering wheel angle and height:

- 1. Pull down the lock-release lever (1).
- Adjust the steering wheel to the desired angle (2) and distance forward/back (3).
- 3. Pull up the lock-release lever to lock the steering wheel in place.

## $\overline{i}$

## Information

Sometimes the lock-release lever may not engage completely. Pull down on the lock-release lever, readjust the steering wheel again, and then pull back up on the lock-release lever to lock the steering wheel in place.

### Power adjustment



To change the steering wheel angle and height:

- Push the switch (1) up and down to adjust the angle (2).
- Push the switch (1) forward or rearward to adjust the height (3).

## NOTICE

Do not adjust the steering wheel longer than necessary when the vehicle is turned off (**READY** indicator off). This may drain the battery. Resetting steering wheel power adjustment If adjustment is no longer possible within the operable range while adjusting the steering wheel position (angle or height), reset as follows.

- From the position the steering wheel
  has stopped, push the control switch
  (1) for 10 seconds in the direction you
  were adjusting the steering wheel.
  The steering wheel will move in the
  direction the control switch is pushed.
- Continue pushing the switch (1) for at least 2 seconds after the steering wheel has stopped. Resetting will be complete after the operational range is recognized.

If the adjustment is still not possible after resetting the steering wheel power adjustment, have the system inspected by authorized retailer of Genesis Branded products.

#### Horn



To sound the horn, press the area indicated by the horn symbol on your steering wheel (see illustration). The horn will operate only when this area is pressed.

## NOTICE

Do not strike the horn severely or hit it with your fist. Do not press on the horn with a sharp-pointed object.

# Heated Steering Wheel (if equipped)



While the vehicle is on (**READY** indicator on) touch the heated steering wheel icon to warm the steering wheel.

### Manually adjusting temperature

Each time you press the heated steering icon, the temperature changes as follows:

- · OFF > HIGH > LOW
- Pressing the icon when the temperature is low, the heated steering wheel turns off.

# Automatically adjusting temperature

- When HIGH is manually selected, the heated steering wheel automatically changes to the LOW position after 30 minutes. You can turn off the heated steering wheel by pressing the icon to the OFF position.
- When LOW is manually selected, the heated steering wheel is not controlled automatically.

# Automatic Controls Linked to Climate Control Settings

The heated steering wheel automatically controls the steering wheel temperature depending on the ambient temperature when the vehicle is turned on (READY indicator on).

- To use this feature, it can be enabled from the Settings menu in the infotainment system.
  - Select: Setup > Vehicle > Seat > Warmer/ Ventilation Features > Auto. Controls That Use Climate Control Settings > Heated steering wheel
- If you press the heated steering wheel icon when the feature is set, you must control the heated steering wheel manually.
- The heated steering wheel defaults to the OFF position whenever the Start/Stop button is pressed to the ON position. However, if the Automatic Controls Linked to Climate Control Settings feature is ON, the heated steering wheel will turn on and off depending on the outside temperature.



## Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

## NOTICE

- Do not install any cover or accessories on the steering wheel to prevent damage to the steering wheel heater system.
- Do not strike the steering wheel surface with a sharp-pointed object. This may damage the heating element in the steering wheel.
- Do not clean the steering wheel surface using the following products.
  - Organic solvents such as thinner, alcohol, and gasoline
  - Chemical products such as leather cleaner, coating agent, and wax.

#### **MIRRORS**

### **Inside Rearview Mirror**

Before driving your vehicle, check to see that your inside rearview mirror is properly positioned. Adjust the rearview mirror so that the view through the rear window is properly centered.



## **WARNING**

Make sure your line of sight is not obstructed. Do not place objects on the rear seat or in the cargo area that may interfere with your vision through the rear window.



### WARNING

To prevent serious injury during an accident or deployment of the airbag, do not modify the rearview mirror and do not install a wide mirror.



### WARNING

NEVER adjust the mirror while driving. This may cause loss of vehicle control resulting in an accident.

## NOTICE

When cleaning the mirror, use a paper towel or similar material dampened with glass cleaner. Do not spray glass cleaner directly on the mirror as this may cause the liquid cleaner to enter the mirror housing.

# Electrochromic mirror (ECM) with HomeLink® system (if equipped)

Your vehicle may be equipped with a Gentex Automatic-Dimming Mirror with an Integrated HomeLink® Wireless Control System.

During nighttime driving, this feature will automatically detect and reduce rearview mirror glare. The HomeLink® Universal Transceiver allows you to activate your garage door(s), electric gate, home lighting, etc.



- (1) HomeLink Channel 1
- (2) HomeLink Channel 2
- (3) HomeLink Channel 3
- (4) Garage Door Opener Status Indicator: Closing or Closed
- (5) HomeLink Operation Indicator
- (6) Garage Door Opener Status Indicator: Opening or Opened
- (7) HomeLink User Interface Indicator

Automatic-Dimming Night Vision Safety<sup>TM</sup> (NVS®) Mirror (if equipped)

The NVS® Mirror automatically reduces glare by monitoring light levels in the front and the rear of the vehicle. Any object that obstructs either light sensor will degrade the automatic dimming control feature.

For more information regarding NVS® mirrors and other applications, please refer to the Gentex website:

www.gentex.com

Your mirror will automatically dim upon detecting glare from the vehicles traveling behind you.

The mirror defaults to the ON position each time the vehicle is started.

Integrated HomeLink® Wireless Control System

The HomeLink® Wireless Control System provides a convenient way to replace up to three hand held radio-frequency transmitters used to activate compatible devices such as gate operators, garage door openers, entry door locks, security systems, and home lighting.

## NOTICE

HomeLink® operates while the Start/ Stop button is in the ACC or ON position for safety reasons. It is to prevent unintentional security problems from happening when the vehicle is parked outside the garage.



Before programming HomeLink® to a garage door opener or gate operator, make sure people and objects are out of the way of the device to prevent potential harm or damage. Do not use the HomeLink® with any garage door opener that lacks the safety stop and reverse features required by U.S. federal safety standards (this includes any garage door opener model manufactured before April 1, 1982). A garage door that cannot detect an object - signaling the door to stop and reverse - does not meet current U.S. federal safety standards. Using a garage door opener without these features increases the risk of serious injury or death.

For more information, contact HomeLink® at www.homelink.com, or call Home-Link customer support at 1-800-355-3515.

It is also recommended that a new battery be replaced in the handheld transmitter of the device being trained to HomeLink® for quicker training and accurate transmission of the radio frequency.

### 1. Programming HomeLink®

The following steps show how to program HomeLink. If you have any questions or are having difficulty programming your HomeLink buttons, refer to the HomeLink website or call the HomeLink customer support toll-free number. Do this, before going back to the dealer who sold you the car.

- Visit the HomeLink website at: www. homelink.com. Then at the top of the page, choose your vehicle make. Then watch the You Tube video, and/or access additional website information.
- If you choose to access the website via your cell phone, scan the QR code.



 Or, call HomeLink customer support at 1-800-355-3515 (Please have the vehicle make/model AND the opener device make/model readily available.)

#### 1) Programming Preparation



 When programming a garage door opener, it is advised to park the vehicle outside of the garage.

- It is recommended that a new battery be placed in the handheld transmitter of the device being programmed to HomeLink for quicker training and accurate transmission of the radiofrequency signal.
- Press the Start/Stop button to the ACC (Accessory) position for programming of Homel ink.

### 2) Programming a New HomeLink®




 Press and release the HomeLink button (1), (2) or (3), you would like to program. The HomeLink indicator light (7) will flash orange slowly (if not, perform the steps of "Erasing HomeLink Buttons" section, and start over).



 Position the garage door opener remote 1 – 3 inches (2 – 8cm) away from the HomeLink buttons.

- 3. While the HomeLink indicator light (7) is flashing orange, press and hold the hand-held remote button. Continue pressing the handheld remote button until the HomeLink indicator light (7) light changes from orange to green. You may now release the handheld remote button.
- Wait until your garage door comes to a complete stop, regardless of position, before proceeding to the next steps.
- Press and release the HomeLink button you are programming and observe the indicator light.
  - If the indicator light remains solid green, your device should operate when the HomeLink button is pressed. At this point, if your device operates, programming is complete.
  - If the indicator light rapidly flashes green, firmly press, hold for two seconds and release the HomeLink button up to three times in a row slowly to complete the programming process. Do not press the HomeLink button rapidly. At this point if your device operates, programming is complete. If the device does not operate, continue with step 6.
- 6. At the garage door opener motor, (security gate motor, etc.) locate the "Learn", "Smart", "Set" or "Program" button. This can usually be found where the hanging antenna wire is attached to the motor-head unit (see the device's manual to identify this button). The name and color of the button may vary by manufacturer.



- \* A ladder and/or second person may simplify the following steps.
- 7. Firmly press and release the "Learn", "Smart", "Set" or "Program" button. You now have up to 30 seconds in which to complete the next step.
- 8. Return to the vehicle and firmly press, hold for two seconds and release, the HomeLink button up to three times in a row slowly. Do not press the HomeLink button rapidly. As soon as you see the garage door start to move, stop pressing any buttons until a few seconds after the garage door has come to a complete stop, regardless of position. At this point, programming is complete and your device should operate when the HomeLink button is pressed and released.

#### Two-Way Communication Programming (For select garage door openers)

If your garage door opener has the 'myQ' logo on its side, your opener likely has Two-Way Communication capability. HomeLink has the capability to establish Two-Way Communication with your garage door opener. HomeLink can receive and display "closing" or "opening" status messages from compatible garage door openers. At any time, Home-Link can also recall and display the last recorded status communicated by the garage door opener to indicate your garage door being "closed" or "opened".

To check if your garage door opener is compatible with this feature, refer to www.homelink.com/compatible/Twoway-Communication. If your garage door opener has this functionality, AND the Two-Way Communication indicators (4), (6) in the mirror appear while the garage door is opening/closing, then no further steps are needed. Two-Way Communication Programming is already complete. However, if your garage door opener has this functionality, AND the Two-Way Communication indicators (4), (6) in the mirror DO NOT appear while the garage door is opening/closing, use the following instructions to enable this functionality.

- In your vehicle, press and hold the programmed HomeLink button for 2 seconds, then release. Confirm that the garage door is moving. AFTER it stops, you will have one minute to complete the following steps:
- \* A ladder and/or second person may simplify the following steps.

- On your garage door opener in your garage, locate the "Learn" button (usually near where the hanging antenna wire is attached to the garage door opener). If there is difficulty locating this button, reference the device's owner's manual.
- 3. Press and release the "Learn" button.
- A light on your garage door opener may flash, and your Two-Way Communication indicators (4), (6) in your vehicle may flash, confirming completion of the process.
- 5. Return to the vehicle and firmly press and release the programmed HomeLink button to activate your garage door. The Two-Way Communication indicators (4), (6) flash in orange when the door is moving. Do not make any additional button presses until AFTER the garage door has come to a complete stop.
- 6. Your Two-Way Communication programming is now complete.

## *i* Information

If your garage door opener has Two-Way Communication functionality, it is possible for HomeLink to stop functioning the garage door shortly after initial programming, IF the Two-Way Communication Programming wasn't properly completed. This usually happens after the first 10 times a programmed HomeLink button is pressed. If you experience this, completing the "Programming a New HomeLink Button" and "Two-Way Communication Programming" will restore door operation.

#### 4) Canadian Programming

Canadian radio-frequency laws require transmitter remote signals to "time-out" (or quit) after a couple seconds of transmission, which may not be long enough for HomeLink to pick up the signal during programming.

If you live in Canada or you are having difficulties programming a gate operator or garage door opener by using the programming procedures, replace "Programming a New HomeLink Button" step 3 with the following:

While the HomeLink indicator light (7) is flashing orange, press and release ("cycle") your device's handheld remote every two seconds until the HomeLink indicator light (7) changes from orange to green. You may now release the hand-held remote button. Then proceed with "Programming a New HomeLink Button" step 4.

#### 2. Operating HomeLink®

#### 1) Operating HomeLink®



 Press and release the desired programmed HomeLink button (1, 2 or 3).

## *i* Information

The HomeLink indicator (7) should light green, solid or flashing, and your programmed device should operate.

If your device does not operate, the HomeLink programming was not successful, and you'll need to reprogram the button.

# 2) Two-Way Communication Display Behavior



 Press and release one of the programmed HomeLink buttons (1, 2 or 3).



The indicator (4) and (6) operates as below, if your garage door opener has Two-Way Communication functionality.

- If the indicator (4) flashes in Orange, it indicates that the garage door is "Closing".
- The indicator (4) turns solid green once the garage door has closed.
- If the indicator (6) flashes in Orange, it indicates that the garage door is "Opening".
- The indicator (6) turns solid green once the garage door has fully opened.
- If the indicator (4) or (6) does not turn to green, it indicates that the last status of garage door was not received properly. The HomeLink mirror tries to receive the last known status of the garage door for a few seconds.

#### 3) Recalling Garage Door Status

HomeLink mirror with Two-Way Communication provides a way to view the last stored message from the garage door opener. In order to recall the last known status of the last activated device, press the buttons "1 and 2" OR "2 and 3" simultaneously.

- If the indicator (4) appears solid Green, it indicates that the last activated device was "closed" properly.
- If the indicator (6) appears solid Green, it indicates that the last activated device was "open" properly.

- 3. Erasing HomeLink® Buttons
- Erasing and Reprogramming a Single HomeLink® Button:
- Press and hold the desired HomeLink button you want to re-program. DO NOT release the button.
- The HomeLink indicator light (7) will illuminate solid green. Release the button as soon as the HomeLink indicator light (7) begins to flash orange, usually about 20 seconds.
- 3. Proceed with the steps in the "Programming a New HomeLink Button" section.

## **Information**

If you do not complete the reprogramming of a new device to the button, it will revert to the previously stored programming.

 The following instructions will erase ALL HomeLink® programming from ALL buttons:



- 1. Press and hold the buttons (1) and (3) simultaneously.
- 2. The HomeLink indicator light (7) will illuminate solid Orange for about 10 seconds.
- Release the buttons once the HomeLink indicator light (7) changes to Green and flashes rapidly.
- Now all three HomeLink buttons (1), (2) and (3) are cleared of any programming.



## Information

HomeLink\* and the HomeLink\* House logo are registered trademarks of Gentex Corporation.

The myQ logo is a registered trademark of The Chamberlain Group, Inc.

#### FCC (USA) and ISED (Canada)

This device complies with FCC rules part 15 and Innovation, Science, and Economic Development Canada RSS-210. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference that may be received including interference that may cause undesired operation. WARNING: The transmitter has been tested and complies with FCC and ISED rules. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the

This equipment complies with FCC and ISED radiation exposure limits set forth for an uncontrolled environment. End Users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must be at least 20cm from the user and must not be co-located or operating in conjunction with any other antenna or transmitter.

#### FCC (Htats-Unis) et ISED (Canada)


Cet appareil est conforme aux règlements de la FCC, section 15, et au CNR-210 d'Innovation. Sciences et Dhveloppement économique Canada. Le fonctionnement est assujetti aux deux conditions suivantes: (1) cet appareil ne doit pas causer d'interférences nuisibles et (2) cet appareil doit accepter toute interférence reçue, y compris celle qui pourrait entraîner un dysfonctionnement. MISE EN GARDE: L'émetteur a subi des tests et est conforme aux règlements de la FCC et d'ISDE. Les changements ou modifications non approuvés explicitement par la partie responsable de la conformité pourraient rendre caduque l'autorisation de l'utilisateur de se servir du dispositif.

Cet appareil est conforme aux limites d'exposition aux radiations de la FCC et d'ISDE établies pour un environnement non contrôlé. Les utilisateurs finaux doivent respecter les instructions d'utilisation spécifiques pour satisfaire aux exigences de conformité aux expositions de RF. L'émetteur doit se trouver à 20 cm au minimum de l'utilisateur et ne doit pas être situé au même endroit que tout autre émetteur ou antenne ni fonctionner avec un autre émetteur ou antenne.

#### Méiico

La operación de este equipo está sujeta a las siguientes dos condiciones: (1) es posible que este equipo o dispositivo pueda no causar interferencia dañina, y (2) este dispositivo o dispositivos deben aceptar cualquier interferencia, que incluye la interferencia que puede causar su operación no deseada.

## **HomeLink 5 Programing Flow Chart**



#### **Side View Mirrors**



Your vehicle is equipped with both lefthand and right-hand side view mirrors. The mirrors can be adjusted remotely with mirror adjustment control switch. Adjust the side view mirrors to your desired position before driving.

The side view mirrors can be folded remotely to help prevent damage when going through an automatic car wash or when passing through a narrow street.

## $\triangle$

## WARNING

The right side view mirror is convex.

Objects seen in the mirror are closer than they appear.

Use the rear view mirror or turn your head and look to determine the actual distance of other vehicles prior to changing lanes.



## **WARNING**

Do not adjust or fold the side view mirrors while driving. This may cause loss of vehicle control resulting in a collision.

## NOTICE

- Do not scrape ice off the mirror face.
   This may damage the surface of the glass.
- If the mirror is jammed with ice, do not adjust the mirror by force. Use an approved de-icer (not radiator antifreeze) spray, or a sponge or soft cloth with very warm water, or move the vehicle to a warm place and allow the ice to melt.
- Do not clean the mirror with harsh abrasives, fuel, or other petroleum based cleaning products.

### Adjusting the side view mirrors



Adjusting the side view mirrors:

- When the Start/Stop button is in the ACC, ON or START position, press either the L (Left side) or R (Right side) button (1) to select the side view mirror you would like to adjust.
- 2. Use the mirror adjustment control switch (2) to position the selected mirror up, down, left or right.
- 3. After adjustment, press both L and R button off (indicator light off) to prevent unintended adjustment.

## NOTICE

- The mirrors stop moving when they reach the maximum adjusting angles, but the motor continues to operate while the switch is pressed. Do not press the switch longer than necessary, because this can damage the motor.
- Do not attempt to adjust the side view mirrors by hand, because this can damage the motor.

### Folding the side view mirrors



Press the button to fold or unfold the side view mirrors.

#### Infotainment system setting

- Enable on door unlock
  - If Setup > Vehicle > Welcome Mirror/ Light > Enable on Door Unlock is selected from the Settings menu in the infotainment system,
  - The mirror will fold or unfold when the door is locked or unlocked by the smart key.
  - The mirror will fold or unfold when the door is locked or unlocked by the touch sensor on the outside door handle.
- Enable on driver approach
   If Setup > Vehicle > Welcome Mirror/
   Light > Enable on Driver Approach
   is selected from the Settings menu
   in the infotainment system, the
   mirror will unfold when the vehicle
   is approached with the smart key in
   possession.

## **Information**

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

## NOTICE

- The electric type side view mirror operates even though the Start/ Stop button is in the OFF position. However, to prevent unnecessary battery discharge, do not adjust the mirrors longer than necessary while the vehicle is turned off (READY indicator off).
- Do not fold the electric type side view mirror by hand. It could cause motor failure.

## **Reverse Parking Aid (if equipped)**



When the gear is shifted to the R (Reverse) position, the side view mirror(s) will rotate downwards to aid with driving in reverse.

The position of the side view mirror button (1) determines whether or not the mirrors will move:

#### How it works

- When the L or R button (1) is pressed (indicator lights ON), both side view mirrors will move.
- If the L and R buttons (1) are not pressed (indicator lights OFF), both side view mirrors will not move

The side view mirrors will automatically revert to their original positions if any of the following occur:

- The Start/Stop button is pressed to either the OFF position or the ACC position.
- The gear is shifted to any position except R (Reverse).
- The side view mirror adjustment button is not selected.

## Reverse parking aid user settings mode

You may change the angle of the side view mirror if it is difficult to see the rear view with the basic downward mirror angle provided when reversing.

When the vehicle is first delivered, the set downward angle of the left and right side view mirror are different to ensure driver visibility.

- 1. Make sure the vehicle is stopped.
- Depress the brake pedal and shift the gear to R (Reverse). When L (Left) or R (Right) button is pressed, both side view mirror angle will move downward to the basic set position.
- Press either L or R button to select the side view mirror you would like to adjust. Then press "▼, ▲, ▼, ►" switch to adjust the side view mirror to the desired angle.
- 4. After adjusting the angle to save the adjusted side view mirror angle, shift the gear to another position other than R (Reverse), or change the L and R buttons to the neutral position (L and R buttons are not pressed).
- 5. Set the opposite side view mirror following the above procedure 1 to 4.


Resetting reverse parking aid user settings mode

To change the side view mirror angle back to the basic angle, shift the gear to R (Reverse), and adjust the mirror angle higher than when the gear is in P (Park), N (Neutral) and D (Drive).

## NOTICE

When changing the angle of both side view mirrors, it is recommended to change the angle one side at a time following the procedure 1 to 4.

## **WINDOWS**




- (1) Driver's door power window switch
- (2) Front passenger's door power window switch
- (3) Rear door (left) power window switch
- (4) Rear door (right) power window switch
- (5) Window opening and closing
- (6) Automatic power window
- (7) Power window lock switch

#### **Power Windows**

The Start/Stop button must be in the ON position to be able to raise or lower the windows. Each door has a Power Window switch to control that door's window. The driver has a Power Window Lock button which can block the operation of passenger windows. The power windows will operate for about 3 minutes after the Start/Stop button is in the ACC or OFF position. However, if the front doors are opened, the Power Windows will not operate even within the 3 minute period.

### Window opening and closing



#### To open:

Press the window switch down to the first detent position (5). Release the switch when you want the window to stop.

#### To close:

Pull the window switch up to the first detent position (5). Release the window switch when you want the window to stop.

### Auto up/down window

Pressing or pulling up the power window switch momentarily to the second detent position (6) completely lowers or lifts the window even when the switch is released. To stop the window at the desired position while the window is in operation, pull up or press down and release the switch.

## A

### WARNING

- Do not leave the vehicle turned on (READY indicator on) and the key in your vehicle with unsupervised children. Unattended children could operate the window, which could result in serious injury.
- Do not extend your head, arms, body parts or objects outside the window while driving.

#### Resetting the power windows

If the power windows do not operate normally, the automatic power window system must be reset as follows:

- Press the Start/Stop button to the ON position.
- Close the window and continue pulling up on the power window switch for at least one second.

If the power windows do not operate properly after resetting, have the system inspected by an authorized retailer of Genesis Branded products.



## WARNING

Make sure body parts or other objects are out of the way before closing the windows. The automatic reverse feature does not operate while resetting the power window system.

#### Automatic reversal



If a window senses any obstacle while it is closing automatically, it will stop and lower about 12 inches (30 cm) to allow the object to be cleared.

If the window detects the resistance while the power window switch is pulled up continuously, the window will stop upward movement then lower about 1 inch (2.5 cm).

If the power window switch is pulled up continuously again within 5 seconds after the window is lowered by the automatic window reverse feature, the automatic window reverse will not operate.



## Information

The automatic reverse feature is only active when the "Auto Up" feature is used by fully pulling up the switch to the second detent.

## NOTICE

Do not install any accessories on the windows. The automatic reverse feature may not operate.



## **WARNING**

Make sure body parts or other objects are safely out of the way before closing the windows to avoid injuries or vehicle damage.

Objects less than 0.16 inches (4 mm) in diameter caught between the window glass and the upper window channel may not be detected by the automatic reverse window and the window will not stop and reverse direction.

#### Power window lock button



The driver can disable the power window switches on the rear passenger doors by pressing the power window lock button. When the power window lock button is pressed:

- The driver's master control can operate all the power windows.
- The front passenger's control can operate the front passenger's power window.
- The rear passenger's control cannot operate the rear passengers' power window.

## **MARNING**

Do not allow children to play with the power windows. Keep the driver's door power window lock button in the LOCK position. Serious injury or death can result from unintentional window operation by a child.

## NOTICE

- To prevent possible damage to the power window system, do not open or close two windows or more at the same time. This also ensures the longevity of the fuse.
- Never try to operate the main switch on the driver's door and the individual door window switch in opposite directions at the same time. If this is done, the window stops and cannot be opened or closed.

### Remote window opening feature (Remote Window Control) (if equipped)

Press and hold the Door Unlock (1) button on the smart key for more than 3 seconds and the windows move down after the doors are unlocked. Window movement stops when you release the door unlock button.



## *I* Information

- The remote window opening function may abruptly stop when you move away from your vehicle during operation. Stay in close proximity from your vehicle, while monitoring the window movement.
- Please be aware that the doors unlock when the windows are opened using the remote window open/closing function.

## PANORAMIC SUNROOF (IF EQUIPPED)

If your vehicle is equipped with a sunroof, you can slide or tilt your sunroof with the sunroof switch located on the overhead console.



The sunroof can only be operated when the Start/Stop button is in the ON or START position.

The sunroof can be operated for about 3 minutes after the Start/Stop button is in the ACC or OFF position. However, if the front door is open, the sunroof cannot be operated even within the 3minute period.

## <u></u> ₩

## WARNING

To prevent serious injury or death:

- Adjust the sunroof or sunshade when your vehicle stops.
- Do not leave the vehicle turned on (READY indicator on) and the key in your vehicle with unsupervised children. Unattended children could operate the sunroof.
- Do not sit on the top of the vehicle.

## NOTICE

Do not operate the sunroof if it contacts any roof rack or cargo.

#### **Power Sunshade**



Use the power sunshade to block direct sunlight coming through the sunroof glass.

- Push the sunroof switch rearward to the first detent position, the power sunshade automatically slides open.
- Push the sunroof switch forward to the first detent position, the power sunshade automatically closes.
   However, if the sunroof glass is open, the glass will close first.

To stop the power sunshade at any point, push the sunroof switch in any direction.

## NOTICE

Do not pull or push the power sunshade by hand as such action may damage the power sunshade or cause it to malfunction.



## *i* Information

Wrinkles formed on the power sunshade are normal due to material characteristic.

## Tilt Open/Close



- Push the sunroof switch upward, the sunroof glass tilts open. However, if the power sunshade is closed, the sunshade will open first.
- Push the sunroof switch upward or forward when the sunroof glass is tilt opened, the sunroof glass automatically closes.

To stop the sunroof movement at any point, push the sunroof switch in any direction.

## Slide Open/Close



 Push the sunroof switch rearward to the first detent position, the sunroof glass opens. However, if the power sunshade is closed, the power sunshade will open first.

Push the sunroof switch forward to the first detent position, the sunroof glass closes. However, if the sunroof glass is closed, the power sunshade will close.

 Push the sunroof switch forward or rearward to the second detent position, the power sunshade and sunroof glass operate automatically (auto slide feature).

To stop the sunroof movement at any point, push the sunroof switch in any direction.

### **Automatic Reversal**



If the power sunshade or sunroof glass senses any obstacle while it is closing automatically, it will reverse direction then stop at a certain position.

The auto reverse function may not work if an object thin or soft is caught between the sliding power sunshade or sunroof glass and sunroof sash.

## **MARNING**

- Make sure heads, hands, arms or any other body parts or objects are out of the way before operating the sunroof. Body parts or objects may get caught causing injuries or vehicle damage.
- Never deliberately use your body parts to test the automatic reversal function. The power sunshade or sunroof glass may reverse direction, but there is a risk of injury.

## **NOTICE**

- Do not continue to push the sunroof switch after the sunroof is fully opened, closed, or tilted. Damage to the sunroof motor could occur.
- Continuous operations such as slide open/close, tilt open/close, etc. may cause the motor or sunroof system to malfunction.
- Regularly remove any accumulated dust on the suproof rail.
- Dust accumulated between the sunroof and roof panel can make noise. Open the sunroof and remove dust regularly using a clean cloth.
- Do not try to open the sunroof when the temperature is below freezing or when the sunroof is covered with snow or ice. The sunroof may not work properly and may break if opened by force.
- Do not open or drive with the sunroof glass open immediately after rain or washing the vehicle. Water may wet the interior of the vehicle.
- Do not extend any luggage outside the sunroof while driving. Vehicle damage may occur if the vehicle suddenly stops.

## WARNING

Do not extend your head, arms, body parts or objects outside the sunroof while driving. Injuries may occur if the vehicle suddenly stops.

## **Resetting the Sunroof**



To reset the sunroof:

- It is recommended to perform the reset procedure with the vehicle turned on (READY indicator on). Start the vehicle in P (Park).
- Make sure the power sunshade and sunroof glass are in the fully closed position. If the power sunshade and sunroof glass are open, push the switch forward until the power sunshade and sunroof glass are fully closed.
- Release the switch when the power sunshade and sunroof glass are fully closed.
- Push the switch forward until the power sunshade and sunroof glass move slightly. Then release the switch.
- 5. Once again push and hold the sunroof switch forward until the power sunshade and sunroof glass slide open and close. Do not release the switch until the operation is completed. If you release the switch during operation, start the procedure again from step 2.

## Information

If the sunroof is not reset after the vehicle battery is disconnected or discharged, or the sunroof fuse is blown, the sunroof may not operate normally.

## **Sunroof Open Warning**



If the driver turns off the vehicle when the sunroof is not fully closed, the warning chime will sound for several seconds and the sunroof open warning will appear on the cluster display.

Close the sunroof securely when leaving your vehicle.



Do not leave sunroof open when leaving the vehicle to prevent theft or damage from water entering the vehicle.

#### HOOD

## **Opening the Hood**



- Park the vehicle and apply the parking brake.
- 2. Pull the release lever to unlatch the hood. The hood pops open slightly.



 Go to the front of the vehicle, raise the hood slightly, push up the secondary hood release lever (1) inside of the hood center and lift the hood (2).
 After the hood has been lifted halfway, it will raise completely by itself.

## Closing the Hood

- Before closing the hood, check in and around the motor compartment to ensure the following:
  - Any tools or other loose objects have been removed.
  - All glove, rags, or other combustible material have been removed.
  - All filler caps are tightly and correctly installed.
- 2. Lower the hood until it is about 12 inches (30 cm) above the closed position and then let it drop.
- 3. Check the hood has locked properly. If the hood is raised slightly, open it again and drop it from a little higher. Check again.

## **WARNING**

- Before closing the hood, ensure all obstructions are removed from around the hood opening.
- Always double check to make sure that the hood is firmly latched before driving away. Check there is no hood open warning light or message displayed on the instrument cluster. Driving with the hood open may cause a total loss of visibility, resulting in a collision.
- Do not move the vehicle with the hood raised. It may block your vision and may result in a collision.

### **FRONT TRUNK**

## **Opening the Front Trunk**



- 1. Open the hood
- 2. Lift up the front trunk cover while pressing the front trunk lever (1).

## **Closing the Front Trunk**

Push down the front trunk cover.



## Information

Front trunk weight limit: 26 lbs (12 kg)
The front trunk's weight limit depends on the specifications.

## **MARNING**

- NEVER make an attempt to get inside the front trunk. It may cause a fatal injury.
- Before closing the hood, ensure all obstructions are removed from around the hood opening. The hood rises up or moves down automatically if its height is not firmly adjusted. Be careful not to damage or be injured caused by unintended hood movements.
- Never place cigarette lighters, propane cylinders, or other flammable materials in your vehicle. These items may catch fire or explode if your vehicle is exposed to hot weather for a long time.

#### **CAUTION**

- Do not store items in excess of the specified front trunk weight limit. The front trunk may be damaged.
- · Do not store the fragile items in the front trunk.
- ALWAYS keep the front trunk cover closed securely while driving. Loose items in your vehicle may move around. If you stop or turn your vehicle quickly, or if there is a collision, the items may be damaged.
- Do not spray water directly on the front trunk. Vehicle driving system may get damaged since the front trunk is located at the center of motor compartment.
- Be careful when storing any liquid in the front trunk. If liquid leak outside the front trunk, it may cause damage to the electric devices in the motor compartment.
- Do not press the front trunk cover or place any objects on the front trunk cover. The front trunk may be deformed or damaged.
- When closing the front trunk cover, be careful not to touch objects inside the trunk. Loaded objects or the front trunk may be deformed or damaged. and the front trunk cover may be opened during driving. Poor closing may cause noise or damage.

- Do not store plastic items in the front trunk when the outside temperature is high. If the inside temperature increases due to direct sunlight, the plastic items may be deformed or damaged.
- When the front trunk cover is frozen and does not open, lightly tap or indirectly warm the front trunk cover.
- Do not apply excessive force or use sharp objects on the front trunk cover. It may damage the front trunk cover.

## NOTICE

To avoid possible theft, do not leave valuables in the front trunk.

#### **POWER LIFTGATE**

# Power Liftgate Operation Condition

The power liftgate operates when the gear is in P (Park) with the vehicle turned on (READY indicator on). However, the power liftgate will operate regardless of the gear position when the vehicle is turned off (READY indicator off). Also, the liftgate can be opened only when vehicle speed is below 1.8 mph (3 km/h).

For safety, before attempting to open or close the liftgate, make sure the vehicle is in P (Park).

## **!** WARNING

 Never leave children or animals unattended in your vehicle. Children may operate the power liftgate. Doing so can result in injury to themselves or others and can damage the vehicle.



Make sure that there are no people or objects in the path of the power liftgate or smart liftgate prior to use. Serious injury, damage to the vehicle or damage to surrounding objects (for example, walls, ceilings, vehicles, etc.) may result if contact with the liftgate occurs.

## **NOTICE**

- Do not close or open the liftgate manually. This may cause damage to the power liftgate. If it is necessary to close or open the liftgate manually when the battery is discharged or disconnected, do not apply excessive force.
- Do not operate the power liftgate more than 10 times continuously when the vehicle is turned off (READY indicator off). Use the power liftgate with the vehicle turned on (READY indicator on) when the power liftgate is used repeatedly to prevent battery discharge.
- Do not leave the power liftgate open for a long period of time. This may drain the battery.
- Do not apply excessive force when the power liftgate is operating. Doing so could result in vehicle damage.



Always close the liftgate before driving. Do not grab or hold on to the liftgate support struts or they may be damaged. Deformation of the liftgate support struts may result in vehicle damage and personal injury.

 Do not modify or repair any part of the power liftgate by yourself. This must be done by an authorized retailer of Genesis Branded products.


- Do not operate the power liftgate under the following conditions.
   The power liftgate may not operate properly.
  - One side of the vehicle is lifted to inspect the vehicle or change a tire
  - Parking on an uneven road such as a slope, etc.
- Close the liftgate completely and lock all doors and liftgate using the central door lock button before using an automatic car wash.
- Do not spray high pressure water directly on the power liftgate outside open/close button. The liftgate may open unintentionally.



### Information

- If the liftgate is not fully closed and vehicle speed is at or above 1.8 mph (3 km/h), a warning will sound 10 times.
   Immediately park the vehicle at a safe place, close the liftgate, and check that the liftgate open warning on the instrument cluster is turned off.
- In cold and wet climates, the outside power liftgate open/close button may not work properly due to freezing conditions. If this occurs, remove the ice before using the outside power liftgate open/close button or use the power liftgate open/close button on the smart key or the instrument panel.
- Operating the power liftgate more than 5 times continuously could cause damage to the operating motor. If this occurs, the power liftgate will not operate to prevent the motor from overheating. If any of the power liftgate buttons are pressed to try to open the liftgate, the chime will sound 3 times, but the liftgate will remain closed. Allow the power liftgate system to cool for about 1 minute before operating the system again.

#### Operating the Power Liftgate Power liftgate open/close button (Smart key, Instrument panel)





When the liftgate is closed, press the power liftgate open/close button for 1 second. The power liftgate opens or closes with a warning sound.

While the liftgate is opening or closing, press the button to stop liftgate operation.

Also, if the smart key is not within operation range from the vehicle, power liftgate operation will stop with a warning sound for 5 seconds.

# Power liftgate open/close button (Outside the power liftgate)



When the liftgate is closed, press the power liftgate open/close button to open the liftgate.

If the vehicle is locked, press the power liftgate open/close button with the smart key in your possession.

If the liftgate is unlocked, the liftgate will open or close with a warning sound when the power liftgate open/close button is pressed without carrying the smart key.

# Power liftgate open/close button (Inside the power liftgate)



Press the power liftgate open/close button. The liftgate opens or closes automatically.

# Power liftgate lock button (Inside the power liftgate)



Press the power liftgate lock button while carrying the smart key. The liftgate closes and locks automatically. Additionally, all doors will lock. The liftgate can be closed and locked, and all doors locked only when the button is pressed while the vehicle is turned off (READY indicator off).

#### Automatic reverse

During power liftgate operation if the power liftgate senses any obstacle, the liftgate will stop or will fully open. The automatic reverse feature may not operate properly, or it may operate unexpectedly under the following circumstances:

- The automatic reverse feature may not detect the resistance if the detected resistance is below a certain level, or if the liftgate is almost fully closed near the latched position.
- The automatic reverse feature may operate if a strong impact is applied with no obstructions placed.

## A

## WARNING

Never intentionally place any object or part of your body in the path of the power liftgate to make sure the automatic reverse feature operates. Serious injury, or damage to the vehicle or object may occur.



#### Information

The power liftgate may stop operating if the automatic reverse feature operates more than two times while attempting to open or close the liftgate. If this occurs, carefully open or close the liftgate manually, and then after 30 seconds try to operate the power liftgate automatically again.

#### **Setting the Power Liftgate**

To use each feature, you must select the opening speed and opening height from the settings menu. Deselect the settings when you do not want to use the feature.

#### Power liftgate opening speed

To adjust the power liftgate speed, select Setup > Vehicle > Door/Liftgate > Power Liftgate Speed > Fast/Slow in the infotainment system. (Default setting is 'Fast'.)

#### Power liftgate opening height

To adjust the power liftgate opening height, select Setup > Vehicle > Door/Liftgate > Power Liftgate Opening Height > Full Open/Level 3/Level 2/Level 1/User Height Setting in the infotainment system.

#### User height setting

- 1. Position the liftgate manually to the height you prefer.
- Press the power liftgate open/close button located inside the liftgate for more than 3 seconds.
- If 'User Height Setting' is selected for the power liftgate opening height, the power liftgate will automatically open to the height manually set by you.

## *i* Information

- If the power liftgate opening height has not been manually set, the power liftgate will fully open when 'User Height Setting' from the infotainment system is selected.
- If one of the height setting (Full Open/ Level 3/Level 2/Level 1) is selected from the settings menu in the infotainment system, and then 'User Height Setting' is selected, the liftgate will open to the height manually set by you.
- The power liftgate opening speed and opening height settings change according to the linked User Profile. If the User Profile is changed, power liftgate opening speed and opening height settings will change accordingly.
- The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

## **Resetting the Power Liftgate**



To reset the Power Liftgate:

- With the vehicle turned off or on (READY indicator off or on), put the gear in P (Park).
- Press the power liftgate open/close inner button (A) and outer button (B) simultaneously until a chime sounds.
- 3. Slowly close the liftgate manually.
- 4. Press the power liftgate open/close outer button (B). The power liftgate will open with a chime sound. Wait until the liftgate fully opens to complete resetting. If the liftgate stops before it is fully open, resetting cannot be completed.

## *i* Information

- If the power liftgate is not reset after the vehicle battery is disconnected or discharged, or the power liftgate fuse is blown, the power liftgate may not operate normally.
- If the power liftgate does not operate properly after the above procedure, have the system inspected by an authorized retailer of Genesis Branded products.

#### Emergency Liftgate Safety Release



To unlock and open the liftgate manually from inside the cargo area, perform the following procedure:

- 1. Remove the cover at the bottom of the liftgate.
- 2. Slide the latch in the direction of the arrow to unlock the liftgate.
- 3. Push the liftgate to open.

## **MARNING**

- For emergencies, be fully aware of the location of the emergency liftgate safety release latch in the vehicle and how to open the liftgate if you are accidentally locked in the cargo area.
- No one, including animals, should be allowed to occupy the cargo area of the vehicle at any time. The cargo area is a very dangerous location in the event of an accident.
- Use the release latch for emergencies only. Use extreme caution, especially while the vehicle is in motion.

### **SMART LIFTGATE (IF EQUIPPED)**



On a vehicle equipped with a smart key, the liftgate can be opened with handsfree activation using the smart liftgate system.

#### **Using Smart Liftgate**

The hands-free smart liftgate system can be used when:

- The smart liftgate option is enabled in the Settings menu in the infotainment system.
- The smart liftgate is activated 15 seconds after all the doors are closed and locked.
- The smart liftgate opens when the smart key is detected in the area behind the vehicle for 3 seconds.

## Information

The smart liftgate will does not operate when:

- · A door is not locked or closed.
- The smart key is detected within 15 seconds from when the doors were closed and locked.
- The smart key is detected within 15 seconds after the doors are closed and locked, and within 60 inches (1.5 m) from the front door handles. (for vehicles equipped with Welcome Mirror).
- · The smart key is in the vehicle.
- · The vehicle is being charged.

#### 1. Settings

To use smart liftgate, it must be enabled from the Settings menu in the infotainment system.

Select: Setup > Vehicle > Door/ Liftgate > Smart Liftgate

## i

#### Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

#### 2. Detect and Alert

The smart liftgate detecting area extends about 20-40 inches (50-100 cm) behind the vehicle. If you are positioned in the detecting area and are carrying the smart key, the hazard warning lights blink and the chime sounds before opening.

## i

### Information

If you unintentionally enter the detecting area and the hazard warning lights and chime starts, move away from the vehicle with the smart key. The liftgate remains closed.

#### 3. Automatic opening

After the hazard warning lights blink and the chime sounds 6 times, the smart liftgate opens.

### **Deactivating Smart Liftgate**

If you press any button on the smart key during the Detect and Alert stage, the smart liftgate is deactivated.

#### Using the smart key:

- If you press the door unlock button, the smart liftgate is deactivated temporarily. If you do not open any door for 30 seconds, the smart liftgate is activated again.
- If you press the liftgate open button for more than 1 second, the liftgate opens.
- The smart liftgate is still activated if you press the door lock button or liftgate open/close button as long as the smart liftgate is not in the Detect and Alert stage.

### **Detecting Area**



- The smart liftgate detecting area extends about 20-40 inches (50-100 cm) behind the vehicle. If you are positioned in the detecting area and are carrying the smart key, the hazard warning lights will blink and the chime will sound for about 3 seconds to alert you that the liftgate will open.
- The alert stops once the smart key is moved outside of the detecting area within the 3 second period.

## *i* Information

- Smart liftgate may not operate properly if any of the following occur:
  - The smart key is close to a radio transmitter such as a radio station or an airport which can interfere with normal operation of the transmitter.
  - The smart key is near a mobile two way radio system or a mobile phone.
  - Another vehicle's smart key is being operated close to your vehicle.
- Smart liftgate detecting area may change when:
  - The vehicle is parked on an incline or slope.
  - One side of the vehicle is raised or lowered relative to the opposite side.

#### **CHARGING DOOR**

## **Opening the Charging Door**



- 1. Parking brake is applied automatically when shifting to P (Park).
- 2. Shift to P (Park), and turn off the vehicle.
- Push the charging door where the triangle symbol (1) is located. The charging door opens only when the vehicle is unlocked.
- 4. Remove the inlet cover (2).



#### Information

If you cannot open the charging door due to freezing weather, tap lightly or remove any ice near the charging door. Do not try to forcibly open the charging door.

## **Closing the Charging Door**



- 1. Install the charging inlet cover.
- 2. Close the charging door until it is latched securely.

For more information, refer to the "Electric Vehicle Guide" provided in the front of the owner's manual.

### **HEAD-UP DISPLAY (IF EQUIPPED)**



The Head-Up Display is an optional feature that allows the driver to view information projected onto a transparent screen while still keeping your eyes safely on the road ahead while driving.

### **Head-up Display Settings**



OJKEV052057L

 Head-up display can be enabled from the Settings menu in the infotainment system.

#### Select: Setup > Vehicle > Head-Up Display > Enable Head-Up Display

 After turning on the head-up display, you can change the settings of 'Display Control' and 'Content Selection' of the Head-Up Display.



The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

## **Head-up Display Information**



- (1) Turn by Turn (TBT) navigation information
- (2) Traffic signs or speed limit
- (3) Speedometer
- (4) SCC set speed information
- (5) SCC vehicle distance information
- (6) Lane Following Assist information
- (7) Lane Safety information
- (8) Blind-Spot Safety information
- (9) Highway Auto Speed Change information
- (10) Highway Driving Assist information
- (11) Surrounding vehicles

# Precautions while Using the Head-up Display

- It may sometimes be difficult to read information on the Head-Up Display in the following situations:
  - The driver is improperly positioned in the driver's seat
  - The driver wears polarizing-filter sunglasses
  - An object is located above the head-up display cover
  - The vehicle is driven on a wet road
  - Any improper lighting accessory is installed inside the vehicle, or there is incoming light from outside of the vehicle
  - The driver wears glasses
  - The driver wears contact lenses

When it is difficult to read the head up display information, adjust the image height or brightness level from the Settings menu in the infotainment system.

- Make sure to stop the vehicle before adjusting the settings.
- Do not tint the front windshield glass or add other types of metallic coating. Otherwise, the head-up display image may be invisible.
- Do not place any accessories on the dashboard or attach any objects on the windshield glass.
- When replacing the front windshield glass, replace it with a windshield glass designed for the head-up display operation. Otherwise, duplicated images may be displayed on the windshield glass.



### ! WARNING

The warning information of Blind Spot Safety on the Head-Up Display are supplemental. Do not solely depend on function to change lanes. Always take a look around before changing lanes.



#### Information


Head-up Display includes GPL, LGPL, MPL and other open source license softwares. All license notices including related source code are provided at http://www.mobis.co.kr/opensource/list.do.

If the driver requests on-board software open source code via MOBIS\_OSSrequest@mobis.co.kr within 3 years after buying this product, a CD-ROM or other storage device will be sent with the minimum cost covering storage device cost and delivery cost.

#### **EXTERIOR LIGHTS**

### **Lighting Control**

To operate the lights, turn the knob at the end of the control lever to one of the following positions:



- 1. OFF
- 2. AUTO headlight
- 3. Parking light
- 4. Headlight


#### Daytime Running Light (DRL)

The Daytime Running Lights (DRL) can make it easier for others to see the front of your vehicle during the day, especially after dawn and before sunset.

The DRL system will turn the dedicated light OFF when:

- The headlights are ON.
- The parking brake is applied.
- The vehicle is turned off.

#### AUTO headlight



The parking light and headlight will be turned ON or OFF automatically depending on the amount of daylight as measured by the ambient light sensor (1) at the upper end of the windshield glass.

Even with the AUTO headlight feature in operation, it is recommended to manually turn ON the headlights when driving at night or in a fog, driving in the rain, or when you enter dark areas, such as tunnels and parking facilities.

## NOTICE

- Do not cover or spill anything on the sensor (1) located at the upper end of the windshield glass.
- Do not clean the sensor using a window cleaner, the cleanser may leave a light film which could interfere with sensor operation.
- If your vehicle window tint or other types of metallic coating on the front windshield, the AUTO headlight system may not work properly.

#### Parking light (⊅€)



The parking light, license plate light and instrument panel light are turned ON.

#### Headlight (≦□)



The headlight, parking light, license plate light and instrument panel light are turned ON.

## *i* Information

The Start/Stop button must be in the ON position to turn on the headlight.

## **High Beam Operation**



To turn on the high beam headlight, push the lever away from you. The lever will return to its original position.

The high beam indicator will light when the headlight high beams are switched on.

To turn off the high beam headlight, pull the lever towards you. The low beams will turn on.



To flash the high beam headlight, pull the lever towards you, then release the lever. The high beams will remain ON as long as you hold the lever towards you.

# Turn Signals and Lane Change Signals



To signal a turn, push down on the lever for a left turn or up for a right turn in position (A).

If an indicator stays on and does not flash or if it flashes abnormally, one of the turn signal bulbs may be burned out and will require replacement.

#### One touch turn signal

To use One Touch Turn Signal push the turn signal lever up or down to position (B) and then release it.

The lane change signals will blink 3, 5 or 7 times.

You can enable the One Touch Turn Signal function or choose the number of blinking by selecting Setup > Vehicle > Lights > One Touch Turn Signal (or Onetouch indicator) > 3 flashes/5 flashes /7 flashes/Off in the infotainment system.



### Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

#### **Battery Saver Function**

To prevent the battery from being discharging, the system automatically turns off the parking lights when the driver turns the vehicle off and opens the driver's door.

To keep the lights on when the vehicle is turned off:

- (1) Open the driver's door.
- (2) Turn the parking lights OFF and ON again using the headlight switch.

#### **Headlight Delay Function**

If the Start/Stop button is in the ACC position or the OFF position with the headlights ON, the headlights (and/ or parking lights) remain on for about 5 minutes. However, if the driver's door is opened and closed, the headlights are turned off after 15 seconds. Also, with the vehicle off if the driver's door is opened and closed, the headlights (and/ or parking lights) are turned off after 15 seconds.

The headlights (and/or parking lights) can be turned off by pressing the lock button on the smart key twice or turning the headlight switch to the OFF or AUTO position.

You can enable the headlight delay function by selecting **Setup > Vehicle > Lights > Headlight Delay** in the infotainment system.



#### Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

## NOTICE

If the driver exits the vehicle through another door besides the driver door, the battery saver function does not operate and the headlight delay function does not turn OFF automatically.

This may cause the battery to discharge. To avoid battery discharge, turn OFF the headlights manually from the headlight switch before exiting the vehicle.

#### **Headlight Leveling Device**

Headlight leveling device automatically adjusts the headlight beam level according to the number of passengers and loading weight in the luggage area.lt also adjusts to the appropriate headlight beam level for various situations.



#### **WARNING**

If the function does not work properly, have the system inspected by an authorized retailer of Genesis Branded products. Do not attempt to inspect or replace the wiring yourself.

# Headlight Moisture Removal Function

When moisture fogs up inside of the headlight, if the headlight is on for certain period of time, the fan circulates the air inside to remove moisture. If moisture is not removed, have the vehicle inspected by an authorized retailer of Genesis Branded products.

### **Reverse Guide Light**

When the gear is in R (Reverse), the reverse light turns on and the reverse guide light at the back of the vehicle lights the floor.

The light informs nearby drivers that your vehicle is backing up.

#### INTERIOR LIGHTS



## ! WARNING

Do not use the interior lights when driving in the dark. The interior lights may obscure your view and cause an accident.

### NOTICE

Do not use the interior lights for extended periods when the vehicle is turned off or the battery will discharge.

### Interior Light AUTO Cut

The interior lights will automatically go off about 20 minutes after the vehicle is turned off and the doors are closed. If a door is opened, the light will go off 25 minutes after the vehicle is turned off. If the doors are locked by the smart key and the vehicle enters the armed stage of the theft alarm system, the lights will go off five seconds later.

### Front Lamps

Front map lamp ( 💢 🔍 ):



Touch either icons to turn the map lamp on or off. This light produces a spot beam for convenient use as a map lamp at night or as a personal lamp for the driver and the front passenger.

#### Door lamp ( ):

The front or rear room lamps come on when the front or rear doors are opened. When doors are unlocked by the smart key, the front and rear lamps come on for about 30 seconds as long as any door is not opened. The front and rear room lamps go out gradually after about 30 seconds when the door is closed. However, if the Start/Stop button is in the ON position or all doors are locked. the front and rear lamps will turn off. If a door is opened with the Start/Stop button in the ACC position or the OFF position, the front and rear lamps will stay on for about 5 minutes.

### Room lamp ( )

Press the button to turn ON the room lamp for the front/rear seats.

## **Rear Lamps**



[A]: Room lamp (without sunroof)

· / 맛 굯:

Touch the icon to turn either lamp on or off.

· <u>\</u>:

Touch the icon to turn the mood lamp on or off.



[B]: Personal lamp (with sunroof)

· ※:

Press the button to turn the lamp on or off.

## **Vanity Mirror Lamp**




Opening the lid of the vanity mirror will automatically turn on the mirror lamp.

## **Glove Box Lamp**



The glove box lamp turns on when the glove box is opened.

#### Door Handle Lamp/Mood Lamp/Door Courtesy Lamp (if equipped)



- Door handle lamp (A):
   The lamp turns on when the parking lights are on.
- Mood lamp (B):
   The lamp turns on when Setup> Vehicle > Lights > Ambient Light is selected from the infotainment system.
- Door courtesy lamp (C):
   The lamp turns on when a door is open and turns off when the door is closed.

## Cargo Area Lamp



The cargo area lamp turns on when the liftgate is opened.

# Puddle Light Welcome light



When all doors (and liftgate) are closed and locked, the puddle light will turn on for 15 seconds if the door is unlocked by the smart key or when you put your hand in the outside door handle with the smart key in possession.

For more information, refer to the "Welcome System" section in this chapter.

#### **Escort light**

When the Start/Stop button is in the OFF position and the driver's door is opened, the puddle light will turn on for 30 seconds. If the driver's door is closed within the 30 second period, the puddle light will turn off after 15 seconds. If the driver's door is closed and locked, the puddle light will turn off immediately.

The Puddle Light Escort Light will turn on only the first time the driver's door is opened after the vehicle is turned off (**READY** indicator off).

#### **Welcome System**



Welcome system helps keep the driver visible by turning on vehicle lights when the driver approaches the vehicle.

#### Puddle light and door handle light

When all the doors (and liftgate) are closed and locked, the puddle light and door handle light will turn on for about 15 seconds if any of the below is performed.

- When the door unlock button is pressed on the smart key.
- When you put your hand in the outside door handle with the smart key in possession.
- If Setup > Vehicle > Lights > Welcome Mirror/Light > Enable on Driver Approach is selected from the Settings menu in the infotainment system, the lamps will turn on when the vehicle is approached with the smart key in possession.

## **information**

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

#### Headlight and parking light

When the light switch is ON, and all the doors (and liftgate) are closed and locked, the headlight and parking light will turn on for about 15 seconds if the door unlock button is pressed on the smart key. Note that if the light switch is in the AUTO position, the headlight and parking light will turn on only when it is dark outside.

Select **Setup > Vehicle > Lights > Headlight Delay** from the Settings menu to turn on this function.

#### Interior lamp

When the interior lamp switch is in the position and all doors (and liftgate) are closed and locked, the room lamp will come on for 30 seconds if any of the below is performed.

- When the door unlock button is pressed on the smart key.
- When you put your hand in the outside door handle while carrying the smart key.

At this time, if you press the door lock or unlock button on the smart key the lamps will turn off immediately.

#### **HIGH BEAM ASSIST (HBA)**



High Beam Assist will automatically adjust the headlight range (switches between high beam and low beam) depending on the brightness of detected vehicles and certain road conditions.

#### **Detecting sensor**



[1]: Front view camera

The front view camera is used as a detecting sensor to detect ambient light and brightness while driving.

Refer to the picture above for the detailed location of the detecting sensor.

## NOTICE

- Always keep the front view camera in good condition to maintain optimal performance of High Beam Assist.
- For more information on the precautions of the front view camera, refer to the "Forward Collision-Avoidance Assist (FCA)" section in chapter 7.

### **High Beam Assist Setting**



With the Start/Stop button in the ON position, select **Setup > Vehicle > Lights > High Beam Assist** from the Settings menu to turn on High Beam Assist and deselect to turn off the function.



For your safety, change the Settings after parking the vehicle at a safe location.

## High Beam Assist Operation Display and control

- After selecting 'High Beam Assist' in the Settings menu, High Beam Assist will operate by following the procedure below.
  - Place the headlight switch in the AUTO position and push the headlight lever towards the instrument cluster. The High Beam Assist (氣) indicator light will illuminate on the cluster and High Beam Assist will be enabled.
  - When High Beam Assist is enabled, high beam will turn on when vehicle speed is above 25 mph (40 km/h). When vehicle speed is below 15 mph (25 km/h), high beam will turn off.
  - The High Beam (
     im) indicator light will illuminate on the cluster when high beam is on.
- When High Beam Assist is operating, if the headlight lever or switch is used, High Beam Assist operates as follow:
  - If the headlight lever is pulled towards you when the high beam is off, the high beam will turn on without High Beam Assist canceled. When you let go of the headlight lever, the lever will move to the middle and the high beam will turn off.
  - If the headlight lever is pulled towards you when the high beam is on by High Beam Assist, low beam will turn on and the High Beam Assist will turn off.
  - If the headlight switch is placed from AUTO to another position (headlight/parking light/off), High Beam Assist will turn off and the corresponding light will turn on.

- When High Beam Assist is operating, high beam switches to low beam if any of the following conditions occur:
  - When the headlight of an oncoming vehicle is detected.
  - When the tail light of a vehicle in front is detected.
  - When the headlight or tail light of a motorcycle or a bicycle is detected.
  - When the surrounding ambient light is bright enough that high beams are not required.
  - When streetlights or other lights are detected.




#### Information

The images and colors in the instrument cluster may differ depending on the cluster type or theme selected from the settings menu.

# High Beam Assist Malfunction and Limitations

High Beam Assist malfunction



OJWEV051094L

When High Beam Assist is not working properly, the 'Check High Beam Assist system' warning message will appear and \( \frac{\Lambda}{\text{ warning light will illuminate on the instrument cluster. Have the vehicle inspected by an authorized retailer of Genesis Branded products.

### Limitations of High Beam Assist

High Beam Assist may not work properly in the following situations:

- The headlights from an oncoming or front vehicle is damaged or out of the detection range.
- Headlight of an oncoming or front vehicle is covered with dust, snow or water.
- There are lights that have a similar shape as a vehicle's light ahead.
- Headlights have been damaged or not repaired properly.
- Headlights are not aimed properly.
- Driving on a narrow-curved road, curved road, rough road, uphill or downhill.

- Vehicle in front is partially visible on a crossroad or curved road.
- There is a traffic light, reflecting sign, flashing sign or mirror ahead.
- There is a temporary reflector or flash ahead (construction area).
- The road conditions are bad such as being wet, iced or covered with snow.
- A vehicle suddenly appears from a curve.
- The vehicle is tilted from a flat tire or is being towed.
- The headlights from an oncoming or front vehicle is not detected because of exhaust fumes, smoke, fog, snow, blizzard, water spray on the road, or windshield condensation, etc.

## (i)

#### Information

For more information on the limitations of the Front View Camera, refer to the "Forward Collision-Avoidance Assist (FCA)" section in chapter 7.



#### **WARNING**

- At times, High Beam Assist may not work properly High Beam Assist is for your convenience only. It is the responsibility of the driver for safe driving practices and always check the road conditions for your safety.
- When High Beam Assist does not operate properly, change the headlight position manually between high beam and low beam.

#### WIPERS AND WASHERS



### **Front Windshield Wipers**

Operates as follows when the Start/Stop button is in the ON position.

MIST: For a single wiping cycle, push

the lever upward and release. The wipers will operate continuously if the lever is held in this position.

OFF: Wiper is not in operation.

AUTO: The rain sensor located on the

upper end of the windshield glass senses the amount of rainfall and controls the wiping cycle for the proper interval. The more it rains, the faster the wiper operates. When the rain stops, the wiper stops. To vary the speed setting, turn the speed control knob.

LO: The wiper runs at a lower speed.
HI: The wiper runs at a higher speed.

# *i* Information

If there is heavy accumulation of snow or ice on the windshield, defrost the windshield for about 10 minutes, or until the snow and/or ice is removed before using the windshield wipers to ensure proper operation.

If you do not remove the snow and/or ice before using the wiper and washer, it may damage the wiper and washer system.

#### AUTO (Automatic) control



The rain sensor located on the upper end of the windshield glass senses the amount of rainfall and controls the wiping cycle for the proper interval.

The wiper operation time will be automatically controlled depends on rainfall.

When the rain stops, the wiper stops.

To vary the sensitivity setting, turn the sensitivity control knob.

If the wiper switch is set in AUTO mode when the Start/Stop button is in the ON position, the wiper will operate once to perform a self-check of the system. Set the wiper to the OFF position when the wiper is not in use.

# **WARNING**

To avoid personal injury from the windshield wipers, when the vehicle is running and the windshield wiper switch is placed in the AUTO mode:

- Do not touch the upper end of the windshield glass facing the rain sensor.
- Do not wipe the upper end of the windshield glass with a damp or wet cloth.
- Do not put pressure on the windshield glass.

## NOTICE

- When washing the vehicle, set the wiper switch in the OFF position to stop the auto wiper operation. The wiper may operate and be damaged if the switch is set in the AUTO mode while washing the vehicle.
- Do not remove the sensor cover located on the upper end of the passenger side windshield glass.
   Damage to system components could occur and may not be covered by your vehicle warranty.
- Because of using a photo sensor, temporary malfunction could occur according to sudden ambient light change made by stone and dust while driving.

#### **Front Windshield Washers**



In the OFF position, pull the lever gently toward you to spray washer fluid on the windshield and to run the wipers 1-3 cycles. The spray and wiper operation will continue until you release the lever. If the washer does not work, you may need to add washer fluid to the washer fluid reservoir.

# Recirculating air when washer fluid is used

When washer fluid is used, in order to reduce any objectionable scent of the washer fluid from entering the cabin, recirculation mode and air conditioning are automatically activated depending on the outside temperature. If you select fresh mode while the function is operating, the function will resume after a certain amount of time. It may not work in some conditions such as cold weather or vehicle OFF.

For more information, refer to the "Climate Control Additional Features" section in this chapter.




## WARNING

When the outside temperature is below freezing, ALWAYS warm the windshield using the defroster to help prevent the washer fluid from freezing on the windshield and obscuring your vision which could result in an accident and serious injury or death.

#### NOTICE

- To prevent possible damage to the washer pump, do not operate the washer when the fluid reservoir is empty.
- To prevent possible damage to the wipers or windshield, do not operate the wipers when the windshield is dry.
- To prevent damage to the wiper arms and other components, do not attempt to move the wipers manually.
- To prevent possible damage to the wipers and washer system, use antifreezing washer fluids in the winter season or cold weather.

## **Rear Window Wiper and Washer**



The rear window wiper and washer switch is located at the end of the wiper and washer switch lever. Turn the switch to the desired position to operate the rear wiper and washer.

HI: High wiper speed LO: Low wiper speed

OFF: Off



Push the lever away from you to spray rear washer fluid and to run the rear wipers 1-3 cycles. The spray and wiper operation will continue until you release the lever.

#### Auto rear wiper

The rear wiper will operate while the vehicle is in reverse with the front wiper ON by selecting the function from the Settings menu in the infotainment system.

Select: Setup > Vehicle > Convenience > Auto Rear Wiper (in R)



#### Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the guick reference guide.

#### **AUTOMATIC CLIMATE CONTROL SYSTEM**

#### Front seat



#### [A] Front seat control

- (1) Driver's temperature control
- (2) Passenger's temperature control
- (3) Fan speed control
- (4) Driver's mode selection
- (5) Passenger's mode selection
- (6) AUTO (automatic control)
- (7) OFF (system off)
- (8) Front windshield defroster
- (9) Air intake control
- (10) SYNC

- (11) Rear window defroster
- (12) A/C (air conditioning)
- (13) Rear control
- (14) Driver's seat climate control
- (15) HEAT button

## [B] Rear seat control

- (1) Temperature control
- (2) Mode selection
- (3) AUTO
- (4) OFF (system off)
- (5) Climate control information screen

# *i* Information

Use a clean soft microfiber cloth to gently wipe any fingerprints off the touch screen.

## Rear Seat (if equipped)



- (1) Fan speed control
- (2) Temperature control
- (3) OFF (system off)

- (4) AUTO (automatic control)
- (5) Mode selection

## *i* Information

Temperature and Mode selection (air flow direction) can be controlled from the rear seat. However, if **Setup > Vehicle > Climate > Climate Features > Lock the Rear Climate Control** is selected, the rear climate control can be operated only from the front seat. Deselect 'Lock the Rear Climate Control' before using it from the rear seats.


# Automatic Temperature Control Mode

The Automatic Climate Control System is controlled by setting the desired temperature.

1. Select AUTO.

The mode selection, fan speed, air intake and air conditioning will be controlled automatically by the temperature setting you select.

 When the climate control system is being automatically controlled, fan speed can be selected (Low/Medium/ High).



- High: Use when quick heating or cooling is preferred with higher fan speed capability.
- Medium: Use when medium fan speed is preferred for cooling or heating with moderate fan speed capability.
- Low: Use when low fan speed is preferred for cooling or heating with lower fan speed capability.
- 3. Turn the temperature control knob to the desired temperature. If the temperature is set to the lowest setting (62 °F (17 °C)), the air conditioning system will operate continuously. After the interior has cooled sufficiently, adjust the knob to a higher temperature set point whenever possible.

To turn the automatic operation off, select any function of the following:

- Mode selection
- Front windshield defroster button (Press the button one more time to deselect the front windshield defroster function. The 'AUTO' sign will illuminate on the climate information screen once again.)
- Fan speed control
- A/C (air conditioning)

The selected function will be controlled manually while other functions operate automatically.

For your convenience and to improve the efficiency of the climate control, use the AUTO button and set the temperature to 72°F (22°C).

To change the temperature unit from °F to °C:

Select Setup > General > Unit >
Temperature Unit > °C/°F from the
Settings menu in the infotainment
system.

## i

#### Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the guick reference guide.

## *i* Information



Never place anything near the ambient light/solar sensor to ensure better control of the heating and cooling system.

# Manual Temperature Control Mode

The heating and cooling system can be controlled manually by pushing buttons other than the AUTO button. In this case, the system works sequentially according to the order of buttons selected.


When pressing any button except the AUTO button while using automatic operation, the functions not selected will be controlled automatically.

- 1. Start the vehicle.
- Set the mode to the desired position.
   To improve the effectiveness of heating and cooling, select the mode according to the following:
  - Heating: 🎝
  - Cooling: 🏏
- 3. Set the temperature control to the desired position.
- 4. Set the air intake control to Fresh or Recirculation mode.
- 5. Set the fan speed control to the desired speed.
- 6. If air conditioning is desired, turn the air conditioning system on.
- 7. Press the AUTO button to convert to full automatic control of the system.

The climate control system settings will be maintained, even when the vehicle is turned OFF. However, the climate control system settings will be initialized when the battery has been discharged, or when the cables have been disconnected.

In this case, adjust the climate control system settings again.

#### **Mode selection**




[A]: Front seat control, [B]: Rear seat control

#### Front seat mode selection

 Press the arrows on the climate control information screen to select air flow direction.

OJKEV052104N

- Press SYNC. The SYNC indicator light turns off, the air flow direction of the driver's seat, passenger seat, and rear seat can be controlled individually. However, passengers and rear seats cannot select \( \frac{1}{2} \).
- You may select 2-3 modes at the same time.



#### Rear seat mode selection

- Press the button to select the direction of the air flow to the desired position.
- You may select 2 modes at the same time.



Air flow direction

The mode selection icon or button controls the direction of the  $\operatorname{air}$  flow through the ventilation system.

· Front seat



Defrost (A, D)

Most of the air flow is directed to the windshield.



Face-level (B, D)

Air flow is directed toward the upper body and face. Additionally, each outlet can be controlled to direct the air discharged from the outlet.



• Floor-level (A, C, D)

Most of the air flow is directed to the floor, with a small amount of the air being directed to the windshield and side window defrosters.

· Rear seat



Face-level (E)

Air flow is directed toward the upper body and face.



• Floor-level (F)

Most of the air flow is directed to the floor.



#### Information

Two to three air flow modes can be selected at the same time.

#### Front windshield defroster



Defrost-level (A, D)

Press the button, and the indicator light on the button will illuminate and the windshield defroster indicator will appear on the climate control information screen.

Most of the air flow is directed to the windshield with a small amount of air directed to the side window defrosters.

When Defogging logic is enabled, Fresh mode is selected and air conditioning is selected according to outside temperature.

Press the button again, the indicator light will turn off and the previous settings will be selected.

#### Instrument panel vents





[A]: Front seat, [B]: Rear seat

The instrument panel vent air flow can be directed up/down or left/right using the vent adjustment lever.

The air flow can also be CLOSED using the vent adjustment lever. Move the lever away horizontally from the seat to close until the levers click and lock. Slightly move the lever toward the sitting position to unlock and open.

#### Temperature control





[A]: Front seat (Front seat control),

[B]: Front seat (Rear seat control),

[C]: Rear seat

Turn the knob to the right to increase the temperature. Turn the knob to the left to decrease temperature.

Also, press the  $\wedge$  or  $\vee$  icon to select the temperature for rear seats from the front seats.

The temperature can be increased or decreased by increments of 1°F (0.5°C) for each incremental location. When set to the lowest temperature setting, the air conditioning will operate continuously to quickly cool the interior of the vehicle initially. After interior temperature has been cooled down sufficiently, select AUTO and set the temperature to 72°F (22°C).

#### SYNC



# Adjusting the temperature and air flow direction equally

Press SYNC (indicator light ON), the rear seat's temperature and air flow direction will be adjusted same as the driver's control. You can also turn the SYNC function on or off by pressing the air flow direction of the driver's seat and the passenger seat at the same time on the front climate control information screen.

# Adjusting the temperature and air flow direction individually

Press SYNC (indicator light OFF), the front and rear seat's temperature and air flow direction will be adjusted individually.

#### Air intake control



Air intake control is used to select either Fresh mode (outside air) or Recirculation mode (cabin air).

#### Recirculation mode



When Recirculation mode is selected, air from the passenger compartment will be recirculated through the system and heated or cooled according to the function selected.

#### Fresh mode



When Fresh mode is selected, air enters the vehicle from outside and is heated or cooled according to the function selected.



Operating the system primarily in Fresh mode is recommended. Use Recirculation mode temporarily only when needed. Prolonged operation of the heater in Recirculation mode and without the air conditioning ON can cause fogging of the windshield. In addition, prolonged use of the air conditioning ON in Recirculation mode may result in excessively dry, dehumidified air in the cabin and may promote formation of musty vent odor due to stagnant air.

## ! WARNING

- Continued use of the climate control system operation in Recirculation mode for a prolonged period of time may cause drowsiness to the occupants in the cabin. This may lead to loss of vehicle control which may lead to an accident.
- Continued use of the climate control system operation in Recirculation mode with the air conditioning OFF may allow humidity to increase inside the cabin. This may cause condensation to accumulate on the windshield and obscure visibility.
- Do not sleep in your vehicle or remain parked in your vehicle with the windows up and either the heater or the air conditioning ON for prolonged periods of time. Doing so may increase the levels of carbon dioxide in the cabin which may lead to serious injury or death.

#### Fan speed control





[A]: Front seat, [B]: Rear seat

The fan speed can be set to the desired speed pressing the stored icon, or by turning the fan speed control knob.

More air is delivered with higher fan speeds.

Pressing the OFF icon or button turns off the fan.

The airflow in the front and rear seats is always operated in conjunction.



### Information

To help improve microphone voice input sound, fan speed may automatically slow down for a couple of minutes when you activate voice recognition or hands free.

### NOTICE

Operating the fan when the Start/ Stop button is in the ON position could cause the battery to discharge. Operate the fan when the vehicle is on (READY indicator on).

### **Driver only**



If you press the DRIVER ONLY icon (\$\mathbb{G}^{\text{RIVER}}\_{\text{ONLY}}\$) and the indicator light illuminates in the infotainment climate control screen, cold air mostly blows towards the driver's seat. However, some of the cold air may come out of other seating position ducts to keep indoor air pleasant.

If you use the DRIVER ONLY with no passenger in the front passenger seat, energy consumption is reduced.

DRIVER ONLY is turned off under the following conditions:

- · The front defroster is on.
- The DRIVER ONLY icon is repressed.
- The Passenger's mode selection is pressed.
- SYNC button is pressed.
- · Passenger's temperature is adjusted.

### Air conditioning



Press the A/C icon to manually turn the air conditioning on (indicator light ON) and off.

### **HEAT** button



Press the HEAT icon to turn the heater on (indicator light will illuminate).

Press the icon again to turn the heater off.

The air conditioner and heater uses energy from the high voltage battery. If you use the heater or air conditioner for too long, distance to empty can be reduced due to too much power consumption.


Turn off the heater and air conditioner if you do not need them.



### Information

If the vehicle is turned off after heating and cooling operation, a sound may be generated temporarily because the mode of the climate control system has changed.

### **OFF** mode





[A]: Front seat (Front seat control), [B]: Front seat (Rear seat control), [C]: Rear seat

Press the OFF icon or OFF button to turn the climate control system off. You can still operate mode selection and air intake control as long as the Start/Stop button is in the ON position.

### **System Operation**

### Cooling / Ventilation

- 1. Select the Face Level imode.
- Set the air intake control to fresh or recirculation mode.
- 3. Set the temperature control to the desired position.
- 4. Set the fan speed control to the desired speed.

### Heating

- 1. Select the Floor Level , mode.
- 2. Set the air intake control to fresh or recirculation mode.
- 3. Set the temperature control to the desired position.
- 4. Set the fan speed control to the desired speed.
- If desired, turn the air conditioning ON with the temperature control knob set to heat in order to dehumidify the air before it enters into the cabin.

If the windshield fogs up, select the Front Defrost mode.

### **Operation Tips**

- To keep dust or unpleasant fumes from entering the vehicle through the ventilation system, temporarily set the air intake control to the recirculation mode. Return the control to Fresh mode when the unpleasant air outside has diminished. This will help keep the driver alert and comfortable.
- To help prevent the inside of the windshield from fogging, set the air intake control to fresh mode and the fan speed to the desired position, turn on the air conditioning system, and adjust the temperature control to the desired temperature.

### Air conditioning

Your Genesis Branded Vehicle air conditioning system is filled with R-1234yf refrigerant.


- 1. Start the vehicle.
- 2. Press the air conditioning button.
- 3. Set the mode to the Face Level mode.
- 4. Set the air intake control to Recirculation mode temporarily to allow the cabin to cool quickly. When the desired temperature in the cabin is reached, change the air intake control back to Fresh mode.
- Adjust the fan speed control and temperature control to maintain maximum comfort.

When maximum cooling is desired, set the temperature control to the lowest position, then set the fan speed control to the highest setting. Air conditioning system operation tips

- If the vehicle has been parked in direct sunlight during hot weather, open the windows for a short time to let the hot air inside the vehicle escape.
- After sufficient cooling has been achieved, switch back from recirculation mode to fresh mode.
- To help reduce moisture inside of the windows on rainy or humid days, decrease the humidity inside the vehicle by operating the air conditioning system with the windows and sunroof closed.
- Use the air conditioning system every month only for a few minutes to ensure maximum system performance.
- If you operate air conditioner excessively, the difference between the temperature of the outside air and that of the windshield could cause the outer surface of the windshield to fog up, causing loss of visibility. In this case, set the mode selection to the position and fan speed control to the lowest speed.

### System Maintenance

Cabin air filter



[A]: Outside air, [B]: Recirculated air, [C]: Climate control air filter, [D]: Blower, [E]: Evaporator core, [F]: PTC & Inner condenser

The cabin air filter is installed under the front trunk cover. It filters the dust or other pollutants that enter the vehicle through the heating and air conditioning system.

Have the cabin air filter be replaced by an authorized retailer of Genesis Branded products according to the maintenance schedule. If the vehicle is being driven in severe conditions such as dusty or rough roads, more frequent cabin air filter inspections and changes are required.

If the air flow rate suddenly decreases, have the system inspected at an authorized retailer of Genesis Branded products.

# Checking the amount of air conditioner refrigerant and compressor lubricant

When the amount of refrigerant is low, the performance of the air conditioning is reduced. Overfilling also reduces the performance of the air conditioning system.

Therefore, if abnormal operation is found, have the system inspected by an authorized retailer of Genesis Branded products.

### NOTICE

It is important that the correct type and amount of oil and refrigerant is used. Otherwise, damage to the compressor and abnormal system operation may occur. To prevent damage, the air conditioning system in your vehicle should only be serviced by trained and certified technicians.

### NOTICE

- The refrigerant system should only be serviced by trained and certified technicians to insure proper and safe operation.
- The refrigerant system should be serviced in a well-ventilated place.
- The air conditioning evaporator (cooling coil) shall never be repaired or replaced with one removed from a used or salvaged vehicle and new replacement MAC evaporators shall be certified (and labeled) as meeting SAE Standard J2842.



### **WARNING**

Vehicles equipped with R-1234yf



Since the refrigerant is mildly flammable and operated at high pressure, the air conditioning system should only be serviced by trained and certified technicians. It is important that the correct type and amount of oil and refrigerant are used.

All refrigerants should be reclaimed with proper equipment.

Venting refrigerants directly to the atmosphere is harmful to individuals and environment. Failure to heed these warnings can lead to serious injuries.



Air Conditioning refrigerant label
You can find out which air conditioning
refrigerant is applied to your vehicle on
the label located inside of the hood.



Each symbols and specification on the air conditioning refrigerant label is represented as below:

- (1) Classification of refrigerant
- (2) Amount of refrigerant
- (3) Classification of compressor lubricant
- (4) Caution
- (5) Flammable refrigerant
- (6) To require registered technician to service air conditioning system

### WINDSHIELD DEFROSTING AND DEFOGGING

# **WARNING**

Windshield heating


Do not use the mposition during cooling operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield could cause the outer surface of the windshield to fog up, causing loss of visibility could cause an accident resulting in serious injury or death. In this case, set the mode selection button to the position and fan speed control knob to a lower speed.

- For maximum defrost performance, set the temperature control to the highest temperature setting and the fan speed control to the highest setting.
- If warm air to the floor is desired while defrosting or defogging, set the mode to the floor-defrost position.
- Before driving, clear all snow and ice from the windshield, rear window, side view mirrors, and all side windows.
- Clear all snow and ice from the hood and air inlet in the cowl grill to improve heater and defroster efficiency and to reduce the probability of fogging up the inside of the windshield.

### NOTICE

If the vehicle temperature is still cold after starting, then a brief vehicle warm up period may be required for the vented air flow to become warm or hot.

### To Defog Inside Windshield




- 1. Select the desired fan speed.
- 2. Select the desired temperature.
- 3. Press the defroster button ( m).
- 4. Fresh mode will be selected automatically.

Check to make sure the air intake control is in Fresh mode. If the air intake control indicator light is illuminated, press the button once to enable Fresh mode (indicator light OFF).

If the mosition is selected, the fan speed is automatically increased.

### **To Defrost Outside Windshield**



- 1. Set the fan speed to the highest (extreme right) position.
- 2. Set the temperature to the extreme hot (82 °F (27 °C)) position.
- 3. Press the defroster button (\(\pi\)).
- 4. Fresh mode will be selected automatically.

Check to make sure the air intake control is in Fresh mode. If the air intake control indicator light is illuminated, press the button once to enable Fresh mode (indicator light OFF).

If the mosition is selected, lower fan speed is adjusted to a higher fan speed.

### **Defogging Logic**

To reduce the probability of fogging up the inside of the windshield, the air intake or air conditioning are controlled automatically according to certain conditions such as (##) positions. To cancel or reset the defogging logic, do the following.

- 1. Press the Start/Stop button to the ON position.
- 2. Press the defroster button ( ) or ( ).
- While pressing the air conditioning button (A/C), press the air intake control button at least 5 times within 3 seconds.

The air intake control button indicator will blink 3 times to indicate that the defogging logic has been disabled. Repeat the steps again to re-enable the defogging logic.

If the battery has been discharged or disconnected, it resets to the defog logic status.

### **Rear Window Defroster**

### NOTICE

To prevent damage to the rear window defroster conducting elements bonded to the inside surface of the rear window, never use sharp instruments or window cleaners containing abrasives to clean the window.



The defroster heats the window to remove frost, fog and thin ice from the interior and exterior of the rear window, while the vehicle is on (READY indicator on).

- To activate the rear window defroster, press the rear window defroster button located in the center control panel. The indicator on the rear window defroster button illuminates when the defroster is ON.
- To turn off the defroster, press the rear window defroster button again.

### $\overline{i}$

### Information

- If there is heavy accumulation of snow on the rear window, brush it off before operating the rear defroster.
- The rear window defroster automatically turns off after about 20 minutes or when the Start/Stop button is in the OFF position.

# Side view mirror defroster (if equipped)

The side view mirror defrosters operate when you turn on the rear window defroster.

### **CLIMATE CONTROL ADDITIONAL FEATURES**



### Information

The settings menu described in the "Climate Control Additional Features" section may change after infotainment system software update. For more information, refer to the user's manual provided in the infotainment system and the quick reference quide.

### **Auto Defogging System**



Auto Defogging helps reduce the possibility of fogging up the inside of the windshield by automatically sensing the moisture on inside the windshield.

The Auto Defogging system operates when the heater or air conditioning is on.



### Information

The Auto Defogging system may not operate normally, when the outside temperature is below 14 °F (-10 °C).



When the Auto Defogging system operates, the indicator will illuminate.

If a high amount of humidity is detected in the vehicle, the Auto Defogging System will be enabled. The following steps will be performed automatically:

- Step 1) Air conditioning will turn ON.
- Step 2) Air intake control will change to Fresh mode.
- Step 3) Mode will change to defrost to direct airflow to the windshield.
- Step 4) Fan speed will be set to MAX.

If the air conditioning is off or recirculation mode is manually selected while Auto Defogging system is ON, the Auto Defogging system indicator blinks 3 times to signal that the manual operation has been canceled.

# Turning the Auto Defogging System On or Off

### **Climate control system**

Press the front windshield defroster button for 3 seconds when the Start/ Stop button is in the ON position. When the Auto Defogging system is turned off, the **ADS OFF** symbol blinks 3 times and "ADS OFF" appears on the climate control information screen.

When the Auto Defogging system is turned on, the **ADS OFF** symbol blinks 6 times without a signal.

#### Infotainment system

Auto Defogging system can be turned on and off by selecting Setup > Vehicle > Climate > Defog/Defrost Options > Auto Defog from the Settings menu.



### Information

- When the air conditioning is turned on by Auto Defogging system, if you try to turn off the air conditioning, the indicator blinks 3 times and the air conditioning does not turn off.
- To maintain the effectiveness and efficiency of the Auto Defogging system, do not select recirculation mode while the system is operating.
- When Auto Defogging system is operating, fan speed adjustment, temperature adjustment, and air intake control selection are all disabled.

### NOTICE

Do not remove the sensor cover located on the upper end of the windshield glass. Damage to system parts could occur and may not be covered by your vehicle warranty.

# A/C Automatic Drying (if equipped)

The A/C Automatic Drying feature operates the blower motor automatically 30 minutes after the vehicle is turned off. It can reduce odor inside the cabin by drying the remaining moisture in the air conditioner after use.

# Turning A/C Automatic Drying On or off

- On the infotainment system, swipe the Home screen to the left to display the All menus screen.
- On the All menus screen, select Setup > Vehicle > Climate > Climate Features.
- 3. Select **A/C Automatic Drying** to turn the feature on or off.

After turning on the feature, it operates as follows:

- When the vehicle is turned off and operation conditions are met, the A/C Automatic Drying indicator illuminates for about 10 seconds.
- When the blower motor automatically operates, the A/C Automatic Drying indicator blinks.
- When the A/C Automatic Drying feature operates, the air conditioner sets the fan speed to the third level, selects Fresh mode, and directs the air flow to the floor.

#### **Operating conditions**

The A/C Automatic Drying feature operates under the following conditions:

- 30 minutes have passed since the vehicle was turned off after using the air conditioning.
- The outside temperature is above a certain level.
- The 12 V battery level is sufficient.

#### **Non-operating conditions**

The A/C Automatic Drying feature stops operating under the following conditions:

- The A/C Automatic Drying feature has operated for 10 minutes.
- The Start/Stop button is pressed, or the vehicle is on (READY indicator on).
- The climate control system is operated remotely.

### i

### Information

- The A/C Automatic Drying feature reduces air conditioning odor but may not completely remove it.
- When the A/C Automatic Drying feature is operating, the Rear Occupant Alert (if equipped) does not operate.

### **Auto Dehumidify (if equipped)**

To increase cabin air quality and reduce windshield misting, recirculation mode switches off automatically after about 5 to 30 minutes, depending on the outside temperature, and the air intake will change to fresh mode.

### Turning Auto Dehumidify On or Off

#### Climate control system

no turn the Auto Dehumidify feature on or off, select Face level () mode and press the air intake control () button at least five times within four seconds while pressing the A/C icon. When Auto Dehumidify is turned on, the air intake control button indicator will blink 6 times. When turned off, the indicator will blink 3 times.

#### **Infotainment system**

Auto Dehumidify can be turned on and off by selecting Setup > Vehicle > Climate > Automatic Ventilation > Automatic Dehumidify from the Settings menu.



### Information

If the 12 V battery is discharged or disconnected, the settings for Auto Dehumidify needs to be reselected.

# Recirculating Air when Washer Fluid is Used

Recirculation mode automatically activates to reduce any objectionable scent of the washer fluid from entering the cabin when the windshield washer is used.

### Turning Activate upon Washer Fluid Use On or Off

### Climate control system

To turn the Activate upon Washer Fluid Use feature on or off, select Floor level (رم) mode, and then press the air intake control (رم) button four times within two seconds while pressing the A/C icon.

When Activate upon Washer Fluid Use ON is turned on, the air intake control button indicator will blink 6 times. When turned off, the indicator will blink 3 times.

#### Infotainment system

Activate upon Washer Fluid Use can be turned on and off by selecting Setup > Vehicle > Climate > Recirculate Air > Activate upon Washer Fluid Use from the Settings menu.

However, in cold weather to prevent the windshield from fogging up, the recirculation mode may not be selected.

# Automatic Controls Linked to Climate Control Settings (for driver's seat)

The temperature of the driver's seat warmer, air ventilated seat and heated steering wheel is automatically controlled depending on the inside and outside temperature of the vehicle when the vehicle is on (READY indicator on).

These features can be enabled from the Settings menu in the infotainment system.

Select: Setup > Vehicle > Seat >
Heated/Ventilated Features > Warmer/
Ventilation Features > Automatic
Controls Linked to Climate Control
Settings

For more information on Auto Comfort Control, refer to the "Seat Warmers" and "Air ventilation seats" section in chapter 3 and "Heated Steering Wheel" section in chapter 5.

### STORAGE COMPARTMENT



### ! WARNING

Never store cigarette lighters, propane cylinders, or other flammable/explosive materials in the vehicle. These items may catch fire and/or explode if the vehicle is exposed to hot temperatures for extended periods.



### ! WARNING

ALWAYS keep the storage compartment covers closed securely while driving. Items inside your vehicle are moving as fast as the vehicle. If you have to stop or turn quickly, or if there is a crash, the items may fly out of the compartment and may cause an injury if they strike the driver or a passenger.

### NOTICE

To avoid possible theft, do not leave valuables in the storage compartments.

### **Center Console Storage**



To open: Press the button.

#### **Glove Box**



The glove box can be locked and unlocked with the mechanical key (1).

To open:

Pull the lever (2).



### WARNING

ALWAYS close the glove box door after use.

An open glove box door can cause serious injury to the passenger in an accident, even if the passenger is wearing a seat belt.

### **Sunglass Holder**



### To open:

Push and release the cover and the holder will slowly open. Place your sunglasses in the compartment door with the lenses facing out.

#### To close:

Push back into position.

Make sure the sunglass holder is closed while driving.

### **⚠** WARNING

- Do not keep objects except sunglasses inside the sunglass holder.
   Such objects can be thrown from the holder in the event of a sudden stop or an accident, possibly injuring the passengers in the vehicle.
- Do not open the sunglass holder while the vehicle is moving. The side view mirror of the vehicle can be blocked by an open sunglass holder.
- Do not put the glasses forcibly into a sunglass holder. It may cause personal injury if you try to open it forcibly when the glasses are jammed in holder.

### **Mobile Phone Holder**



Store your phone or other small items while driving.


### NOTICE

The item you have stored such as a mobile phone may not fit in the mobile phone holder depending on the size or shape of the item. Do not forcibly push items into the holder and close the cover. The mobile phone holder may not open, or it may damage the stored item. In addition, do not forcibly open the mobile phone storage cover, when it is jammed with a stored item inside.

### INTERIOR FEATURES

### **Cup Holder**





[A]: Front seat, [B]: Rear seat

Cups or small beverages cups may be placed in the cup holders.


# **⚠** WARNING

- Avoid abrupt starting and braking when the cup holder is in use to prevent spilling your drink. If hot liquid spills, you could be burned. Such a burn to the driver could cause loss of vehicle control resulting in an accident.
- Do not place uncovered or unsecured cups, bottles, cans, etc., in the cup holder containing hot liquid while the vehicle is in motion. Injuries may result in the event of a sudden stop or collision.
- Only use soft cups in the cup holders. Hard objects can injure you in an accident.

### NOTICE

- Keep your drinks sealed while driving to prevent spilling your drink. If liquid spills, it may get into the vehicle's electrical/electronic system and damage electrical/electronic parts.
- When cleaning spilled liquids do not use hot air to blow out or dry the cup holder. This may damage the interior.
- Keep cans or bottles out of direct sun light and do not put them in a hot vehicle. Otherwise, they may explode.

### Sunvisor



To use the sunvisor, pull it downward. To use the sunvisor to block the sun from the side window, pull it downward, release it from the bracket (1) and swing it to the side (2) towards the window.

To use the vanity mirror, pull down the sunvisor and slide the mirror cover (3).

Adjust the sunvisor forward or backward (4) as needed. Use the ticket holder (5) to hold tickets.

Close the vanity mirror cover securely and return the sunvisor to its original position after use.



Do not block your view when using the sunvisor.

#### **Power Outlet**





[A]: Front seat, [B]: Cargo area

The power outlet is designed to provide power for mobile telephones or other devices designed to operate with vehicle electrical systems. The devices should draw less than 180 W with the vehicle is on (READY indicator on).

# **MARNING**

Avoid electrical shocks. Do not place your fingers or foreign objects (pin, etc.) into a power outlet or touch the power outlet with a wet hand.

### NOTICE

To prevent damage to the power outlets:

- Use the power outlet only when the vehicle is running and remove the accessory plug after use. Using the accessory plug for prolonged periods of time with the vehicle off may cause the battery to discharge.
- Only use 12 V electric accessories which are less than 180 W in electric capacity.
- Adjust the air conditioner or heater to the lowest operating level when using the power outlet.
- · Close the cover when not used.
- Some electronic devices can cause electronic interference when plugged into a vehicle's power outlet. These devices may cause excessive audio static and malfunctions in other electronic systems or devices used in your vehicle.
- Push the plug in as far as it goes. The plug may overheat and the fuse may open.
- Only connect devices with reverse current protection or the current from the device battery may cause the vehicle's electrical/electronic system to malfunction.

### **USB Charger (if equipped)**





[A]: Front, [B]: Rear

port after use.

The USB charger is designed to recharge batteries of small size electrical devices using a USB cable.

The electrical devices can be recharged when the Start/Stop button is in the ON or START position.

The battery charging state may be monitored on the electrical device.

Disconnect the USB cable from the USB

- A smartphone or a tablet PC may get warmer during the re-charging process. It does not indicate any malfunction with the charging system.
- A smartphone or a tablet PC that does not use a USB cable to charge should be charged using its own charger.
- Do not attempt to use the charging terminal to turn on an audio or to play media with the infotainment system.

### NOTICE

- Use the USB charger when the vehicle is on (READY indicator on).
   Using the USB charger for prolonged periods of time with the vehicle off (READY indicator off) could cause the battery to discharge.
- To prevent damage to the USB charger:
  - Do not insert foreign objects or spill liquid into the outlet. The USB charging terminal may be damaged.
  - Do not use devices with current consumption exceeding 2,100 mA (2.1 A).

## *i* Information

Charging may not be possible when using a Type-C converter sold by a mobile phone manufacturer or commercially available.

# Wireless Smartphone Charging System



[A]: Charging pad, [B]: Indicator light

### Charging smartphone

The wireless smartphone charging system charges only the Qi-enabled smartphones ( $\hat{\mathbf{q}}$ ). Read the label on the smartphone accessory cover or visit your smartphone manufacturer's website to check whether your smartphone supports the Qi technology.

The wireless charging process starts when you put a Qi-enabled smartphone on the wireless charging unit.

 The system is available when all doors are closed, and when the Start/ Stop button is in the ON (or START) position. 2. You can turn on or off the wireless charging function from the Settings menu in the infotainment system.

Select: Setup > Vehicle > Convenience > Wireless Charging System

The indicator light is orange when the smartphone is charging. The indicator light will turn blue when phone charging is complete.



- Remove other items, including the smart key from the wireless charging pad.
- The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

If your smartphone is not charging:

- Slightly change the position of the smartphone on the charging pad.
- Make sure the indicator light is orange.

The indicator light will blink orange for 10 seconds if there is a malfunction in the wireless charging system.

In this case, temporarily stop the charging process, and re-attempt to charge your smartphone again.

The system warns you with a message on the cluster display if the smartphone is still on the wireless charging unit after the vehicle is turned OFF and the front door is opened.

For some manufacturer's smartphones, the system may not warn you even though the smartphone is left on the wireless charging unit. This is due to the particular characteristic of the smartphone and not a malfunction of the wireless charging.

### i

### Information

- The wireless smartphone charging system may not support smartphones that do not meet the Qi specification (qi).
- When placing your smartphone on the charging pad, position the phone in the middle of the charging pad. If your smartphone is off to the side, the charging rate may be less and in some cases the smartphone may experience higher heat conduction.
- Wireless charging may stop temporarily when the smart key is used, or when starting the vehicle or locking/unlocking the doors.
- When charging certain smartphones, the charging indicator may not change to blue when the smartphone is fully charged.
- The wireless charging process may temporarily stop, when temperature abnormally increases inside the wireless smartphone charging system. The wireless charging process does not restart until the temperature falls.
- The wireless charging process may temporarily stop when there is any metallic item, such as coin, between the wireless smartphone pad and smartphone.

- When charging some smartphones with a self-protection feature, the wireless charging speed may decrease and the wireless charging may stop.
- If the smartphone has a thick case, it may not charge.
- If the smartphone is not completely contacting the charging pad, wireless charging may not operate properly.
- Some magnetic items such as credit cards, phone cards, or transit cards may be damaged if left with the smartphone during the charging process.
- When any smartphone without a wireless charging function or a metallic object is placed on the charging pad, a small noise may sound. This small sound is due to the sound because the vehicle discerns compatibility of the object placed on the charging pad. It does not affect your vehicle or the smartphone.
- Some smartphones may not charge depending on the internal structure of the smartphone. If this occurs, try charging the smartphone by moving it to the left or right side of the wireless charging pad. However, for some foldable smartphones that have magnets inside the smartphone, try charging the smartphone while holding it close to the left side of the wireless charging pad.
- If the Start/Stop button is in the OFF position, the charging stops.

### i

### Information

This device complies with Part 15 of the FCC rules. Operation is subject to the following three conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

# Vehicle to Load (V2L) (if equipped)



V2L(Vehicle to Load) is installed on the lower right side of the cargo area. V2L is a convenient feature which provides electricity to use diverse household electrical appliances in the vehicle.

For more information, refer to the "Vehicle to Load (V2L)" section in chapter 1.

### Clock

The clock can be set from the infotainment system.



### Information

For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.



### WARNING

Do not attempt to adjust the clock while driving. Doing so may result in distracted driving which may lead to an accident involving personal injury or death.

### **Coat Hook**



These hooks are not designed to hold large or heavy items.



### **WARNING**



Do not hang other objects such as hangers or hard objects except clothes. Also, do not put heavy, sharp or breakable objects in the clothes pockets. In an accident or when the curtain airbag is inflated, it may cause vehicle damage or personal injury.

### Floor Mat Anchor(s)

ALWAYS use the Floor Mat Anchors to attach the front floor mats to the vehicle. The anchors on the front floor carpet keep the floor mats from sliding forward.

## **WARNING**

Do not overlay additional mats or liners over the floor mats. If using All Weather mats, remove the carpeted floor mats before installing them. Only use floor mats designed to connect to the anchors.

### **M** WARNING

The following must be observed when installing ANY floor mat to the vehicle.


- Ensure to remove a protective film attached on the carpet before attaching a floor mat on the front floor carpet. Otherwise, the floor mat may move freely on the protective film and it could result in unintentional braking or accelerating.
- Ensure that the floor mats are securely attached to the vehicle's floor mat anchor(s) before driving the vehicle.
- Do not use ANY floor mat that cannot be firmly attached to the vehicle's floor mat anchors.
- Do not stack floor mats on top of one another (for example, all-weather rubber mat on top of a carpeted floor mat). Only a single floor mat should be installed in each position.

IMPORTANT Your vehicle was manufactured with driver's side floor mat anchors that are designed to securely hold the floor mat in place. To avoid any interference with pedal operation, Genesis Branded Vehicle recommends that the Genesis floor mat designed for use in your vehicle be installed.

# Rear Side Window Sunshades (if equipped)

Use the rear side window sunshade to block external light coming through the rear window glass.

#### Manual sunshades



- 1. Lift the sunshade by the handle (A).
- Hang the sunshade on both sides of the hook (B). If the sunshade is hung on one side of the hook, the sunshade may be wrinkled.

### NOTICE

- Do not hang any other object except the rear side window sunshade on the hooks.
- If you pull the rear side window sunshade or apply force to return the sunshade to its original position after use, you may find the sunshade wrinkled or out of shape. To lower the sunshade, be sure to put the handle downward and slowly return the sunshade to its original position.
- Sunshades may not work properly if foreign objects (coins, toys, cookies, etc.) are stuck in the door. Be careful that the foreign objects do not get into the door.

### Cargo Net Holder (if equipped)



To keep items from shifting in the cargo area, use the 4 holders located in the cargo area side trim to attach the cargo net.

Make sure the cargo net is securely attached to the holders in the cargo board.




### WARNING

Avoid eye injury. Do not overstretch the cargo net. Always keep your face and body out of the cargo net's recoil path. Do not use the cargo net when the strap has visible signs of wear or damage.

# Cargo Security Screen (if equipped)

Using the cargo security screen



- Pull the cargo security screen towards the rear of the vehicle by the handle (1).
- 2. Insert the guide pin (2) into the guides on both sides (3).



### Information

Pull out the cargo security screen with the handle in the center to prevent the guide pin from falling out of the guide.

When the cargo security screen is not in use:

Pull the cargo security screen backward and up to release it from the guides.

The cargo security screen automatically slides back in.



### Information

The cargo security screen may not automatically slide back in if the cargo security screen is not fully pulled out. Pull the cargo screen out all the way and then slowly allow the screen to retract back in.

### **MARNING**

- Do not place objects on the cargo security screen. Such objects may be thrown about inside the vehicle and possibly injure vehicle occupants during an accident or when braking.
- Never allow anyone to ride in the cargo area.
- Maintain the balance of the vehicle and locate the weight as forward as possible.

### Removing the cargo security screen



- Push one side of the cargo screen inward to compress the spring and release the screen from the vehicle.
- 2. While the spring is compressed, pull out the cargo security screen.
- 3. Open the cargo tray and keep the cargo security screen in the tray.

# Removing the cargo security screen from the cargo tray



1. Pull up the screen board.



2. Push in the guide pin.



3. While pushing the guide pin, pull out the cargo security screen.

### **EXTERIOR FEATURES**

### **Roof Side Rails**



If your vehicle is equipped with roof side rails, you can add crossbars as an accessory (not shown).

The crossbars are an accessory and are available at your local retailer of Genesis Branded products.

### NOTICE

- If the vehicle is equipped with a sunroof, do not position the cargo onto the roof side rails in such a way that it may interfere with sunroof operation.
- Always take precautions to make sure the cargo does not damage the roof.
- When carrying large objects on the roof side rails, make sure they do not exceed the overall roof length or width.
- When carrying cargo on the roof side rails, take necessary precautions to make sure the cargo does not damage the roof of the vehicle.
- When carrying large objects on the roof side rails, make sure they do not exceed the overall roof length or width.

# **WARNING**

 Loading cargo or luggage in excess of the specified weight limit on the roof side rails may damage your vehicle.

	220 lbs. (100 kg) NLY DISTRIBUTED
--	--------------------------------------

- Avoid sudden starts, braking, sharp turns, abrupt maneuvers, or high speeds that may result in loss of vehicle control or rollover resulting in a collision. The vehicle center of gravity is higher when items are loaded onto the roof side rails.
- Always drive slowly and turn corners carefully when carrying items on the roof side rails. Severe wind updrafts caused by passing vehicles or natural causes, can cause sudden upward pressure on items loaded on the roof side rails. This is especially true when carrying large, flat items such as wood panels or mattresses. This may cause the items to fall off the roof side rails and cause damage to your vehicle or others around you.
- To prevent damage or loss of cargo while driving, check frequently before or while driving to make sure the items on the roof side rails are securely fastened.

### **INFOTAINMENT SYSTEM**

### NOTICE

- If you install an aftermarket HID headlight, your vehicle's audio and electronic devices may not function properly.
- Prevent chemicals such as perfume, cosmetic oil, sun cream, hand cleaner, and air freshener from contacting the interior parts because they may cause damage or discoloration.

#### **USB Port**



You can use an USB cable to connect audio devices to the vehicle USB port.

### **Information**

When using a portable audio device connected to the power outlet, noise may occur during playback. If this happens, use the portable audio device's power source.

### **Antenna**



The shark fin antenna will receive AM, FM broadcast signals and transmit data.

### **Steering Wheel Remote Controls**



### NOTICE

Do not operate multiple audio remote control buttons simultaneously.

### VOLUME(VOL + / VOL -)(1)

- Rotate the VOLUME scroll up to increase volume.
- Rotate the VOLUME scroll down to decrease volume.

## *i* Information

You can set the volume level of each source (FM, AM, SXM, USB, BT, etc.) individually by adjusting the VOLUME scroll.

Then the infotainment system saves the last volume level of each source in the system sound settings.

If you change the source, the volume will revert to the previously set volume for that source.

### SEEK/PRESET $( \land / \lor )$ (2)

If the SEEK/PRESET switch is pressed up or down and held for 0.8 second or more, it will function in the following modes:

- · RADIO mode
  - It will function as the AUTO SEEK select button. It will SEEK until you release the button.
- MEDIA mode
   It will function as the FF/RW button.

If the SEEK/PRESET switch is pressed up or down, it will function in the following modes:

- RADIO mode
   It will function as the PRESET STATION UP/DOWN button.
- MEDIA mode
   It will function as the TRACK UP/DOWN button.

### **MODE** (3)

Press the MODE button to toggle through Radio modes.

### MUTE (**Y**) (4)

 Press the MUTE(M) button to mute or activate the sound.

For detailed information, scan the QR code in a separately supplied simple manual.

## *i* Information

For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

### **Infotainment System**



### **i** Information

For more information, refer to the user's manual provided in the infotainment system and the quick reference quide.

### **Voice Recognition**



# *i* Information

For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

### **Bluetooth® Wireless Technology**





- (1) Call / Answer / Call end button
- (2) Microphone

### *i* Information

For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.



To avoid driver distractions, do not excessively operate the device while driving the vehicle which may lead to an accident.

# Lexicon Premium Sound System (if equipped)



### CAUTION

Lexicon premium sound system is equipped with speaker grills made of stainless steel. The grill surface can be heated when the vehicle is exposed to hot weather for a long period of time. Keep away from the speaker grill when it is hot.

# 6. Driving Your Vehicle

Before Driving	6-4
Before Entering the Vehicle	6-4
Before Starting	6-4
Start/Stop Button	6-5
Start/Stop Button Positions	
Starting the Vehicle	6-7
Turning Off the Vehicle	
Remote Start	6-9
Shift By Wire	6-10
Shift By Wire Operation	
Cluster Display Message Information	6-15
Good Driving Practices	6-16
Regenerative Braking System (Paddle Shifter)	6-18
Using Regenerative Braking System	
Regenerative Braking System Limitations	6-19
One Pedal Driving	
Using i-PEDAL	6-21
Smart Regeneration System	6-22
Smart Regeneration System On/Off	
Smart Regeneration System Operating Condition	6-23
Smart Regeneration Level Settings	6-23
Pausing Smart Regeneration System	
Front Sensor	
System Check Message	
Smart Regeneration System Precautions	6-25

Braking System Power-assist Brakes Disc Brakes Wear Indicator. High Performance Brake Electronic Parking Brake (EPB). Auto Hold Brake Disc Cleaning Anti-lock Brake System (ABS).	.6-29 6-30 6-30 6-30 .6-34
Electronic Stability Control (ESC)	.6-39 6-42 6-43
Hill-Start Assist Control (HAC)	6-44 6-44
All Wheel Drive (AWD)	.6-47
Electronic Control Suspension	
Electronically Controlled Suspension with Road Preview	.6-52
Drive Mode Integrated Control System  Selecting Drive Mode  ECO, COMFORT, SPORT, SNOW Mode Features  Drive Modes Characteristic	.6-53 .6-53
Boost Mode Using Boost Mode Boost Mode Limitations	.6-55
Active Noise Control-road	

# 6. Driving Your Vehicle

Active Sound Design	6-56
Special Driving Conditions	6-57
Hazardous Driving Conditions	
Rocking the Vehicle	
Driving at Night	
Driving in the Rain	
Driving in Flooded Areas	
Highway Driving	
Reducing the Risk of a Rollover	6-59
Winter Driving Snow or Icy Conditions Winter Precautions	6-60
Trailer Towing	6-63
If You Decide to Pull a Trailer?	
Trailer Towing Equipment Driving with a Trailer	
Maintenance When Towing a Trailer	6-71
Vehicle Load Limit	
The Loading Information Label	6-72

### **BEFORE DRIVING**

### **Before Entering the Vehicle**

- Make sure all windows, side view mirror(s), and outside lights are clean and unobstructed.
- Remove frost, snow, or ice from both the front and rear windshield as well as the front side windows.
- Visually check the tires for uneven wear and damage.
- Check under the vehicle for any sign of leaks.
- Make sure there are no obstacles behind you if you intend to back up.

### **Before Starting**

- Make sure the hood, the liftgate, and the doors are securely closed and locked.
- Adjust the position of the seat and steering wheel.
- Adjust the inside rearview mirror and outer side view mirrors.
- Verify all the lights work.
- Fasten your seat belt. Check that all passengers have fastened their seat belts.
- Check the gauges and indicators in the instrument panel and the messages on the instrument display when the vehicle is in the ON position.
- Check that any items you are carrying are stored properly or fastened down securely.

# **⚠** WARNING

To reduce the risk of SERIOUS INJURY or DEATH, take the following precautions:

- ALWAYS wear your seat belt. All passengers must be properly belted whenever the vehicle is moving. For more information, refer to the "Seat Belts" section in chapter 3.
- Always drive defensively. Assume other drivers or pedestrians may be careless and make mistakes.
- Stay focused on the task of driving. Driver distraction can cause accidents
- Leave plenty of space between you and the vehicle in front of you.

### **MARNING**

NEVER drink or take drugs and drive.

Drinking or taking drugs and driving is dangerous and may result in an accident and SERIOUS INJURY or DEATH.

Drunk driving is the number one contributor to the highway death toll each year. Even a small amount of alcohol will affect your reflexes, perceptions and judgment. Just one drink can reduce your ability to respond to changing conditions and emergencies. Your reaction time gets worse with each additional drink.

Driving while under the influence of drugs is as dangerous as or more dangerous than driving under the influence of alcohol.

You are much more likely to have a serious accident if you drink or take drugs and drive. If you are drinking or taking drugs, don't drive. Do not ride with a driver who has been drinking or taking drugs. Choose a designated driver or call a taxi.

### START/STOP BUTTON



Whenever the front door is opened, the Start/Stop button will illuminate and will go off 30 seconds after the door is closed.



To turn the vehicle off in an emergency: Press and hold the Start/Stop button for more than two seconds OR Rapidly press and release the Start/Stop button three times (within three seconds).

If the vehicle is still moving, you can restart the vehicle without depressing the brake pedal by pressing the Start/Stop button with the gear in the N (Neutral) position.

## **MARNING**

- NEVER press the Start/Stop button while the vehicle is in motion except in an emergency. This will result in the vehicle turning off and loss of power assist for the steering and brake systems. This may lead to loss of directional control and braking function, which could cause an accident.
- Before leaving the driver's seat, always make sure the gear is in the P (Park) position, set the parking brake, press the Start/Stop button to the OFF position, and take the Smart Key with you. Unexpected vehicle movement may occur if these precautions are not followed.
- NEVER reach through the steering wheel for the Start/Stop button or any other control while the vehicle is in motion. The presence of your hand or arm in this area may cause a loss of vehicle control resulting in an accident.

### **Start/Stop Button Positions**

Button Position	Action	Notes
OFF	To turn off the vehicle, press the Start/Stop button with the vehicle shifted to P (Park).  Note if the Start/Stop button is pressed with the vehicle shifted to D (Drive), R (Reverse) or N (Neutral), the gear will automatically shift to P (Park).  If the Start/Stop button is pressed with the gear shifted to N (Neutral), the Start/Stop button will change to the ACC position.  The steering wheel locks to protect the vehicle from theft.	If the steering wheel is not locked properly when you open the driver's door, the warning chime sounds.
ACC	Press the Start/Stop button when the button is in the OFF position without depressing the brake pedal. Some of the electrical accessories are usable. The steering wheel unlocks.	<ul> <li>If you leave the Start/Stop button in the ACC position for more than one hour, the battery power turns off automatically to prevent the battery from discharging.</li> <li>If the steering wheel does not unlock properly, the Start/Stop button does not work. Press the Start/Stop button while turning the steering wheel right and left to release.</li> </ul>
ON	Press the Start/Stop button while it is in the ACC position without depressing the brake pedal. The warning lights can be checked before the vehicle is started.	Do not leave the Start/Stop button in the ON position when the vehicle is not running to prevent the battery from discharging.
START	To start the vehicle, depress the brake pedal and press the Start/ Stop button with the gear shifted to the P (Park) position. For your safety, start the vehicle with the gear shifted to the P (Park) position.	If you press the Start/Stop button without depressing the brake pedal, the vehicle does not start and the Start/Stop button changes as follows:  OFF > ACC > ON > OFF or ACC

### *i* Information

To prevent vehicle battery discharge, the Start/Stop button changes to the OFF position when the Start/Stop button is in the ACC or ON position with the gear in P (Park) for a certain period of time. When the function operates, the tail lights will turn off. To use the tail lights again, turn the headlight switch located on the steering column to the OFF and ON position again.

### Starting the Vehicle

### **⚠** WARNING

- Always wear appropriate shoes when operating your vehicle. Unsuitable shoes, such as high heels, ski boots, sandals, flipflops, etc., may interfere with your ability to use the brake and accelerator pedals.
- Do not start the vehicle with the accelerator pedal depressed.
   The vehicle can move which can lead to an accident.

### *i* Information

- The vehicle will start by pressing the Start/Stop button, only when the smart key is in the vehicle.
- The vehicle may not start even if the smart key is in the vehicle but it is not near you (e.g. in the cargo area).
- When the Start/Stop button is in the ACC or ON position, if any door is open, the system checks for the smart key. When the smart key is not in the vehicle, the indicator will blink and the warning 'Key not in vehicle' will come on. When all doors are closed, the chime will also sound for about 5 seconds. Keep the smart key in the vehicle when in the ACC position or if the vehicle is on (READY indicator on).

- 1. Always carry the smart key with you.
- 2. Make sure the parking brake is applied.
- 3. Make sure the gear is in P (Park).
- 4. Depress the brake pedal.
- Press the Start/Stop button. If the vehicle starts, the READY indicator illuminates.

## *i* Information

- Always start the vehicle with your foot on the brake pedal. Do not depress the accelerator while starting the vehicle. Do not race the motor while warming it up.
- If ambient temperature is low, the indicator may remain illuminated longer than the normal amount of time.

### NOTICE

To prevent damage to the vehicle:

- If the vehicle turns off while you are in motion, do not attempt to shift the gear to the P (Park) position.
   If traffic and road conditions permit, you may put the gear in N (Neutral)
  - you may put the gear in N (Neutral) while the vehicle is still moving and press the Start/Stop button in an attempt to restart the vehicle.
- Do not push or tow your vehicle to start the vehicle.

## NOTICE

To prevent damage to the vehicle:

Do not press the Start/Stop button for more than 10 seconds except when the stop light fuse is blown.

When the stop light fuse is blown, you cannot normally start the vehicle. Replace the fuse with a new one. If you are not able to replace the fuse, you can start the vehicle by pressing and holding the Start/Stop button for 10 seconds with the Start/Stop button in the ACC position.

Pressing the brake pedal many times when the vehicle is off (**READY** indicator off) increases the possibility of discharging the 12 V battery.

For your safety always depress the brake pedal before starting the vehicle.



### CAUTION

Always check your surroundings while driving, backing up, or before driving from a stop because your electric vehicle does not make vehicle sounds.

### **Emergency starting**



If the smart key battery is weak or the smart key does not work correctly, press the Start/Stop button with the smart key in the direction of the picture shown above.

## **Turning Off the Vehicle**

- 1. Stop the vehicle and depress the brake pedal fully.
- 2. Shift to P (Park).
- 3. Press the Start/Stop button to the OFF position and apply the parking brake.
- 4. Make sure the **READY** indicator is turned off on the instrument cluster.



## **CAUTION**

If the **READY** indicator on the instrument cluster is still on, the vehicle is not turned off and can move when the gear is in any position except P (Park).

## Remote Start (if equipped)





You can start the vehicle using the Remote Start button of the smart key.

To start the vehicle remotely:

- 1. Press the door lock button within 32 feet (10 m) from the vehicle.
- 2. Press and hold the remote start  $(\bigcap_{\text{HOLD}})$  button within 4 seconds.

To turn off the vehicle:

Press the remote start button  $(\bigcap_{y \in V})$  once.



## Information

- The vehicle does not remotely start if the hood or liftgate is opened.
- The vehicle must be in P (Park) for the remote start function to start.
- The vehicle turns off if you get in the vehicle without a registered smart key or you do not get in the vehicle within 10 minutes.

#### SHIFT BY WIRE



[A]: Rotary shifter, [B]: P button, [C]: P>N PARK button

## **Shift By Wire Operation**

Depress the brake pedal whenever rotating the rotary shifter to change gear or selecting P.

## **MARNING**

To reduce the risk of serious injury or death:

- ALWAYS check the surrounding areas near your vehicle for people, especially children, before shifting a vehicle into D (Drive) or R (Reverse).
- Before leaving the driver's seat, always make sure the vehicle is shifted to the P (Park) position, then apply the parking brake, then press the Start/Stop button to the OFF position. Unexpected and sudden vehicle movement can occur if these precautions are not followed.

#### P (Park)

Always come to a complete stop before shifting into P (Park).



To shift the gear to P (Park), press the P button while depressing the brake pedal.

If you turn the vehicle off in R (Reverse), N (Neutral) or D (Drive), the gear will automatically shift to P (Park).

## **MARNING**

- Shifting into P (Park) while the vehicle is in motion may cause you to lose control of the vehicle.
- After the vehicle has stopped, always make sure the vehicle is in P (Park), apply the parking brake, and turn the vehicle off.
- When parking on an incline, shift the gear to P (Park) and apply the parking brake to prevent the vehicle from rolling downhill.

## *i* Information

For vehicles equipped with the Electronic Parking Brake (EPB), EPB is applied automatically when the gear is shifted to P (Park).

#### Automatic gear shift to P (Park)

The gear is automatically shifted to P (Park), and the Electronic Parking Brake (EPB) applies automatically under the following conditions:

- When the vehicle is turned off with the gear in R (Reverse), D (Drive) or N (Neutral).
- When the driver's door is open with the vehicle on (READY indicator on), the gear in R (Reverse), D (Drive) or N (Neutral), and the vehicle at a standstill.
- When the driver's door is open with the gear in N (Neutral) and the vehicle is off

In situations the gear must be in P (Park), always check if the gear is shifted to P (Park) by checking the instrument cluster.

#### R (Reverse)

Use this position to drive the vehicle rearward.



To shift the gear to R (Reverse), rotate the rotary shifter to R (Reverse) while depressing the brake pedal.

When the vehicle is stopped in the R (Reverse) position, if you open the driver's door, the gear may automatically shift to P (Park).

However, if the vehicle is in motion, the gear may not automatically shift to P (Park) to prevent gear damage.

## NOTICE

Always come to a complete stop before shifting into or out of R (Reverse) to prevent damaging the gear.

#### N (Neutral)



To shift the gear to N (Neutral), rotate the rotary shifter clockwise from R (Reverse) or counterclockwise from D (Drive) while depressing the brake pedal.

Always depress the brake pedal when you are shifting from N (Neutral) to another gear.

When the vehicle is turned off with the gear in N (Neutral), the gear automatically shifts to P (Park), and the Electronic Parking Brake (EPB) applies automatically.

However, if you need to stay in N (Neutral) with the vehicle off, refer to the "To stay in N (Neutral) when vehicle is OFF" section in the following page.



#### **CAUTION**

The vehicle can be started with the gear in N (Neutral), but for your safety, be sure to start the vehicle with the gear in P (Park).

## To stay in N (Neutral) when vehicle is OFF





If you want to stay in N (Neutral) after the vehicle is OFF, do the following:

- Turn off Auto Hold and release Electronic Parking Brake when the vehicle is on (READY indicator on).
- 2. Rotate the rotary shifter to N (neutral) while depressing the brake pedal.
- Take your foot off the brake pedal.
   The message 'Press and hold the OK button on the steering wheel to stay in Neutral' appears on the cluster display.

- Press and hold the **OK** button on the steering wheel for more than 1 second.
- When the message 'Vehicle will stay in (N). Change gear to cancel' appears on the cluster display, press the Start/ Stop button while depressing the brake pedal.

However, if you open the driver's door, the gear automatically shifts to P (Park) and the Start/Stop button changes to the OFF position.

## NOTICE

With the gear in N (Neutral) the Start/ Stop button is in the ACC position. In the ACC position, the doors cannot be locked. The high voltage battery may discharge if left in the ACC position for a long time.

#### D (Drive)

This is the normal driving position.

The regenerative braking system automatically activates according to the road conditions.



To shift the gear to D (Drive), rotate the rotary shifter to D (Drive) while depressing the brake pedal.

When the vehicle is stopped in the D (Drive) position, if you open the driver's door, the gear may automatically shift to P (Park).

However, if the vehicle is in motion, the gear may not automatically shift to P (Park) to prevent gear damage.

## NOTICE

Always come to a complete stop before shifting into D (Drive).



#### **CAUTION**

When you drive after stopping on a steep incline, if you do not depress the accelerator pedal or brake pedal, the vehicle may roll backwards resulting in a collision.

#### Shift-lock system

For your safety, your vehicle has a shiftlock system which prevents shifting the gear from P (Park) or N (Neutral) into R (Reverse) or D (Drive) unless the brake pedal is depressed.

To shift from P (Park) or N (Neutral) into R (Reverse) or D (Drive), from R (Reverse) into D (Drive) or from D (Drive) into R (Reverse):

- 1. Depress and hold the brake pedal.
- 2. Start the vehicle.
- 3. Shift the gear in R (Reverse) or D (Drive).

## **i** Information

The gear cannot be shifted while the charging cable is connected.

### When the battery is discharged

You cannot shift gears when the battery is discharged.

In an emergency:

- Connect jumper cables from another vehicle or from another battery following the "Jump Starting" directions in chapter 8.
- Release the Electronic Parking Brake with the Start/Stop button in the ON position and the gear in P (Park).



3. Remove the cap-cover (1) and press the button (2) while depressing the brake pedal.

## **Parking**

Always come to a complete stop and continue to depress the brake pedal. Shift the gear to P (Park), apply the parking brake, and press the Start/Stop button to the OFF position. Take the key with you when leaving the vehicle.

## **Cluster Display Message Information**

Press brake pedal to change gear



This message is displayed when the brake pedal is not depressed while shifting out of P (Park).

Depress the brake pedal and then shift the gear.

### Shift to P after stopping



This message is displayed when the gear is shifted to P (Park) while the vehicle is moving.

Stop the vehicle before shifting to P (Park).

### Shifter system malfunction



This message is displayed when the shift gear does not properly operate in the P (Park) position.

Have the vehicle inspected by an authorized retailer of Genesis Branded products.

#### Check shifter dial



This message is displayed when there is a malfunction with the rotary shifter.

Have the vehicle inspected by an authorized retailer of Genesis Branded products.

#### Check P button



This message is displayed when there is a problem with the P button.

Have the vehicle inspected by an authorized retailer of Genesis Branded products.

#### Rotary shifter stuck



OJKEV062066N

This message is displayed when the rotary shifter does not return back to it's normal position.

Have the vehicle inspected by an authorized retailer of Genesis Branded products.

## **Good Driving Practices**

- Never shift the gear from P (Park) or N (Neutral) to any other position with the accelerator pedal depressed.
- Never shift the gear into P (Park) when the vehicle is moving. Completely stop before shifting into R (Reverse) or D (Drive).
- Do not shift the gear to N (Neutral) when driving. If the gear is shifted to N (Neutral) while driving. Doing so may increase the risk of an accident.
  - Also, shifting the gear back to D (Drive) while the vehicle is moving may severely damage the gear.
- Never attempt to select a gear that is opposite the direction of the vehicle motion. Check the gear position before driving. Stop the vehicle before shifting to the desired gear. The vehicle may turn off, causing a collision.
- Do not drive with your foot resting on the brake pedal. Even light, but consistent pedal pressure can result in the brakes overheating, brake wear and possibly even brake failure.
- Always apply the parking brake when leaving the vehicle. Do not depend on placing the shift gear in P (Park) to keep the vehicle from moving.

- Exercise extreme caution when driving on a slippery surface. Be especially careful when braking, accelerating, or shifting gears. On a slippery surface, an abrupt change in vehicle speed can cause the drive wheels to lose traction and may cause loss of vehicle control resulting in an accident.
- Optimum vehicle performance and economy is obtained by smoothly depressing and releasing the accelerator pedal.

## **WARNING**

To reduce the risk of SERIOUS INJURY or DEATH:

- ALWAYS wear your seat belt. In a collision, an unbelted occupant is significantly more likely to be seriously injured or killed than a properly belted occupant.
- Avoid high speeds when cornering or turning.
- Do not make quick steering wheel movements, such as sharp lane changes or fast, sharp turns.
- The risk of rollover is greatly increased if you lose control of your vehicle at highway speeds.
- Loss of control often occurs if two or more wheels drop off the roadway and the driver over steers to reenter the roadway.
- In the event your vehicle leaves the roadway, do not steer sharply. Instead, slow down before pulling back into the travel lanes.
- Genesis Branded Vehicle recommends you follow all posted speed limits.

#### REGENERATIVE BRAKING SYSTEM (PADDLE SHIFTER)

Regenerative braking system operates the paddle shifter to control the regenerative braking intensity of the vehicle. It improves the fuel efficiency of the vehicle and helps the driver to have a better driving experience.



#### Information

The regenerative braking system uses the electric motor to engage the brake. The electric motor converts the kinetic energy generated from decelerating the vehicle to electricity and charges the high voltage battery.

### Using Regenerative Braking System

#### Operating paddle shifter

Operate the paddle shifter as shown below to use the regenerative braking system.



- Pull the right paddle shifter (-1) once to lower the regenerative braking intensity level by 1. It will decrease decelerating intensity.

- Pull and hold the left paddle shifter (+0) for over 0.5 seconds to keep raising the regenerative braking intensity level. Holding the paddle shifter brings the vehicle to stop.
- While the smart regeneration system is turned on, pull and hold the right paddle (-1) shifter for over 1 second to turn off the smart regeneration system. (Refer to the "Smart Regeneration System" section for the details.)

## Checking the amount of regenerative braking





The selected regenerative braking level appears on the instrument cluster.

- When the vehicle is turned off and on again after the regenerative braking level is in 0, the braking level is changed to 1.
- When the vehicle is turned off and on again after the i-PEDAL is on, the braking level is changed to 3.

#### Regenerative Braking System Limitations

Regenerative braking intensity cannot be changed using the paddle shifter in the following situations when:

- The  $[\underline{+9}]$  and  $[\underline{-9}]$  paddle shifters are pulled at the same time.
- The vehicle is decelerating by depressing the brake pedal.
- · Smart Cruise Control is activated.
- The regenerative braking is continuously operated with the battery fully charged
- The Downhill Brake Control (DBC) is activated

Initial setting of the regenerative braking level and adjustable range may vary according to the selected Drive mode.

Drive Mode	Adjustable Range
ECO	0 to 3
COMFORT	0 to 3
SPORT	0 to 3
SNOW	0 to 1

For more information, refer to the "Drive Mode Integrated Control System" section in this chapter.

### One Pedal Driving

One pedal driving operates the paddle shifter while coasting to control the intensity of regenerative braking. It assists the driver to stop the vehicle without depressing the brake.



#### Information

Coasting is the process of driving a vehicle without the brake pedal and the accelerator pedal depressed. Coasting uses the inertia of driving energy instead of the vehicle power.

### Using one pedal driving

Pull and hold the left paddle shifter (\_+1) for over 0.5 seconds while coasting to enable the one pedal driving mode.

- Release the paddle shifter when the vehicle speed is above 1.8 mph (3 km/h) to return to the previously set regenerative braking level.
- If the vehicle speed is below 1.8 mph (3 km/h), the vehicle will keep engaging the brake although the driver releases the paddle shifter.
- Releasing the paddle shifter after the vehicle comes to a stop will maintain the vehicle stationary.

### ! CAUTION

- The vehicle may not come to a stop although the one pedal driving function is active, depending on the condition of the vehicle and the road. Check the surroundings and depress the brake pedal to decelerate.
- If the driver depresses the accelerator pedal while pulling and holding the left paddle shifter  $(\cancel{+9})$  to increase the braking level, one pedal driving function operates same as i-PEDAL function. In this case, the vehicle speed is no longer controllable through the paddle shifter.

#### One pedal driving limitations

In the following conditions, the vehicle may not come to a stop although the one pedal driving function is active. Depress the brake pedal to stop the vehicle when:

- Driving on a slope, or when the vehicle is repeatedly driven and stopped.
- · The vehicle is driving through the end of the slope.
- Driving on a slippery surface such as an icy, rainy, or muddy road.
- The wheels are not properly aligned.
- A wheel slip or wheel spin occurs.
- The weight on board is heavy.
- The vehicle is tilted to one side.
- The tire is worn out.

#### Automatic engagement of EPB

Use one pedal driving function to bring the vehicle to a stop and automatically engage the Electronic Parking Brake (EPB).

After the vehicle is stopped, EPB is automatically applied when any of the following conditions are satisfied:

- The driver's seatbelt is unfastened and the driver's door is open.
- The gear shifts to N (Neutral).
- The hood is open.
- The liftgate is open.
- 5 minutes have passed after the vehicle has stopped.
- · One pedal driving is limited due to other reasons.

#### Using i-PEDAL

i-PEDAL assists the driver to accelerate, decelerate, and stop the vehicle with only the accelerator pedal.

#### Turning on/off the i-PEDAL

• Turning on i-PEDAL:

Pull the left paddle shifter (2+9)once when the regenerative braking level is at 3. i-PEDAL is turned on and the instrument cluster displays the 'i-PEDAL' message. i-PEDAL is not available while the smart regeneration system is on. Turn off the smart regeneration system first before using i-PEDAL.

· Turning off i-PEDAL:

Pull the right paddle shifter (-19) once while the function is on. Otherwise, shift the gear to R (Reverse) then to D (Drive) while the function is on. i-PEDAL is disabled and regenerative braking level is set to 3.



## **!** CAUTION

- Depending on the vehicle and road condition, the vehicle may not come to a stop although the i-PEDAL function is active. Check surroundings and depress the brake pedal to control the vehicle speed.
- Do not use i-PEDAL on slippery roads.

#### i-PEDAL limitations

In the following conditions, the vehicle may not come to a stop although the i-PEDAL is properly activated. Depress the brake to stop the vehicle when:

- Driving on a slope, or when the vehicle is repeatedly driven and stopped.
- The vehicle is driving through the end of the slope.
- Driving on a slippery surface such as an icy, rainy, or muddy road.
- The wheels are not properly aligned.
- A wheel slip or wheel spin occurs.
- The weight on board is heavy.
- The vehicle is tilted to the side.
- The tire is worn out.

#### SMART REGENERATION SYSTEM

The smart regeneration system recognizes vehicle-to-vehicle distance, road gradient, and speed cameras and controls the regenerative braking level while coasting. It reduces unnecessary depressing of pedals to improve fuel efficiency and driver convenience.

## *i* Information

- Coasting is the process of driving a vehicle without the brake pedal and the accelerator depressed. Coasting uses the inertia of driving energy instead of the vehicle power.
- The regenerative braking system uses the electric motor to engage the brake. The electric motor converts the kinetic energy generated from decelerating the vehicle to electricity and charges the high voltage battery.

### Smart Regeneration System On/ Off

Operate the paddle shifter as shown below to use the smart regeneration system.

 Turning on the smart regeneration system: While the READY indicator is on, shift the gear to D (Drive), and pull and hold the right paddle shifter (-1) for over a second.





The smart regeneration system turns on and the regenerative braking level is displayed as 'AUTO'.

- Turning off the smart regeneration system: While the smart regeneration system is on, pull and hold the right paddle shifter (-10) for over a second The instrument cluster displays the regenerative braking level instead of 'AUTO', and the smart regeneration system turns off.
- Using one pedal driving: While the smart regeneration system is on, pull and hold the left paddle shifter (+0) for over 0.5 seconds (Refer to the "One Pedal Driving" section for details.)

i-PEDAL is not available while the smart regeneration system is on. Turn off the smart regeneration system first before using i-PEDAL.

### Smart Regeneration System Operating Condition

When the regenerative braking level is displayed as AUTO and the vehicle speed is above 6 mph (10 km/h), the system automatically controls the regenerative braking level under the following conditions:

- The road gradient changes
- Distance from the vehicle ahead reduces or increases
- Speed of the vehicle ahead reduces or increases

## **A** CAUTION

- When the forward safety warning light is ON, the smart regeneration system does not work properly. Depress the brake pedal for deceleration.
- The function that adjusts the regenerative braking intensity depending on the road gradient is only effective when the regenerative braking level is 0. Braking intensity does not significantly change depending on the road gradient if the regenerative braking level is 1 or above.

# Smart Regeneration Level Settings





The instrument cluster displays 'AUTO' (1) when the smart regeneration system is on. Depending on the conditions, the system adjusts the regenerative braking level (2). The indicator light (3) illuminates when the vehicle recognizes a vehicle.

## Smart regeneration default setting

The default braking level of the smart regeneration system can be changed. Set the default braking level to the lowest and let the system adjust the braking intensity automatically.

To change the default level of the smart regeneration system, pull the right paddle shifter (-19) once while the system is on.

#### Smart regeneration intensity setting

Regenerative braking intensity of the smart regeneration system can be adjusted to match the driver's preference. Adjust the braking intensity makes the decelerating faster or slower.



To adjust the regenerative braking level of the smart regeneration system, go to 'Setup > EV > Smart Regeneration' from the infotainment system.

# Pausing Smart Regeneration System

The smart regeneration system is temporarily turned off in the following conditions. While the system is turned off, the driver must keep eyes on the road and depress the brake pedal to decelerate.

- The gear is shifted to N (Neutral), R (Reverse) or P (Park)
- · Smart Cruise Control is ON
- ESC (Electronic Stability Control) is operating
- · ABS is operating

#### **Front Sensor**



[A]: Front radar

Front sensor recognizes the distance from the vehicle ahead to control the regenerative braking intensity. If the sensor is covered with snow, rain, or other foreign substances, the performance of the sensor may deteriorate, and the smart regeneration system may turn off. Always keep the sensor clean.

### System Check Message



When the front radar is covered or blocked, the smart regeneration system may be temporarily disabled.

The "Check Regeneration System" warning message may appear, and the regenerative braking level is displayed on the instrument cluster.

The system operates normally when such foreign material is removed, and the system is turned on by pulling and holding the right paddle shifter for over one second.

If the smart regeneration system does not operate normally after the sensor has been uncovered or unblocked, have the vehicle inspected by an authorized retailer of Genesis Branded products.

## Smart Regeneration System Precautions

- Always monitor the distance to vehicles ahead on the road. The smart regeneration system is not a substitute for safe driving practices, but a supplemental function only.
- Always maintain a safe distance from the vehicles ahead and adjust your vehicle speed to the road conditions. The smart regeneration system may not recognize unexpected and sudden situations or complex driving situations.

#### General precautions

- Always maintain a safe distance from the vehicles ahead and adjust your vehicle speed depending on the road conditions.
- Always prepare for unexpected situations and depress the brake pedal to decelerate when necessary. The smart regeneration system cannot react to pedestrians, vehicles making a sudden stop and vehicles coming from the opposite lane.
- If the vehicle ahead frequently changes the lane, keep your eyes forward to be prepared for hazardous situations. In this case, the smart regeneration system may respond late and may inappropriately respond to vehicle movements from the side lanes.
- The driver must depress the brake pedal when stopping the vehicle.
- Depress the brake pedal to decelerate in the following conditions when:
  - The front part of the vehicle is lifted up because of the cargo loaded on the rear part of the vehicle.
  - You are operating the steering wheel.
  - You are not driving in the center of the lane.
  - You are driving on a narrow or curved road.
- The smart regeneration system may temporarily turn off when exposed to strong electromagnetic waves.
- If the vehicle starts coasting near the speed camera and engages the brake with the smart regeneration system, the vehicle may not be able to keep the speed limit. Always comply with the road and traffic law.

#### Sensor precautions

- Never disassemble the radar or radar assembly, and never apply any impact on it.
- If there is impact on or near the radar, the sensors may be damaged or not be properly aligned near the radar, even though a warning message does not appear on the instrument cluster, the Smart Regeneration System may not operate properly. Have the vehicle inspected by an authorized retailer of Genesis Branded products.
- If the radar has been replaced or repaired, have the vehicle inspected by an authorized retailer of Genesis Branded products.
- Use only genuine parts to repair the bumper where the radar is located.
- Do not install a license plate frame or other objects such as bumper sticker, film, bumper guard, or bumper wrap near the radar.
- The Smart Regeneration System may not work properly if the bumper has been replaced, or the surroundings of the radar has been damaged or painted.
- Do not spray the sensors or the surrounding area directly with high pressure water.

#### **Detecting vehicle**

 The front sensor may not detect the vehicle ahead or may suddenly detect the vehicle ahead, such as when the smart regeneration system responds slowly, when driving on a hill ends, or when driving through a curve. The regenerative braking intensity may increase and decelerate your vehicle.



Some vehicles in your lane may not be detected by the sensor:

- Narrow vehicles such as motorcycles or bicycles
- Vehicles offset to one side
- Slow-moving vehicles or sudden decelerating vehicles
- Vehicles with small rear profile such as trailers with no loads
- When a vehicle in front of you merges out of the lane, the front sensor may not detect the new stopped vehicle that is now in front of your vehicle.

#### **Driving on curves**



The front sensor may not detect the vehicle ahead if you are coasting on a curve. The regenerative braking intensity may automatically decrease and accelerate the vehicle.



On curves, if a vehicle is detected in an adjacent lane, the regenerative braking intensity may increase and decelerate your vehicle.


 If the front sensor suddenly detects the vehicle ahead, the regenerative braking intensity may increase and decelerate your vehicle.

#### **Driving on hills**



When coasting uphill or downhill, the front sensor may not detect the vehicle ahead or suddenly detect the vehicle ahead at the end of the incline or at the point where the incline changes. The regenerative braking intensity is adjusted automatically changing your vehicle speed. Brake as needed to reduce your driving speed.

#### **Changing lanes**



- When a vehicle moves into your lane from an adjacent lane, it cannot be detected by the sensor until it is in the sensor's detection range.
- The smart regeneration system may not immediately detect the vehicle when your vehicle changes lanes abruptly.

#### **BRAKING SYSTEM**

#### **Power-assist Brakes**

Your vehicle has power-assisted brakes that adjust automatically through normal usage.

In the event of a vehicle power failure, the power assist for the brakes will not work. You can still stop your vehicle, but it will require greater force and increased pedal travel than normal. The stopping distance, however, will be longer than with power brakes.



#### Information

- When the brake pedal is depressed under certain driving conditions or weather conditions, you may temporarily hear a noise. This is normal and does not indicate a problem with your brakes.
- · While driving on a road with deicing chemicals, brake noise or abnormal tire wear may occur due to deicing chemicals. In a safe traffic condition. additionally apply the brakes to remove deicing chemicals on the brake discs and pads.



## ! WARNING

Take the following precautions:

 Do not drive with your foot resting on the brake pedal. This will create abnormal high brake temperatures, excessive brake lining and pad wear, and increased stopping distances. So increase the regeneration braking level with the left paddle shifter to decrease the speed.

- When descending down a long or steep hill, use the paddle shifter to increase the regeneration braking level in order to decrease your speed without using the brake pedal excessively. Applying the brakes continuously will cause the brakes to overheat and could result in a temporary loss of braking performance.
- Wet brakes may impair the vehicle's ability to safely slow down; the vehicle may also pull to one side when the brakes are applied. Applying the brakes lightly will indicate whether they have been affected in this way. Always test your brakes in this fashion after driving through deep water. To dry the brakes, lightly tap the brake pedal to heat up the brakes while maintaining a safe forward speed until brake performance returns to normal. Avoid driving at high speeds until the brakes function correctly.

## **NOTICE**

- Do not continue depressing the brake pedal if the vehicle is off (READY indicator off). The battery may be discharged.
- Noise and vibration generated during braking is normal.
- Under normal operation, electric brake pump noise and motor vibration may occur temporarily in below cases.
  - When the pedal is depressed suddenly.
  - When the pedal is repeatedly depressed in short intervals.
  - When the ABS function is activated while braking.

#### **Disc Brakes Wear Indicator**

When your brake pads are worn and new pads are required, you will hear a high pitched warning sound from your front or rear brakes. You may hear this sound come and go or it may occur whenever you depress the brake pedal.

## NOTICE

To avoid costly brake repairs, do not continue to drive with worn brake pads.



#### Information

Always replace brake pads as complete front or rear axle sets.

#### **High Performance Brake**

For vehicles equipped with the High Performance Brake (large diameter monoblock brakes with enhanced braking performance), noise such as a squeal, squeak or groan is generated while braking. This is normal and the friction may create circle patterns on the disc surface. This is also a normal condition which does not affect braking performance.



### WARNING

Frequent braking may deform components and wear the disc brake causing vibration when braking. Observe the speed limit to prevent brake damage from excessive braking.

Brake wear, noise, vibration from excessive braking or deformation of the brakes caused by repeatedly braking in high speed, racing on tracks, etc., can be excluded from warranty coverage.

# Electronic Parking Brake (EPB) Applying the parking brake



To apply EPB (Electronic Parking Brake):

- 1. Depress and hold the brake pedal.
- 2. Pull up the EPB switch.

Make sure the Parking Brake warning light comes on.

EPB (Electronic Parking Brake) may be automatically applied when:

- Requested by other systems.
- The driver turns the vehicle off while Auto Hold is operating.
- The gear is shifted to P (Park).

#### **Emergency braking**

If there is a problem with the brake pedal while driving, emergency braking is possible by pulling up and holding the EPB switch. Braking is possible only while you are holding the EPB switch. However, braking distance will be longer than normal.



### **WARNING**

To reduce the risk of SERIOUS INJURY or DEATH, do not operate the EPB while the vehicle is moving except in an emergency situation. It could damage the brake system and lead to an accident.



During emergency braking, the Parking Brake warning light will illuminate to indicate that the system is operating.

### NOTICE

If you continuously notice a noise or burning smell when the EPB is used for emergency braking, have the system inspected by an authorized retailer of Genesis Branded products.

#### Releasing the parking brake



To release EPB (Electronic Parking Brake):

- Press the Start/Stop button to the ON or START position.
- 2. Press the EPB switch while depressing the brake pedal.

Make sure the Parking Brake warning light goes off.

To release EPB (Electronic Parking Brake) automatically:

- Gear in P (Park)
   With the vehicle on (READY indicator on), depress the brake pedal and shift out of P (Park) to R (Reverse) or D (Drive).
- Gear in N (Neutral)
   With the vehicle on (READY indicator on), depress the brake pedal and shift out of N (Neutral) to R (Reverse) or D (Drive).

- · Satisfy the following conditions
  - Ensure seat belts are fastened and the doors, hood and liftgate are closed.
  - 2. With the vehicle on (**READY** indicator on), depress the brake pedal and shift out of P (Park) to R (Reverse), D (Drive).
  - Depress the accelerator pedal.
     Make sure the Parking Brake warning light goes off.

## *i* Information

- You can engage EPB even though the Stop/Start button is in the OFF position (only if battery power is available), but you cannot release it.
- Depress the brake pedal and release the parking brake manually with the EPB switch before you drive downhill or when backing up.

## NOTICE

- If the Parking Brake warning light is still on even though the EPB has been released, have the system checked by an authorized retailer of Genesis Branded products.
- Do not drive your vehicle with EPB applied. It may cause excessive brake pad and brake rotor wear.

#### Warning messages



To release EPB, fasten seatbelt and close door, hood and liftgate

If the driver's seat belt is unfastened, or the hood, liftgate, doors are open, and you try to drive with EPB applied, a warning sounds and a message appears.

## $\Lambda$

### WARNING

To prevent serious injury or death from unintended vehicle movement:

- Always come to a complete stop and continue to depress the brake pedal before parking, shift the gear into P (Park), pull up the EPB switch, and press the Start/Stop button to the OFF position. Take the key with you when leaving the vehicle.
- Never allow anyone who is unfamiliar with the vehicle to touch the EPB switch.
- Only release EPB when you are seated inside the vehicle with your foot firmly on the brake pedal.

## NOTICE

Driving with the parking brake on may overheat the braking system and cause premature wear or damage to brake parts.



## Information

- In winter, the EPB related device may freeze and cannot be released. Do not use the EPB but park on a flat surface with the gear in P (Park). Use wheel chocks under the wheels if necessary.
   If the EPB applies automatically when the gear is shifted to P (Park), turn off Auto Hold, and press EPB switch to release the parking brake.
- A clicking sound may be heard while operating or releasing the EPB. These conditions are normal and indicate that EPB is functioning properly.
- When leaving your keys with a parking attendant or assistant, be sure to inform him/her how to operate the EPB.



**AUTO HOLD turning Off! Press brake** pedal

When the conversion from Auto Hold to EPB is not working properly a warning will sound and a message will appear.



Parking brake automatically engaged When EPB is applied while Auto Hold is activated, a warning will sound and a message will appear.

#### EPB malfunction

Electronic Parking Brake (EPB) warning light illuminates if the Start/Stop button is pressed to the ON position and goes off in about 3 seconds if the system is operating normally.

If the EPB warning light remains on, comes on while driving, or does not come on when the Start/Stop button is pressed to the ON position, this indicates that the EPB may have malfunctioned.

If this occurs, have the system checked by an authorized retailer of Genesis Branded products.

The EPB warning light may illuminate when the ESC indicator comes on to indicate that ESC is not working properly, but it does not indicate a malfunction of EPB.

### NOTICE

- If the Parking Brake warning light does not illuminate or blinks after the EPB switch has been pulled, the EPB may not be applied.
- If the EPB warning light is still on or the Parking Brake warning light blinks when the EPB warning light is on, press the switch, and then pull it up. Repeat this one more time. If the EPB warning does not go off, have the system checked by an authorized retailer of Genesis Branded products.

## Parking brake warning light



Check the Parking Brake warning light by pressing the BRAKE Vehicle Stop/Start button to the ON position.

This light will be illuminated when the parking brake is applied with the Vehicle Stop/Start button in the START or ON position.

Before driving, be sure the parking brake is released and the Parking Brake warning light is OFF.

If the Parking Brake warning light remains on after the parking brake is released while the motor is running, there may be a malfunction in the brake system. Immediate attention is necessary.

If at all possible, cease driving the vehicle immediately. If that is not possible, use extreme caution while operating the vehicle and only continue to drive the vehicle until you can reach a safe location.

#### When the EPB (Electronic Parking Brake) does not release

If the EPB does not release normally. contact an authorized retailer of Genesis Branded products by loading the vehicle on a flatbed tow truck and have the system checked.

#### **Auto Hold**

Auto Hold maintains the vehicle in a standstill even though the brake pedal is not depressed after the driver brings the vehicle to a complete stop by depressing the brake pedal.



#### Information

The Auto Hold On or Off setting is maintained when the vehicle is turned off. When the vehicle is restarted the last setting for Auto Hold is applied.

#### To apply:



1. With the driver's door and hood closed, depress the brake pedal and then press the AUTO HOLD switch. The white AUTO HOLD indicator will come on and the system will be in the standby position.



[A]: White, [B]: Green

- 2. When you stop the vehicle completely by depressing the brake pedal, Auto Hold maintains the brake pressure to hold the vehicle stationary. The indicator changes from white to green.
- 3. The vehicle will remain stationary even if you release the brake pedal.
- 4. If EPB is applied, Auto Hold will be released.

#### To release:

If you depress the accelerator pedal with the gear in D (Drive), R (Reverse) or Manual shift mode, the Auto Hold will be released automatically and the vehicle will start to move. The AUTO HOLD indicator changes from green to white.

## **MARNING**

Always look around your vehicle before depressing the accelerator pedal to release Auto Hold.

#### To cancel:



[A]: OFF

- 1. Depress and hold the brake pedal.
- Press the AUTO HOLD switch.The AUTO HOLD indicator will turn off.

## **!** WARNING

To prevent unintended vehicle movement, always depress your foot on the brake pedal to cancel the Auto Hold before you:

- Drive downhill.
- Drive the vehicle in R (Reverse).
- Park the vehicle.

## **information**

- · The Auto Hold does not operate when:
  - The gear is in P (Park)
  - EPB is applied
- For your safety, the Auto Hold automatically switches to EPB when:
  - The driver's door is opened
  - The liftgate is opened
  - The hood is opened
  - The vehicle is in a standstill for more than 10 minutes
  - The vehicle is standing on a steep slope
  - The vehicle moved several times

The Parking Brake warning light comes on, the AUTO HOLD indicator changes from green to white, and a warning sounds and a message appears to inform you that EPB has been automatically engaged. Before driving, depress the brake pedal, check the surrounding area and release the parking brake manually with the EPB switch.

## NOTICE

If the AUTO HOLD indicator changes to yellow, or the driver's door, hood, or liftgate open detection system malfunctions, Auto Hold does not work properly. Contact an authorized retailer of Genesis Branded products.



Depress the accelerator pedal slowly when you start the vehicle.

#### Warning messages



Parking brake automatically engaged When EPB is applied while Auto Hold is activated, a warning will sound and a message will appear.



AUTO HOLD turning Off! Press brake pedal

When the conversion from Auto Hold to EPB is not working properly a warning will sound and a message will appear.

When this message is displayed, Auto Hold and EPB may not operate. For your safety, depress the brake pedal.



Press brake pedal to deactivate AUTO HOLD

If you did not apply the brake pedal when you release Auto Hold by pressing the AUTO HOLD switch, a warning will sound and a message will appear.

## **Brake Disc Cleaning**

Use the Brake Disc Cleaning function if noise is generated when depressing the brake while driving or if the brake disc gets rusty. It helps reduce the noise and rust. Regenerative braking is restrained while Brake Disc Cleaning is operated, which may lower the electric energy efficiency.

Press and hold the AUTO HOLD button for over 3 seconds.

- Brake Disc Cleaning starts operating when the message 'Brake disc cleaning' is displayed on the instrument cluster.
- Regenerative braking is restrained while the brake is depressed about 10 times while driving (it may differ depending on driving conditions). It helps reduce the noise and rust.
- Brake Disc Cleaning function will turn off automatically when the operation is completed. It can also be turned off before operation is completed by turning off the vehicle or pressing the AUTO HOLD button for over 3 seconds.

### Anti-lock Brake System (ABS)



#### WARNING

Anti-Lock Braking System (ABS) or Electronic Stability Control (ESC) system will not prevent accidents due to improper or dangerous driving maneuvers. Even though vehicle control is improved during emergency braking, always maintain a safe distance between you and objects ahead of you. Vehicle speeds should always be reduced during extreme road conditions. The braking distance for vehicles equipped with ABS or ESC may be longer than for those without these systems in the following road conditions.

Drive your vehicle at reduced speeds during the following conditions:

- Rough, gravel or snow-covered roads.
- On roads where the road surface is pitted or has different surface height.
- Tire chains are installed on your vehicle.

The safety features of ABS or ESC equipped vehicle should not be tested by high speed driving or cornering. This could endanger the safety of yourself or others.

ABS is an electronic braking system that helps prevent a braking skid. ABS allows the driver to steer and brake at the same time.

### **Using ABS**

To obtain the maximum benefit from your ABS in an emergency situation, do not attempt to modulate your brake pressure and do not try to pump your brakes.

When you apply your brakes under conditions which may lock the wheels, you may hear sounds from the brakes, or feel a corresponding sensation in the brake pedal. This is normal and it means your ABS is active.

ABS does not reduce the time or distance it takes to stop the vehicle.

Always maintain a safe distance from the vehicle in front of you.

ABS will not prevent a skid that results from sudden changes in direction, such as trying to take a corner too fast or making a sudden lane change. Always drive at a safe speed for the road and weather conditions.

ABS cannot prevent a loss of stability. Always steer moderately when braking hard. Severe or sharp steering wheel movement can still cause your vehicle to veer into oncoming traffic or off the road.

On loose or uneven road surfaces, operation of the anti-lock brake system may result in a longer stopping distance than for vehicles equipped with a conventional brake system.

The ABS (((((s)))) warning light will stay on for several seconds after the Start/Stop button is in the ON position.

During that time, ABS will go through self-diagnosis and the light will go off if everything is normal. If the light stays on, you may have a problem with your ABS. Contact an authorized retailer of Genesis Branded products as soon as possible.



#### WARNING

If the ABS (((B))) warning light is on and stays on, you may have a problem with the ABS. Your power brakes will work normally. To reduce the risk of serious injury or death, contact an authorized retailer of Genesis Branded products as soon as possible.

## NOTICE

When you drive on a road having poor traction, such as an icy road, and apply your brakes continuously, ABS will be active continuously and the ABS (((B))) warning light may illuminate. Pull your vehicle over to a safe place and turn the vehicle off.

Restart the vehicle. If the ABS warning light is off, then your ABS system is normal.

Otherwise, you may have a problem with your ABS system. Contact an authorized retailer of Genesis Branded products as soon as possible.



## Information

When you jump start your vehicle because of a drained battery, the ABS (((B))) warning light may turn on at the same time. This happens because of the low battery voltage. It does not mean your ABS is malfunctioning. Have the battery recharged before driving the vehicle.

## **Electronic Stability Control (ESC)**



Electronic Stability Control helps to stabilize the vehicle during cornering maneuvers.

ESC checks where you are steering and where the vehicle is actually going. ESC applies braking pressure to any one of the vehicle's brakes and intervenes in the electric vehicle control system to assist the driver with keeping the vehicle on the intended path. It is not a substitute for safe driving practices. Always adjust your speed and driving to the road conditions.

## **MARNING**

Never drive too fast for the road conditions when cornering. ESC will not prevent accidents.

Excessive speed in turns, abrupt maneuvers, and hydroplaning on wet surfaces can result in severe accidents.

#### ESC operation

#### **ESC ON condition**

When the Start/Stop button is in the ON position, ESC and the ESC OFF indicator lights illuminate for about three seconds. After both lights go off, ESC is enabled.

#### When operating



When ESC is in operation, the ESC indicator light blinks:

- When you apply your brakes under conditions which may lock the wheels, you may hear sounds from the brakes, or feel a corresponding sensation in the brake pedal. This is normal and it means your ESC is active.
- When ESC activates, the vehicle may not respond to the accelerator as it does under routine conditions.
- If Smart Cruise Control (SCC) was in use when ESC activates, Smart Cruise Control (SCC) automatically disengages. Smart Cruise Control (SCC) can be reengaged when the road conditions allow. Refer to the "Smart Cruise Control (SCC)" section in chapter 7 (if equipped).

#### **ESC OFF condition**



To cancel ESC operation:

#### State 1

Press the ESC OFF button briefly. The ESC OFF indicator light and/or message 'Traction Control disabled' will illuminate. In this state, the traction control function of ESC is disabled, but the brake control function of ESC (braking management) still operates.

#### State 2

Press and hold the ESC OFF button continuously for more than 3 seconds. The ESC OFF indicator light and/or message 'Traction & Stability Control disabled' illuminates and a warning chime sounds. In this state, both the traction control function of ESC and the brake control function of ESC (braking management) are disabled.

If the Start/Stop button is pressed to the OFF position when ESC is off, ESC remains off. Upon restarting the vehicle, ESC will automatically turn on again.

#### **Indicator lights**

■ ESC indicator light (blinks)



■ ESC OFF indicator light (comes on)



When the Start/Stop button is pressed to the ON position, the ESC indicator light illuminates, then goes off if the ESC system is operating normally.

The ESC indicator light blinks whenever ESC is operating.

If the ESC indicator light stays on, your vehicle may have a malfunction with the ESC system. When this warning light illuminates, have the vehicle inspected by an authorized retailer of Genesis Branded products as soon as possible.

The ESC OFF indicator light comes on when ESC is turned off.



### **WARNING**

When ESC is blinking, this indicates ESC is active:

Drive slowly and NEVER attempt to accelerate. NEVER turn ESC off while the ESC indicator light is blinking or you may lose control of the vehicle resulting in an accident.

## NOTICE

Driving with wheels and tires with different sizes may cause the ESC system to malfunction. Before replacing tires, make sure all four tires and wheels are the same size. Never drive the vehicle with different sized wheels and tires installed.

#### ESC OFF usage

#### When Driving

The ESC OFF mode should only be used briefly to help free the vehicle if stuck in snow or mud, by temporarily stopping operation of ESC, to maintain wheel torque.

To turn ESC off while driving, press the ESC OFF button while driving on a flat road surface.

## NOTICE

To prevent damage to the gear:

- Do not allow wheel(s) of one axle to spin excessively while the ESC, ABS, and Parking Brake warning lights are displayed. The repairs would not be covered by the vehicle warranty. Reduce motor power and do not spin the wheel(s) excessively while these lights are displayed.
- When operating the vehicle on a dynamometer, make sure ESC is turned off (ESC OFF light illuminated).



## Information

Turning ESC off does not affect ABS or standard brake system operation.

## Vehicle Stability Management (VSM)

Vehicle Stability Management is a function of the Electronic Stability Control (ESC) system. It helps the vehicle stay stable when accelerating or braking suddenly on wet, slippery and rough roads where traction over the four tires can suddenly become uneven.

## **MARNING**

Take the following precautions when using Vehicle Stability Management:

- ALWAYS check the speed and the distance to the vehicle ahead. VSM is not a substitute for safe driving practices.
- Never drive too fast for the road conditions. VSM will not prevent accidents. Excessive speed in bad weather, on slippery and uneven roads can result in severe accidents.

## VSM operation

#### When operating

When you apply your brakes under conditions which may activate ESC, you may hear sounds from the brakes, or feel a corresponding sensation in the brake pedal. This is normal and it means your VSM is active.

## *i* Information

VSM does not operate when:

- Driving on a banked road such as gradient or incline.
- · Driving in reverse.
- The ESC OFF indicator light is on.
- The MDPS (Motor Driven Power Steering) warning light (♠!) is on or blinks.

#### VSM OFF condition

To cancel VSM operation, press the ESC OFF button. ESC OFF ( ) indicator light will illuminate.

To turn on VSM, press the ESC OFF button again. The ESC OFF indicator light will go out.

## **WARNING**

If the ESC (\$\overline{\Pi}\) indicator light or MDPS (\$\overline{\Pi}\)) warning light stays illuminated or blinks, your vehicle may have a malfunction with the VSM system. When the warning light illuminates, have the vehicle inspected by an authorized retailer of Genesis Branded products as soon as possible.

### NOTICE

Driving with wheels and tires with different sizes may cause the VSM system to malfunction. Before replacing tires, make sure all four tires and wheels are the same size. Never drive the vehicle with different sized tires and wheels installed.

### Trailer Stability Assist (TSA)

Trailer stability assist is operated as a vehicle stability control system. The Trailer stability assist system stabilizes the vehicle and trailer when the trailer sways or oscillates. In most cases, trailer sway happens at high speeds.

Factors that can cause trailer sway include:

- High speed
- Strong crosswinds
- Improper overloading
- Sudden steering inputs
- Uneven road

When the Trailer stability assist system detects sway, the front brakes are applied automatically. If it is not enough braking, the brakes are applied on all wheels automatically and vehicle power is reduced.

### Hill-Start Assist Control (HAC)

Hill-Start Assist Control helps prevent the vehicle from rolling backwards when starting a vehicle from a stop on a hill. The system operates the brakes automatically for about 2 seconds (maximum of 5 seconds when the accelerator pedal is slightly depressed during HAC operation) and releases the brake after 2 seconds or when the accelerator pedal is depressed.



## **WARNING**

Always be ready to depress the accelerator pedal when starting off an incline. Hill-Start Assist Control activates only for about 2 seconds (maximum of 5 seconds when the accelerator pedal is slightly depressed during HAC operation).



#### Information

- Hill-Start Assist Control does not operate when the gear is shifted to P (Park) or N (Neutral).
- Hill-Start Assist Control activates even when the ESC (Electronic Stability Control) is off. However, it does not activate, when ESC does not operate normally.

# **Brake Assistant System (BAS)**

The Brake Assistant System provides additional pressure when the brake pedal is momentarily and strongly depressed in a situation sudden braking is required while driving.

The Brake Assistant System reduces the time for ABS(Anti-Lock Brake System) control to enter and consequently reduces the braking distance, by providing additional pressure up to the point of ABS intervention.

### **BAS** operation

- When the vehicle speed is more than 18 mph (30 km/h) and the ABS control is not entered.
- When the brake pedal is depressed strongly over a certain level.
- When the friction of the road surface is above a certain level.

## BAS operation off

- The vehicle speed is below 6 mph (10 km/h).
- The brake pedal is depressed over a certain conditions.
- The friction of the road surface is below a certain level.

# **!** WARNING

The system may not operate depending on driver's driving habit, the degree to which the brake pedal is depressed and the road surface condition.

# **Downhill Brake Control (DBC)**



Downhill Brake Control assists the driver to descend down a steep hill without having to depress the brake pedal.

The system automatically applies the brakes to maintain vehicle speed below a certain speed and allows the driver to concentrate on steering the vehicle down hill.

The system is turned off whenever the vehicle is turned off.

Press the button to turn on the system and press the button again to turn it off.

# System operation

Mode	Indicator	Description		
Standby	Green light on	Press the Downhill Brake Control button when vehicle speed is under 37 mph (60 km/h). Downhill Brake Control will turn on and enter the standby mode. The system does not turn on if vehicle speed is over 37 mph (60 km/h).		
Activated	Green light blink	In the standby mode, Downhill Brake Control will activate under the following conditions:  • The hill is steep enough.  • The brake pedal or accelerator pedal is not depressed.  Within the activation speed range 2-25 mph (4-40 km/h), the driver can control the vehicle speed by depressing the brake pedal or accelerator pedal.		
Descrivated	Green light off	Downhill Brake Control will turn off under the following conditions:  • The Downhill Brake Control button is pressed again.  • Vehicle speed is over 37 mph (60 km/h).		
Deactivated	Green light on	Downhill Brake Control will be deactivated but maintain the standby mode under the following conditions:  • The hill is not steep enough.  • Vehicle speed is between 18-37 mph (30-60 km/h).		
System malfunction	Yellow light on	The yellow warning light illuminates when the system may have malfunctioned or may not work properly during activation. If this occurs, Downhill Brake Control is deactivated. Have the system inspected by an authorized retailer of Genesis Branded products as soon as possible.		



Downhill Brake Control disabled. Control vehicle speed (manually)

When Downhill Brake Control is not working properly this warning message will appear on the cluster display and you will hear a warning sound. If this occurs, control vehicle speed by depressing the brake pedal.

# A

### **WARNING**

Always turn off Downhill Brake Control on normal roads. The system might activate inadvertently from the standby mode when driving through speed bumps or making sharp curves.



## Information

- Downhill Brake Control may not deactivate on steep inclines even though the brake pedal or accelerator pedal is depressed.
- Downhill Brake Control may not always maintain vehicle speed at a certain speed.
- Downhill Brake Control does not operate when:
  - The gear is in P (Park).
  - ESC is activated.
- Noise or vibration may occur from the brakes when Downhill Brake Control is activated.
- The rear stop light comes on when Downhill Brake Control is activated.
- When Downhill Brake Control (DBC) is activated, paddle shift operation is limited.

# **Good Braking Practices**



## WARNING

Whenever leaving the vehicle or parking, always come to a complete stop and continue to depress the brake pedal. Shift the gear to the P (Park) position, then apply the parking brake, and press the Start/Stop button to the OFF position.

Vehicles parked with the parking brake not applied or not fully engaged may roll inadvertently and may cause injury to the driver and others. ALWAYS apply the parking brake before exiting the vehicle.

Be aware of wet brakes. The brakes may get wet if the vehicle is driven through standing water or if it is washed. Your vehicle will not stop as quickly if the brakes are wet. Wet brakes may cause the vehicle to pull to one side.

To dry the brakes, apply the brakes lightly until the braking action returns to normal. If the braking action does not return to normal, stop as soon as it is safe to do so and call an authorized retailer of Genesis Branded products for assistance.

DO NOT drive with your foot resting on the brake pedal. Even light, but constant pedal pressure can result in the brakes overheating, brake wear, and possibly even brake failure.

If a tire goes flat while you are driving, apply the brakes gently and keep the vehicle pointed straight ahead while you slow down. When you are moving slowly enough for it to be safe to do so, pull off the road and stop in a safe location.

Keep your foot firmly on the brake pedal when the vehicle is stopped to prevent the vehicle from rolling forward.

# **ALL WHEEL DRIVE (AWD)**

When All Wheel Drive (AWD) is activated, driving forces are distributed appropriately to front and rear wheels. It could improve driving performance by maximizing the driving force of vehicles on severe road conditions such as steep hills, unpaved, slippery, etc.

## Advantage of electronic AWD

- 1. Improvement of straight stability
- 2. Improvement of driving performance on curve
- 3. Secure stability on severe condition such as wet and sandy roads.
- Improvement of energy efficiency from driving mode automatic control.



#### Information

AWD vehicles could change the engagement status of the motor according to the situation required. Auto changing the driving mode(2WD/AWD) helps improve energy efficiency and driving stability.



# **WARNING**

To reduce the risk of SERIOUS INJURY or DEATH:

- Avoid high speeds when cornering or turning.
- Do not make quick steering wheel movements, such as sharp lane changes or fast, sharp turns.
- The risk of a rollover is greatly increased if you lose control of your vehicle at highway speeds.
- Loss of control often occurs if two or more wheels drop off the roadway and the driver over steers to reenter the roadway.
- In the event your vehicle leaves the roadway, do not steer sharply. Instead, slow down before pulling back into the travel lanes.

# **NOTICE**

- Do not drive in water if the water level is higher than the bottom of the vehicle.
- Check your brake condition once you are out of mud or water. Depress the brake pedal several times as you move slowly until you feel normal braking condition is returned.
- Shorten your scheduled maintenance interval if you drive in off-road conditions such as sand, mud or water (Refer to the "Maintenance Under Severe Usage Conditions" section in chapter 9).
- Always wash your vehicle thoroughly after off road use, especially the bottom of the vehicle.
- Be sure to equip the vehicle with four tires of the same size and type.
- Make sure that a full time AWD vehicle is towed by a flat bed tow truck.

# All Wheel Drive (AWD) Operation Auto AWD mode (Normal diving)

If the AWD system determines there is a need for four wheel drive, the motor's driving power is distributed to all four wheels automatically.

### For safe AWD operation

#### Before driving

- Make sure all passengers are wearing seat belts.
- Sit upright and closer to the steering wheel than usual. Adjust the steering wheel to a position comfortable for you to drive.

#### Driving on snow-covered or icy roads

- Start off slowly by applying the accelerator pedal gently.
- · Use snow tires or tire chains.
- Keep sufficient distance between your vehicle and the vehicle in front of you.
- Avoid speeding, rapid acceleration, sudden brake applications, and sharp turns to prevent skids.
- It is difficult to start again if the vehicle stops on an uphill road. Keep your distance from other vehicles and drive slowly.

# **Information**

When using Snow Tires, mount them on all four wheels.

When using tire chains, install them on the rear tires.

However, driving speed must be below 18 mph (30 km/h) and minimize the driving distance. High-speed or long-term driving with tire chains installed may malfunction or damage the AWD system.

For more information on Snow Tires and Tire Chains, refer to the "Winter Driving" section later in this chapter.

#### Driving in sand or mud

- · Maintain slow and constant speed.
- Use tire chains driving in mud if necessary.
- Keep sufficient distance between your vehicle and the vehicle in front of you.
- Reduce vehicle speed and always check the road condition.
- Avoid speeding, rapid acceleration, sudden brake applications, and sharp turns to prevent getting stuck.

## NOTICE

When the vehicle is stuck in snow, sand or mud, place a nonslip material under the drive wheels to provide traction OR slowly spin the wheels in forward and reverse directions which causes a rocking motion that may free the vehicle.

#### Driving up or down hills

- · Driving uphill
  - Before starting off, check if it is possible to drive uphill.
  - Drive as straight as possible.
- · Driving downhill
  - Do not change gear while driving downhill. Select gear before driving downhill.
  - Drive straight as possible.



# WARNING

Exercise extreme caution driving up or down steep hills. The vehicle may flip over depending on the grade, terrain, water and mud conditions.



# ! WARNING

Do not drive across the contour of steep hills. A slight change in the wheel angle can destabilize the vehicle, or a stable vehicle may lose stability if the vehicle stops its forward motion. Your vehicle may roll over and lead to a serious injury or death.

### Driving through water

- Try to avoid driving in deep standing water.
- Do not change gear while driving in water.



# **CAUTION**

Always drive slowly in water. If you drive too fast, water may get into the motor compartment, causing your vehicle to suddenly stop.

## Additional driving conditions

- Become familiar with the off-road conditions before driving.
- Always pay attention when driving offroad and avoid dangerous areas.
- Drive slowly when driving in heavy wind.
- Reduce vehicle speed when cornering. The center of gravity of AWD vehicles is higher than conventional 2WD vehicles, making them more likely to roll over when you rapidly turn corners.
- Always hold the steering wheel firmly when you are driving off-road.



# ! WARNING

Do not grab the inside of the steering wheel when you are driving off-road. You may hurt your arm by a sudden steering maneuver or from steering wheel rebound due to an impact with objects on the ground. You could lose control of the steering wheel which may lead to serious injury or death.

# **Emergency Precautions**

#### **Tires**

When replacing tires, be sure to equip all four tires with the same size, type, tread patterns, brand and load-carrying capacity.



# **WARNING**

Do not use tire and wheel with different size and type from the one originally installed on your vehicle. It can affect the safety and performance of your vehicle, which could lead to steering failure or rollover causing serious injury.

# **MARNING**



Never start or run the vehicle while an AWD vehicle is raised on a jack. The vehicle can slip or roll off of a jack causing serious injury or death to you or those nearby.

## **Towing**

AWD vehicles must be towed with a wheel lift and dollies or flatbed equipment with all the wheels off the ground. For more information, refer to "Towing" section in chapter 8.

# Vehicle inspection

- If the vehicle needs to be operated on a vehicle lift do not attempt to stop any of the four wheels from turning. This could damage the AWD system.
- Never engage the parking brake while running the vehicle on a car lift. This may damage the AWD system.

### Dynamometer testing

An AWD vehicle must be tested on a special four wheel chassis dynamometer.



[A]: Roll tester (Speedometer),

[B]: Temporary free roller

An AWD vehicle should not be tested on a 2WD roll tester. If a 2WD roll tester must be used, perform the following procedure:

- 1. Check the tire pressures recommended for your vehicle.
- Place the rear wheels on the roll tester for a speedometer test as shown in the illustration.
- 3. Release the parking brake.
- 4. Place the front wheels on the temporary free roller as shown in the illustration.



# **WARNING**

Keep away from the front of the vehicle while the vehicle is in gear on the dynamometer. The vehicle can jump forward and cause serious injury or death.

# **ELECTRONIC CONTROL SUSPENSION (IF EQUIPPED)**

Electronic Control Suspension controls the vehicle suspension automatically using vehicle sensors to maximize driving comfort by taking into account the driving conditions such as speed, surface of the road, cornering, braking, and acceleration.

# **System Malfunction**



**Check Electronic Suspension** 

When Electronic Control Suspension is not working properly, this warning message appears on the cluster display. Have the system inspected by an authorized retailer of Genesis Branded products.

# ELECTRONICALLY CONTROLLED SUSPENSION WITH ROAD PREVIEW (IF EQUIPPED)

Electronically Controlled Suspension with Road Preview controls the vehicle suspension automatically using the front view camera and vehicle sensors to maximize driving comfort by taking into account the driving conditions such as speed, surface of the road, cornering, braking, and acceleration.

#### Front view camera



[1]: Front view camera

The front view camera is a sensor that detects the front road. If the windshield or the front view camera is covered with snow, rain or foreign matters, the data collected by the camera is limited due to the degradation of the camera's performance. Always keep the front view camera clean.

# NOTICE

- Never disassemble the camera sensors or camera sensor assemblies.
- Only have the detecting sensor replaced or repaired by an authorized HYUNDAI dealer.
- Never install any accessories, stickers, or tint the front windshield.
- Always keep the camera dry.
- Never place any reflective objects (e.g. white paper, mirror) on the dashboard.

# **System Malfunction**



**Check Electronic Suspension** 

When Electronically Controlled Suspension with Road Preview is not working properly, this warning message appears on the cluster display. Have the system inspected by an authorized retailer of Genesis Branded products.

# NOTICE

If the battery level is high or low, Electronically Controlled Suspension with Road Preview may not work temporarily to protect the system. If this occurs, 'Check Electronic Suspension' warning message appears.

# **Limitations of the System**

Electronically Controlled Suspension with Road Preview always operates while driving according to the vehicle's movement, and the preview function starts to work when the front view camera detects road conditions such as speed bumps. Therefore, the preview function is limited when there is an extreme condition that the front view camera may not work normally. In this case, the electronic control suspension function operates without the preview function in accordance with vehicle movement.

#### DRIVE MODE INTEGRATED CONTROL SYSTEM

# **Selecting Drive Mode**

Drive mode may be selected according to the driver's preference or road condition.

### Changing drive mode (ECO, COMFORT, SPORT, MY DRIVE, SNOW)



The mode changes, as the following, whenever the DRIVE MODE switch is pushed up or down.

 ECO > COMFORT > SPORT > MY (preselected MY DRIVE mode)

To select SNOW mode, push the DRIVE MODE switch up or down for more than one second.

# Setting MY DRIVE mode

MY DRIVE mode allows the driver to personalize the setting of the motor, steering wheel, and suspension.

- To set MY DRIVE mode, go to Setup > Vehicle > Drive Mode > MY DRIVE MODE in the infotainment system.
  - Motor: ECO/COMFORT/SPORT
  - Steering: COMFORT/SPORT
  - Suspension: COMFORT/SPORT
- The drive mode shifts from ECO, COMFORT, SPORT to the pre-selected MY DRIVE mode when the DRIVE MODE switch is pushed up or down.

### Setting BRAKE mode

You can adjust the brake response by selecting the drive mode from the Settings menu.

- To set BRAKE mode, go to Setup > Vehicle > Drive Mode > Brakes in the infotainment system.
  - COMFORT: Brake response appropriate for comfort driving.
  - SPORT: Brake response appropriate for dynamic driving.

# ECO, COMFORT, SPORT, SNOW Mode Features

#### ECO mode

ECO mode is a driving mode that helps improve energy efficiency by limiting maximum vehicle power (torque), providing smooth vehicle response, and driving the vehicle with the rear wheels (2WD).

Energy efficiency varies according to the driver's driving habit and road condition.

 When ECO mode is selected, the ECO indicator illuminates on the instrument cluster and theme of the instrument cluster is changed.

#### When ECO mode is activated:

- All wheel drive and sharp acceleration and deceleration is limited.
- The vehicle automatically converts between 2WD to AWD when:
  - i-Pedal or One Pedal Driving is operating
  - The temperature is low
  - Driving on a hill or a slippery road

#### **COMFORT** mode

COMFORT mode is a driving that provides comfortable driving with normal motor response. The vehicle is driven mainly with the rear wheels (2WD), and automatically converts to AWD according to the road and driving conditions.

#### SPORT mode

SPORT mode is a driving mode that provides sporty but firm riding by making the motor response more quickly, making the steering wheel heavier and driving the vehicle with all four wheels (AWD).

In SPORT mode, the energy efficiency may decrease.

- When SPORT mode is selected, the SPORT indicator illuminates on the instrument cluster and theme of the instrument cluster is changed.
- Whenever the vehicle is restarted, the drive mode reverts back to COMFORT mode. If SPORT mode is required, re-select SPORT mode.

#### SNOW mode

SNOW mode offers special traction tuning to optimize available traction in adverse conditions. Snow mode adjusts the left and right wheel slip control, and distributes the driving power to the four wheels automatically according to available traction levels.

- Push the switch up or down and hold the DRIVE MODE switch to select SNOW mode.
- When the SNOW mode is selected, the SNOW indicator illuminates on the instrument cluster.
- When SNOW mode is selected while the regenerative braking level is in 2, 3, AUTO
  or i-PEDAL is on, regenerative braking level changes to 1 automatically.

### **Drive Modes Characteristic**

The characteristic of each components varies depending on which drive mode is selected.

Drive Mode	COMFORT	ECO	SPORT	SNOW
Characteristics	Comfortable driving mode	High electric energy efficiency mode	Sporty driving mode	Snow optimizing available traction mode
Switch activation	Push up or down	Push up or down	Push up or down	Push up or down and hold
Indicator on the instrument cluster	-	ECO	SPORT	SNOW
Climate control system	COMFORT	ECO (ECO/ COMFORT) *1	COMFORT	COMFORT
Speed Limit	-	-	-	-
Regenerative braking level				0-1

<sup>\*1:</sup> You can set the driving condition for each drive mode, at the drive mode setting in the infotainment system.

For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

# **BOOST MODE**



Boost mode maximizes motor performance for about 10 seconds for rapid acceleration.

# **Using Boost Mode**

Press the **BOOST** button on the steering wheel while driving to enable boost mode.

While on boost mode, the motor overboost activates. The boost mode is maintained for 10 seconds and turns off automatically.

# $\triangle$

# CAUTION

- The driver should hold the responsibility to safely drive and control the vehicle when using Boost mode.
- Do not attempt to drive dangerously while using Boost mode.

### **Boost Mode Limitations**

Boost mode may turn off during operation or may not operate when:

- The gear is shifted to N (Neutral), R (Reverse), or P (Park)
- The motor or the battery has a problem
- The high voltage battery state of charge is under 25 %

# **ACTIVE NOISE CONTROL-ROAD (IF EQUIPPED)**

Active noise control-road helps reduce noise caused while driving.

The system may not operate properly in the following conditions:

- Any of the window is open
- Any of the door is open
- The liftgate is open
- Vehicle's microphone and speaker is blocked by loads

# **System Malfunction**



OJWEV061046L

When Active noise control-road is not working properly, this warning message will appear on the cluster display. Have the system inspected by an authorized retailer of Genesis Branded products.

### **ACTIVE SOUND DESIGN**

- Active Sound Design provides various virtual driving sounds based on the driving mode, vehicle speed, and accelerator pedal. You can adjust the volume and change the settings for acceleration pedal response and sound style.
- · To change settings or turn off the Active Sound Design in the infotainment system, select:
  - Setup > Vehicle > Active Sound Design, or Setup > Sound > Active **Sound Design**
- · When Advanced Settings is selected, you can set a sound for your electric vehicle:
  - Futuristic: Futuristic driving sound
  - G-Engine: Engine sound
  - E-Motor: Added motor sound
- The volume of the Active Sound Design is adjusted according to the drive mode (Eco, Comfort, Sport) selected or Boost mode
- Any unauthorized replacement of the vehicle's speaker and amplifier may cause Active Sound Design to malfunction.

# Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

#### SPECIAL DRIVING CONDITIONS

# **Hazardous Driving Conditions**

When hazardous driving elements are encountered such as water, snow, ice, mud and sand, take the following precautions:

- Drive cautiously and maintain a longer braking distance.
- · Avoid abrupt braking or steering.
- When your vehicle is stuck in snow, mud, or sand, use second gear. Accelerate slowly to avoid unnecessary wheel spin.
- Put sand, rock salt, tire chains or other non-slip materials under the wheels to provide additional traction while the vehicle becomes stuck in ice, snow, or mud.

# **MARNING**

Changing the tire speed suddenly could cause the tires to skid while driving on slippery surface. Be careful when driving on slippery surfaces.

# **Rocking the Vehicle**

If it is necessary to rock the vehicle to free it from snow, sand, or mud, first turn the steering wheel right and left to clear the area around your front wheels. Then, shift back and forth between R (Reverse) and a forward gear.

Try to avoid spinning the wheels, and do not race the vehicle.

To prevent gear wear, wait until the wheels stop spinning before shifting gears. Release the accelerator pedal while shifting, and press lightly on the accelerator pedal while the vehicle is in gear. Slowly spinning the wheels in forward and reverse directions causes a rocking motion that may free the vehicle.



Always turn off the ESC system before rocking the vehicle. If the vehicle is stuck and excessive wheel spin occurs, the temperature in the tires may increase very quickly. If the tires become damaged, a tire blow out or tire explosion may occur - you and others may be injured. Do not attempt this procedure if people or objects are near the vehicle.

If you attempt to free the vehicle, the vehicle may overheat quickly, possibly causing a motor compartment fire or other damage. Try to avoid spinning the wheels as much as possible to prevent overheating of the tires or the motor. DO NOT allow the vehicle to spin the wheels above 35 mph (56 km/h).

If you are still stuck after rocking the vehicle a few times, have the vehicle pulled out by a tow vehicle to avoid motor overheating, possible damage to the gear, and tire damage. Refer to the "Towing" section in chapter 8.

# **Smooth Cornering**

Avoid braking or gear changing in corners, especially when roads are wet. Ideally, cornering should be taken under gentle acceleration.

# **Driving at Night**

Night driving presents more hazards than driving in the daylight. Here are some important tips to remember:

- Slow down and keep more distance between you and other vehicles, as it may be more difficult to see at night, especially in areas where there may not be any street lights.
- Adjust your mirrors to reduce the glare from other drivers' headlights.
- Keep your headlights clean and properly aimed. Dirty or improperly aimed headlights will make it much more difficult to see at night.
- Avoid staring directly at the headlights of oncoming vehicles. You could be temporarily blinded, and it will take several seconds for your eyes to readjust to the darkness.

# Driving in the Rain

Rain and wet roads can make driving dangerous. When driving in the rain or on slick pavement:

- Slow down and allow extra following distance. A heavy rainfall makes it harder to see and increases the distance needed to stop your vehicle.
- Turn OFF your Smart Cruise Control. (if equipped)
- Replace your windshield wiper blades when they show signs of streaking or missing areas on the windshield.
- Make sure your tires have enough tread. If your tires do not have enough tread, making a quick stop on wet pavement may cause a skid and possibly lead to a collision. Refer to the "Tire Tread" section in chapter 9.
- Turn on your headlights to make it easier for others to see you. Using your headlights when using your windshield wipers is required in some jurisdictions.

- Driving too fast through large puddles may affect your brakes. If you must go through puddles, try to drive through them slowly.
- If you believe your brakes are wet, apply them several times while the vehicle is moving slowly.

### Hydroplaning

If the road is wet enough and you are going fast enough, your vehicle may have little or no contact with the road surface and actually ride on the water. The best advice is SLOW DOWN when the road is wet.

The risk of hydroplaning increases as the depth of tire tread decreases, refer to the "Tire Tread" section in chapter 9.

# **Driving in Flooded Areas**

Avoid driving through flooded areas unless you are sure the water is not deeper than the bottom of the wheel hub. If you are not sure, turn around and find a different route.

Drive through any water slowly. Allow adequate stopping distance because the brake performance can be reduced.

After driving through water, dry the brakes by gently applying them several times while the vehicle is moving slowly.

# **Highway Driving**

#### Tires

Adjust the tire inflation pressure, as specified. Under-inflation may overheat or damage the tires.

Do not install worn-out or damaged tires, which may reduce traction or fail.



# Information

Never over-inflate your tires above the maximum inflation pressure, as specified on your tires.

## Coolant and high voltage battery

Driving at higher speeds on the highway consumes more electric energy and is less efficient than driving at a slower. more moderate speed. Maintain a moderate speed in order to conserve electric energy when driving on the highway.

Be sure to check both the coolant level and the electric energy level before driving.

# Reducing the Risk of a Rollover

Your multi-purpose passenger vehicle is defined as a Sports Utility Vehicle (SUV). SUV's have higher ground clearance and a narrower track to make them capable of performing in a wide variety of off-road applications. The specific design characteristics give them a higher center of gravity than ordinary vehicles making them more likely to roll over if you make abrupt turns. Utility vehicles have a significantly higher rollover rate than other types of vehicles. Due to this risk, driver and passengers are strongly recommended to buckle their seat belts. In a rollover crash, an unbelted person is significantly more likely to die than a person wearing a seat belt.

There are steps that a driver can make to reduce the risk of a rollover. If at all possible, avoid sharp turns or abrupt maneuvers, do not load your vehicle with heavy cargo on the roof, and never modify your vehicle in any way.



# ! WARNING

Utility vehicles have a significantly higher rollover rate than other types of vehicles. To prevent rollovers or loss of control:

- Take corners at slower speeds than you would with a passenger vehicle.
- · Avoid sharp turns and abrupt maneuvers.
- Do not modify your vehicle in any way that you would raise the center of gravity.
- Keep tires properly inflated.
- Do not carry heavy cargo on the roof.



# **WARNING**

In a rollover crash, an unbelted person is significantly more likely to die than a person wearing a seat belt. Make sure all passengers are wearing their seat belts.

#### WINTER DRIVING

The severe weather conditions of winter quickly wear out tires and cause other problems. To minimize winter driving problems, you should take the following suggestions:

# **Snow or Icy Conditions**

You need to keep sufficient distance between your vehicle and the vehicle in front of you.

Apply the brakes gently. Speeding, rapid acceleration, sudden brake applications, and sharp turns are potentially very hazardous practices. Sudden brake applications on snowy or icy roads may cause the vehicle to skid.

To drive your vehicle in deep snow, it may be necessary to install tire chains on your tires.

Always carry emergency equipment. Some of the items you may want to carry include tire chains, tow straps or chains, a flashlight, emergency flares, sand, a shovel, jumper cables, a window scraper, gloves, ground cloth, coveralls, a blanket, etc.

#### Snow tires



Snow tires should be equivalent in size and type to the vehicle's standard tires. Otherwise, the safety and handling of your vehicle may be adversely affected.

Use snow tires when road temperature is below 45°F (7°C). Refer to the below chart, and mount the recommended snow tire for your vehicle.

Standa	ard tire	Recommended snow tire		
Tire size	Wheel size	Tire size	Wheel size	
265/45 R20	8.5J x 20	265/45 R20	8.5J x 20	

If you mount snow tires on your vehicle, make sure to use the same Inflation pressure as the original tires. Mount snow tires on all four wheels to balance your vehicle's handling in all weather conditions. The traction provided by snow tires on dry roads may not be as high as your vehicle's original equipment tires. Check with the tire dealer for maximum speed recommendations.

#### Summer tires

- Summer tires are used to maximize the driving performance on dry roads.
- If the temperature is below 45°F (7°C) or you are driving on snowy or icy roads, the summer tires lose their brake performance and traction as the tire grip weakens significantly.
- If the temperature is below 45°F
   (7°C) or you are driving on snowy or
   icy roads, mount snow tires or all season tires of the same size with your
   vehicle's standard tire for safe driving.
   Both snow and all-season tires have
   M+S markings.
- When using the M+S tires, use tires with the same tread produced by the same manufacturer for safe driving.
- When driving with the M+S tires with the lower maximum allowable speed than that of the vehicle's standard summer tire, be careful not to exceed the speed allowed for the M+S tires.

## Tire chains (Auto sock)



Since the sidewalls of radial tires are thinner, they can be damaged by mounting some types of snow chains on them. Therefore, the use of snow tires is recommended instead of snow chains.

Do not mount tire chains on vehicle equipped with aluminum wheels; snow chains may cause damage to the wheels. If possible, use AutoSock (fabric snow chain). Damage to your vehicle caused by improper snow chain use is not covered by your vehicle manufacturer's warranty.

When using tire chains, install tire chains only on the rear tires.



# **WARNING**

The use of AutoSock (fabric snow chain) may adversely affect vehicle handling:

- Drive less than 20 mph (30 km/h) or the chain manufacturer's recommended speed limit, whichever is lower.
- Drive carefully and avoid bumps, holes, sharp turns, and other road hazards, which may cause the vehicle to bounce.
- Avoid sharp turns or locked wheel braking.

# *i* Information

- Install AutoSock (fabric snow chain) only in pairs and on the rear tires. It should be noted that installing AutoSock (fabric snow chain) on the tires will provide a greater driving force, but will not prevent side skids.
- Do not install studded tires without first checking local and municipal regulations for possible restrictions against their use.

#### **Chain Installation**

When installing tire chains, follow the manufacturer's instructions and mount them as tightly possible. Drive slowly (less than 20 mph (30 km/h)) with chains installed. If you hear the chains contacting the body or chassis, stop and tighten them. If they still make contact, slow down until the noise stops. Remove the tire chains as soon as you begin driving on cleared roads.

When mounting snow chains, park the vehicle on level ground away from traffic. Turn on the vehicle Hazard Warning Flasher and place a triangular emergency warning device behind the vehicle (if available). Always place the vehicle in P (Park), apply the parking brake and turn off the vehicle before installing snow chains.

# NOTICE

When using AutoSock (fabric snow chain):

- Wrong size chains or improperly installed chains can damage your vehicle's brake lines, suspension, body and wheels.
- If you hear noise caused by chains contacting the body, retighten the chain to prevent contact with the vehicle body.
- To prevent body damage, retighten the chains after driving 0.3-0.6 miles (0.5-1.0 km).

#### Winter Precautions

#### Use high quality ethylene glycol coolant

Your vehicle is delivered with high quality ethylene glycol coolant in the cooling system. It is the only type of coolant that should be used because it helps prevent corrosion in the cooling system, lubricates the water pump, and prevents freezing. Be sure to replace or replenish your coolant in accordance with the maintenance schedule in chapter 9. Before winter, have your coolant tested to make sure that its freezing point is sufficient for the temperatures anticipated during the winter.

#### Check battery and cables

Winter temperatures affect battery performance. Inspect the battery and cables, as specified in chapter 9. Have the battery charging level inspected by an authorized retailer of Genesis Branded products or in a service station.

#### To prevent locks from freezing

Spray approved de-icing fluid or glycerin into key holes. When a lock opening is already covered with ice, spray approved de-icing fluid over the ice to remove it. When an internal part of a lock freezes, try to thaw it with a heated key. Carefully use the heated key to avoid an injury.

#### Use approved window washer antifreeze solution

Add window washer anti-freeze solution, as specified on the window washer container. Window washer anti-freeze solution is available from an authorized retailer of Genesis Branded products, and most vehicle accessory outlets. Do not use coolant or other types of anti-freeze solution, to prevent any damage to the vehicle paint.

#### Do not let your parking brake freeze

Under some conditions, your parking brake may freeze in the engaged position. This is most likely to happen when there is an accumulation of snow or ice around or near the rear brakes or the brakes are wet. When there is the risk that your parking brake may freeze: temporarily apply the parking brake with the gear in P (Park), then block the rear wheels, and then release the parking brake.

# Do not let ice and snow accumulate underneath

Under some conditions, snow and ice may build up under the fenders and interfere with the steering. When driving in such conditions during the severe winter, check underneath the vehicle on a regular basis, to make sure that the front wheels and the steering components are not blocked.

### Carry emergency equipment

In accordance with weather conditions, carry appropriate emergency equipment, while driving. Some of the items you may want to carry include tire chains, tow straps or chains, flashlight, emergency flares, sand, shovel, jumper cables, window scraper, gloves, ground cloth, coveralls, blanket, etc.

# Do not place objects or materials in the motor compartment

Putting objects or materials in the motor compartment may cause a motor failure. Such damage is not be covered by the manufacturer's warranty.

#### TRAILER TOWING

If you are considering to tow with your vehicle, you should first your state's legal requirements. As laws vary the requirements for towing trailers, cars, or other types of vehicles or apparatus may differ. Ask an authorized retailer of Genesis Branded products for further details before towing.

Remember that trailering is different than just driving your vehicle by itself. Trailering means changes in handling, durability, and fuel economy. Successful, safe trailering requires correct equipment, and it has to be used properly. Damage to your vehicle caused by improper trailer towing is not covered by your vehicle manufacturer's warranty.

This section contains many time-tested, important trailering tips and safety rules. Many of these are important for your safety and that of your passengers. Please read this section carefully before you pull a trailer.



# WARNING

Take the following precautions:

- If you don't use the correct equipment and/or drive improperly, you can lose control of the vehicle when you are pulling a trailer. For example, if the trailer is too heavy, the braking performance may be reduced. You and your passengers could be seriously or fatally injured. Pull a trailer only if you have followed all the steps in this section.
- Before towing, make sure the total trailer weight, GCW (Gross Combination Weight), GVW (Gross Vehicle Weight), GAW (Gross Axle Weight) and trailer tongue load are all within the limits.

# **A** CAUTION

- Always have your eyes on the road when towing a trailer. When a trailer is connected to the tow hitch harness installed to your vehicle, the following functions are turned off automatically:
  - Forward Collision-Avoidance Assist
  - Lane Keeping Assist
  - Blind-Spot Collision-Avoidance Assist
  - Safe Exit Assist
  - Smart Cruise Control
  - Navigation-based Smart Cruise Control
  - Lane Following Assist
  - Highway Driving Assist
  - Rear Cross-Traffic Collision-Avoidance Assist
  - Reverse Parking Distance Warning
  - Parking Collision-Avoidance Assist
  - Remote Smart Parking Assist

For more information on each function, refer to chapter 7.

The tow hitch harness installed to your vehicle must be a genuine Genesis parts. For more information, consult an authorized retailer of Genesis Branded products.


- If a trailer or hitch mounted carrier is attached, it may adversely affect the performance of the rear corner radar.
- If a trailer, carrier or other attachment is installed around the rear corner radar, Blind-Spot Collision-Avoidance Assist, Safe Exit Assist, Rear Cross-Traffic Collision-Avoidance Assist may not operate properly, or it may operate unexpectedly.

#### If You Decide to Pull a Trailer?

Here are some important points if you decide to pull a trailer:


- Consider using a sway control. You can ask a trailer hitch dealer about sway control.
- Do not do any towing with your vehicle during its first 1,200 miles (2,000 km) in order to allow the motor to properly break in. Failure to heed this caution may result in serious motor or gear damage.
- When towing a trailer, be sure to consult an authorized retailer of Genesis Branded products for further information on additional requirements such as a towing kit, etc.
- Always drive your vehicle at a moderate speed (less than 60 mph (100 km/h)) or posted towing speed limit.
- On a long uphill grade, do not exceed 45 mph (70 km/h) or the posted towing speed limit, whichever is lower.
- Carefully observe the weight and load limits provided in the following pages.

# Trailer weight



What is the maximum safe weight of a trailer? It should never weigh more than the maximum trailer weight with trailer brakes. But even that can be too heavy. It depends on how you plan to use your trailer. For example, speed, altitude, road grades, outside temperature and how often your vehicle is used to pull a trailer are all important. The ideal trailer weight can also depend on any special equipment that you have on your vehicle.

## Tongue load



The tongue load is an important weight to measure because it affects the total Gross Vehicle Weight (GVW) of your vehicle. The trailer tongue should weigh a maximum of 10 % of the total loaded trailer weight, within the limits of the maximum trailer tongue load permissible.

After you've loaded your trailer, weigh the trailer and then the tongue, separately, to see if the weights are proper. If they aren't, you may be able to correct them simply by moving some items around in the trailer.



# WARNING

Take the following precautions:

- Never load a trailer with more weight in the rear than in the front. The front should be loaded with about 60 % of the total trailer load; the rear should be loaded with about 40 % of the total trailer load.
- Never exceed the maximum weight limits of the trailer or trailer towing equipment. Improper loading can result in damage to your vehicle and/ or personal injury. Check weights and loading at a commercial scale or highway patrol office equipped with scales.

## Towing a trailer - Maximum towing limits

The following table indicates the maximum trailer weight for your vehicle. Do not exceed the maximum allowable trailer weight. The maximum trailer weight includes the weight of the trailer, any cargo, and equipment or items attached to the trailer. The towing load in excess of these limits can seriously affect vehicle steering and performance, and may damage the motor and drivetrain.

Item		AWD		
	With brake system	3,500 lbs. (1,588 kg)		
Maximum trailer weight	Without brake system	1,653 lbs. (750 kg)		
Maximum permissible tongue weight		397 lbs. (180 kg)		
Recommended distance from rear wheel center to coupling point		42.32 in. (1,075 mm)		

Any additional weight, cargo, or accessories in your vehicle will reduce the maximum trailer weight and corresponding tongue load limits.

# Trailer Towing Equipment Hitches





The mounting hole for hitches are located on both sides of the underbody behind the rear tires.

It's important to have the correct hitch equipment. Crosswinds, large trucks going by, and rough roads are a few reasons why you'll need the right hitch. Here are some rules to follow:

- Do you have to make any holes in the body of your vehicle when you install a trailer hitch? If you do, then be sure to seal the holes later when you remove the hitch. If you don't seal them, dirt and water can get into your vehicle
- The bumpers on your vehicle are not intended for hitches. Do not attach rental hitches or other bumper-type hitches to them. Use only a framemounted hitch that does not attach to the bumper.

 Any part of the rear number plate or lighting devices of the vehicle must not be obscured by the mechanical coupling device.

If the rear number plate and/or lighting devices can be obscured partially by any part of the mechanical coupling device, mechanical coupling devices that can not be easily removed or repositioned without use of any tools, except an easily operated (for example, an effort not exceeding 20Nm) release key which is supplied by the manufacturer of the coupling device, are not permitted for use.

Please note that the mechanical coupling device that is fitted and not in use must always be removed or repositioned if the rear number plate and/or rear lighting devices are obscured by any part of the mechanical coupling device.

 A Genesis Branded Vehicle trailer hitch accessory is available at an authorized retailer of Genesis Branded products.

### Safety chains

Always attach chains between your vehicle and your trailer.

Instructions about safety chains may be provided by the hitch manufacturer or trailer manufacturer. Follow the manufacturer's recommendation for attaching safety chains. Always leave just enough slack so you can turn with your trailer. And, never allow safety chains to drag on the ground.

#### Trailer brakes

If your trailer is equipped with a braking system, make sure it conforms to your state's regulations and that it is properly installed and operating correctly.

If your trailer weighs more than the maximum trailer weight without trailer brakes loaded, then it needs its own brakes and they must be adequate. Be sure to read and follow the instructions for the trailer brakes so you'll be able to install, adjust and maintain them properly. Be sure not to modify your vehicle's brake system.



#### WARNING

Do not use a trailer with its own brakes unless you are absolutely certain that you have properly set up the brake system. This is not a task for amateurs. Use an experienced, competent trailer shop for this work.

## **Driving with a Trailer**

Towing a trailer requires a certain amount of experience. Before setting out for the open road, you must get to know your trailer. Acquaint yourself with the feel of handling and braking with the added weight of the trailer. And always keep in mind that the vehicle you are driving is now longer and not nearly as responsive as your vehicle is by itself.

Before you start, check the trailer hitch and platform, safety chains, electrical connector(s), lights, tires and brakes.

During your trip, occasionally check to be sure that the load is secure, and that the lights and trailer brakes are still working.



## Information

When the ambient temperature is lower than 32 °F (0 °C) and the remaining high voltage battery is low, the power of the vehicle with a trailer can be dropped, causing a trouble in acceleration or drop of the speed when driving hills.

When driving with a trailer, be sure to charge the high voltage battery more than 50 % if the ambient temperature is lower than 32 °F (0 °C).



# Information

When towing a trailer, select COMFORT mode as drive mode.

#### Distance

Stay at least twice as far behind the vehicle ahead as you would when driving your vehicle without a trailer. This can help you avoid situations that require heavy braking and sudden turns.

### **Passing**

You will need more passing distance up ahead when you're towing a trailer. And, because of the increased vehicle length, you'll need to go much farther beyond the passed vehicle before you can return to your lane.

## Backing up

Hold the bottom of the steering wheel with one hand. Then, to move the trailer to the left, move your hand to the left. To move the trailer to the right, move your hand to the right. Always back up slowly and, if possible, have someone guide you.

# Making turns

When you're turning with a trailer, make wider turns than normal. Do this so your trailer won't strike soft shoulders, curbs, road signs, trees, or other objects. Avoid jerky or sudden maneuvers. Signal well in advance.

### Turn signals

When you tow a trailer, your vehicle has to have a different turn signal flasher and extra wiring. The green arrows on your instrument panel will flash whenever you signal a turn or lane change. Properly connected, the trailer lights will also flash to alert other drivers you're about to turn, change lanes, or stop.

When towing a trailer, the green arrows on your instrument panel will flash for turns even if the bulbs on the trailer are burned out. Thus, you may think drivers behind you are seeing your signals when, in fact, they are not. It's important to check occasionally to be sure the trailer bulbs are still working. You must also check the lights every time you disconnect and then reconnect the wires.



## **WARNING**

Do not connect a trailer lighting system directly to your vehicle's lighting system. Use an approved trailer wiring harness. Failure to do so could result in damage to the vehicle electrical system and/or personal injury. Consult an authorized retailer of Genesis Branded products for assistance.

# **Driving on hills**

Reduce speed before you start down a long or steep downgrade.

On a long uphill grade, reduce your speed to around 45 mph (70 km/h) to reduce the possibility of motor overheating.

# NOTICE

To prevent motor overheating:

- If you tow a trailer with the maximum gross vehicle weight and maximum trailer weight, it can cause the motor to overheat. When driving in such conditions, allow the motor to idle until it cools down. You may proceed once the motor has cooled sufficiently.
- When towing a trailer, your vehicle speed may be much slower than the general flow of traffic, especially when climbing an uphill grade. Use the right hand lane when towing a trailer on an uphill grade. Choose your vehicle speed according to the maximum posted speed limit for vehicles with trailers, the steepness of the grade, and your trailer weight.

### Parking on hills

Generally, if you have a trailer attached to your vehicle, you should not park your vehicle on a hill.

However, if you ever have to park your trailer on a hill, here's how to do it:

- Pull the vehicle into the parking space.
   Turn the steering wheel in the direction of the curb (right if headed down hill, left if headed up hill).
- 2. Shift the gear to P (Park).
- 3. Set the parking brake and shut off the vehicle
- Place wheel chocks under the trailer wheels on the down hill side of the wheels.
- Start the vehicle, hold the brakes, shift to neutral, release the parking brake and slowly release the brakes until the trailer chocks absorb the load.
- 6. Reapply the brakes and parking brakes.
- 7. Shift the gear to P (Park).
- 8. Shut off the vehicle and release the vehicle brakes but leave the parking brake set.



# **WARNING**

To prevent serious or fatal injury:

- Do not get out of the vehicle without the parking brake firmly set. If you have left the vehicle on (READY indicator on), the vehicle can move suddenly. You and others could be seriously or fatally injured.
- Do not apply the accelerator pedal to hold the vehicle on an uphill.

# Driving the vehicle after it has been parked on a hill

- With the gear in P (Park), apply your brakes and hold the brake pedal down while you:
  - · Start your vehicle;
  - · Shift into gear; and
  - Release the parking brake.
- 2. Slowly remove your foot from the brake pedal.
- 3. Drive slowly until the trailer is clear of the chocks.
- 4. Stop and have someone pick up and store the chocks.

# Maintenance When Towing a Trailer

Your vehicle will need service more often when you regularly pull a trailer. Important items to pay particular attention to include gear fluid, axle lubricant and cooling system fluid. Brake condition is another important item to frequently check. If you're trailering, it's a good idea to review these items before you start your trip. Don't forget to also maintain your trailer and hitch. Follow the maintenance schedule that accompanied your trailer and check it periodically. Preferably, conduct the check at the start of each day's driving. Most importantly, all hitch nuts and bolts should be tight.

# NOTICE

To prevent vehicle damage:

- Due to higher load during trailer usage, overheating might occur on hot days or during uphill driving.
- When towing check gear fluid more frequently.

#### VEHICLE LOAD LIMIT

Two labels on your driver's door sill show how much weight your vehicle was designed to carry: the Tire and Loading Information Label and the Certification Label.

Before loading your vehicle, familiarize yourself with the following terms for determining your vehicle's weight ratings, from the vehicle's specifications and the Certification Label:

## Base curb weight

This is the weight of the vehicle including a full tank of fuel and all standard equipment. It does not include passengers, cargo, or optional equipment.

# Vehicle curb weight

This is the weight of your new vehicle when you picked it up from your dealer plus any aftermarket equipment.

# Cargo weight

This figure includes all weight added to the Base Curb Weight, including cargo and optional equipment.

# GAW (Gross Axle Weight)

This is the total weight placed on each axle (front and rear) - including vehicle curb weight and all payload.

# GAWR (Gross Axle Weight Rating)

This is the maximum allowable weight that can be carried by a single axle (front or rear). These numbers are shown on the Certification Label. The total load on each axle must never exceed its GAWR.

## **GVW (Gross Vehicle Weight)**

This is the Base Curb Weight plus actual Cargo Weight plus passengers.

## **GVWR (Gross Vehicle Weight Rating)**

This is the maximum allowable weight of the fully loaded vehicle (including all options, equipment, passengers and cargo). The GVWR is shown on the Certification Label located on the driver's door sill.

# The Loading Information Label



The label located on the driver's door sill gives the original tire size, cold tire pressures recommended for your vehicle, the number of people that can be in your vehicle and vehicle capacity weight.

### Vehicle capacity weight

5 persons: 882 lbs. (400 kg) Vehicle capacity weight is the maximum combined weight of occupants and cargo. If your vehicle is equipped with a trailer, the combined weight includes the tongue load.

## Seating capacity

Total: 5 persons (Front seat: 2 persons, Rear seat: 3 persons)

Seating capacity is the maximum number of occupants including a driver, your vehicle may carry.

However, the seating capacity may be reduced based upon the weight of all of the occupants, and the weight of the cargo being carried or towed. Do not overload the vehicle as there is a limit to the total weight, or load limit including occupants and cargo, the vehicle can carry.

# Towing capacity

With trailer brakes: 3500 lbs. (1588 kg) Without trailer brakes: 1653 lbs. (750 kg)

Towing capacity is the maximum trailer weight including its cargo weight, your vehicle can tow.

# Cargo capacity

The cargo capacity of your vehicle will increase or decrease depending on the weight and the number of occupants and the tongue load, if your vehicle is equipped with a trailer.

# Steps for determining correct load limit

- Locate the statement "The combined weight of occupants and cargo should never exceed XXX lbs. or XXX kg" on your vehicle's placard.
- 2. Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- Subtract the combined weight of the driver and passengers from XXX lbs. or XXX kg.
- 4. The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1400 lbs. and there will be five 150 lb passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs. (1400 750 (5 x 150) = 650 lbs.)
- Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.
- If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle.



Do not overload the vehicle as there is a limit to the total weight, or load limit, including occupants and cargo, the vehicle can carry. Overloading can shorten the life of the vehicle. If the GVWR or the GAWR is exceeded, parts on the vehicle can be broken, and it can change the handling of your vehicle. These could cause you to lose control and result in an accident.

Example 1	Vehicle Capacity	2	<b>*</b>	+	
	Maximum Load (1400 lbs.) (635 kg)		Passenger Weight (150 lbs. × 2 = 300 lbs.) (68 kg × 2 = 136 kg)		Cargo Weight (1100 lbs.) (499 kg)
Example 2	Vehicle Capacity	≥	<b>**</b> *	+	
	Maximum Load (1400 lbs.) (635 kg)		Passenger Weight (150 lbs. × 5 = 750 lbs.) (68 kg × 5 = 340 kg)		Cargo Weight (650 lbs.) (295 kg)
Example 3	Vehicle Capacity	2	<b>444</b> <b>44</b>	+	
	Maximum Load (1400 lbs.) (635 kg)		Passenger Weight (172 lbs. × 5 = 860 lbs.) (78 kg × 5 = 390 kg)		Cargo Weight (540 lbs.) (245 kg)

#### Certification label



The certification label is located on the driver's door sill at the center pillar and shows the maximum allowable weight of the fully loaded vehicle. This is called the GVWR (Gross Vehicle Weight Rating). The GVWR includes the weight of the vehicle, all occupants, fuel and cargo.

This label also tells you the maximum weight that can be supported by the front and rear axles, called Gross Axle Weight Rating (GAWR).

The total weight of the vehicle, including all occupants, accessories, cargo, and trailer tongue load must not exceed the Gross Vehicle Weight Rating (GVWR) or the Gross Axle Weight Rating (GAWR). To find out the actual loads on your front and rear axles, you need to go to a weigh station and weigh your vehicle. Be sure to spread out your load equally on both sides of the centerline.



# ! WARNING

#### Overloading

- Never exceed the GVWR for your vehicle, the GAWR for either the front or rear axle and vehicle capacity weight. Exceeding these ratings can affect your vehicle's handling and braking ability, and cause an accident.
- Do not overload your vehicle. Overloading your vehicle can cause heat buildup in your vehicle's tires and possible tire failure, increased stopping distances and poor vehicle handling-all of which may result in a collision.

# NOTICE

Overloading your vehicle may cause damage. Repairs would not be covered by your warranty. Do not overload your vehicle.



# **WARNING**

If you carry items inside your vehicle (for example, suitcases, tools, packages, or anything else), they are moving as fast as the vehicle. If you have to stop or turn quickly, or if there is a crash, the items will keep going and can cause an injury if they strike the driver or a passenger.


- Put items in the cargo area of your vehicle. Try to spread the weight evenly.
- Do not stack items like suitcase inside the vehicle above the tops of the seats.
- Do not leave an unsecured child restraint in your vehicle.
- When you carry something inside the vehicle, secure it.

# 7. Driver Assistance System

Due to the infotainment software update, the description of each function of the driver assistance system may differ from the owner's manual. In this case, for detailed information on updates, scan the QR code in the separately supplied simple manual.

Driving Safety	
Forward Collision-Avoidance Assist (FCA)	7-2
Lane Keeping Assist (LKA)	7-28
Blind-Spot Collision-Avoidance Assist (BCA)	7-35
Safe Exit Assist (SEA)	7-49
Manual Speed Limit Assist (MSLA)	7-55
Intelligent Speed Limit Assist (ISLA)	
Driver Attention Warning (DAW)	
Forward Attention Warning (FAW)	7-70
Blind-Spot View Monitor (BVM)	
Driving Convenience	
Smart Cruise Control (SCC)	
Navigation-based Smart Cruise Control (NSCC)	7-94
Lane Following Assist (LFA)	7-101
Highway Driving Assist (HDA)	7-105
Parking Safety	
Rear View Monitor (RVM)	7-118
Surround View Monitor (SVM)	7-121
Rear Cross-Traffic Collision-Avoidance Assist (RCCA)	
Forward/Reverse Parking Distance Warning (PDW)	
Reverse Parking Collision-Avoidance Assist (PCA)	7-143
Parking Convenience	
Remote Smart Parking Assist (RSPA)	7-151
Declaration of Conformity	

# FORWARD COLLISION-AVOIDANCE ASSIST (FCA)




OJKEV071082

Forward Collision-Avoidance Assist is designed to help detect and monitor the vehicle ahead or help detect a pedestrian or cyclist in the roadway and warn the driver that a collision is imminent with a warning message and warning and application of emergency braking.


In addition, if equipped with front corner radars, when driving at high speeds, Forward Collision-Avoidance Assist will help detect vehicles in front and adjacent lanes. If a collision is imminent when changing lanes, Forward Collision-Avoidance Assist will apply emergency braking to help prevent a collision. (if equipped)

# **Junction Turning function**



Junction Turning function can help avoid a collision with an oncoming vehicle in an adjacent lane when turning left at a crossroad with the turn signal on by applying emergency braking.

# Junction Crossing function (if equipped)



Junction Crossing function can help avoid a collision with oncoming vehicles on the left or right side when crossing an intersection by applying emergency braking.


# Lane-Change Oncoming function (if equipped)



[A]: Oncoming vehicle

Lane-Change Oncoming function helps avoid a collision with an oncoming vehicle when changing lanes by assisting the driver's steering.


# Lane-Change Side function (if equipped)



[A]: Front-side vehicle

Lane-Change Side function helps avoid a collision with the vehicle ahead in the next lane when changing lanes by assisting the driver's steering.

# **Evasive Steering Assist function (if equipped)**



- Driver steering assist
   Evasive Steering Assist function
   helps avoid a collision with a vehicle,
   pedestrian or cyclist ahead in the
   same lane. When a risk of collision
   is detected, Evasive Steering Assist
   function will warn the driver and if the
   driver steers to avoid collision it will
   assist the driver's steering.
- Evasive steering assist
   Evasive Steering Assist function helps avoid a collision with a pedestrian or cyclist ahead in the same lane. When a risk of collision is detected, Evasive Steering Assist function will warn the driver and if there is space to avoid collision in the lane, it will assist the driver's steering.

# **Detecting sensor**







- [1]: Front view camera,
- [2]: Front radar,
- [3]: Front corner radar (if equipped),
- [4]: Rear corner radar

Refer to the picture above for the detailed location of the detecting sensors.

# **A** CAUTION

Take the following precautions to maintain optimal performance of the detecting sensor:

- Never disassemble the detecting sensor or sensor assembly, or cause any damage to it.
- If the detecting sensors have been replaced or repaired, have your vehicle inspected by an authorized retailer of Genesis Branded products.
- Never install any accessories or stickers on the front windshield, or tint the front windshield.
- Exercise extreme caution to keep the front view camera dry.
- Never place any reflective objects (for example, white paper, mirror) over the dashboard.
- Do not place any objects near
  the front windshield or install any
  accessories on the front windshield.
  It can affect the performance of the
  defogging and defrosting function of
  the climate control system, which may
  prevent the Driver Assistance systems
  from operating.
- Do not apply license plate frame or objects, such as a bumper sticker, film or a bumper guard, near the front radar cover.
- Always keep the front radar and cover clean and free of dirt and debris.
   Use only a soft cloth to wash the vehicle. Do not spray pressurized water directly on the sensor or sensor cover.

- If the radar or the area around the radar has been damaged or impacted in any way, Forward Collision-Avoidance Assist may not properly operate even though a warning message does not appear on the cluster. Have the vehicle inspected by an authorized retailer of Genesis Branded products.
- The performance of the front radar cover genuine parts have been proven. Replacing or painting the front radar cover may result in poor performance of Forward Collision-Avoidance Assist. When the parts need to be replaced or modified, make sure to use genuine Genesis parts.
- Vehicles equipped with front corner radar and/or rear corner radar
  - Do not apply license plate frame or objects, such as a bumper sticker, film or a bumper guard, near the front corner radar or rear corner radar.
  - The function may not work properly when the bumper has been replaced, or the surroundings of the front corner radar or rear corner radar has been damaged or paint has been applied.
  - If a trailer, carrier, etc., is installed, it may adversely affect the performance of the rear corner radar or Forward Collision-Avoidance Assist may not operate properly.

## Forward Collision-Avoidance Assist Settings

Forward Safety



OJKEV072001N

With the vehicle on, select or deselect **Setup > Vehicle > Driver Assistance > Forward Safety** from the Settings menu to set whether to use each function.

- If Active Assist is selected, Forward Collision-Avoidance Assist will warn the driver with a warning message, an audible warning and steering wheel vibration depending on the collision risk levels. Braking assist or steering assist will be applied depending on the collision risk levels.
- If Warning Only is selected, Forward Collision-Avoidance Assist will warn the driver with a warning message, an audible warning and steering wheel vibration depending on the collision risk levels. Braking and steering will not be assisted. The driver must apply the brake pedal or steer the vehicle if necessary.
- If Off is selected, Forward Collision-Avoidance Assist will turn off. The warning light pwill illuminate on the cluster.

The driver can monitor Forward Collision-Avoidance Assist On/Off status from the Settings menu. If the warning light ♣ remains ON when Forward Collision-Avoidance Assist is on, have the vehicle inspected by an authorized retailer of Genesis Branded products.

# Forward Cross-Traffic Safety (if equipped)



OJKEV072002N

With the vehicle on, select Setup > Vehicle > Driver Assistance > Forward Safety > Forward Cross-Traffic Safety from the Settings menu to turn on Junction Crossing function and deselect to turn off the function.



## WARNING

When the vehicle is restarted, Forward Collision-Avoidance Assist will always turn on. However, at all times, and especially if **Off** is selected, the driver should always be aware of the surroundings and drive safely.



## CAUTION

- If Warning Only is selected, braking or steering is not assisted.
- The settings for Forward Safety include 'Basic function', 'Junction Turning', 'Lane-Change Oncoming', 'Lane-Change Side' and 'Evasive Steering Assist'.
- If Forward Safety is set to Off, Junction Crossing function will not operate even when Forward Cross-Traffic Safety is selected.
- When a trailer is connected to the tow hitch harness installed to your vehicle, Forward Collision-Avoidance Assist automatically turns off (if equipped). In this case, Forward Collision-Avoidance Assist is not functional. Always have your eyes on the road.

## Warning Timing



OJKEV072003N

With the vehicle on, select **Setup > Vehicle > Driver Assistance > Warning Timing** from the Settings menu to
change the initial warning activation time
for Forward Collision-Avoidance Assist.
The warning time can be set to either **Standard** or **Late**.

- Use Standard in normal driving conditions. If the Warning Timing seems sensitive, change it to Late.
- If Late is selected, Forward Collision-Avoidance Assist, warns the driver more slowly.

# *i* Information

If you change the Warning Timing, the Warning Timing of other Driver Assistance systems may change.

### Warning Methods





With the vehicle on, go to Setup > Vehicle > Driver Assistance > Warning Methods from the Settings in the infotainment system to select the following:

- Warning Volume: The Warning Volume can be adjusted.
- Haptic Warning: The steering wheel vibration can be set (type A) or adjusted (type B).
- Driving Safety Priority: Your vehicle lowers all other audio volumes when the Driver Assistance system warning sounds.

# *i* Information

- If you change the Warning Methods, Warning Methods of other Driver Assistance systems may change.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- There may be no Settings menu depending on the feature applied to your vehicle.
- Even though 0 is selected for Warning Volume, Warning Volume will not be turned off but Warning Volume will sound as 1.
- When Haptic Warning is selected as 0 or deselected while Warning Volume is selected as 0, Warning Volume will activate and be selected as 2.
- When Warning Volume is selected as 0 while Haptic Warning is selected as 0 or deselected, steering wheel vibration will activate or be selected as 2.

# **CAUTION**

- The setting of the Warning Timing applies to all functions of Forward Collision-Avoidance Assist.
- Even though Standard is selected for Warning Timing, if a detected vehicle in front suddenly stops, the warning may seem late.
- Select Late for Warning Timing when traffic is light and when driving speed is slow.

## Forward Collision-Avoidance Assist Operation

#### Basic function

The basic function for Forward Collision-Avoidance Assist is to warn and help control the vehicle depending on the collision risk level: 'Collision Warning', 'Emergency Braking' and 'Stopping vehicle and ending brake control'.



#### **Collision Warning**

- To warn the driver of a collision, the 'Collision Warning' warning message will appear on the instrument cluster, an audible warning will sound and the steering wheel will vibrate.
- If a vehicle is detected in front, the function will operate when your vehicle speed is between about 6-124 mph (10-200 km/h).
- If a pedestrian or cyclist is detected in front, the function will operate when your vehicle speed is between about 6-53 mph (10-85 km/h).



**Emergency Braking** 

To warn the driver that emergency braking will be assisted, the 'Emergency Braking' warning message will appear on the instrument cluster, an audible warning will sound and the steering wheel will vibrate.

Emergency braking will operate under the following conditions:

· Vehicle:

	Driving vehicle	Stopped vehicle
Weak braking power	About 6-125 mph (10-200 km/h)	
Strong braking power	About 6-81 mph (10-130 km/h)	About 6-47 mph (10-75 km/h) (6-62 mph (10-100 km/h))*

- \*: If Forward Collision-Avoidance Assist judges that avoiding a collision is difficult even by changing the driving lane. The function operation range may decrease due to surroundings of the vehicle. (if equipped)
- · Pedestrian or cyclist:

The function will operate when your vehicle speed is between about 6-40 mph (10-65 km/h).

The function operation range may decrease due to the front traffic condition or the surroundings of the vehicle.



Stopping vehicle and ending brake control

- When the vehicle is stopped due to emergency braking, the 'Drive carefully' warning message will appear on the instrument cluster.
   For your safety, the driver should depress the brake pedal immediately and check the surroundings.
- Brake control will end after the vehicle is stopped by emergency braking for about 2 seconds.

## **Junction Turning function**

Junction Turning function will warn and control the vehicle depending on the collision risk level: 'Collision Warning', 'Emergency Braking' and 'Stopping vehicle and ending brake control'.



#### **Collision Warning**

- To warn the driver of a collision, the 'Collision Warning' warning message will appear on the instrument cluster, an audible warning will sound and the steering wheel will vibrate.
- The function will operate when your vehicle speed is between about 6-19 mph (10-30 km/h) and the oncoming vehicle speed is between about 19-44 mph (30-70 km/h).



OJKEV072260N

#### **Emergency Braking**

- To warn the driver that emergency braking will be assisted, the 'Emergency Braking' warning message will appear on the instrument cluster, an audible warning will sound and the steering wheel will
- · In emergency braking situation, braking is assisted with strong braking power by the function to help prevent collision with the oncoming vehicle.
- The function will operate when your vehicle speed is between about 6-19 mph (10-30 km/h) and the oncoming vehicle speed is between about 19-44 mph (30-70 km/h).



O.JKFV072007N

#### Stopping vehicle and ending brake control

- When the vehicle is stopped due to emergency braking, the 'Drive carefully' warning message will appear on the instrument cluster. For your safety, the driver should depress the brake pedal immediately and check the surroundings.
- · Brake control will end after the vehicle is stopped by emergency braking for about 2 seconds.

## **Junction Crossing function (if** equipped)

Junction Crossing function will warn and control the vehicle depending on collision risk level: 'Collision Warning', 'Emergency Braking' and 'Stopping vehicle and ending brake control'





OJKEV072013N

#### **Collision Warning**

- To warn the driver of a collision, the 'Collision Warning' warning message will appear on the instrument cluster, an audible warning will sound and the steering wheel will vibrate.
- The function will operate when your vehicle speed is between about 10-30 mph (6-19 km/h) and the crossing vehicle speed is between about 6-37 mph (10-60 km/h).





#### **Emergency Braking**

- To warn the driver that emergency braking will be assisted, the 'Emergency Braking' warning message will appear on the instrument cluster, an audible warning will sound and the steering wheel will vibrate.
- In emergency braking situation, braking is assisted with strong braking power by the function to help prevent collision with the crossing vehicle.
- The function will operate when your vehicle speed is between about 10–30 mph (6-19 km/h) and the crossing vehicle speed is between about 6–12 mph (10-20 km/h).



Stopping vehicle and ending brake control

- When the vehicle is stopped due to emergency braking, the 'Drive carefully' warning message will appear on the instrument cluster.
   For your safety, the driver should depress the brake pedal immediately and check the surroundings.
- Brake control will end after the vehicle is stopped by emergency braking for about 2 seconds.



## CAUTION

If the collision angle with the crossing vehicle is beyond a certain range, Junction Crossing function warning and control may be late or may not operate.

### Lane-Change Oncoming function (if eauipped)

Lane-Change Oncoming function will warn and control the vehicle depending on collision risk level: 'Collision Warning' and 'Emergency Steering'



OJKEV072008N

#### **Collision Warning**

- To warn the driver of a collision, the 'Collision Warning' warning message will appear on the instrument cluster. an audible warning will sound and the steering wheel will vibrate.
- The function will operate when your vehicle speed is between about 25-90 mph (40-145 km/h) and the oncoming vehicle speed is about above 6 mph (10 km/h) and the relative speed with your vehicle is about below 124 mph (200 km/h).



OJKEV072015N

#### **Emergency Steering**

- To warn the driver that emergency steering will be assisted, the 'Emergency Steering' warning message will appear on the instrument cluster, an audible warning will sound and the steering wheel will
- In an emergency steering situation, steering is assisted by the function to help prevent a collision with the oncoming vehicle.
- The function will operate when your vehicle speed is between about 25-90 mph (40-145 km/h) and the oncoming vehicle speed is about above 6 mph (10 km/h) and the relative speed with your vehicle is about below 124 mph (200 km/h).

# Lane-Change Side function (if equipped)

Lane-Change Side function will warn and control the vehicle depending on collision risk level: 'Collision Warning' and 'Emergency Steering'





#### **Collision Warning**

- To warn the driver of a collision, the 'Collision Warning' warning message will appear on the instrument cluster, an audible warning will sound and the steering wheel will vibrate.
- The function will operate when your vehicle speed is between about 25-90 mph (40-145 km/h).





**Emergency Steering** 

- To warn the driver that emergency steering will be assisted, the 'Emergency Steering' warning message will appear on the instrument cluster, an audible warning will sound and the steering wheel will vibrate.
- In emergency steering situation, steering is assisted by the function to help prevent collision with the frontside vehicle.
- The function will operate when your vehicle speed is between about 25-90 mph (40-145 km/h) and front-side vehicle is driving.



## **CAUTION**

Lane-Change Side function does not operate if the vehicle speed of the preceding vehicle from the front side is 0 mph (0 km/h).

### Evasive Steering Assist function (if eauipped)

Evasive Steering Assist function will warn and control the vehicle with 'Emergency steering'.






OJKEV072018N

#### **Emergency Steering (Driver steering** assist)

- To warn the driver that emergency steering will be assisted, the 'Emergency Steering' message will appear on the instrument cluster, an audible warning will sound and the steering wheel will vibrate.
- · If there is a risk of collision with a vehicle, pedestrian and cyclist in front, the steering will be assisted to help prevent collision when the driver steers the vehicle to avoid collision.
- The function will operate when your vehicle speed is between about 25-53 mph (40-85 km/h).





**Emergency Steering (Evasive steering** assist)

- To warn the driver that emergency steering will be assisted, the 'Emergency Steering' message will appear on the instrument cluster, an audible warning will sound and the steering wheel will vibrate.
- · If there is high risk of collision with a pedestrian and cyclist in front, and the vehicle speed to operate emergency braking is within the operation range. the steering will be assisted to help prevent collision when there is space to avoid collision in the driving lane.
- The function will operate when your vehicle speed is between about 40-47 mph (65-75 km/h).

# **CAUTION**

- The steering wheel may turn automatically when emergency steering is operating.
- Emergency steering will automatically cancel when risk factors disappear.
   The driver must steer the vehicle.
- Emergency steering may not operate or may cancel during operation if the steering wheel is held tight or steered in the opposite direction.
- When steering is assisted to avoid collision with a vehicle, pedestrian and cyclist, evasive steering assist will be canceled if collisions with other objects (vehicles, pedestrians, or cyclists) are expected.
- Evasive steering assist may not operate if space to avoid collision in the driving lane is insufficient.

# *i* Information

For more information on warning messages, refer to Collision Warning in "Basic Function".

# A

## WARNING

Take the following precautions when using Forward Collision-Avoidance Assist:

- For your safety, only change the Settings after parking the vehicle at a safe location.
- Forward Collision-Avoidance Assist does not operate in all situations and cannot avoid all collisions.
- The driver has the responsibility to control the vehicle. Do not solely depend on Forward Collision-Avoidance Assist. Rather, maintain a safe braking distance, and if necessary, depress the brake pedal to reduce driving speed or to stop the vehicle.
- Never deliberately operate Forward Collision-Avoidance Assist on people, objects, etc. It may cause serious injury or death.
- Forward Collision-Avoidance
   Assist may not operate if the driver depresses the brake pedal to avoid a collision.

- Depending on the road and driving conditions, Forward Collision-Avoidance Assist may warn the driver late or may not warn the driver.
- During Forward Collision-Avoidance Assist operation, the vehicle may stop suddenly injuring passengers and shifting loose objects. Always have the seat belt on and keep loose objects secured.
- If any other system's warning message is displayed or audible warning is generated, Forward Collision-Avoidance Assist warning message may not be displayed and audible warning may not be generated.
- You may not hear the warning sound of Forward Collision-Avoidance Assist if the surrounding is noisy.
- Forward Collision-Avoidance Assist may turn off or may not operate properly or may operate unnecessarily depending on the road conditions and the surroundings.

# **MARNING**

- Even if there is a problem with Forward Collision-Avoidance Assist, the vehicle's basic braking will function normally.
- During emergency braking, braking control by Forward Collision-Avoidance Assist will automatically cancel when the driver excessively depresses the accelerator pedal or sharply steers the vehicle.

# **A** CAUTION

- Depending on the condition of the vehicle, pedestrian and cyclist in front and the surroundings, the speed range to operate Forward Collision-Avoidance Assist may reduce. Forward Collision-Avoidance Assist may only warn the driver, or it may not operate.
- Forward Collision-Avoidance Assist will operate under certain conditions by judging the risk level based on the condition of the oncoming vehicle, driving direction, speed and surroundings.
- When a collision with a surrounding vehicle is expected, Lane-Change Oncoming, Lane-Change Side and Evasive Steering Assist will not assist you with steering but only warn the you of a collision (if equipped).

# *i* Information

- In a situation where collision is imminent, braking may be assisted by Forward Collision-Avoidance Assist when braking is insufficient by the driver.
- The images and colors in the instrument cluster may differ depending on the cluster type or theme selected from the settings menu.

## Forward Collision-Avoidance Assist Malfunction and Limitations

Forward Collision-Avoidance Assist malfunction



OTM070094N

When Forward Collision-Avoidance Assist is not working properly, the 'Check Forward Safety system' warning message will appear, and the A and warning lights will illuminate on the instrument cluster. Have the vehicle inspected by an authorized retailer of Genesis Branded products.

# Forward Collision-Avoidance Assist disabled



When the front view camera or radar is blocked or obscured by foreign material, rain, or snow, it can reduce the detecting performance and temporarily limit or disable Forward Collision-Avoidance Assist.

If this occurs the 'Forward Safety system(s) disabled. Camera obscured' or the 'Forward Safety system(s) disabled. Radar blocked' warning message, and the ⚠ and ఈ warning lights will illuminate on the instrument cluster.

Forward Collision-Avoidance Assist will operate properly when snow, rain or foreign material is removed.

If Forward Collision-Avoidance Assist does not operate properly after obstruction (snow, rain, or foreign material) is removed (including trailer, carrier, etc., from the rear bumper), have the vehicle inspected by an authorized retailer of Genesis Branded products.

# **MARNING**

- Even though the warning message or warning light does not appear on the cluster, Forward Collision-Avoidance Assist may not properly operate.
- Forward Collision-Avoidance Assist may not properly operate in an area (for example, open terrain), where any objects are not detected after turning ON the vehicle.

#### Limitations of Forward Collision-Avoidance Assist

Forward Collision-Avoidance Assist may not operate properly, or it may operate unexpectedly under the following circumstances:

- The detecting sensor or the surroundings are contaminated or damaged
- The temperature around the front view camera is high or low due to surrounding environment
- The camera lens is contaminated due to tinted, filmed or coated windshield, damaged glass, or sticky foreign material (sticker, bug, etc.) on the glass
- Moisture is not removed or frozen on the windshield
- Washer fluid is continuously sprayed, or the wiper is on
- Driving in heavy rain or snow, or thick fog
- The field of view of the front view camera is obstructed by sun glare
- Street light or light from an oncoming traffic is reflected on the wet road surface, such as a puddle on the road
- An object is placed on the dashboard
- Your vehicle is being towed

- · The surrounding is very bright
- The surrounding is very dark, such as in a tunnel, etc.
- The brightness changes suddenly, for example when entering or exiting a tunnel
- The brightness outside is low, and the headlights are not on or are not bright
- Driving through steam, smoke or shadow
- Only part of the vehicle, pedestrian or cyclist is detected
- The vehicle in front is a bus, heavy truck, truck with an unusually shaped cargo, trailer, etc.
- The vehicle in front has no tail lights, tail lights are located unusually, etc.
- The brightness outside is low, and the tail lights are not on or are not bright
- The rear of the front vehicle is small or the vehicle does not look normal, such as when the vehicle is tilted, overturned, or the side of the vehicle is visible, etc.
- The front vehicle's ground clearance is low or high
- A vehicle, pedestrian or cyclist suddenly cuts in front
- The bumper around the front radar is impacted, damaged or the front radar is out of position
- The temperature around the front radar is high or low
- · Driving through a tunnel or iron bridge

- Driving in vast areas where there are few vehicles or structures (for example, desert, meadow, suburb, etc.)
- Driving near areas containing metal substances, such as a construction zone, railroad, etc.
- A material is near that reflects very well on the front radar, such as a guardrail, nearby vehicle, etc.
- The cyclist in front is on a bicycle made of material that does not reflect on the front radar
- · The vehicle in front is detected late
- The vehicle in front is suddenly blocked by an obstacle
- The vehicle in front suddenly changes lane or suddenly reduces speed
- The vehicle in front is bent out of shape
- · The front vehicle speed is fast or slow
- The vehicle in front steers in the opposite direction of your vehicle to avoid a collision
- With a vehicle in front, your vehicle changes lane at low speed
- The vehicle in front is covered with snow
- You are departing or returning to the lane
- Unstable driving
- You are on a roundabout and the vehicle in front is not detected

- · You are continuously driving in a circle
- The vehicle in front has an unusual shape
- The vehicle in front is driving uphill or downhill
- The pedestrian or cyclist is not fully detected, for example, if the pedestrian is leaning over or is not fully walking upright
- The pedestrian or cyclist is wearing clothing or equipment that makes it difficult to detect



The illustration above shows the image the front view camera and front radar are capable of detecting as a vehicle, pedestrian and cyclist.

- The pedestrian or cyclist in front is moving very quickly
- The pedestrian or cyclist in front is short or is posing a low posture
- The pedestrian or cyclist in front has impaired mobility
- The pedestrian or cyclist in front is moving intersected with the driving direction

- There is a group of pedestrians, cyclists or a large crowd in front
- The pedestrian or cyclist is wearing clothing that easily blends into the background, making it difficult to detect
- The pedestrian or cyclist is difficult to distinguish from the similarly shaped structure in the surroundings
- You are driving by a pedestrian, cyclist, traffic signs, structures, etc., near the intersection
- · Driving in a parking lot
- Driving through a tollbooth, construction area, unpaved road, partial paved road, uneven road, speed bumps, etc.
- Driving on an incline road, curved road, etc.
- Driving through a roadside with trees or streetlights
- The adverse road conditions cause excessive vehicle vibrations while driving
- Your vehicle height is low or high due to heavy loads, abnormal tire pressure, etc.
- Driving through a narrow road where trees or grass are overgrown
- There is interference by electromagnetic waves, such as driving in an area with strong radio waves or electrical noise

Junction Crossing, Lane-Change Oncoming, Lane-Change Side, Evasive Steering Assist function (if equipped)

- The temperature around the front corner radar or rear corner radar is high or low
- A trailer or carrier is installed around the rear corner radar
- The front corner radar or rear corner radar is covered with snow, rain, dirt, etc.
- The bumper around the front corner radar or rear corner radar is covered with objects, such as a bumper sticker, bumper guard, bike rack, etc.
- The bumper around the front corner radar or rear corner radar is impacted, damaged or the radar is out of position
- The front corner radar or rear corner radar is blocked by other vehicles, walls or pillars
- Driving on a highway ramp or driving through a tollbooth
- Driving on a road where the guardrail or wall is in double structure
- The other vehicle drives very close behind your vehicle, or the other vehicle passes by your vehicle in close proximity

- The speed of the other vehicle is very fast so that it passes by your vehicle in a short time
- Your vehicle passes by the other vehicle
- Your vehicle has started at the same time as the vehicle next to you and has accelerated
- The vehicle in the next lane moves two lanes away from you, or when the vehicle two lanes away moves to the next lane from you
- · A motorcycle or bicycle is detected
- A vehicle such as a flat trailer is detected
- A big vehicle such as a bus or truck is detected
- A small moving obstacle such as a pedestrian, animal, shopping cart or a baby stroller is detected
- A vehicle with low height such as a sports car is detected
- The lane is difficult to see due to foreign material, such as rain, snow, dust, sand, oil and water puddles
- The color of the lane marking is not distinguishable from the road

- There are markings on the road near the lane or the markings on the road looks similar to the lane markings
- The shadow is on the lane marking by a median strip, trees, guardrail, noise barriers, etc.
- The lane number increases or decreases, or the lane markings are crossing
- There are more than two lane markings on the road
- The lane markings are complicated or a structure substitutes for the lines, such as a construction area
- There are road markings, such as zigzag lanes, crosswalk markings and road signs
- The lane suddenly disappears, such as at the intersection
- · The lane is very wide or narrow
- There is a curb or road edges without a lane
- The vehicle in front is driving with one side on the lane marking
- The distance to the front vehicle is extremely short



#### · Driving on a curved road







Forward Collision-Avoidance Assist may not detect other vehicles, pedestrians or cyclists in front of you when driving on curved roads adversely affecting the performance of the sensors. This may result in no warning, braking assist or steering assist (if equipped) when necessary.

When driving on a curve, you must maintain a safe braking distance, and if necessary, steer the vehicle and depress the brake pedal to reduce your driving speed in order to maintain a safe distance.








Forward Collision-Avoidance Assist may detect a vehicle, pedestrian or cyclist in the next lane or outside the lane when driving on a curved road.

If this occurs, Forward Collision-Avoidance Assist may unnecessarily warn the driver and control the brake or steering wheel (if equipped). Always check the traffic conditions around the vehicle.

#### · Driving on an inclined road



Forward Collision-Avoidance Assist may not detect other vehicles, pedestrians or cyclists in front of you while driving uphill or downhill, adversely affecting the performance of the sensors.

This may result in unnecessary warning, braking assist (if equipped) or steering assist or no warning, braking assist or steering assist (if equipped) when necessary.

Also, vehicle speed may rapidly decrease when a vehicle, pedestrian or cyclist ahead is suddenly detected.

Always have your eyes on the road while driving uphill or downhill and if necessary, steer your vehicle and depress the brake pedal to reduce your driving speed in order to maintain a safe distance.

#### · Changing lanes



[A]: Your vehicle, [B]: Lane changing vehicle

When a vehicle moves into your lane from an adjacent lane, it cannot be detected by the sensor until it is in the sensor's detection range. Forward Collision-Avoidance Assist may not immediately detect the vehicle when the vehicle changes lanes abruptly. In this case, you must maintain a safe braking distance, and if necessary, steer your vehicle and depress the brake pedal to reduce your driving speed in order to maintain a safe distance.



[A]: Your vehicle,

[B]: Lane changing vehicle,

[C]: Same lane vehicle

When a vehicle in front of you merges out of the lane, Forward Collision-Avoidance Assist may not immediately detect the vehicle that is now in front of you. In this case, you must maintain a safe braking distance, and if necessary, steer your vehicle and depress the brake pedal to reduce your driving speed in order to maintain a safe distance.

#### · Detecting vehicle



If the vehicle in front of you has cargo that extends rearward from the cab, or when the vehicle in front of you has higher ground clearance, additional special attention is required. Forward Collision-Avoidance Assist may not be able to detect the cargo extending from the vehicle. In these instances, you must maintain a safe braking distance from the rearmost object, and if necessary, steer your vehicle and depress the brake pedal to reduce your driving speed in order to maintain distance.

# **MARNING**

- When you are towing a trailer or another vehicle, turn off Forward Collision-Avoidance Assist for safety reasons.
- Forward Collision-Avoidance Assist may operate if objects that are similar in shape or characteristics to vehicles, pedestrians and cyclists are detected.
- Forward Collision-Avoidance Assist does not operate on bicycles, or smaller wheeled objects, such as luggage bags, shopping carts, or strollers.
- Forward Collision-Avoidance Assist may not operate properly if interfered by strong electromagnetic waves.
- Forward Collision-Avoidance Assist may not operate for 15 seconds after the vehicle is started, or the front view camera is initialized.

# *i* Information

This device complies with Part 15 of the FCC rules.

Operation is subject to the following three conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

# Information

Radio frequency radiation exposure information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance of 8 in. (20 cm) between the radiator (antenna) and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## LANE KEEPING ASSIST (LKA)

Lane Keeping Assist is designed to help detect lane markings (or road edges) while driving over a certain speed. Lane Keeping Assist will warn the driver if the vehicle leaves the lane without using the turn signal, or will automatically assist the driver's steering to help prevent the vehicle from departing the lane.

### **Detecting sensor**



[1]: Front view camera

The front view camera is used as a detecting sensor to detect lane markings (or road edges).

Refer to the picture above for the detailed location of the detecting sensor.



### CAUTION

For more information on the precautions of the front view camera, refer to the "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

## Lane Keeping Assist Settings Lane Safety



With the vehicle on, select or deselect Setup > Vehicle > Driver Assistance > Lane Safety from the Settings menu to set whether to use each function.

- If Assist is selected, Lane Keeping
   Assist will automatically assist the
   driver's steering when lane departure
   is detected to help prevent the vehicle
   from moving out of its lane.
- If Warning Only is selected, Lane Keeping Assist will warn the driver with an audible warning and steering wheel vibration when lane departure is detected. The driver must steer the vehicle.
- If Off is selected, Lane Keeping Assist will turn off. The / indicator light will turn off on the cluster.

# **MARNING**

- If Warning Only is selected, steering is not assisted.
- Lane Keeping Assist does not control the steering wheel when the vehicle is driven in the middle of the lane.
- The driver should always be aware of the surroundings and steer the vehicle especially if Off is selected.



## CAUTION

When a trailer is connected to the tow hitch harness installed to your vehicle. Lane Keeping Assist automatically turns off (if equipped). In this case, Lane Keeping Assist is not functional. Always have your eyes on the road.

### Warning Methods





OJKEV072309N

В



OJKEV072310N

With the vehicle on, go to Setup > Vehicle > Driver Assistance > Warning **Methods** from the Settings in the infotainment system to select the following:

- Warning Volume: The Warning Volume can be adjusted.
- Haptic Warning: The steering wheel vibration can be set (type A) or adjusted (type B).
- Lane Safety Audible Warning Off: The warning volume of Lane Safety does not sound when Haptic Warning is selected (type A) or when adjusted between 1 to 3 (type B).

 Driving Safety Priority: Your vehicle lowers all other audio volumes when the Driver Assistance system warning sounds.



### Information

- If you change the Warning Methods, Warning Methods of other Driver Assistance systems may change.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- There may be no Settings menu depending on the feature applied to your vehicle.
- Even though 0 is selected for Warning Volume, the Hands-Off warning volume will not be turned off but Warning volume will sound as 1.
- When Haptic Warning is selected as 0 or deselected while Warning Volume is selected as 0, Warning Volume will activate and be selected as 2.
- When Warning Volume is selected as **0** while **Haptic Warning** is selected as **0** or deselected, steering wheel vibration will activate or be selected as 2.

# Keeping Assist Operation Turning Lane Keeping Assist On/Off



OJKEVO/112

With the vehicle on, press and hold the Lane Driving Assist button located on the steering wheel to turn on Lane Keeping Assist. The Lane Safety ( indicator light will illuminate on the cluster.

Press and hold the button again to turn off the function.


If the vehicle is restarted, Lane Keeping Assist will maintain the last setting.

# *i* Information

- When the Lane Driving Assist button is pressed shortly, Lane Following Assist will turn on and off.
- If the vehicle is restarted, Lane Keeping Assist will maintain the last setting.

Lane Keeping Assist will warn and help control the vehicle with Lane Departure Warning and Lane Keeping Assist.

### Warning and control



[A]: Left, [B]: Right

#### **Lane Departure Warning**

- To warn the driver that the vehicle is departing from the projected lane in front, the green ♠ indicator light will blink on the instrument cluster, the lane line will blink on the instrument cluster depending on which direction the vehicle is veering, and an audible warning will sound. Also, the steering wheel will vibrate.
- Lane Departure Warning will operate when your vehicle speed is between about 40-120 mph (60-200 km).

#### Lane Keeping Assist

- To warn the driver that the vehicle is departing from the projected lane in front, the green indicator light will blink on the cluster, and the steering wheel will make adjustments to keep vehicle inside the lane.
- Lane Keeping Assist will operate when your vehicle speed is between about 40-120 mph (60-200 km).

### Hands-off warning




If the driver takes their hands off the steering wheel for several seconds, the 'Keep hands on steering wheel' warning message will appear on the instrument cluster, and an audible warning will sound in stages.

# **MARNING**

- The steering wheel may not be assisted if the steering wheel is held very tight or the steering wheel is steered over a certain degree.
- Lane Keeping Assist does not operate at all times. It is the responsibility of the driver to safely steer the vehicle and to maintain the vehicle in its lane.
- The hands-off warning message may appear late depending on road conditions. Always have your hands on the steering wheel while driving.
- If the steering wheel is held very lightly, the hands-off warning message may appear because Lane Keeping Assist may not recognize that the driver has their hands on the steering wheel.
- If you attach objects to the steering wheel, the hands-off warning may not work properly.

# *î* Information

- For more information on instrument cluster settings, refer to the "Cluster Display Control" section in chapter 4.
- When lane markings (or road edges) are detected, the lane lines on the cluster will change from grey to white and the green indicator light will illuminate.
- When the lane markings (or road edges) are detected and Highway Lane Change Assist is on, the lane lines on the cluster may change to green.



[A]: Lane undetected, [B]: Lane detected

- The images and colors in the instrument cluster may differ depending on the cluster type or theme selected from the settings menu.
- Even though the steering is assisted by Lane Keeping Assist, the driver may control the steering wheel.
- The steering wheel may feel heavier or lighter when the steering wheel is assisted by Lane Keeping Assist than when it is not.

# Lane Keeping Assist Malfunction and Limitations

Lane Keeping Assist malfunction



ORG3EV071192L

When Lane Keeping Assist is not working properly, the 'Check Lane Keeping Assist (LKA) system' warning message will appear and the yellow / indicator light will illuminate on the instrument cluster. If this occurs, have the vehicle inspected by an authorized retailer of Genesis Branded products.

#### Limitations of Lane Keeping Assist

Lane Keeping Assist may not operate properly or may operate unexpectedly under the following circumstances:

- The lane is contaminated or difficult to detect because:
  - The lane markings (or road edge) are covered with rain, snow, dirt, oil, etc.
  - The color of the lane marking (or road edge) is not distinguishable from the road
  - There are markings (or road edges) on the road near the lane or the markings (or road edges) on the road look similar to the lane markings (or road edge)
  - The lane marking (or road edge) is indistinct or damaged
  - The shadow is on the lane marking (or road edge) by a median strip, trees, guardrail, noise barriers, etc.
- The lane number increases or decreases, or the lane markings (or road edges) are crossing
- There are more than two lane markings (or road edges) on the road
- The lane markings (or road edges) are complicated or a structure substitutes for the lines, such as a construction area
- There are road markings, such as zigzag lanes, crosswalk markings and road signs
- The lane suddenly disappears, such as at the intersection
- The lane (or road width) is very wide or narrow

- There is a road edge without a lane
- There is a boundary structure in the roadway, such as a tollgate, sidewalk, curb, etc.
- The distance to the front vehicle is extremely short or the vehicle in front is covering the lane marking (or road edge)



### Information

For more information on the limitations of the front view camera, refer to the "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

# **MARNING**

Take the following precautions when using Lane Keeping Assist:


- The driver has the responsibility to safely drive and control the vehicle.
   Do not solely rely on Lane Keeping Assist.
- The operation of Lane Keeping Assist can be canceled or not work properly depending on road conditions and surroundings. Always be cautious while driving.
- Refer to "Limitations of Lane Keeping Assist" if the lane is not detected properly.
- When you are towing a trailer or another vehicle, turn off Lane Keeping Assist for safety reasons.
- If the vehicle is driven at high speed, the steering wheel will not be controlled. The driver must always follow the speed limit when using Lane Keeping Assist.
- If any other system's warning message is displayed or audible warning is generated, Lane Keeping Assist warning message may not be displayed and audible warning may not be generated.

- You may not hear the warning sound of Lane Keeping Assist if the surrounding is noisy.
- If you attach objects to the steering wheel, steering may not be assisted properly.
- Lane Keeping Assist may not operate for 15 seconds after the vehicle is started, or the front view camera is initialized.
- Lane Keeping Assist will not operate when:
  - The turn signal or hazard warning flasher is turned on.
  - The vehicle is not driven in the center of the lane when Lane Keeping Assist is turned on or right after changing a lane.
  - ESC (Electronic Stability Control) or VSM (Vehicle Stability Management) is activated.
  - The vehicle is driven on a sharp curve.
  - Vehicle speed is below 35 mph (55 km) or above 130 mph (210 km).
  - The vehicle makes sudden lane changes.
  - The vehicle brakes suddenly.

## **BLIND-SPOT COLLISION-AVOIDANCE ASSIST (BCA)**

Blind-Spot Collision-Avoidance Assist is designed to help detect and monitor approaching vehicles in the driver's blind spot area and warn the driver of a possible collision with a warning message and audible warning.

In addition, if there is a risk of collision when changing lanes or driving forward out of a parking space, Blind-Spot Collision-Avoidance Assist can help avoid a collision by applying the brake.




Blind-Spot Collision-Avoidance Assist helps detect and informs the driver that a vehicle is in the blind spot.



#### **CAUTION**

The detecting range may vary depending on the speed of your vehicle. Even if there is a vehicle in the blind spot area. Blind-Spot Collision-Avoidance Assist may not warn you when you pass by at high speeds.



Blind-Spot Collision-Avoidance Assist helps detect and informs the driver that a vehicle is approaching at high speed from the blind spot area.




## **CAUTION**

Warning timing may vary depending on the speed of the vehicle approaching at high speed.



When changing lanes by detecting the lane ahead, if Blind-Spot Collision-Avoidance Assist detects that there is a collision risk with an approaching vehicle in the blind spot, it can help avoid collision by applying the brake.



When you are driving forward out of a parking space, if Blind-Spot Collision-Avoidance Assist judges that there is a collision risk with an approaching vehicle in the blind spot, it can help avoid collision by applying the brake.

# **Detecting sensor**





- [1]: Front view camera,
- [2]: Rear corner radar

Refer to the picture above for the detailed location of the detecting sensors.

# **A** CAUTION

Take the following precautions to maintain optimal performance of the detecting sensor:

- Never disassemble the detecting sensor assembly, or cause any damage to it.
- If the detecting sensor or the area the sensor has been damaged or impacted in any way, even though the warning message does not appear on the cluster, Blind-Spot Collision-Avoidance Assist may not operate properly. Have the vehicle inspected by an authorized retailer of Genesis Branded products.
- If the detecting sensors have been replaced or repaired, have the vehicle inspected by an authorized retailer of Genesis Branded products.
- Rear bumper genuine parts with rear corner radars have proven their performance. Replacing or painting the rear bumper may result in poor performance of Blind-Spot Collision-Avoidance Assist. When the parts need to be replaced or modified, make sure to use genuine Genesis parts.
- Do not apply license plate frame or objects, such as a bumper sticker, film or a bumper guard near the rear corner radar.
- Blind-Spot Collision-Avoidance
   Assist may not work properly if the
   bumper has been replaced, or the
   surroundings of the rear corner radar
   has been damaged or paint has been
   applied.
- If a trailer, carrier, etc., is installed, it may adversely affect the performance of the rear corner radar or Blind-Spot Collision-Avoidance Assist may not operate.
- For more information on the precautions of the front view camera, refer to the "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

## Blind-Spot Collision-Avoidance Assist Settings

Blind-Spot Safety



With the vehicle on, select or deselect **Setup > Vehicle > Driver Assistance > Blind-Spot Safety** from the Settings menu to set whether to use each function.

- If Active Assist is selected, Blind-Spot Collision-Avoidance Assist will warn the driver with a warning message, an audible warning and steering wheel vibration depending on the collision risk levels. Braking assist will be applied depending on the collision risk levels.
- If Warning Only is selected, Blind-Spot Collision-Avoidance Assist will warn the driver with a warning message, an audible warning and steering wheel vibration depending on the collision risk levels. Braking will not be assisted.
- If Off is selected, Blind-Spot Collision-Avoidance Assist will turn off.



When the vehicle is restarted with Blind-Spot Collision-Avoidance Assist off, the 'Blind-Spot Safety System is Off' message will appear on the instrument cluster.

If you change the setting from **Off** to **Active Assist** or **Warning Only**, the warning light on the side view mirror will blink for three seconds.

In addition, if the vehicle is turned on, when Blind-Spot Collision-Avoidance Assist is set to **Active Assist** or **Warning Only**, the warning light on the side view mirror will blink for three seconds.

# **WARNING**

- If Warning Only is selected, braking is not assisted.
- The driver should always be aware of the surroundings and drive safely especially if Off is selected.



If the vehicle is restarted, Blind-Spot Collision-Avoidance Assist will maintain the last setting.

# **CAUTION**

When a trailer is connected to the tow hitch harness installed to your vehicle, Blind-Spot Collision-Avoidance Assist automatically turns off (if equipped). In this case, Blind-Spot Collision-Avoidance Assist is not functional. Always have your eyes on the road.

### Warning Timing



With the vehicle on, select **Setup > Vehicle > Driver Assistance > Warning Timing** from the Settings menu to change the initial warning activation time for Blind-Spot Collision-Avoidance Assist. The warning time can be set to either **Standard** or **Late**.

- Use Standard in normal driving conditions. If the Warning Timing seems sensitive, change it to Late.
- If Late is selected, Blind-Spot Collision-Avoidance Assist, warns the driver more slowly.

# *i* Information

If you change the Warning Timing, the Warning Timing of other Driver Assistance systems may change.

### Warning Methods





OJKEV072325N

В



OJKEV072326N

With the vehicle on, go to **Setup > Vehicle > Driver Assistance > Warning Methods** from the Settings in the infotainment system to select the following:

- Warning Volume: The Warning Volume can be adjusted.
- Haptic Warning: The steering wheel vibration can be set (type A) or adjusted (type B).
- Driving Safety Priority: Your vehicle lowers all other audio volumes when the Driver Assistance system warning sounds.

# *i* Information

- If you change the Warning Methods, Warning Methods of other Driver Assistance systems may change.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- There may be no Settings menu depending on the feature applied to your vehicle.
- Even though 0 is selected for Warning Volume, Warning Volume will not be turned off but Warning Volume will sound as 1.
- When Haptic Warning is selected as 0 or deselected while Warning Volume is selected as 0, Warning Volume will activate and be selected as 2.
- When Warning Volume is selected as 0 while Haptic Warning is selected as 0 or deselected, steering wheel vibration will activate or be selected as 2.



## CAUTION

- The setting of the Warning Timing applies to all functions of Blind-Spot Collision-Avoidance Assist.
- Even though Standard is selected for Warning Timing, if a vehicle approaches at high speed, the warning may seem late.
- Select Late for Warning Timing when traffic is light and when driving speed is slow.

## Blind-Spot Collision-Avoidance Assist Operation

Vehicle detection



- To warn the driver a vehicle is detected, the warning light on the side view mirror and head-up display (if equipped) will illuminate.
- Blind-Spot Collision-Avoidance Assist will operate when your vehicle speed is above 12 mph (20 km/h) and the speed of the vehicle in the blind spot area is above 7 mph (10 km/h).

### **Collision warning**

- Collision warning will operate when the turn signal is turned on in the direction of the detected vehicle.
- To warn the driver of a collision, the warning light on the side view mirror and head-up display (if equipped) will blink. At the same time, an audible warning will sound and the steering wheel will vibrate.
- When the turn signal is turned off or you move away from the lane, the collision warning will be canceled and Blind-Spot Collision-Avoidance Assist will return to vehicle detection state.

# in

## Information

If 'Warning Only' is selected from the Settings menu, the collision warning will operate when your vehicle approaches the lane the blind spot vehicle is detected.

# A

## WARNING

- The detecting range of the rear corner radar is determined by a standard road width, therefore, on a narrow road, Blind-Spot Collision-Avoidance Assist may detect other vehicles two lanes over and warn you. In contrast, on a wide road, Blind-Spot Collision-Avoidance Assist may not be able to detect a vehicle driving in the next lane and may not warn you.
- When the hazard warning flasher is on, the collision warning by the turn signal will not operate.

## Collision-Avoidance Assist (while driving)



- To warn the driver of a collision, the warning light on the side view mirror will blink and a warning message will appear on the instrument cluster. At the same time, an audible warning will sound, warning light on the head-up display (if equipped) will blink and the steering wheel will vibrate.
- Emergency braking will be assisted to help prevent collision with the vehicle in the blind spot area.
- Blind-Spot Collision-Avoidance Assist will operate when your vehicle speed is between 37-124 mph (60-200 km/h) and both lane markings of the driving lane are detected.

## **MARNING**

- Collision-Avoidance Assist will be canceled under the following circumstances:
  - Your vehicle enters the next lane by a certain distance
  - Your vehicle is away from the collision risk
  - The steering wheel is sharply steered
  - The brake pedal is depressed
  - Forward Collision-Avoidance Assist is operating
- After Blind-Spot Collision-Avoidance
   Assist operation or lane change, you
   must drive to the center of the lane.
   Blind-Spot Collision-Avoidance Assist
   will not operate if the vehicle is not
   driven in the center of the lane.

### Collision-avoidance assist (while departing)



- To warn the driver of a collision, the warning light on the side view mirror will blink and a warning message will appear on the instrument cluster. At the same time, an audible warning will sound, warning light on the head-up display (if equipped) will blink and the steering wheel will vibrate.
- Emergency braking will be assisted to help prevent collision with the vehicle in the blind spot area.
- Blind-Spot Collision-Avoidance Assist will operate when your vehicle speed is below 2 mph (3 km/h) and the speed of the vehicle in the blind spot area is above 3 mph (5 km/h).



- OJKEV072007N
- When the vehicle is stopped due to emergency braking, the 'Drive carefully' warning message will appear on the instrument cluster. For your safety, the driver should depress the brake pedal immediately and check the surroundings.
- Brake control will end after the vehicle is stopped by emergency braking for about 2 seconds.

### WARNING

Take the following precautions when using Blind-Spot Collision-Avoidance Assist:

- For your safety, only change the Settings after parking the vehicle at a safe location.
- If any other system's warning message is displayed or audible warning is generated, Blind-Spot Collision-Avoidance Assist's warning message may not be displayed and audible warning may not be generated.
- You may not hear the warning sound of Blind-Spot Collision-Avoidance Assist if the surrounding is noisy.
- Blind-Spot Collision-Avoidance Assist may not operate if the driver applies the brake pedal to avoid a collision.

- When Blind-Spot Collision-Avoidance Assist is operating, braking control by the function will automatically cancel when the driver excessively depresses the accelerator pedal or sharply steers the vehicle.
- During Blind-Spot Collision-Avoidance Assist operation, the vehicle may stop suddenly injuring passengers and shifting loose objects. Always have the seat belt on and keep loose objects secured.
- Even if there is a problem with Blind-Spot Collision-Avoidance Assist, the vehicle's basic braking will function normally.
- Blind-Spot Collision-Avoidance Assist does not operate in all situations and cannot avoid all collisions.
- Blind-Spot Collision-Avoidance Assist may warn the driver late or may not warn the driver depending on the road and driving conditions.
- Driver should maintain control of the vehicle at all times. Do not depend on Blind-Spot Collision-Avoidance Assist. Maintain a safe braking distance, and if necessary, depress the brake pedal to reduce driving speed or to stop the vehicle.
- · Never operate Blind-Spot Collision-Avoidance Assist on people, animal, objects, etc. It may cause serious injury or death.

### WARNING

The brake control may not operate properly depending on the status of ESC (Electronic Stability Control).

There will only be a warning when:

- The ESC (Electronic Stability Control) warning light is on
- · ESC (Electronic Stability Control) is engaged in a different function

### **Blind-Spot Collision-Avoidance** Assist Malfunction and Limitations

Blind-Spot Collision-Avoidance Assist malfunction



OJWEV071019L

When Blind-Spot Collision-Avoidance Assist is not working properly, the 'Check Blind-Spot Safety system' warning message will appear on the instrument cluster for several seconds, and the master ( $\Lambda$ ) warning light will illuminate on the instrument cluster. If this occurs, have the vehicle inspected by an authorized retailer of Genesis Branded products.



When the side view mirror warning light is not working properly, the 'Check side view mirror warning light' warning message will appear on the instrument cluster for several seconds, and the master (A) warning light will illuminate on the instrument cluster. If this occurs, have the vehicle inspected by an authorized retailer of Genesis Branded products.

#### Blind-Spot Collision-Avoidance Assist disabled



When the rear bumper around the rear corner radar or sensor is covered with foreign material, such as snow or rain, or installing a trailer or carrier, it can reduce the detecting performance and temporarily limit or disable Blind-Spot Collision-Avoidance Assist.

If this occurs, the 'Blind-Spot Safety system disabled. Radar blocked' warning message will appear on the instrument cluster.

Blind-Spot Collision-Avoidance Assist will operate properly when such foreign material or trailer, etc., is removed, and then the vehicle is restarted.

If Blind-Spot Collision-Avoidance Assist does not operate properly after it is removed, have the vehicle inspected by an authorized retailer of Genesis Branded products.

### **MARNING**

- Even though the warning message does not appear on the cluster, Blind-Spot Collision-Avoidance Assist may not properly operate.
- Blind-Spot Collision-Avoidance Assist
  may not properly operate in an area
  (for example, open terrain) where any
  objects are not detected right after
  the vehicle is turned on, or when
  the detecting sensor is blocked with
  foreign material right after the vehicle
  is turned on.



### **CAUTION**

Turn off Blind-Spot Collision-Avoidance Assist to install or remove a trailer, carrier, or another attachment. Turn on Blind-Spot Collision-Avoidance Assist when finished.

#### Limitations of Blind-Spot Collision-Avoidance Assist

Blind-Spot Collision-Avoidance Assist may not operate properly, or it may operate unexpectedly under the following circumstances:

- There is inclement weather, such as heavy snow, heavy rain, etc.
- The detecting sensor is covered with snow, rain, dirt, etc.
- The temperature around the detecting sensor is high or low due to surrounding environment.
- The detecting sensor is blocked while driving near a vehicle, pillar, or wall.
- Driving on a highway ramp or driving through a tollbooth.

- The road pavement (or the peripheral ground) abnormally contains metallic components (for example, possibly due to subway construction).
- There is a fixed object near the vehicle, such as sound barriers, guardrails, central dividers, entry barriers, street lamps, signs, tunnels, walls, etc. (including double structures)
- Driving through a narrow road where trees or grass are overgrown
- Driving in vast areas where there are few vehicles or structures (for example, desert, meadow, suburb, etc.)
- The lane is difficult to see due to foreign material, such as rain, snow, dust, sand, oil and water puddles
- The color of the lane marking is not distinguishable from the road
- There are markings on the road near the lane or the markings on the road look similar to the lane markings
- The shadow is on the lane marking by a median strip, trees, guardrail, noise barriers, etc.
- The lane number increases or decreases, or the lane markings are crossing
- There are more than two lane markings on the road
- The lane markings are complicated or a structure substitutes for the lines, such as a construction area
- There are road markings, such as zigzag lanes, crosswalk markings and road signs
- The lane suddenly disappears, such as at the intersection
- The lane is very wide or narrow

- There is a curb or road edges without a lane
- The vehicle in front is driving with one side on the lane marking
- The distance to the front vehicle is extremely short or the vehicle in front is covering the lane marking
- The other vehicle drives very close behind your vehicle, or the other vehicle passes by your vehicle in close proximity
- The speed of the other vehicle is very fast that it passes by your vehicle in a short time
- Your vehicle passes by the other vehicle
- · Your vehicle changes lane
- Your vehicle has started at the same time as the vehicle next to you and has accelerated
- The vehicle in the next lane moves two lanes away from you, or when the vehicle two lanes away moves to the next lane from you
- A trailer, carrier or other attachment is installed around the rear corner radar
- The bumper around the rear corner radar is covered with objects, such as a bumper sticker, bumper guard, bike rack, etc.
- The bumper around the rear corner radar is impacted, damaged or the radar is out of position
- Your vehicle height is low or high due to heavy loads, abnormal tire pressure, etc.

Blind-Spot Collision-Avoidance Assist may not operate properly, or it may operate unexpectedly when the following objects are detected:

- · A motorcycle or bicycle is detected
- A vehicle such as a flat trailer is detected
- A big vehicle such as a bus or truck is detected
- A moving obstacle such as a pedestrian, animal, shopping cart or a baby stroller is detected
- A vehicle with low height such as a sports car is detected

Braking control may not work, driver's attention is required in the following circumstances:

- The vehicle severely vibrates while driving over a bumpy road, uneven road or concrete patch
- Driving on a slippery surface due to snow, water puddle, ice, etc.
- The tire pressure is low or a tire is damaged
- The braking system has been modified
- The vehicle makes abrupt lane changes



### Information

For more information on the limitations of the front view camera, refer to the "Forward Collision-Avoidance Assist (FCA)" and "Lane Keeping Assist (LKA)" section in this chapter.

### **MARNING**

#### · Driving on a curved road



Blind-Spot Collision-Avoidance Assist may not operate properly when driving on a curved road. The function may not detect the vehicle in the next lane.


Always pay attention to road and driving conditions while driving.



Blind-Spot Collision-Avoidance Assist may not operate properly when driving on a curved road. The function may recognize a vehicle in the same lane.

Always pay attention to road and driving conditions while driving.

#### Driving on an inclined road



Blind-Spot Collision-Avoidance Assist may not operate properly when driving on a slope. The function may not detect the vehicle in the next lane or may incorrectly detect the ground or structure. Always pay attention to road and driving conditions while driving.


#### Driving where the road is merging/ dividing



Blind-Spot Collision-Avoidance Assist may not operate properly when driving where the road merges or divides. The function may not detect the vehicle in the next lane.

Always pay attention to road and driving conditions while driving.

#### Driving where the heights of the lanes are different



Blind-Spot Collision-Avoidance Assist may not operate properly when driving where the heights of the lanes are different. The function may not detect the vehicle on a road with different lane heights (underpass joining section, grade separated intersections, etc.).

Always pay attention to road and driving conditions while driving.

### **M** WARNING

- When you are towing a trailer or another vehicle, make sure that you turn off Blind-Spot Collision-Avoidance Assist.
- Blind-Spot Collision-Avoidance Assist may not operate properly if interfered by strong electromagnetic waves.
- Blind-Spot Collision-Avoidance Assist may not operate for 15 seconds after the vehicle is started, or the front view camera or rear corner radars are initialized.

### *i* Information

This device complies with Part 15 of the FCC rules.

Operation is subject to the following three conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

### *i* Information


Radio frequency radiation exposure information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance of 8 in. (20 cm) between the radiator (antenna) and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

### **SAFE EXIT ASSIST (SEA)**



After the vehicle stops, when an approaching vehicle from the rear area is detected after a passenger opens the door. Safe Exit Assist will warn the driver with a warning message and an audible warning to help prevent a collision.



In addition, when the electronic child safety lock button is in the LOCK position and an approaching vehicle from the rear area is detected, the electronic child safety lock button will not unlock even if the driver presses the button to prevent the rear doors from opening.

### ! CAUTION

Warning timing may vary depending on the speed of the approaching vehicle.

Do not use Safe Exit Assist instead of the electronic child safety lock button. To protect rear seat passengers, use the electronic child safety lock button.

For more information, refer to the "Electronic Child Safety Lock" section in chapter 5.

#### **Detecting sensor**



[1]: Rear corner radar

Refer to the picture above for the detailed location of the detecting sensors.



### **CAUTION**

For more information on the precautions of the rear corner radars, refer to the "Blind-Spot Collision-Avoidance Assist (BCA)" section in this chapter.

### **Safe Exit Assist Settings**

Safe Exit Assist



With the vehicle on, select Setup > Vehicle > Driver Assistance > Blind-Spot Safety > Safe Exit Assist from the Settings menu to turn on Safe Exit Assist and deselect to turn off the function.



### **WARNING**

The driver should always be aware of the surroundings. If **Safe Exit Assist** is deselected, Safe Exit Assist cannot assist you.



### **CAUTION**

When a trailer is connected to the tow hitch harness installed to your vehicle, Safe Exit Assist automatically turns off (if equipped). In this case, Safe Exit Assist is not functional. Always have your eyes on the road.



#### Information

If the vehicle is restarted, Safe Exit Assist will maintain the last setting.

### Warning Methods



OJKEV072322N

With the vehicle on, go to Setup > Vehicle > Driver Assistance > Warning Methods from the Settings in the infotainment system to select the following:

- Warning Volume: The Warning Volume can be adjusted.
- Driving Safety Priority: Your vehicle lowers all other audio volumes when the Driver Assistance system warning sounds.



### Information

- If you change the Warning Methods, Warning Methods of other Driver Assistance systems may change.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- There may be no Settings menu depending on the feature applied to your vehicle.
- Even though 0 is selected for Warning Volume, Warning Volume will not be turned off but Warning Volume will sound as 1.

# Safe Exit Assist Operation Collision warning when exiting vehicle





OJKEV072026N

- When an approaching vehicle from the rear is detected at the moment a door is opened, the 'Watch for traffic' warning message will appear on the instrument cluster, and an audible warning will sound.
- Safe Exit Assist will warn the driver when your vehicle speed is below 2 mph (3 km/h), and the speed of the approaching vehicle from the rear is above 4 mph (6 km/h).

### Safe Exit Assist linked with Electronic child safety lock



OTM070145L

- When Electric child safety lock is operating and an approaching vehicle from the rear area is detected, the rear doors cannot be unlocked even if the driver tries to unlock the rear doors using the electronic child safety lock button. The warning light on the side view mirror will blink and 'Check traffic in the blind spot, then try again' warning message will appear on the instrument cluster.
- Safe Exit Assist will warn the driver when vehicle speed is below 2 mph (3 km/h) and the speed of the approaching vehicle from the rear is above 4 mph (6 km/h).

### *i* Information

For more information on electric child safety lock button, refer to the "Electronic Child Safety Lock" section in chapter 5.

### ! CAUTION

If the driver presses the electronic child safety lock button again within 10 seconds after the warning message appears, Safe Exit Assist judges that the driver has unlocked the doors acknowledging the rear status. The electronic child safety lock will turn off (button indicator OFF) and the rear doors will unlock. Always check the surroundings before turning off the electronic child safety lock button.



### WARNING

Take the following precautions when using Safe Exit Assist:

- · For your safety, only change the Settings after parking the vehicle at a safe location.
- If any other system's warning message is displayed or audible warning is generated, Safe Exit Assist warning message may not be displayed and audible warning may not be generated.
- You may not hear the warning sound of Safe Exit Assist if the surroundings are noisy.
- Safe Exit Assist does not operate in all situations and cannot prevent all collisions.
- · Safe Exit Assist may warn the driver late or may not warn the driver depending on the road and driving conditions. Always check vehicle surroundings.
- The driver and passengers are responsible for accidents that occur while exiting the vehicle. Always check the surroundings before you exit the vehicle.
- Never deliberately operate Safe Exit Assist. Doing so may lead to serious injury or death.

### Information

- · After the vehicle is turned off, Safe Exit Assist operates about for 3 minutes, but turns off immediately if the doors are locked.
- The images and colors in the instrument cluster may differ depending on the cluster type or theme selected from the settings menu.

### Safe Exit Assist Malfunction and Limitations

Safe Exit Assist malfunction



OJWEV071019L

When Safe Exit Assist is not working properly, the 'Check Blind-Spot Safety system' warning message will appear on the instrument cluster for several seconds, and the master (//) warning light will illuminate on the instrument cluster. If this occurs, have the vehicle inspected by an authorized retailer of Genesis Branded products.



When the side view mirror warning light is not working properly, the 'Check side view mirror warning light' warning message will appear on the instrument cluster for several seconds, and the master (/\) warning light will illuminate on the instrument cluster. If this occurs, have the vehicle inspected by an authorized retailer of Genesis Branded products.

#### Safe Exit Assist disabled



When the rear bumper around the rear corner radar or sensor is covered with foreign material, such as snow or rain, or installing a trailer or carrier, it can reduce the detecting performance and temporarily limit or disable Safe Exit Assist.

If this occurs, the 'Blind-Spot Safety system disabled. Radar blocked' warning message will appear on the instrument cluster.

Safe Exit Assist will operate properly when such foreign material or trailer, etc., is removed, and then the vehicle is restarted.

If Safe Exit Assist does not operate properly after it is removed, have the vehicle inspected by an authorized retailer of Genesis Branded products.

### **WARNING**

- Even though the warning message does not appear on the cluster, Safe Exit Assist may not properly operate.
- Safe Exit Assist may not properly operate in an area (for example, open terrain) where any objects are not detected right after the vehicle is turned on, or when the detecting sensor is blocked with foreign material right after the vehicle is turned on.

### **A** CAUTION

Turn off Safe Exit Assist to install or remove a trailer, carrier, or another attachment. Turn on Safe Exit Assist when finished.

#### Limitations of Safe Exit Assist

Safe Exit Assist may not operate properly, or it may operate unexpectedly under the following circumstances:

- Getting out of the vehicle where trees or grass are overgrown
- Getting out of the vehicle where the road is wet
- The approaching vehicle is very fast or very slow



### Information

For more information on the limitations of the rear corner radar, refer to the "Blind-Spot Collision-Avoidance Assist (BCA)" section in this chapter.

### A

### WARNING

- Safe Exit Assist may not operate properly if interfered by strong electromagnetic waves.
- Safe Exit Assist may not operate for 3 seconds after the vehicle is started, or the rear corner radars are initialized.

### **MANUAL SPEED LIMIT ASSIST (MSLA)**



O.JKFV072027N

- (1) Speed Limit indicator
- (2) Set speed

You can set the speed limit when you do not want to drive over a specific speed.

If you drive over the preset speed limit, Manual Speed Limit Assist operates (set speed limit will blink and chime will sound) until the vehicle speed returns within the speed limit.

### **Manual Speed Limit Assist** Operation

Setting speed limit



OJKEV071118

1. Press and hold Driving Assist (Fig.) button at the desired speed. The Speed Limit (6) LIMIT) indicator will illuminate on the cluster.



OJKEV071119

2. Push the + switch up or - switch down, and release it at the desired speed.

Push the + switch up or - switch down and hold it. The speed will increase or decrease to the nearest multiple of five (multiple of ten in km/h) at first, and then increase or decrease by 5 mph (10 km/h).



3. The set speed limit will be displayed on the cluster.

If you would like to drive over the preset speed limit, depress the accelerator pedal beyond the pressure point to activate the kickdown function.

The set speed limit will blink and chime will sound until you return the vehicle speed within the speed limit.

### *i* Information

When the accelerator pedal is not depressed beyond the pressure point, vehicle speed will maintain within the speed limit.

#### Temporarily pausing Manual Speed Limit Assist



Press the **II** Switch to temporarily pause the set speed limit. The set speed limit will turn off but the Speed Limit (**O**I IMIT) indicator will stay on.

### Resuming Manual Speed Limit Assist



OJKEV071119

To resume Manual Speed Limit Assist after the function was paused, operate the +, -, || switch.

If you push the + switch up or - switch down, vehicle speed will be set to the current speed on the cluster.

If you press the **II** S switch, vehicle speed will resume to the preset speed.

#### Turning off Manual Speed Limit Assist



Press the Driving Assist (\*\*) button to turn Manual Speed Limit Assist off. The Speed Limit (\*\*) indicator will go off.

### **MARNING**

Take the following precautions when using Manual Speed Limit Assist:

- Always set the vehicle speed under the speed limit in your area.
- Keep Manual Speed Limit Assist off when the function is not in use, to avoid inadvertently setting a speed. Check that the Speed Limit (SILIMIT) indicator is off.
- Manual Speed Limit Assist does not substitute for proper and safe driving. It is the responsibility of the driver to always drive safely and be aware of unexpected and sudden situations. Pay attention to the road conditions at all times.

### **INTELLIGENT SPEED LIMIT ASSIST (ISLA) (IF EQUIPPED)**

Intelligent Speed Limit Assist uses information from the detected road sign and navigation system to inform the driver of the speed limit and additional information of the current road. Also, Intelligent Speed Limit Assist helps the driver to maintain within the speed limit of the road.

### ⚠ c

### CAUTION

- Intelligent Speed Limit Assist may not operate properly if the function is used in other states.
- If a navigation system is equipped to your vehicle, the navigation needs to be regularly updated for Intelligent Speed Limit Assist to operate properly.

#### **Detecting sensor**



[1]: Front view camera

Refer to the picture above for the detailed location of the detecting sensor.



### CAUTION

For more information on the precautions of the front view camera, refer to the "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

### Intelligent Speed Limit Assist Settings Speed Limit



With the vehicle on, select or deselect **Setup > Vehicle > Driver Assistance > Speed Limit** from the Settings menu to set whether to use each function.

- If Speed Limit Assist is selected, Intelligent Speed Limit Assist will inform the driver of speed limit and additional road signs. In addition, Intelligent Speed Limit Assist will inform the driver to change set speed of Manual Speed Limit Assist and/or Smart Cruise Control to help the driver stay within the speed limit.
- If Speed Limit Warning is selected, Intelligent Speed Limit Assist will inform the driver of speed limit and additional road signs. In addition, Intelligent Speed Limit Assist will warn the driver when the vehicle is driven faster than the speed limit.
- If **Off** is selected, Intelligent Speed Limit Assist will turn off.

#### **Speed Limit Offset**



OJKEV072030N

With the vehicle on, when Setup > Vehicle > Driver Assistance > Speed Limit > Speed Limit Offset is selected, the Speed Limit Offset can be changed. Speed Limit Warning and Speed Limit Assist will operate by applying the Speed Limit Offset setting to the detected speed limit.

### A

### **WARNING**

 For your safety, only change the Settings after parking the vehicle at a safe location



#### Information

- Speed Limit Assist function operates based on the Offset setting added to the speed limit. If you want to change the set speed according to the speed limit, adjust the offset to 0.
- Speed Limit Warning function warns the driver when driving speed exceeds the speed at which the set Offset is added to speed limit. If you want Speed Limit Warning to warn you immediately when the driving speed exceeds the speed limit, adjust the offset to 0.
- The setting of 'Speed Offset' is not reflected in Navigation-based Smart Cruise Control (NSCC).

# Intelligent Speed Limit Assist Operation

Intelligent Speed Limit Assist will warn and control the vehicle speed by 'Displaying speed limit', 'Warning overspeed' and 'Changing set speed'.



### Information

Intelligent Speed Limit Assist warning and control are described based on the Offset adjust to **0**. For details on Offset setting, refer to the "Intelligent Speed Limit Assist Settings".

#### Displaying speed limit



Speed limit information is displayed on the instrument cluster.

### **Information**

- If speed limit information of the road cannot be recognized, '---' sign will be displayed. Refer to "Limitations of Intelligent Speed Limit Assist" if the road signs are difficult to recognize.
- Intelligent Speed Limit Assist provides additional road sign information in addition to speed limit. The additional road sign information provided may vary according to your state.
- The images and colors in the instrument cluster may differ depending on the cluster type or theme selected from the settings menu.

### Warning overspeed



When driving at a speed higher than the displayed speed limit, the speed limit is displayed in red.

### Changing set speed



If the speed limit of the road changes during the operation of Manual Speed Limit Assist or Smart Cruise Control, an arrow in the direction of up or down is displayed to inform the driver that the set speed needs to be changed. At this time, the driver can change the set speed according to the speed limit by using the + or – switch on the steering wheel.

### **MARNING**

- If the Offset is adjusted over '0', the set speed will change to a higher speed than the speed limit of the road. If you want to drive below the speed limit, adjust the Offset under '0' or use the – switch on the steering wheel to lower the set speed.
- Even after changing the set speed according to the speed limit of the road, the vehicle can still be driven over the speed limit. If necessary, depress the brake pedal to reduce your driving speed.
- If the speed limit of the road is under 20 mph (30 km/h), the set speed change function will not work.
- Intelligent Speed Limit Assist
   operates using the speed unit in the
   instrument cluster set by the driver.
   If the speed unit is set to a unit other
   than the speed unit used in your area,
   Intelligent Speed Limit Assist may not
   operate properly.

### Information

- For more information on Manual Speed Limit Assist operation, refer to the "Manual Speed Limit Assist (MSLA)" section in this chapter.
- For more information on Smart Cruise Control operation, refer to the "Smart Cruise Control (SCC)" section in this chapter.

# Intelligent Speed Limit Assist Malfunction and Limitations Intelligent Speed Limit Assist

Intelligent Speed Limit Assist malfunction



When Intelligent Speed Limit Assist is not working properly, the 'Check Speed Limit system' warning message will appear on the instrument cluster for several seconds, and the master (A) warning light will illuminate on the instrument cluster. If this occurs, have the vehicle inspected by an authorized retailer of Genesis Branded products.

### Intelligent Speed Limit Assist disabled



When the front windshield where the front view camera is located is covered with foreign material, such as snow or rain, it can reduce the detecting performance and temporarily limit or disable Intelligent Speed Limit Assist. If this occurs, the 'Speed Limit system disabled. Camera obscured' warning message will appear on the instrument cluster.

Intelligent Speed Limit Assist will operate properly when snow, rain or foreign material is removed.

If Intelligent Speed Limit Assist does not operate properly after it is removed, have the vehicle inspected by an authorized retailer of Genesis Branded products.



If the detecting sensor is contaminated immediately after starting the vehicle, Intelligent Speed Limit Assist may not operate properly.

#### Limitations of Intelligent Speed Limit Assist

Intelligent Speed Limit Assist may not operate properly, or it may operate unexpectedly under the following circumstances:

- The road sign is contaminated or indistinguishable
  - The road sign is difficult to see due to bad weather, such as rain, snow, fog, etc.
  - The road sign is not clear or damaged
  - The road sign is partially obscured by surrounding objects or shadow
- The road signs do not conform to the standard
  - The text or picture on the road sign is different from the standard
  - The road sign is installed between the main line and the exit road or between diverging roads
  - There is no conditional road signs on the road sign located on the exit road
  - A sign is attached to another vehicle
- The distance between the vehicle and the road signs is too far
- The vehicle encounters illuminant road signs
- Intelligent Speed Limit Assist incorrectly recognizes numbers or pictures in the street signs or other signs as the speed limit
- A road sign near the road you are driving is detected
- Multiple signs are installed close together
- The minimum speed limit sign is misrecognized

- The minimum speed limit sign is on the road
- The brightness changes suddenly, for example when entering or exiting a tunnel or passing under a bridge
- Headlights are not used or the brightness of the headlights are weak at night or in the tunnel
- Road signs are difficult to recognize due to the reflection of sunlight, street lights, or oncoming vehicles
- The navigation information or GPS information contain errors.
- The driver does not follow the guide of the navigation.
- The driver is driving a new road that is not in the navigation system yet.
- The field of view of the front view camera is obstructed by sun glare
- Driving on a road that is sharply curved or continuously curved
- Driving through speed bumps, or driving up and down or left to right on steep inclines
- The vehicle is shaking heavily



### **!** WARNING

- Intelligent Speed Limit Assist is a supplemental function that helps the driver comply with the speed limit on the road, and may not display the correct speed limit or control the driving speed properly.
- Always set the vehicle speed to the speed limit in your area.
- Intelligent Speed Limit Assist may not operate for 15 seconds after the vehicle is started, or the front view camera is initialized.



### Information

For more information on the limitations of the front view camera, refer to the "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

#### **DRIVER ATTENTION WARNING (DAW)**

#### **Basic function**

Driver Attention Warning can help determine the driver's attention level by analyzing driving pattern and driving time while the vehicle is driven. Driver Attention Warning will recommend a break when the driver's attention level falls below a certain level.

### Leading vehicle departure alert function

Leading Vehicle Departure Alert function will inform the driver when a detected vehicle in front departs.

#### **Detecting sensor**



[1]: Front view camera

The front view camera is used as a detecting sensor to help detect driving patterns and front vehicle departure while vehicle is being driven.

Refer to the picture above for the detailed location of the detecting sensor.

### ? CAUTION

- Always keep the front view camera in good condition to maintain optimal performance of Driver Attention Warning.
- For more information on the precautions of the front view camera, refer to the "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

# **Driver Attention Warning Settings**

**Driver Attention Warning** 



With the vehicle on, select or deselect **Setup > Vehicle > Driver Assistance** > **Driver Attention Warning** from the Settings menu to set whether to use each function.


 If Inattentive Driving Warning is selected, Driver Attention Warning will recommend taking a break when the level falls below a certain level.

### Leading Vehicle Departure Alert



 If Leading Vehicle Departure Alert is selected, the function will inform the driver when a detected vehicle in front departs from a stop.

#### Warning Timing



OJKEV072003N

With the vehicle on, select Setup > Vehicle > Driver Assistance > Warning Timing from the Settings menu to change the initial warning activation time for Driver Attention Warning. The warning time can be set to either Standard or Late.

- Use **Standard** in normal driving conditions. If the Warning Timing seems sensitive, change it to Late.
- If Late is selected. Driver Attention Warning, warns the driver more slowly.

### Information

- If you change the Warning Timing, the Warning Timing of other Driver Assistance systems may change.
- · If the vehicle is restarted, Driver Attention Warning will maintain the last setting.

### **Driver Attention Warning** Operation

#### Basic function

The basic function of Driver Attention Warning is to warn the driver 'Consider taking a break'.

### Taking a break



OJKEV072233L

- The 'Consider taking a break' message will appear on the instrument cluster and an audible warning will sound to suggest that the driver take a break, when the driver's attention level is below a certain level.
- Driver Attention Warning will not suggest a break when the total driving time is shorter than 10 minutes or 10 minutes has not passed after the last break was suggested.
- A break is suggested when your vehicle speed is between about 0-120 mph (0-200 km/h).



Only change the Settings after parking the vehicle at a safe location.

### **CAUTION**

- Driver Attention Warning may suggest a break depending on the driver's driving pattern or habits, even if the driver doesn't feel fatigued.
- Driver Attention Warning is a supplemental function and may not be able to determine whether the driver is inattentive.
- A driver who feels fatigued should take a break at a safe location, even though there is no break suggestion by Driver Attention Warning.



For more information on instrument cluster settings, refer to the "Cluster Display Control" section in chapter 4.

### Leading vehicle departure alert function



OJKEV072315N

When a detected vehicle in front departs from a stop, Leading Vehicle Departure Alert will inform the driver by displaying the 'Leading vehicle is driving away' message on the instrument cluster and an audible warning will sound.

### **MARNING**

- If any other system's warning message is displayed or audible warning is generated, Leading Vehicle Departure Alert's warning message may not be displayed and audible warning may not be generated.
- The driver has the responsibility to safely drive and control the vehicle.

### **A** CAUTION

- Leading Vehicle Departure Alert is a supplemental function and may not alert the driver whenever the front vehicle departs from a stop.
- Always check the front of the vehicle and road conditions before departure.

### **Information**

The images and colors in the instrument cluster may differ depending on the cluster type or theme selected from the settings menu.

### **Driver Attention Warning Malfunction and Limitations**

**Driver Attention Warning** malfunction



When Driver Attention Warning is not working properly, the 'Check Inattentive Driving Warning system' warning message will appear on the instrument cluster for several seconds, and the master (\hat{\Lambda}) warning light will illuminate on the instrument cluster. If this occurs, have the vehicle inspected by an authorized retailer of Genesis Branded products.


#### Limitations of Driver Attention Warning

Driver Attention Warning may not work properly in the following situations:


- · The vehicle is driven violently
- The vehicle intentionally crosses over lanes frequently
- · The vehicle is controlled by Driver Assistance system, such as Lane **Keeping Assist**

#### Leading vehicle departure alert function

When the vehicle cuts in



OJKEV072121L




O.JKEV072122L

[A]: Your vehicle, [B]: Front vehicle

If a vehicle cuts in front of your vehicle, Leading Departure Alert may not operate properly.


· When the vehicle ahead sharply steers



[A]: Your vehicle, [B]: Front vehicle

If the vehicle in front makes a sharp turn, such as to turn left or right or make a U-turn, etc., Leading Vehicle Departure Alert may not operate properly.

When the vehicle ahead abruptly departures




If the vehicle in front abruptly departures, Leading Vehicle Departure Alert may not operate properly.

• When a pedestrian or bicycle is between you and the vehicle ahead




If there is a pedestrian(s) or bicycle(s) in between you and the vehicle in front, Leading Vehicle Departure Alert may not operate properly.

· When in a parking lot



If a vehicle parked in front drives away from you, Leading Vehicle Departure Alert may alert you that the parked vehicle is driving away.

When driving at a tollbooth or intersection, etc.



If you pass a tollbooth or intersection with lots of vehicles or you drive where lanes are merged or divided frequently, Leading Vehicle Departure Alert may not operate properly.

### 7 Information

- For more information on the precautions of the front view camera, refer to the "Forward Collision-Avoidance Assist (FCA)" section in this chapter.
- Driver Attention Warning may not operate for 15 seconds after the vehicle is started, or the front view camera is initialized.

### FORWARD ATTENTION WARNING (FAW) (IF EQUIPPED)

Forward Attention Warning will warn the driver with a warning message on the cluster to help prevent the driver from being distracted while using the interior view camera installed in the instrument cluster.

# Forward Attention Warning Settings

Setting features



Forward Attention Warning

With the vehicle on, select Setup > Vehicle > Driver Assistance > Driver Attention Warning > Forward Attention Warning from the Settings menu to turn on Forward Attention Warning and deselect to turn off the function.

## **MARNING**

If the vehicle is restarted, Forward Attention Warning will maintain the last setting. At all times, and especially if Forward Attention Warning is deselected, the driver should be aware of the surroundings and drive safely.



O.JKFV072003N

#### **Warning Timing**

With the vehicle on, select **Setup > Vehicle > Driver Assistance > Warning Timing** from the Settings menu to
change the initial warning activation time
for Forward Attention Warning.

When the vehicle is first delivered, Warning Timing is set to **Standard**. If you change the Warning Timing, the warning time of other Driver Assistance systems may change.

### $\triangle$

### **CAUTION**

- Select Late for Warning Timing when traffic is light and when driving speed is slow.
- While Smart Cruise Control is operating, Forward Attention Warning may warn later than the set warning time.



### CAUTION

The setting of the Warning Timing applies to all functions of Forward Attention Warning.

### **Forward Attention Warning** Operation

### Operating conditions

Forward Attention Warning will operate when the following conditions are satisfied:

- Vehicle speed is above 0.6 mph (1 km/h)
- The gear is in D (Drive) or N (Neutral)

#### Forward Attention Warning



Forward Attention Warning determines whether the driver is focused on the road depending on information, such as the amount of time the driver is looking elsewhere, the amount of time the eyes are closed, how frequently the driver yawns, etc. If Forward Attention Warning judges the driver is not focused. the 'Keep eyes on the road and drive careful' warning message will appear on the cluster, and an audible warning will sound.

### WARNING

If any other system's warning message is displayed or audible warning is generated, Forward Attention Warning's warning message may not be displayed and audible warning may not be generated.

### ! CAUTION

- · Forward Attention Warning may warn the driver even though the driver is focused on the road due to driving style and driving pattern.
- Forward Attention Warning is a supplemental function and may not be able to determine whether the driver is distracted while driving in every condition.
- The driver has the responsibility to safely drive and focus on the road.

### Information

Forward Attention Warning does not transmit recorded videos outside of the vehicle or store the video.

### **Forward Attention Warning** Malfunction and Limitations

Forward Attention Warning malfunction



When Forward Attention Warning is not working properly, the 'Check Forward Attention Warning system' warning message will appear on the instrument cluster. If this occurs, have the vehicle inspected by an authorized retailer of Genesis Branded products.

#### Forward Attention Warning disabled



When there is an object right in front of the camera or between the driver and the camera for a certain period of time, Forward Attention Warning will not operate properly, and the 'Forward Attention Warning disabled. Camera obscured' warning message will appear on the cluster.

After the warning message appears, if the object is removed, or Forward Attention Warning is able to detect the driver's face, the function will operate properly.

### **CAUTION**



[A]: Interior view camera

- Do not apply any impact on the surface of the instrument cluster, interior view camera or around the area of the interior view camera. If the interior view camera is damaged, Forward Attention Warning may not work properly.
- Do not place a mobile phone or an object in front of the interior view camera. The surface of the instrument cluster or interior view camera might be damaged due to an impact while driving.
- Do not place anything on the interior view camera or in front of interior view camera while driving. Interior view camera may not operate properly.
- If anything else is placed in front of the camera, Forward Attention Warning may not operate properly.
- When cleaning the instrument cluster or camera, wipe with a soft and clean cloth to prevent damages on the surface of the cluster or camera lens. In addition, you should not use sharp tools near the cluster or camera, or use chemicals to clean the cluster or camera.
- Always keep the camera and around the area of the interior view camera clean and dry.
- Do not apply foreign objects, such as a sticker, around the infrared LED located near the camera.

### *i* Information

- Two red lights may appear on the camera in the following conditions when:
  - The outside brightness is dim or driving at night
  - The vehicle drives inside a building, such as a basement parking lot, garage or tunnel
  - The camera case of the instrument cluster is partially broken
- The 3D cluster may flicker when adjusting to the driver's eyes or when the instrument cluster's camera view is blocked by the steering wheel or other objects.

### **↑** WARNING

Do not look toward the camera within 8 inches (20 cm) for longer than a minute.

### Limitations of Forward Attention Warning

Forward Attention Warning may be limited or may not operate properly in the following circumstances:

- The driver is wearing sunglasses, special glasses, infrared cutoff glasses, refracting glasses or thick glasses
- The driver has heavy eye makeup (eyeliner, mascara, color makeup, false eyelash) or eye piercing
- The driver's view is blocked by his/her hair, hat, etc.
- The driver is winking or wearing an eye patch on one eye
- The driver's face is covered partially by a mask, muffler, etc.
- The driver's view is blocked by incoming light from outside of the vehicle

- Light from outside, sunlight or infrared LED light of the camera is reflected by glasses or sunglasses
- The driver turns or lowers his/her head so that the face or an eye is hidden from the camera
- The camera is out of the range to monitor or close within 8 inches (20 cm)
- The driver shakes his/her head up and down, or adverse road conditions cause excessive vehicle vibrations while driving
- The driver is improperly positioned in the driver's seat so that the driver's face is not detected
- · The driver is too tall or short
- The camera is blocked by the adjusted steering wheel height or the turned steering wheel
- More than two people are looking at the instrument cluster simultaneously from the driver's seat
- The driver's eyes are narrowed due to laughing or sun glare
- Misrecognize a picture that has a similar size of the driver's face
- There are other devices using infrared light in the vehicle

### **BLIND-SPOT VIEW MONITOR (BVM) (IF EQUIPPED)**





[A]: Left side, [B]: Right side

Blind-Spot View Monitor displays the rear blind spot area of the vehicle in the cluster when the turn signal is turned on to help safely change lanes.

### **Detecting sensor**



[A], [B]: Wide-side view camera (camera located at bottom of the mirror)

Refer to the picture above for the detailed location of the detecting sensors.

# Blind-Spot View Monitor Settings

### Setting features

**Blind-Spot View** 

With the vehicle on, select Setup > Vehicle > Driver Assistance > Blind-Spot Safety > Blind-Spot View from the Settings menu to turn on Blind-Spot View Monitor and deselect to turn off the function.

### Blind-Spot View Monitor Operation

Operating switch



Turn signal switch

Blind-Spot View Monitor will turn on and off when the turn signal is turned on and off.

#### **Blind-Spot View Monitor**

#### **Operating conditions**

When the left or right side turn signal turns on, the image in that direction is displayed on the instrument cluster.

#### Off conditions

- When the turn signal turns off, the image on the instrument cluster will turn off.
- When the hazard warning flasher is on, Blind-Spot View Monitor will turn off, regardless of the turn signal status.
- When other important warning is displayed on the instrument cluster, Blind-Spot View Monitor may turn off.

### Blind-Spot View Monitor Malfunction

When Blind-Spot View Monitor is not working properly, or the cluster display flickers, or the camera image does not display properly, have the vehicle inspected by an authorized retailer of Genesis Brand products.

### **MARNING**

- The image shown on the cluster may differ from the actual distance of the object. Make sure to directly check the vehicle's surroundings for safety.
- Always keep the camera lens clean.
  If the lens is covered with foreign
  material, it may adversely affect
  camera performance and BlindSpot View Monitor may not operate
  properly.

### **SMART CRUISE CONTROL (SCC)**

Smart Cruise Control is designed to help detect the vehicle ahead and help maintain the desired speed and minimum distance between the vehicle ahead.

#### **Overtaking Acceleration Assist**

While Smart Cruise Control is operating, if the function judges that the driver is determined to overtake the vehicle in front, acceleration will be assisted.

#### Based on Driving Style (if equipped)

Smart Cruise Control will operate based on the driver's driving style, such as vehicle distance, acceleration, reaction speed.

#### **Detecting sensor**





- [1]: Front view camera,
- [2]: Front radar,
- [3]: Front corner radar (if equipped)

The front view camera, front radar and front corner radar are used as a detecting sensor to detect front vehicles.

Refer to the picture above for the detailed location of the detecting sensor.



### CAUTION

Always keep the front view camera and front radar in good condition to maintain optimal performance of Smart Cruise Control.

For more information on the precautions of the front view camera and front radar, refer to the "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

#### Smart Cruise Control Settings Smart Cruise Control



With the vehicle on, select Setup > Vehicle > Driver Assistance > Driving Convenience > Smart Cruise Control from the setting menu, to change Distance, Acceleration, Reaction Speed manually.

#### Based on Driving Style (if equipped)



With the vehicle on, if Setup > Vehicle > Driver Assistance > Driving Convenience > Smart Cruise Control > Based on Driving Style is selected from the Settings menu, Smart Cruise Control will operate based on the driver's driving style, such as vehicle distance, acceleration, reaction speed.

# **CAUTION**

When a trailer is connected to the tow hitch harness installed to your vehicle, Smart Cruise Control automatically turns off (if equipped). In this case, Smart Cruise Control is not functional. Always have your eyes on the road.




#### Information

- While Smart Cruise Control is operating with Based on Driving Style selected, if you press and hold the Vehicle Distance ( ) button, Based on Driving Style will deactivate. If you press and hold the Vehicle Distance ( ) button again, Driving Style Setting will activate.
- Based on Driving Style setting continuously learns when the driver drives the vehicle.
- When Based on Driving Style is deactivated, the driver's driving style such as vehicle distance, acceleration, reaction speed will maintain in the same stage.

#### Warning Methods







OJKEV072326N

With the vehicle on, go to **Setup > Vehicle > Driver Assistance > Warning Methods** from the Settings in the infotainment system to select the following:

- Warning Volume: The Warning Volume can be adjusted.
- Haptic Warning: The steering wheel vibration can be set (type A) or adjusted (type B).
- Driving Safety Priority: Your vehicle lowers all other audio volumes when the Driver Assistance system warning sounds.

## *i* Information

- If you change the Warning Methods, Warning Methods of other Driver Assistance systems may change.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- There may be no Settings menu depending on the feature applied to your vehicle.
- Even though 0 is selected for Warning Volume, Warning Volume will not be turned off but Warning Volume will sound as 1.
- When Haptic Warning is selected as 0 or deselected while Warning Volume is selected as 0, Warning Volume will activate and be selected as 2.
- When Warning Volume is selected as 0 while Haptic Warning is selected as 0 or deselected, steering wheel vibration will activate or be selected as 2.

#### Smart Cruise Control Operation Operating conditions for basic function

#### **Basic function**

Smart Cruise Control operates when the following conditions are satisfied.

- The gear is in D (Drive)
- Your vehicle speed is within the operating speed range
  - 5-120 mph (10-200 km): when there is no vehicle in front
  - 0-120 mph (0-200 km): when there is a vehicle in front
- ESC (Electronic Stability Control) or ABS (Anti-Lock Braking System) is on

Smart Cruise Control does not operate in the following conditions.

- · The driver's door is opened
- Your vehicle is in power down mode
   (A)
- EPB (Electronic Parking Brake) is applied
- ESC (Electronic Stability Control) or ABS (Anti-Lock Braking System) is controlling the vehicle
- Forward Collision-Avoidance Assist brake control is operating
- Remote Smart Parking Assist brake control is operating (if equipped)

## *i* Information

When stopped behind another vehicle, the driver can turn on Smart Cruise Control while the brake pedal is depressed.

#### Operating conditions for Acceleration Assist

Overtaking Acceleration Assist operates when the turn signal indicator is turned on to the left while Smart Cruise Control is operating, and the following conditions are satisfied:

- Your vehicle speed is above 40 mph (60 km/h)
- A vehicle is detected in front of your vehicle

Overtaking Acceleration Assist does not operate in the following conditions.

- The hazard warning flasher is on
- Vehicle speed is reduced to maintain distance with the vehicle in front



When the turn signal indicator is turned on to the left while there is a vehicle ahead, the vehicle may accelerate temporarily. Pay attention to the road conditions at all times.

#### **Turning on Smart Cruise Control**



- Press the Driving Assist button to turn on Smart Cruise Control. The speed will be set to the current speed on the cluster.
- If there is no vehicle in front of you, the set speed will be maintained, but if there is a vehicle in front of you, the speed may decrease to maintain the distance to the vehicle ahead. If the vehicle ahead accelerates, your vehicle will travel at a steady cruising speed after accelerating to the set speed.

## *i* Information

If your vehicle speed is between 0-20 mph (0-30 km/h) when you press the Driving Assist button, the set speed will be set to 20 mph (30 km/h).

#### Setting vehicle distance



Each time the button is pressed, the headway changes as follows:



## *i* Information

- If you drive at 56 mph (90 km/h), the distance is maintained as follows:
  - Distance 4 about 172 feet (53 m)
  - Distance 3 about 130 feet (40 m)
  - Distance 2 about 106 feet (30 m)
  - Distance 1 about 82 feet (25 m)
- The distance is set to the last set distance when the vehicle is restarted, or when Smart Cruise Control was temporarily canceled.

#### Increasing set speed



- Push the + switch up and release it immediately. The set speed will increase by 1 mph (1 km/h) each time the switch is operated in this manner.
- Push the + switch up and hold it while monitoring the set speed on the cluster. The set speed will increase by 5 mph (10 km/h) each time the switch is operated in this manner. Release the switch when the desired speed is shown, and the vehicle will accelerate to that speed. You can increase the set speed to 120 mph (200 km/h).

## **MARNING**

Check the driving condition before using the + switch. Driving speed may sharply increase when you push up and hold the + switch.

#### Decreasing set speed



- Push the switch down and release it immediately. The set speed will decrease by 1 mph (1 km/h) each time the switch is operated in this manner.
- Push the switch down and hold it while monitoring the set speed on the cluster. The set speed will decrease by 5 mph (10 km/h) each time the switch is operated in this manner.


Release the switch at the speed you want to maintain. You can decrease the set speed to 20 mph (30 km/h).

# Temporarily canceling Smart Cruise Control



Press the **|| 1** switch or depress the brake pedal to temporarily cancel Smart Cruise Control.

#### Resuming Smart Cruise Control



To resume Smart Cruise Control after the function was canceled, operate the +, - or || \( \) switch.

If you push the + switch up or - switch down, vehicle speed will be set to the current speed on the cluster.

If you press the **II 3** switch, vehicle speed will resume to the preset speed.



Check the driving condition before using the **II** witch. Driving speed may sharply increase or decrease when you press the **II** witch.

#### **Turning off Smart Cruise Control**



Press the Driving Assist button to turn Smart Cruise Control off.



#### Information

If your vehicle is equipped with Manual Speed Limit Assist, press and hold the Driving Assist button to turn off Smart Cruise Control. However Manual Speed Limit Assist will turn on.




#### CAUTION

Do not use the switches and buttons at the same time. Smart Cruise Control may not operate properly.

#### Displaying operating status

You can see the status of the Smart Cruise Control operation in the Driving Assist view on the cluster. Refer to the "View Modes" section in chapter 4.

Smart Cruise Control will be displayed as below depending on the status of the function.



[A]: Operating, [B]: Temporarily canceled

- When operating
  - (1) Whether there is a vehicle ahead and the selected distance level
  - (2) Set speed
  - (3) Whether there is a vehicle ahead and the target vehicle distance
- When temporarily canceled
  - (1) Your vehicle (shaded)
  - (2) Previous set speed (shaded)
  - (3) Vehicle ahead and distance level (shaded) (if equipped)

## *i* Information

- The distance of the front vehicle on the cluster is displayed based on the actual distance between your vehicle and the vehicle ahead.
- The target distance may vary according to the vehicle speed and the set distance level. If the vehicle speed is low, even though the vehicle distance have changed, the change of the target vehicle distance may be small.
- The images and colors in the instrument cluster may differ depending on the cluster type or theme selected from the settings menu.

#### Accelerating temporarily



If you want to speed up temporarily without altering the set speed while Smart Cruise Control is operating, depress the accelerator pedal. While the accelerator pedal is depressed, the set speed, distance level and target distance will blink on the cluster.

However, if the accelerator pedal is depressed insufficiently, the vehicle may decelerate.



Be careful when accelerating temporarily, because the speed and distance is not controlled automatically even if there is a vehicle in front of you.

#### Based on Driving Style operation





When Based on Driving Style is operating, 'Driving Style Adaptive SCC' message will appear on the cluster for 2 seconds, and the distance level and target distance will be displayed based on the driving style.

# CAUTION

- The vehicle must be driven sufficiently to reflect the actual driver's driving style to the Based on Driving Style's vehicle distance, acceleration, and reaction speed.
- Based on Driving Style may not reflect driving styles or driving conditions that affect safe driving.
- If you are driving in special conditions, such as snow, rain, fog, or steep slopes, the vehicle may not be driven according to the driver's driving style.

#### Information

- Driving styles that are far from safe driving such as sudden acceleration may not be reflected to Based on Driving Style.
- Based on Driving Style does not reflect any other driving style other than vehicle distance, acceleration and reaction speed.

# Temporarily canceling Smart Cruise Control



Smart Cruise Control will be temporarily canceled automatically when:

- The vehicle speed is above 130 mph (210 km/h)
- The vehicle is stopped for a certain period of time
- The accelerator pedal is continuously depressed for a certain period of time
- The conditions for Smart Cruise Control to operate is not satisfied

If Smart Cruise Control is temporarily canceled automatically, the 'Smart Cruise Control deactivated' warning message will appear on the cluster, and an audible warning will sound to warn the driver.



#### Information

If Smart Cruise Control is temporarily canceled while the vehicle is at a standstill with the function activated, EPB (Electronic Parking Brake) maybe applied.



#### WARNING

When Smart Cruise Control is temporarily canceled, distance with the front vehicle will not be maintained. Always have your eyes on the road while driving, and if necessary, depress the brake pedal to reduce your driving speed in order to maintain a safe distance.

# Smart Cruise Control conditions not satisfied



If the Driving Assist button, + switch, - switch or II S switch is pushed when Smart Cruise Control operating conditions are not satisfied, the 'Smart Cruise Control conditions not met' will appear on the cluster, and an audible warning will sound.

#### In traffic situation



In traffic, your vehicle will stop if the vehicle ahead of you stops. Also, if the vehicle ahead of you starts moving, your vehicle will start as well. In addition, after the vehicle has stopped and a certain time have passed, the 'Use switch or pedal to accelerate' message will appear on the cluster. Depress the accelerator pedal or operate the + switch, - switch or II > switch to start driving.

#### Warning road conditions ahead



O.JKFV072241I

In the following situation, the 'Watch for surrounding vehicles' warning message will appear on the cluster, and an audible warning will sound to warn the driver of road conditions ahead.

 The vehicle in front disappears when Smart Cruise Control is maintaining the distance with the vehicle ahead while driving below a certain speed.

## **MARNING**

Always pay attention to vehicles or objects that may suddenly appear in front of you, and if necessary, depress the brake pedal to reduce your driving speed in order to maintain a safe distance.

#### **Collision Warning**



OJKEV072005N

While Smart Cruise Control is operating, when the collision risk with the vehicle ahead is high, the 'Collision Warning' warning message will appear on the cluster, and an audible warning will sound to warn the driver. Always have your eyes on the road while driving, and if necessary, depress the brake pedal to reduce your driving speed in order to maintain a safe distance.

## A

#### WARNING

In the following situations, Smart Cruise Control may not warn the driver of a collision.

- The distance from the front vehicle is near, or the vehicle speed of the front vehicle is faster or similar to your vehicle
- The speed of the front vehicle is very slow or is at a standstill
- The accelerator pedal is depressed right after Smart Cruise Control is turned on

# **MARNING**

Take the following precautions when using Smart Cruise Control:

- Smart Cruise Control does not substitute for proper and safe driving. It is the responsibility of the driver to always check the speed and distance to the vehicle ahead.
- Smart Cruise Control may not recognize unexpected and sudden situations or complex driving situations, so always pay attention to driving conditions and control your vehicle speed.
- Keep Smart Cruise Control off when the function is not in use to avoid inadvertently setting a speed.
- Do not open the door or leave the vehicle when Smart Cruise Control is operating, even if the vehicle is stopped.
- Always be aware of the selected speed and headway distance.
- Keep a safe distance according to road conditions and vehicle speed. If the headway distance is too close during high-speed driving, a serious collision may result.
- When maintaining distance with the vehicle ahead, if the front vehicle disappears, Smart Cruise Control may suddenly accelerate to the set speed. Always be aware of unexpected and sudden situations from occurring.
- Vehicle speed may decrease on an upward slope and increase on a downward slope.
- Always be aware of situations such as when a vehicle cuts in suddenly.
- When you are towing a trailer or another vehicle, turn off Smart Cruise Control for safety reasons.

- Turn off Smart Cruise Control when your vehicle is being towed.
- Smart Cruise Control may not operate properly if interfered by strong electromagnetic waves.
- Smart Cruise Control may not detect an obstacle in front and lead to a collision. Always look ahead cautiously to prevent unexpected and sudden situations from occurring.
- Vehicles moving in front of you with a frequent lane change may cause a delay in Smart Cruise Control reaction or may cause Smart Cruise Control to react to a vehicle actually in an adjacent lane. Always drive cautiously to prevent unexpected and sudden situations from occurring.
- Always be aware of the surroundings and drive safely, even though a warning message does not appear or an audible warning does not sound.
- If any other system's warning message is displayed or warning sound is generated, Smart Cruise Control warning message may not be displayed and warning sound may not be generated.
- You may not hear the warning sound of Forward Collision-Avoidance Assist if the surrounding is noisy.
- The vehicle manufacturer is not responsible for any traffic violation or accidents caused by the driver.
- Always set the vehicle speed under the speed limit in your area.
- Vehicle distance, acceleration and reaction speed may change if the driver's driving style changes.

# Information

- Smart Cruise Control may not operate for 15 seconds after the vehicle is started or the front view camera or front radar is initialized.
- You may hear a sound when the brake is controlled by Smart Cruise Control.

#### **Smart Cruise Control** Malfunction and Limitations Smart Cruise Control malfunction



OJKEV072242N

When Smart Cruise Control is not working properly, the 'Check Smart Cruise Control System' warning message will appear, and the A warning light will illuminate on the instrument cluster. If this occurs, have the vehicle inspected by an authorized retailer of Genesis Branded products.

#### Smart Cruise Control disabled



OTM070115N

When the front radar cover or sensor is covered with snow, rain, or foreign material, it can reduce the detecting performance and temporarily limit or disable Smart Cruise Control.

If this occurs the 'Smart Cruise Control disabled. Radar blocked' warning message will appear for a certain period of time on the instrument cluster.

Smart Cruise Control will operate properly when snow, rain or foreign material is removed.



#### ♠ WARNING

Even though the warning message does not appear on the cluster, Smart Cruise Control may not properly operate.



#### **CAUTION**

Smart Cruise Control may not properly operate in an area (for example, open terrain), where any objects are not detected after turning ON the vehicle.

#### **Limitations of Smart Cruise Control**

Smart Cruise Control may not operate properly, or it may operate unexpectedly under the following circumstances:

- The detecting sensor or the surroundings are contaminated or damaged
- Washer fluid is continuously sprayed, or the wiper is on
- The camera lens is contaminated due to tinted, filmed or coated windshield, damaged glass, or sticky foreign material (sticker, bug, etc.) on the glass
- Moisture is not removed or frozen on the windshield
- The field of view of the front view camera is obstructed by sun glare
- Street light or light from an oncoming vehicle is reflected on the wet road surface, such as a puddle on the road
- The temperature around the front view camera is high or low
- An object is placed on the dashboard
- The surrounding is very bright
- The surrounding is very dark, such as in a tunnel, etc.
- The brightness changes suddenly, for example when entering or exiting a tunnel
- The brightness outside is low, and the headlights are not on or are not bright
- Driving in heavy rain or snow, or thick fog
- Driving through steam, smoke or shadow

- Only part of the vehicle is detected
- The vehicle in front has no tail lights, tail lights are located unusually, etc.
- The brightness outside is low, and the tail lights are not on or are not bright
- The rear of the front vehicle is small or does not look normal (for example, tilted, overturned, etc.)
- The front vehicle's ground clearance is low or high
- A vehicle suddenly cuts in front
- · Your vehicle is being towed
- · Driving through a tunnel or iron bridge
- Driving near areas containing metal substances, such as a construction zone, railroad, etc.
- An object reflecting off the front radar such as a guardrail, nearby vehicle, etc.
- The bumper around the front radar is impacted, damaged or the front radar is out of position
- The temperature around the front radar is high or low
- Driving in vast areas where there are few vehicles or structures (for example, desert, meadow, suburb, etc.)
- The vehicle in front is made of material that does not reflect on the front radar
- Driving near a highway interchange or tollbooth
- Driving on a slippery surface due to snow, water puddle, ice, etc.
- · Driving on a curved road
- The vehicle in front is detected late
- The vehicle in front is suddenly blocked by an obstacle
- The vehicle in front suddenly changes lane or suddenly reduces speed

- The vehicle in front is bent out of shape
- The front vehicle's speed is fast or slow
- With a vehicle in front, your vehicle changes lane at low speed
- The vehicle in front is covered with snow
- · Unstable driving
- You are on a roundabout and the vehicle in front is not detected
- You are continuously driving in a circle
- · Driving in a parking lot
- Driving through a construction area, unpaved road, partial paved road, uneven road, speed bumps, etc.
- Driving on an incline road, curved road, etc.
- Driving through a roadside with trees or streetlights
- The adverse road conditions cause excessive vehicle vibrations while driving
- Your vehicle height is low or high due to heavy loads, abnormal tire pressure, etc.
- Driving through a narrow road where trees or grass are overgrown
- There is interference by electromagnetic waves, such as driving in an area with strong radio waves or electrical noise

Driving on a curved road



On curves, Smart Cruise Control may not detect a vehicle in the same lane, and may accelerate to the set speed. Also, vehicle speed may rapidly decrease when the vehicle ahead is detected suddenly.

Select the appropriate set speed on curves and apply the brake pedal or accelerator pedal according to the road and driving conditions ahead.



Your vehicle speed can be reduced due to a vehicle in the adjacent lane.

Apply the accelerator pedal and select the appropriate set speed. Check to be sure that the road conditions permit safe operation of Smart Cruise Control.

#### · Driving on an inclined road



During uphill or downhill driving, Smart Cruise Control may not detect a moving vehicle in your lane, and cause your vehicle to accelerate to the set speed. Also, vehicle speed will rapidly decrease when the vehicle ahead is detected suddenly.

Select the appropriate set speed on inclines and apply the brake pedal or accelerator pedal according to the road and driving conditions ahead.

#### Changing lanes



[A]: Your vehicle, [B]: Lane changing vehicle

When a vehicle moves into your lane from an adjacent lane, it cannot be detected by the sensor until it is in the sensor's detection range. Smart Cruise Control may not immediately detect the vehicle when the vehicle changes lanes abruptly. In this case, you must maintain a safe braking distance, and if necessary, depress the brake pedal to reduce your driving speed in order to maintain a safe distance.

· Situations when detecting are limited



In the following cases, some vehicles, pedestrians or animals in your lane cannot be detected by the sensor:


- Vehicles offset to one side
- Slow-moving vehicles or suddendecelerating vehicles
- Vehicles with higher ground clearance or vehicles carrying loads that stick out of the back of the vehicle
- Vehicles that has the front lifted due to heavy loads
- Vehicles within about 6 feet (2m) from your vehicle
- Oncoming vehicles
- Stopped vehicles

- Vehicles with small rear profile, such as trailers
- Narrow vehicles, such as motorcycles or bicycles
- Special vehicles
- Animals and pedestrians

Adjust your vehicle speed by depressing the brake pedal according to the road and driving conditions ahead.


In the following cases, the vehicle in front cannot be detected by the sensor:

- You are steering your vehicle
- Driving on narrow or sharply curved roads




 When a vehicle ahead disappears at an intersection, your vehicle may accelerate.

Always pay attention to road and driving conditions while driving.



 When a vehicle in front of you merges out of the lane, Smart Cruise Control may not immediately detect the new vehicle that is now in front of you.
 Always pay attention to road and driving conditions while driving.



 Always look out for pedestrians when your vehicle is maintaining a distance with the vehicle ahead.



This device complies with Part 15 of the FCC rules.

Operation is subject to the following three conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

## **i** Information

Radio frequency radiation exposure information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance of 8 in. (20 cm) between the radiator (antenna) and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

# NAVIGATION-BASED SMART CRUISE CONTROL (NSCC) (IF EQUIPPED)

Navigation-based Smart Cruise Control can help drive at a certain speed according to the road conditions when driving on highways by using road information from the navigation system while Smart Cruise Control is operating.



#### Information

- Navigation-based Smart Cruise Control is available only on controlled access road of certain highways.
  - \* Controlled access road indicates roads with limited entrances and exits that allow uninterrupted high speed traffic flow. Only passenger cars and motorcycles are allowed on controlled access roads.
- Additional highways may be expanded by future navigation updates.

#### Available Highway (Controlled access road)

USA	Select Interstate Highway and U.S. (Federal) and State Highways
Canada	Select Provincial and Territorial Highways



#### Information

Navigation-based Smart Cruise Control operates on main roads of highways, and does not operate on interchanges or junctions.

#### Highway Curve Zone Auto Slowdown

If vehicle speed is high, Highway Curve Zone Auto Slowdown function will temporarily decelerate your vehicle or limit acceleration to help you drive safely on a curve based on the curve information from the navigation.

#### **Highway Set Speed Auto Change**

Highway Set Speed Auto Change function automatically changes Smart Cruise Control set speed based on the speed limit information from the navigation.

# Navigation-based Smart Cruise Control Settings



With the vehicle on, select Setup > Vehicle > Driver Assistance > Driving Convenience > Highway Auto Speed Change from the Settings menu to turn on Navigation-based Smart Cruise Control and deselect to turn off the



function.

#### Information

When there is a problem with Navigation-based Smart Cruise Control, the function cannot be set from the Settings menu.



#### ! CAUTION

When a trailer is connected to the tow hitch harness installed to your vehicle. Navigation-based Smart Cruise Control automatically turns off (if equipped). In this case, Navigation-based Smart Cruise Control is not functional. Always have your eyes on the road.

#### **Navigation-based Smart Cruise Control Operation**

#### Operating conditions

Navigation-based Smart Cruise Control is ready to operate if all of the following conditions are satisfied:

- Smart Cruise Control is operating
- Driving on main roads of highways



#### Information

For more information on how to operate Smart Cruise Control, refer to the "Smart Cruise Control (SCC)" section in this chapter.

#### **Navigation-based Smart Cruise** Control display and control

When Navigation-based Smart Cruise Control operates, it will be displayed on the cluster as follows:



**Navigation-based Smart Cruise Control** standby

If the operating conditions are satisfied, the white NAV symbol will illuminate.



O.JKFV072048N

**Navigation-based Smart Cruise Control** operating

If temporary deceleration is required in the standby state and Navigation-based Smart Cruise Control is operating, the green NAV symbol will illuminate on the cluster.

If the Highway Set Speed Auto Change function operates, the NAV symbol and set speed will illuminate in green on the cluster, and an audible warning will sound.



#### ♠ WARNING



OJKEV072257N

'Drive carefully' warning message will appear in the following circumstances:

Navigation-based Smart Cruise Control is not able to slow down your vehicle to a safe speed

# *i* Information

- Highway Curve Zone Auto Slowdown and Highway Set Speed Auto Change function uses the same NAV symbol.
- The images and colors in the instrument cluster may differ depending on the cluster type or theme selected from the settings menu.

#### Highway Curve Zone Auto Slowdown

- Depending on the curve ahead on the highway, the vehicle will decelerate, and after passing the curve, the vehicle will accelerate to Smart Cruise Control set speed.
- Vehicle deceleration time may differ depending on the vehicle speed and the degree of the curve on the road. The higher the driving speed, deceleration will start faster.

#### **Highway Set Speed Auto Change**

- Highway Set Speed Auto Change function will operate when Smart Cruise Control set speed and the highway speed limit is matched.
- While Highway Set Speed Auto Change function is operating, when the highway, speed limit changes, Smart Cruise Control set speed automatically changes to the changed speed limit.
- If Smart Cruise Control set speed is adjusted different from the speed limit, Highway Set Speed Auto Change function will be in the standby state.
- If Highway Set Speed Auto Change function has changed to the standby state by driving on a road other than the highway main road, Highway Set Speed Auto Change function will operate again when you drive on the main road again without setting the set speed.
- If Highway Set Speed Auto Change function has changed to the standby state by depressing the brake pedal or pressing the || ) switch on the steering wheel, press the || ) switch to restart the function.
- Highway Set Speed Auto Change function does not operate on highway interchanges or junctions.

## *i* Information


- Highway Set Speed Auto Change function only operates based on the speed limits of the highway, it does not work with the speed cameras.
- When Highway Set Speed Auto Change function is operating, the vehicle automatically accelerates or decelerates when the highway speed limit changes.
- The maximum set speed for Highway Set Speed Auto Change function is 86 mph (140 km/h).
- If the speed limit of a new road is not updated in the navigation, Highway Set Speed Auto Change function may not operate properly.
- If the speed unit is set to a unit other than the speed unit used in your state, Highway Set Speed Auto Change function may not operate properly.

#### Limitations of Navigation-based Smart Cruise Control


Navigation-based Smart Cruise Control may not operate properly under the following circumstances:

- The navigation is not working properly
- Map information is not transmitted due to infotainment system's abnormal operation
- Speed limit and road information in the navigation is not updated
- The map information and the actual road is different because of real-time GPS data or map information error
- The navigation searches for a route while driving
- GPS signals are blocked in areas such as a tunnel
- A road that divides into two or more roads and joins again
- The driver goes off course from the route set in the navigation
- The route to the destination is changed or canceled by resetting the navigation
- The vehicle enters a service station or rest area
- Android Auto or Car Play is operating
- The navigation cannot detect the current vehicle position (for example, elevated roads including overpass adjacent to general roads or nearby roads exist in a parallel way)
- The navigation is being updated while driving
- The navigation is being restarted while driving
- The speed limit of some sections changes according to the road situations


- · Driving on a road under construction
- Driving in lane-restricted driving situations
- There is bad weather, such as heavy rain, heavy snow, etc.
- Driving on a road that is sharply curved



- [1]: Set route,
- [2]: Branch line,
- [3]: Driving route,
- [4]: Main road,
- [5]: Curved road section
- When there is a difference between the navigation set route (branch line) and the driving route (main road), Highway Curve Zone Auto Slowdown function may not operate until the driving route is recognized as the main road.
- When the vehicle's driving route is recognized as the main road by maintaining the main road instead of the navigation set route, Highway Curve Zone Auto Slowdown function will operate. Depending on the distance to the curve and the current vehicle speed, vehicle deceleration may not be sufficient or may decelerate rapidly.



- [1]: Set route,
- [2]: Branch line,
- [3]: Driving route,
- [4]: Main road.
- [5]: Curved road section
- When there is a difference between the navigation route (main road) and the driving route (branch line), Highway Curve Zone Auto Slowdown function will operate based on the curve information on the main road.
- When it is judged that you are driving out of the route by entering the highway interchange or junction, Highway Curve Zone Auto Slowdown function will not operate.



- [1]: Driving route,
- [2]: Branch line,
- [3]: Curved road section,
- [4]: Main road
- If there is no destination set on the navigation, Highway Curve Zone Auto Slowdown function will operate based on the curve information on the main road.
- Even if you depart from the main road, Highway Curve Zone Auto Slowdown function may temporarily operate due to navigation information of the highway curve section.

## **WARNING**

- Navigation-based Smart Cruise Control is not a substitute for safe driving practices, but a convenience function. Always have your eyes on the road, and it is the responsibility of the driver to avoid violating traffic laws.
- The navigation's speed limit information may differ from the actual speed limit information on the road. It is the driver's responsibility to check the speed limit on the actual driving road or lane.

- Navigation-based Smart Cruise Control will automatically be canceled when you leave the highway main road. Always pay attention to road and driving conditions while driving.
- Navigation-based Smart Cruise Control may not operate due to the existence of leading vehicles and the driving conditions of the vehicle. Always pay attention to road and driving conditions while driving.
- When you are towing a trailer or another vehicle, turn off Navigationbased Smart Cruise Control for safety reasons.
- After you pass through a tollbooth on a highway, Navigation-based Smart Cruise Control will operate based on the first lane. If you enter one of the other lanes, Navigation-based Smart Cruise Control might not operate properly.
- The vehicle will accelerate if the driver depresses the accelerator pedal while Navigation-based Smart Cruise Control is operating, and the function will not decelerate the vehicle. However, if the accelerator pedal is depressed insufficiently, the vehicle may decelerate.
- If the driver accelerates and releases the accelerator pedal while Navigation-based Smart Cruise Control is operating, the vehicle may not decelerate sufficiently or may rapidly decelerate to a safe speed.
- If the curve is too large or too small, Navigation-based Smart Cruise Control may not operate.

# *i* Information

- A time gap could occur between the navigation's guidance and when Navigation-based Smart Cruise Control operation starts and ends.
- The speed information on the cluster and navigation may differ.
- Even if you are driving at a speed lower than Smart Cruise Control set speed, acceleration may be limited by the curve sections ahead.
- If Navigation-based Smart Cruise Control is operating while leaving the main road to enter an interchange, junction, rest area, etc., the function may operate for a certain period of time.
- Deceleration by Navigation-based Smart Cruise Control may feel it is not sufficient due to road conditions such as uneven road surfaces, narrow lanes, etc.

## i Info

#### Information

This device complies with Part 15 of the FCC rules.

Operation is subject to the following three conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.



#### Information

Radio frequency radiation exposure information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance of 8 in. (20 cm) between the radiator (antenna) and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

#### LANE FOLLOWING ASSIST (LFA)

Lane Following Assist is designed to help detect lane markings and/or vehicles on the road, and assists the driver's steering to help center the vehicle in the lane.

#### **Detecting sensor**



[1]: Front view camera

The front view camera is used as a detecting sensor to detect lane markings and front vehicles.

Refer to the picture above for the detailed location of the detecting sensor.



#### **CAUTION**

For more information on the precautions of the front view camera, refer to the "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

# Lane Following Assist Settings Warning Methods



With the vehicle on, go to **Setup > Vehicle > Driver Assistance > Warning Methods** from the Settings in the infotainment system to select the following:

- Warning Volume: The Warning Volume can be adjusted.
- Driving Safety Priority: Your vehicle lowers all other audio volumes when the Driver Assistance system warning sounds.



### CAUTION

When a trailer is connected to the tow hitch harness installed to your vehicle, Lane Following Assist automatically turns off (if equipped). In this case, Lane Following Assist is not functional. Always have your eyes on the road.



#### Information

- If you change the Warning Methods, Warning Methods of other Driver Assistance systems may change.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- There may be no Settings menu depending on the feature applied to your vehicle.
- Even though 0 is selected for Warning Volume, the Hands-off warning volume will not be turned off but warning volume will sound as 1.

#### **Lane Following Assist Operation** Turning Lane Following Assist On/ Off



With the vehicle on, short press the Lane Driving Assist button located on the steering wheel to turn on Lane Following Assist. The grey or green (a) indicator light will illuminate on the cluster.

Press the button again to turn off the function.

#### Lane Following Assist



If the vehicle ahead and/or both lane markings are detected and your vehicle speed is below 120 mph (200 km/h), the green (A) indicator light illuminates on the cluster, and Lane Following Assist helps center the vehicle in the lane by assisting the steering wheel.

# **CAUTION**

When the steering wheel is not assisted, the white A indicator light blinks and changes to grey.

#### Hands-off warning



OJKEV072022L

If the driver takes their hands off the steering wheel for several seconds, the 'Keep hands on steering wheel' warning message will appear and an audible warning will sound in stages.

First stage: Warning message

Second stage: Warning message (red

steering wheel) and audible warning




If the driver still does not have their hands on the steering wheel after the hands-off warning, the 'Lane Following Assist deactivated' warning message will appear and Lane Following Assist will be automatically canceled.

## **MARNING**

- The steering wheel may not be assisted if the steering wheel is held very tight or the steering wheel is steered over a certain degree.
- Lane Following Assist does not operate at all times. It is the responsibility of the driver to safely steer the vehicle and to maintain the vehicle in its lane.
- The hands-off warning message may appear late depending on road conditions. Always have your hands on the steering wheel while driving.
- If the steering wheel is held very lightly the hands-off warning message may appear because Lane Following Assist may not recognize that the driver has their hands on the steering wheel.
- If you attach objects to the steering wheel, the hands-off warning may not work properly.

## *i* Information

- For more information on instrument cluster settings, refer to the "Cluster Display Control" section in chapter 4.
- When both lane markings are detected, the lane lines on the cluster will change from grey to white.



[A]: Lane undetected, [B]: Lane detected

- The images and colors in the instrument cluster may differ depending on the cluster type or theme selected from the settings menu.
- If lane markings are not detected, steering wheel control by Lane Following Assist can be limited depending on whether a vehicle is in front or the driving conditions of the vehicle.
- Even though the steering is assisted by Lane Following Assist, the driver may control the steering wheel.
- The steering wheel may feel heavier or lighter when the steering wheel is assisted by Lane Following Assist than when it is not

#### Lane Following Assist Malfunction and Limitations

Lane Following Assist malfunction



When Lane Following Assist is not working properly, the 'Check Lane Following Assist system' warning message will appear for several seconds, and the master (A) warning light will illuminate on the instrument cluster. If this occurs, have the vehicle inspected by an authorized retailer of Genesis Branded products.

#### Limitations of Lane Following Assist

For more information on Lane Following Assist limitations, refer to the "Lane Keeping Assist (LKA)" section in this chapter.



#### Information


For more information on Lane Following Assist precautions, refer to the "Lane Keeping Assist" section in this chapter.

#### **HIGHWAY DRIVING ASSIST (HDA)**

#### **Basic function**

Highway Driving Assist is designed to do the following while driving on the highway:


- Help detect vehicles ahead
- · Help detect lanes ahead
- Help maintain distance from the vehicle ahead
- · Help maintain set speed
- · Help center the vehicle in the lane



OJKEV071145

# Highway Lane Change Assist (if equipped)

Highway Lane Change Assist function helps change lanes to the direction the driver slightly moves the turn signal switch if the function judges that lane change is possible.



## *i* Information

- Highway Driving Assist is available only on controlled access road of certain highways.
  - \* Controlled access road indicates roads with limited entrances and exits that allow uninterrupted high speed traffic flow. Only passenger cars and motorcycles are allowed on controlled access roads.
- Additional highways may be expanded by future navigation updates.

# USA Select Interstate Highway and U.S. (Federal) and State Highways Canada Select Provincial and Territorial Highways



Highway Driving Assist operates on main roads of highways, and does not operate on interchanges or junctions.

#### **Detecting sensor**







- [1]: Front view camera,
- [2]: Front radar,
- [3]: Front corner radar (if equipped),
- [4]: Rear corner radar

Refer to the picture above for the detailed location of the detecting sensors.

# **A** CAUTION

For more information on the precautions of the detecting sensors, refer to the "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

#### **Highway Driving Assist Settings**



With the vehicle on, select or deselect **Setup > Vehicle > Driver Assistance > Driving Convenience** from the Settings menu to set whether to use each function.

#### Basic function

If **Highway Driving Assist** is selected, it helps maintain distance from the vehicle ahead, maintain the set speed, and helps center the vehicle in the lane.

# Highway Lane Change Assist (if equipped)

If **Highway Lane Change Assist** is selected, it helps the driver change lanes.



#### Information

- When Highway Driving Assist is deselected, the setting for 'Highway Lane Change Assist' cannot be changed.
- If there is a problem with the functions, the settings cannot be changed. Have the vehicle inspected by an authorized retailer of Genesis Branded products.
- If the vehicle is restarted, the functions will maintain the last setting.



#### WARNING

For your safety, only change the Settings after parking the vehicle at a safe location.



#### **CAUTION**

When a trailer is connected to the tow hitch harness installed to your vehicle, Highway Driving Assist automatically turns off (if equipped). In this case, Highway Driving Assist is not functional. Always have your eyes on the road.



OJKEV072322N

#### Warning Methods

With the vehicle on, go to **Setup > Vehicle > Driver Assistance > Warning Methods** from the Settings in the infotainment system to select the following:

- Warning Volume: The Warning Volume can be adjusted.
- Driving Safety Priority: Your vehicle lowers all other audio volumes when the Driver Assistance system warning sounds.



#### Information

- If you change the Warning Methods, Warning Methods of other Driver Assistance systems may change.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- There may be no Settings menu depending on the feature applied to your vehicle.
- Even though 0 is selected for Warning Volume, the Hands-off warning volume will not be turned off but warning volume will sound as 1.


# Highway Driving Assist Operation

Basic function

#### Displaying operating status

You can see the status of the Highway Driving Assist operation in the Driving Assist view on the cluster. Refer to the "View Modes" section in chapter 4.

Highway Driving Assist will be displayed as below depending on the status of the function.



[A]: Operating state, [B]: Standby state

- Highway Driving Assist indicator, whether there is a vehicle ahead and the selected distance level are displayed.
  - \* Highway Driving Assist indicator
  - Green HDA: Operating state
  - Grey HDA: Standby state
  - White HDA blink: Accelerator depressed state
- (2) Set speed
- (3) Lane Following Assist indicator
- (4) Whether there is a vehicle ahead and the selected headway
- (5) Whether the lane is detected or not

## *i* Information

- For more information on the display refer to the "Smart Cruise Control (SCC)" and "Lane Following Assist (LFA)" sections in this chapter.
- The images and colors in the instrument cluster may differ depending on the cluster type or theme selected from the settings menu.

# **Highway Driving Assist operation**Highway Driving Assist operates when:

- Driving on the main road of highways, and turning on Highway Driving Assist by pressing the Driving Assist button.
- Entering the main road of highways while Lane Following assist and Smart Cruise Control are operating

#### Restarting after stopping



When Highway Driving Assist is operating, your vehicle will stop if the vehicle ahead of you stops. Also, if the vehicle ahead of you starts moving within 30 seconds after the stop, your vehicle will start as well. In addition, after the vehicle has stopped and 30 seconds have passed, the 'Use switch or pedal to accelerate' message will appear on the cluster. Depress the accelerator pedal or operate the + switch, - switch or II'D switch to start driving.

#### Hands-off warning



If the driver takes their hands off the steering wheel for several seconds, the 'Keep hands on steering wheel' warning message will appear and an audible warning will sound in stages.

First stage: Warning message
Second stage: Warning message (red

steering wheel) and audible warning




If the driver still does not have their hands on the steering wheel after the hands-off warning, 'Highway Driving Assist deactivated' warning message will appear and Highway Driving Assist and Lane Change Assist will be automatically canceled.

#### **Driving speed limit**



When Highway Driving Assist is canceled by the hands-off warning, The driving speed will be limited.

While Driving Speed Limit function is operating, the 'Driver's grasp not detected. Driving speed will be limited' warning message will appear on the cluster, and an audible warning will sound continuously.



O.JKFV071149

# Driving to one side within lane (if equipped)

When vehicle speed is above 40 mph (60 km/h), if a detected vehicle around you is driving at a close distance, your vehicle will control steering in the opposite direction of the vehicle to assist in safe driving. If there are detected vehicles on both sides of the lane that are driving close to you, your vehicle does not control steering in either direction.

#### **Highway Driving Assist standby**

When Smart Cruise Control is temporarily canceled while Highway Driving Assist is operating, Highway Driving Assist will be in the standby state. At this time, Lane Following Assist will operate properly.

## *i* Information

- Driving Speed Limit helps you drive below 40 mph (60 km/h). At this time, the vehicle decelerates due to the vehicle ahead. After the vehicle has decelerated, it cannot automatically accelerate.
- Driving Speed Limit will cancel in the following circumstances:
  - When the driver grabs the steering wheel again
  - When the driver turns on Lane Following Assist by pressing the Lane Driving Assist button
  - When +, -, **|| 1** switch or **!** button is operated, or the accelerator pedal or the brake pedal is depressed

# Highway Lane Change Assist (if equipped)

Displaying operating status

You can see the status of the Highway Lane Change Assist operation in the Driving Assist view on the cluster. Refer to the "View Modes" section in chapter 4.

Highway Lane Change Assist function will be displayed as below depending on the status of the function.



[A]: Ready/Operating, [B]: Standby/Canceled

- (1) Highway Lane Change Assist indicator
  - Green **∜** on: Ready state
  - Green # blink: Operating state
  - Grey 🐈 on: Standby state
- (2) Green lane line

The lane line is displayed same as the Highway Lane Change Assist indicator (1). However, if the function is on standby, it displays whether the lane line is detected.

(3) Green arrow and shade

The green arrow is displayed when a certain amount of time has passed after the function has started operating, and until the lane change has completed.

- (4) Message
  - Message is displayed when the function does not operate even though the turn signal is used.
  - Message is displayed when the function is canceled while operating.

To turn on Highway Lane Change Assist Highway Lane Change Assist function will turn on when the following conditions are satisfied.

 The Driving Assist button or Lane Driving Assist button is used to turn on Highway Driving Assist.

**Highway Lane Change Assist ready to operate** 

While Highway Lane Change Assist function is on, the function will be ready to operate when all the following conditions are satisfied:

- Highway Driving Assist is operating
- · Lane Following Assist is operating
- A vehicle in the rear area of your vehicle is detected more than once after the vehicle is turned on
- Your vehicle speed is above 40 mph (60 km/h)
- Hands-off warning is not displayed on the cluster
- · Hazard warning flasher is off

## *i* Information

- While Lane Change Assist function is turned on (indicator on), Lane Following Assist will not cancel even if the turn signal indicator or hazard warning flasher is operating.
- Lane Change Assist function turns off automatically when driven in the following road conditions:
  - One driving lane
  - A road with a intersection or crosswalk ahead
  - A road with no structure, such as a medium strip, guardrails, etc.
  - There is a pedestrian or cyclist on the road ahead
- When the function is in the ready state, and vehicle speed is below 35 mph (55 km/h), the function will change to the standby state.

## **WARNING**

When Highway Lane Change Assist function turns off while operating, steering assist will be temporarily canceled. Always be cautious while driving.

#### **Highway Lane Change Assist operation**




[1]: Center

- The driver has his/her hand on the steering wheel
- There is no collision risk in the direction of lane change
- There is a single dotted lane line in the direction of lane change
- There are no Forward Collision-Avoidance Assist and Blind Spot Collision-Avoidance Assist warnings
- The vehicle is driven in the middle of the lane (should not be driving close to one side of the lane)
- The road you are driving on, or the road you are about to change lane is a road that the function can operate

# **information**

- Highway Lane Change Assist
  operates when the turn signal lever is
  positioned at A. If the turn signal lever
  is released to the center (1) before
  stepping on the lane, Highway Lane
  Change Assist cancels. If the turn
  signal lever is released to the center
  (1) after stepping on the lane, Highway
  Lane Change Assist changes the lane
  and turns off the turn signal after lane
  change is complete.
- When the turn signal lever is placed at B position for a certain period of time, the green arrow will appear. At this time, even when the lever is released and returns to it's original position (1) lane change will still be assisted.
- While lane change is being made by the function, the turn signal indicator will blink even when the turn signal lever is not held, and the turn signal indicator will turn off when lane change is complete.

 Highway lane change assist does not operate on the entrance or exit of the highway.



Highway Lane Change Assist standby Highway Lane Change Assist function will be in the standby state when one of the ready state condition is not satisfied, or when entering or driving on one of the following roads:

- Road within a certain distance from the tollbooth on the main road of the highway
- The road ahead ends without an interchange or junction
- · Road with sharp curves
- Road with narrow lanes

Highway Lane Change Assist cancel
The function will be canceled when:

- The turn signal lever is moved to the "A" position while the Highway Lane Change Assist function is operating and placed in the center (1) before stepping on the lane line.
- The turn signal lever is turned on in the opposite direction of lane change
- · The steering wheel is steered sharply

## **!** WARNING

- While the function is operating, the function will cancel if one of the following occurs:
  - Highway Driving Assist is turned off
  - Lane Following Assist or Smart Cruise Control is turned off or temporarily canceled
  - Hands-off warning message is displayed on the cluster
  - The hazard warning flasher is turned on
  - Forward Collision-Avoidance Assist or Blind-Spot Collision Avoidance Assist warning message is displayed

- Possible collision is detected in the next lane, even though there are no Forward-Collision Avoidance Assist and Blind-Spot Collision Avoidance Assist warning
- The target lane to make a lane change disappears
- There is a problem with turn signal lights
- Highway Lane Change Assist function is off (The function turns off when the function is turned off from the settings menu, when the road changes to a one-way road, when there is a intersection or crosswalk ahead, when you enter a road with no structure, such as a medium strip, guardrail, etc.,or when there is a pedestrian or cyclist on the driving lane.)
- Your vehicle speed is below 35 mph (55 km/h)
- While the function is operating, when the function is canceled, depending on the driving conditions, the vehicle may drive to the middle of the driving lane or steering assist may stop.
   Always pay attention to road and driving conditions while driving.
- The function may not operate properly on roads with pedestrians or cyclists, such as an intersection or crosswalk.
   Always pay attention to road and driving conditions while driving.

## **Highway Driving Assist Malfunction and Limitations** Highway Driving Assist malfunction





O.JKFV072248N

When Highway Driving Assist or Highway Lane Change function is not working properly, the 'Check Highway Driving Assist system' warning message will appear, and the warning light will illuminate on the instrument cluster. Have the vehicle inspected by an authorized retailer of Genesis Branded products.

## WARNING

- The driver is responsible for controlling the vehicle and safe driving.
- Always have your hands on the steering wheel while driving.
- · Highway Driving Assist is a supplemental function that assists the driver in driving the vehicle and is not a complete autonomous driving system. Always check road conditions, and if necessary, take appropriate actions to drive safely.
- Always have your eyes on the road, and it is the responsibility of the driver to avoid violating traffic laws. The vehicle manufacturer is not responsible for any traffic violation or accidents caused by the driver.

- Highway Driving Assist may not be able to recognize all traffic situations. Highway Driving Assist may not detect possible collisions due to limitations of the function. Always be aware of the limitations of the function. Obstacles such as vehicles, motorcycles, bicycles, pedestrians, or unspecified objects or structures such as guardrails, tollbooth, etc., that may collide with the vehicle may not be detected.
- Highway Driving Assist will turn off automatically under the following situations:
  - Driving on roads that Highway Driving Assist does not operate, such as a rest area, intersection, junction, etc.
  - The navigation does not operate properly such as when the navigation is being updated or restarted
- Highway Driving Assist may inadvertently operate or turn off depending on road conditions (navigation information) and surroundings.
- · Lane Following Assist function may be temporarily disabled when the front view camera cannot detect lanes properly or the hands-off warning is on.
- You may not hear the warning sound of Highway Driving Assist if the surrounding is noisy.

- If the vehicle is driven at high speed above a certain speed at a curve, your vehicle may drive to one side or may depart from the driving lane.
- When you are towing a trailer or another vehicle, turn off Highway Driving Assist for safety reasons.
- The hands-off warning message may appear early or late depending on how the steering wheel is held or road conditions. Always have your hands on the steering wheel while driving.
- For your safety, read the owner's manual before using Highway Driving Assist.
- Highway Driving Assist will not operate when the vehicle is started, or when the detecting sensors or navigation is being initialized.

#### Limitations of Highway Driving Assist

Highway Driving Assist and Highway Lane Change function may not operate properly, or it may not operate under the following circumstances:

- The map information and the actual road is different because the navigation is not updated
- The map information and the actual road is different because of real-time GPS data or map information error
- The infotainment system is overloaded by simultaneously performing functions such as route search, video playback, voice recognition, etc.
- GPS signals are blocked in areas such as a tunnel
- The driver goes off course or the route to the destination is changed or canceled by resetting the navigation
- The vehicle enters a service station or rest area
- Android Auto or Car Play is operating
- The navigation cannot detect the current vehicle position (for example, elevated roads including overpass adjacent to general roads or nearby roads exist in a parallel way)
- White single dotted lane line or road edge cannot be detected
- The road is temporarily controlled due to construction, etc.
- There is no structure, such as a medium strip, guardrails, etc., on the road
- There is a changeable lane in the direction of lane change

# *i* Information

For more information on the limitations of the front view camera, front radar, front corner radar and rear corner radar, refer to the "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

## *i* Information

This device complies with Part 15 of the FCC rules.

Operation is subject to the following three conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

## *i* Information

Radio frequency radiation exposure information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance of 8 in. (20 cm) between the radiator (antenna) and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## **REAR VIEW MONITOR (RVM) (IF EQUIPPED)**

Rear View Monitor shows the area behind the vehicle to assist you when parking or backing up.

### **Detecting sensor**



[1]: Wide-rear view camera

Refer to the picture above for the detailed location of the detecting sensor.

# Rear View Monitor Settings Warning Methods



O.JKFV072312N

With the vehicle on, go to Setup > Vehicle > Driver Assistance > Warning Methods from the Settings in the infotainment system to select the following:

 Parking Safety Priority: Your vehicle lowers all other audio volumes when Rear View Monitor is operating.

## **Information**

- If you change the Warning Methods, Warning Methods of other Driver Assistance systems may change.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- There may be no Settings menu depending on the feature applied to your vehicle.

#### Camera settings



You can change Rear View Monitor Display Contents by touching the setup icon (②) on the screen while Rear View Monitor is operating, or selecting Driver Assistance > Parking Safety > Camera Settings from the Settings menu while the vehicle is on.

 If Display Contents is selected, you may set whether to use Rear View Parking Guide Lines or Extended Rear View Monitor.

#### **Rear View Parking Guide Lines**

If Rear View Parking Guide Lines is selected, the rear view parking guide lines and rear top view guide lines will be displayed at the left side of the infotainment system screen.



### Information

- The horizontal guideline of the Rear View Parking Guidance shows the distance of 1.6 feet (0.5 m), 3.3 feet (1 m), 7.6 feet (2.3 m) from the vehicle.
- The horizontal guideline of the Rear Top View Parking Guidance shows the liftgate opening distance and the distance of 4.9 feet (1.5 m) from the vehicle

#### **Extended Rear View Monitor**

With the vehicle on, select **Driver**Assistance > Parking Safety > Camera
Settings from the infotainment system
Settings menu to turn on Extended Rear
View function and deselect to turn off
the function.

Extended Rear View Monitor will turn off under the following conditions:

- The gear is shifted to P (Park).
- The Parking/View button is pressed.
- The infotainment system button is pressed.
- The Home button is pressed.
- Vehicle speed is above 6 mph (10 km/h).

## Rear View Monitor Operation Parking/View button



Press the Parking/View button (1) to turn on Rear View Monitor.

Press the button again to turn off the function.

#### Rear View function



#### **Operating conditions**

- Shift the gear to R (Reverse), the image will appear on the screen.
- Press the Parking/View button (1)
  while the gear is in P (Park), the image
  will appear on the screen.

#### **Operating conditions**

- The rear view cannot be turned off when the gear is in R (Reverse).
- Press the Parking/View button (1)
  again while the gear is in P (Park) with
  the rear view on the screen, the rear
  view will turn off.
- Shift the gear from R (Reverse) to P (Park), the rear view will turn off.

#### Extended Rear View function

Extended Rear View function maintains showing the rear view when the gear is R (Reverse), N (Neutral) or D (Drive).

Extended Rear View will turn on under the following conditions:

 The gear is in P (Park), N (Neutral) or D (Drive), and vehicle speed is 6 mph (10 km/h) or less.

Extended Rear View will turn off under the following conditions:

- The gear is shifted to P (Park).
- The Parking/View button (1) is pressed.
- Vehicle speed is above 6 mph (10 km/h).

#### Rear Top View



When you touch the icon, the top view is displayed on the screen and shows the distance from the vehicle in the back of your vehicle while parking.

# Rear View Monitor Malfunction and Limitations

#### Rear View Monitor malfunction

When Rear View Monitor is not working properly, or the screen flickers, or the camera image does not display properly, have the vehicle inspected by an authorized retailer of Genesis Branded products.

# A


## WARNING

- The rear view camera does not cover the complete area behind the vehicle. The driver should always check the rear area directly through the inside rearview mirror and outer side view mirror before parking or backing up.
- The image shown on the screen may differ from the actual distance of the object. Make sure to directly check the vehicle's surroundings for safety.
- Always keep the rear view camera lens clean. If the lens is covered with foreign material, it may adversely affect camera performance and Rear View Monitor may not operate properly. However, do not use chemical solvents such as strong detergents containing high alkaline or volatile organic solvents (gasoline, acetone etc.). This may damage the camera lens.

## SURROUND VIEW MONITOR (SVM) (IF EQUIPPED)

Surround View Monitor can assist in parking by allowing the driver to see around the vehicle.

#### **Detecting sensor**





[A]: Wide-front view camera,
[B], [C]: Wide-side view camera
(Below the side view mirror),
[D]: Wide-rear view camera

Refer to the picture above for the detailed location of the detecting sensors.

# **Surround View Monitor Settings** Warning Methods



With the vehicle on, go to **Setup > Vehicle > Driver Assistance > Warning Methods** from the Settings in the infotainment system to select the following:

 Parking Safety Priority: Your vehicle lowers all other audio volumes when Surround View Monitor is operating.



- If you change the Warning Methods, Warning Methods of other Driver Assistance systems may change.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- There may be no Settings menu depending on the feature applied to your vehicle.

#### Camera settings



- You can change Surround View Monitor Display Contents or Display Settings by touching the setup icon ((i)) on the screen while Surround View Monitor is operating, or selecting Setup > Vehicle > Driver Assistance > Parking Safety > Camera Settings from the Settings menu while the vehicle is on.
- In the Display Contents, you can change settings for Top View Parking Guide Lines, Rear View Parking Guide Lines and Parking Distance Warning.

## **Top View Parking Guide Lines**

When the **Top View Parking Guide Lines** is selected, parking guide lines is displayed on the right side of the Surround View Monitor screen.



#### Information

The horizontal guideline of the Rear Top View Parking Guidance shows the liftgate opening distance and the distance of 6.6 feet (2 m) from the vehicle.

#### Rear View Parking Guide Lines

When the **Rear View Parking Guide Lines** is selected, parking guide lines is displayed in the rear view.



#### Information

The horizontal guideline shows the distance of 1.6 feet (0.5 m), 3.3 feet (1 m) and 7.6 feet (2.3 m) from the vehicle.

### Parking Distance Warning

When the **Parking Distance Warning** is selected, parking distance warning is displayed on the right side of the Surround View Monitor screen.

 The image will be displayed only when Parking Distance Warning is warning the driver.

#### Surround View Monitor Auto On

With the vehicle on, select Setup > Vehicle > Driver Assistance > Parking Safety > Surround View Monitor Auto On from the Settings menu to use the function.

# Surround View Monitor Operation





#### Front view

The front image is displayed on the screen when the gear is in N (Neutral) or D (Drive) to assist in parking. Using the view button (2) you may select top view, front view and side view. The front view function will turn on under the following conditions:

- The gear is in N (Neutral) or D (Drive), and vehicle speed is 9 mph (15 km/h) or less.
- The Parking/View button (1) is pressed, while the gear is in N (Neutral) or D (Drive), and vehicle speed is 9 mph (15 km/h) or less.

- Surround view monitor auto On function will operate when the following conditions are satisfied:
  - With Setup > Vehicle > Driver Assistance > Parking Safety > Surround View Monitor Auto On selected from the Settings menu, the front view screen is displayed when Parking Distance Warning warns the driver while driving in D (Drive).

# **i** Information

When the front view is turned on, the previous view mode will be displayed.

The front view function will turn off under the following conditions:

- The Parking/View button (1) or the infotainment system button (3) is pressed.
- Vehicle speed is above 9 mph (15 km/h).
- The gear is shifted to P (Park).

# *i* Information

Surround View Monitor will turn off when vehicle speed is above 9 mph (15 km/h). However, Surround View Monitor will not turn on again although vehicle speed drops below 6 mph (10 km/h).

#### Rear view



The rear image is displayed on the screen when the gear is in P (Park) to assist in parking. Using the view button (2) you may select top view, rear view and side view.

The rear view function will turn on under the following conditions:

- The gear is shifted to R (Reverse).
- The Parking/View button (1) button is pressed when gear is in P (Park).

The rear view function will turn off under the following conditions:

- The gear is shifted from R (Reverse) to P (Park).
- The Parking/View button (1) button is pressed when gear is in P (Park).

# *i* Information

When the gear is in R (Reverse), the rear view does not turn off even if the infotainment system button (3) is pressed.

#### 3D view

The 3D view shows the image around the vehicle from various angles.

You can change angles by tapping the screen. Press the 3D View button again to return to the initial angle.

3D view will turn on when the 3D view is selected among the view buttons (2) under the following conditions:

- The gear is in P (Park), N (Neutral) or D (Drive) when vehicle speed is below 6 mph (10 km/h).
- The Surround View Monitor is turned on when the gear is in R (Reverse).

When the gear is in P (Park), N (Neutral) or D (Drive), 3D view will turn off under the following conditions:

- The gear is shifted to P (Park).
- The Parking/View button (1) is pressed.
- The infotainment system button (3) is pressed.
- The Home button (2) is pressed.
- Vehicle speed is above 6 mph (10 km/h).

## Information

3D view does not display guidelines.

# Surround View Monitor Malfunction and Limitations

## Surround View Monitor malfunction

When Surround View Monitor is not working properly, or the screen flickers, or the camera image does not display properly, have the vehicle inspected by an authorized retailer of Genesis Branded products.

#### Limitations of Surround View Monitor


- The screen may be displayed abnormally, and an icon will appear at the top left side of the screen under the following circumstances:
  - The liftgate is opened
  - The driver or front passenger door is opened
  - The side view mirror is folded

# **!** WARNING

- Always look around your vehicle to make sure there are no objects or obstacles before moving the vehicle. What you see on the screen may differ from the actual vehicle's location.
- The image shown on the screen may differ from the actual distance of the object. Make sure to directly check the vehicle's surroundings for safety.
- Surround View Monitor is designed to be used on a flat surface. Therefore, if used on roads with different heights such as curbs and speed bumps, the image in the screen my not look correct.
- Always keep the camera lens clean.
   If the lens is covered with foreign material, it may adversely affect camera performance and Surround View Monitor may not operate properly. However, do not use chemical solvents such as strong detergents containing high alkaline or volatile organic solvents (gasoline, acetone etc.). This may damage the camera lens.

## REAR CROSS-TRAFFIC COLLISION-AVOIDANCE ASSIST (RCCA)

Rear Cross-Traffic Collision-Avoidance Assist is designed to help detect vehicles approaching from the left and right side while your vehicle is reversing. When a vehicle is detected, the system will warn the driver that a collision is imminent with a visual and audible warning. The system can also provide braking assist to help prevent a collision.



[A]: Rear Cross-Traffic Collision Warning operating range,

[B]: Rear Cross-Traffic Collision-Avoidance Assist operating range

## **Detecting sensor**



[1]: Rear corner radar

Refer to the picture above for the detailed location of the detecting sensors.



### Information

For more information on the precautions of the rear corner radar, refer to the "Blind-Spot Collision-Avoidance Assist (BCA)" section in this chapter.



## CAUTION

Warning timing may vary depending on the speed of the approaching vehicle.

## Rear Cross-Traffic Collision-Avoidance Assist Settings Rear Cross-Traffic Safety



OJKEV072318N

With the vehicle on, select Setup > Vehicle > Driver Assistance > Parking Safety > Rear Cross-Traffic Safety from the Settings menu to turn on Rear Cross-Traffic Collision-Avoidance Assist and deselect to turn off the function.



### **WARNING**

When the vehicle is restarted, Rear Cross-Traffic Collision-Avoidance Assist will always turn on. However, the driver should always be aware of the surroundings and drive safely especially if Rear Cross-Traffic Safety is deselected.



## CAUTION

When a trailer is connected to the tow hitch harness installed to your vehicle, Rear Cross-Traffic Collision-Avoidance Assist automatically turns off (if equipped). In this case, Rear Cross-Traffic Collision-Avoidance Assist is not functional. Always have your eyes on the road.



**Warning Timing** 

With the vehicle on, select Setup > Vehicle > Driver Assistance > Warning Timing from the Settings menu to change the initial warning activation time for Rear Cross-Traffic Collision-Avoidance Assist. The warning time can be set to either Standard or Late.


- Use Standard in normal driving conditions. If the Warning Timing seems sensitive, change it to Late.
- If Late is selected, Rear Cross-Traffic Collision-Avoidance Assist, warns the driver more slowly.



#### Information

If you change the Warning Timing, the Warning Timing of other Driver Assistance systems may change.







### Warning Methods

With the vehicle on, go to Setup > Vehicle > Driver Assistance > Warning Methods from the Settings in the infotainment system to select the following:

- Warning Volume: The Warning Volume can be adjusted.
- Haptic Warning: The steering wheel vibration can be set (type A) or adjusted (type B).

# *i* Information

- If you change the Warning Methods, Warning Methods of other Driver Assistance systems may change.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- There may be no Settings menu depending on the feature applied to your vehicle.
- Even though 0 is selected for Warning Volume, Warning Volume will not be turned off but Warning Volume will sound as 1.
- When Haptic Warning is selected as 0 or deselected while Warning Volume is selected as 0, Warning Volume will activate and be selected as 2.
- When Warning Volume is selected as 0 while Haptic Warning is selected as 0 or deselected, steering wheel vibration will activate or be selected as 2.



## CAUTION

- The setting of the Warning Timing applies to all functions of Rear Cross-Traffic Collision-Avoidance Assist.
- Even though Standard is selected for Warning Timing, if the vehicles from the left and right side approaches at high speed, the warning may seem late
- Select Late for Warning Timing when traffic is light and when driving speed is slow.

## Rear Cross-Traffic Collision-Avoidance Assist Operation

Rear Cross-Traffic Collision-Avoidance Assist will warn and control the vehicle depending on collision risk level: 'Collision Warning', 'Emergency Braking' and 'Stopping vehicle and ending brake control'.







### **Collision Warning**

- To warn the driver of an approaching vehicle from the rear left/right side of your vehicle, the warning light on the side view mirror will blink and a warning will appear on the instrument cluster. At the same time, an audible warning will sound and the steering wheel will vibrate. If Rear View Monitor is operating, a warning will also appear on the infotainment system screen.
- Rear Cross-Traffic Collision-Avoidance Assist will operate when all the following conditions are satisfied:
  - The gear is shifted to R (Reverse)
  - Vehicle speed is below 5 mph (8 km/h)
  - The approaching vehicle is within about 82 feet (25 m) from the left and right side of your vehicle
  - The speed of the vehicle approaching from the left and right is above 3 mph (5 km/h)



O IKEV072252N

## Information

- If the operating conditions are satisfied, there will be a warning whenever the vehicle approaches from the left or right side even though your vehicle speed is 0 mph (0 km/h).
- The images and colors in the cluster may differ depending on the cluster type or theme selected from the cluster.

#### **Emergency Braking**





OJKEV072066N



O IKEV072065N

• To warn the driver of an approaching vehicle from the rear left/right side of your vehicle, the warning light on the side view mirror will blink and a warning message will appear on the instrument cluster. At the same time, an audible warning will sound and the steering wheel will vibrate. A warning will also appear on the infotainment system screen.

- Emergency braking will be assisted to help prevent collision with approaching vehicles from the left and right.
- Rear Cross-Traffic Collision-Avoidance Assist will operate when all the following conditions are satisfied:
  - The gear is shifted to R (Reverse)
  - Vehicle speed is below 5 mph (8 km/h)
  - The approaching vehicle is within about 5 feet (1.5 m) from the left and right side of your vehicle
  - The speed of the vehicle approaching from the left and right is above 3 mph (5 km/h)

# A

## WARNING

Brake control ends when the conditions of the approaching vehicle from the rear left or right side are as below:

- The approaching vehicle is out of the detecting range
- The approaching vehicle passes behind your vehicle
- The approaching vehicle does not drive toward your vehicle
- The approaching vehicle speed slows down
- The driver depresses the brake pedal with sufficient power

# Stopping vehicle and ending brake control



- When the vehicle is stopped due to emergency braking, the 'Drive carefully' warning message will appear on the instrument cluster.
- For your safety, the driver should depress the brake pedal immediately and check the surroundings.
- Brake control will end after the vehicle is stopped by emergency braking for about 2 seconds.
- During emergency braking, braking control by Rear Cross-Traffic Collision-Avoidance Assist will automatically cancel when the driver excessively depresses the brake pedal.



## ! WARNING

Take the following precautions when using Rear Cross-Traffic Collision-Avoidance Assist:

- For your safety, only change the Settings after parking the vehicle at a safe location.
- If any other system's warning message is displayed or audible warning is generated, Rear Cross-Traffic Collision-Avoidance Assist's warning message may not be displayed and audible warning may not be generated.
- You may not hear the warning sound of Rear Cross-Traffic Collision-Avoidance Assist if the surrounding is noisy.
- Rear Cross-Traffic Collision-Avoidance Assist may not operate if the driver applies the brake pedal to avoid collision.
- During Rear Cross-Traffic Collision-Avoidance Assist operation, the vehicle may stop suddenly injuring passengers and shifting loose objects. Always have the seat belt on and keep loose objects secured.
- Even if there is a problem with Rear Cross-Traffic Collision-Avoidance Assist, the vehicle's basic braking will function normally.
- When Rear Cross-Traffic Collision-Avoidance Assist is operating, braking control by function will automatically cancel when the driver excessively depresses the accelerator pedal.
- Rear Cross-Traffic Collision-Avoidance Assist does not operate in all situations or cannot avoid all collisions.

- Rear Cross-Traffic Collision-Avoidance Assist may warn the driver late or may not warn the driver depending on the road and driving conditions.
- The driver has the responsibility to control the vehicle. Do not solely depend on Rear Cross-Traffic Collision-Avoidance Assist. Rather. maintain a safe braking distance, and if necessary, depress the brake pedal to reduce driving speed or to stop the vehicle.
- Never deliberately operate Rear Cross-Traffic Collision-Avoidance Assist on people, animal, objects, etc. It may cause serious injury or death.

# **CAUTION**

The brake control may not operate properly depending on the status of ESC (Electronic Stability Control).

There will only be a warning when:

- The ESC (Electronic Stability Control) warning light is on
- ESC (Electronic Stability Control) is engaged in a different function

## Information

If braking is assisted by Rear Cross-Traffic Collision-Avoidance Assist, the driver must immediately depress the brake pedal and check vehicle surroundings.

After shifting the gear to R (Reverse), braking control will operate once for left and right vehicle approach.

## Rear Cross-Traffic Collision-Avoidance Assist Malfunction and Limitations

Rear Cross-Traffic Collision-Avoidance Assist malfunction



OJKEV072067N

When Rear Cross-Traffic Collision-Avoidance Assist is not working properly, the 'Check Blind-Spot Safety system' warning message will appear on the instrument cluster for several seconds. and the master (/\h) warning light will illuminate on the instrument cluster. If this occurs, have the vehicle inspected by an authorized retailer of Genesis Branded products.



When the side view mirror warning light is not working properly, the 'Check side view mirror warning light' warning message will appear on the instrument cluster for several seconds, and the master (小) warning light will illuminate on the instrument cluster. If this occurs, have the vehicle inspected by an authorized retailer of Genesis Branded products.

#### Rear Cross-Traffic Collision-Avoidance Assist disabled



When the rear bumper around the rearside radar or sensor is covered with foreign material, such as snow or rain, or installing a trailer or carrier, it can reduce the detecting performance and temporarily limit or disable Rear Cross-Traffic Collision-Avoidance Assist.

If this occurs, the 'Rear Cross-Traffic Collision-Avoidance Assist disabled. Radar blocked' warning message will appear on the instrument cluster.

Rear Cross-Traffic Collision-Avoidance Assist will operate properly when such foreign material or trailer, etc., is removed.

If Rear Cross-Traffic Collision-Avoidance Assist does not operate properly after it is removed, have the vehicle inspected by an authorized retailer of Genesis Branded products.



## **WARNING**

- Even though the warning message does not appear on the cluster, Rear Cross-Traffic Collision-Avoidance Assist may not operate properly.
- Rear Cross-Traffic Collision-Avoidance Assist may not operate properly in an area (for example, open terrain), where any substance are not detected after turning ON the vehicle.

# **CAUTION**

Turn off Rear Cross-Traffic Collision-Avoidance Assist to install or remove a trailer, carrier, or another attachment. Turn on Rear Cross-Traffic Collision-Avoidance Assist when finished.

#### Limitations of Rear Cross-Traffic Collision-Avoidance Assist

Rear Cross-Traffic Collision-Avoidance Assist may not operate properly, or it may operate unexpectedly under the following circumstances:

- Departing from where trees or grass are overgrown
- · Departing from where roads are wet
- Speed of the approaching vehicle is fast or slow

Braking control may not work, driver's attention is required in the following circumstances:


- The vehicle severely vibrates while driving over a bumpy road, uneven road or concrete patch
- Driving on a slippery surface due to snow, water puddle, ice, etc.
- The tire pressure is low or a tire is damaged
- · The braking system has been modified
- Remote Smart Parking Assist is operating (if equipped)



For more information on the limitations of the rear corner radar, refer to the "Blind-Spot Collision-Avoidance Assist (BCA)" section in this chapter.

# **MARNING**

Driving near a vehicle or structure




OJKEV071160

[A]: Structure

Rear Cross-Traffic Collision-Avoidance Assist may be limited when driving near a vehicle or structure, and may not detect the vehicle approaching from the left or right. If this occurs, the function may not warn the driver or control the brakes when necessary.

Always check your surroundings while backing up.

# When the vehicle is in a complex parking environment



Rear Cross-Traffic Collision-Avoidance Assist may detect vehicles which are parking or pulling out near your vehicle (for example, a vehicle leaving beside your vehicle, a vehicle parking or pulling out in the rear area, a vehicle approaching your vehicle making a turn, etc.). If this occurs, the function may unnecessarily warn the driver and control the brake.

Always check your surroundings while backing up.


# When the vehicle is parked diagonally



Rear Cross-Traffic Collision-Avoidance Assist may be limited when backing up diagonally, and may not detect the vehicle approaching from the left or right. If this occurs, the function may not warn the driver or control the brakes when necessary.

Always check your surroundings while backing up.


# When the vehicle is on or near a slope



Rear Cross-Traffic Collision-Avoidance Assist may be limited when the vehicle is on a uphill or downhill slope, or near it, and may not detect the vehicle approaching from the left or right. If this occurs, the function may not warn the driver or control the brakes when necessary.

Always check your surroundings while backing up.

#### Pulling into the parking space where there is a structure




[A]: Structure, [B]: Wall

Rear Cross-Traffic Collision-Avoidance Assist may detect vehicles passing by in front of you when parking in reverse into a parking space with a wall or structure in the rear or side area. If this occurs, the function may unnecessarily warn the driver and control the brake.

Always check your surroundings while backing up.

#### When the vehicle is parked rearward



OJKEV071165

Rear Cross-Traffic Collision-Avoidance Assist may detect vehicles passing by behind you when parking in reverse into a parking space. If this occurs, the function may unnecessarily warn the driver and control the brake.

Always check your surroundings while backing up.

# **MARNING**

- When you are towing a trailer or another vehicle, turn off Rear Cross-Traffic Collision-Avoidance Assist for safety reasons.
- Rear Cross-Traffic Collision-Avoidance Assist may not operate properly if interfered by strong electromagnetic waves.
- Rear Cross-Traffic Collision-Avoidance Assist may not operate for 3 seconds after the vehicle is started, or the rear corner radars are initialized.

# *i* Information

This device complies with Part 15 of the FCC rules. Operation is subject to the following three conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

# *i* Information

Radio frequency radiation exposure information:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 8 in. (20 cm) between the radiator (antenna) and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## FORWARD/REVERSE PARKING DISTANCE WARNING (PDW)

Forward/Reverse Parking Distance Warning can help warn the driver if an obstacle is detected within a certain distance when the vehicle is moving forward or in reverse at low speeds.

#### **Detecting sensor**





[A]: Front ultrasonic sensors [B]: Rear ultrasonic sensors

Refer to the picture above for the detailed location of the detecting sensors.

# Parking Distance Warning Settings

Warning Methods



With the vehicle on, go to **Setup > Vehicle > Driver Assistance > Warning Methods** from the Settings in the infotainment system to select the following:

• Warning Volume: The Warning Volume can be adjusted.



## Information

- If you change the Warning Methods, Warning Methods of other Driver Assistance systems may change.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- There may be no Settings menu depending on the feature applied to your vehicle.
- Even though 0 is selected for Warning Volume, Warning Volume will not be turned off but Warning Volume will sound as 1.

#### Parking Distance Warning Auto On

To use Parking Distance Warning Auto On function, select Setup > Vehicle > Driver Assistance > Parking Safety > Parking Distance Warning Auto On from the infotainment system Settings menu.



### Information

When Parking Distance Warning Auto On is selected, the Parking Safety button indicator ( $P_{N_{\underline{A}}}$ ) stays on.



#### **CAUTION**

When a trailer is connected to the tow hitch harness installed to your vehicle, Reverse Parking Distance Warning automatically turns off (if equipped). In this case, Reverse Parking Distance Warning is not functional. Always have your eyes on the road.

# Parking Distance Warning Operation

Parking Safety button



Press the Parking Safety (P™) button to turn on Forward/Reverse Parking Distance Warning. Press the button again to turn off the function.

- When the gear is shift to R (Reverse), Parking Distance Warning will automatically turn on (Parking Safety button indicator on).
- When the gear is in R (Reverse), Parking Distance Warning does not turn off even if the Parking Safety button is pressed.

#### Forward Parking Distance Warning

Forward Parking Distance Warning will operate under the following conditions.

- The gear is shifted from R (Reverse) to D (Drive) with Reverse Parking Distance Warning on
- The gear is in D (Drive) and the Parking Safety (Pm▲) button indicator light is on
- Parking Distance Warning Auto On is selected from the Settings menu and the gear is in D (Drive)



## Information

- Forward Parking Distance Warning operates when the vehicle's speed is below 6 mph (10 km/h).
- Forward Parking Distance Warning is deactivated if the vehicle speed reaches above 18 mph (30 km/h). It will not reactivate although the vehicle speed drops below 6 mph (10 km/h). (Only when Parking Warning Auto On is not selected)

Distance from Object	Warning Indicator when Driving Forward	Warning Sound
24-40 in. (60-100 cm)	Š	Buzzer beeps intermittently
12-24 in. (30-60 cm)	Î	Beeps more frequently
within 12 in. (30 cm)	8	Beeps continuously

- The corresponding indicator will illuminate whenever each ultrasonic sensor detects a person, animal or object in its sensing range. Also an audible warning will sound.
- When more than two objects are detected at the same time, the closest one will be warned with an audible warning.
- The shape of the indicator in the illustration may differ from the actual vehicle.

#### Reverse Parking Distance Warning

Reverse Parking Distance Warning will operate under the following conditions.

• The gear is shifted to R (Reverse).

# *i* Information

Reverse Parking Distance Warning operates when the vehicle's speed is below 6 mph (10 km/h).

Distance from Object	Warning Indicator when Driving Backward	Warning Sound
24-48 in. (60-120 cm)		Buzzer beeps intermittently
12-24 in. (30-60 cm)		Beeps more frequently
within 12 in. (30 cm)		Beeps continuously

- The corresponding indicator will illuminate whenever each ultrasonic sensor detects a person, animal or object in its sensing range. Also an audible warning will sound.
- When more than two objects are detected at the same time, the closest one will be warned with an audible warning.
- The shape of the indicator in the illustration may differ from the actual vehicle.

# Parking Distance Warning Malfunction and Limitations

Parking Distance Warning malfunction

After starting the vehicle, a beep will sound when the gear is shifted to R (Reverse) to indicate Parking Distance Warning is operating properly.

However, if one or more of the following occurs, first check whether the ultrasonic sensor is damaged or blocked with foreign material. If it still does not work properly, have the vehicle inspected by an authorized retailer of Genesis Branded products.

- The audible warning does not sound.
- · The buzzer sounds intermittently.
- The 'Ultrasonic sensor error or blockage' warning message appears on the instrument cluster.



OJKEV072189L

## Parking Distance Warning disabled



OJWEV071233L

If this occurs the 'Parking Distance Warning system limited. Ultrasonic sensor blocked' warning message appears on the instrument cluster. Parking Distance Warning will operate properly when snow, rain or foreign material is removed. If Parking Distance Warning does not operate properly after obstruction (snow, rain, or foreign material) is removed (including trailer, carrier, etc., from the rear bumper), have the vehicle inspected by an authorized retailer of Genesis Branded products.

#### Limitations of Parking Distance Warning

- Parking Distance Warning may not operate properly when:
  - There is excessive moisture or frost on the sensor
  - Sensor is covered with foreign substance, such as snow or water (Parking Distance Warning will operate properly when such substance is removed.)
  - The weather is extremely hot or cold
  - The sensor or sensor assembly is disassembled
  - The surface of the sensor is pressed hard or hit with a hard object
  - The surface of the sensor is scratched with a sharp object
  - The sensors or its surrounding area is directly sprayed with high pressure washer
- Parking Distance Warning may malfunction when:
  - Heavy rain or water spray is present
  - Water flows on the surface of the sensor
  - Affected by another vehicle's sensors
  - The sensor is covered with snow or ice
  - Driving on uneven road, gravel roads or bushes
  - Objects that generate ultrasonic waves are near the sensor
  - License plate is installed in a different spot from the original location
  - The vehicle bumper height or ultrasonic sensor installation has been modified
  - Attaching equipment or accessories next to the ultrasonic sensors

- The following objects may not be detected:
  - Sharp or slim objects, such as ropes, chains or small poles.
  - Narrow objects, such as corners of a square column
  - Objects, which tend to absorb sensor frequency, such as clothes, spongy material or snow.
  - Objects smaller than 40 inches (100 cm) in length and narrower than 6 inches (14 cm) in diameter.
  - Pedestrians, animals or objects that are very close to the ultrasonic sensors

## **MARNING**

- Parking Distance Warning is a supplemental function. The operation of Parking Distance Warning can be affected by several factors (including environmental conditions). It is the responsibility of the driver to always check the front and rear views before and while parking.
- Your new vehicle warranty does not cover any accidents or damage to the vehicle due to the malfunction of Parking Distance Warning.
- Pay close attention when driving near objects, pedestrians, and especially children. Some objects may not be detected by the ultrasonic sensors, due to the objects distance, size or material, all of which can limit the effectiveness of the sensor.
- Parking Distance Warning does not warn you in the order of detection. It varies depending on the speed of the vehicle or the shape of a person, animal, or object.
- If the Parking Distance Warning does not operate properly, have the vehicle inspected by an authorized retailer of Genesis Branded products.

# REVERSE PARKING COLLISION-AVOIDANCE ASSIST (PCA) (IF EQUIPPED)

Reverse Parking Collision-Avoidance Assist can warn the driver or assist with braking to help reduce the possibility of collision with a detected pedestrian or an object while driving at low speed.

#### **Detecting sensor**





[A]: Wide-rear view camera [B]: Rear ultrasonic sensor

Refer to the picture above for the detailed location of the detecting sensors.

## Parking Collision-Avoidance Assist Settings

**Parking Safety** 

With the vehicle on, select or deselect Setup > Vehicle > Driver Assistance > Parking Safety from the Settings menu to set whether to use each function.

- If Rear Active Assist is selected, Reverse Parking Collision-Avoidance Assist will warn the driver and assist with braking when a collision with a detected pedestrian or an object is imminent.
- If Rear Warning Only is selected, Reverse Parking Collision-Avoidance Assist will warn the driver when a collision with a detected pedestrian or an object is imminent. Braking will not be assisted.
- If Off is selected, Reverse Parking Collision-Avoidance Assist will turn off.

### Turning Parking Collision Avoidance Assist On/Off



Press and hold the Parking Safety ( $P^m_{\underline{A}}$ ) button more than 2 seconds, to turn the Parking Collision-Avoidance Assist on or off.

# **i** Information

When a trailer is connected to the tow hitch harness installed to your vehicle, Parking Collision-Avoidance Assist automatically turns off (if equipped). In this case, Parking Collision-Avoidance Assist is not functional. Always have your eyes on the road.

## Warning Methods



OJKEV072313N



With the vehicle on, go to Setup > Vehicle > Driver Assistance > Warning Methods from the Settings in the infotainment system to select the following:

- Warning Volume: The Warning Volume can be adjusted.
- Haptic Warning: The steering wheel vibration can be set (type A) or adjusted (type B).

# *i* Information

- If you change the Warning Methods, Warning Methods of other Driver Assistance systems may change.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- There may be no Settings menu depending on the feature applied to your vehicle.
- Even though 0 is selected for Warning Volume, Warning Volume will not be turned off but Warning Volume will sound as 1.
- When Haptic Warning is selected as 0 or deselected while Warning Volume is selected as 0, Warning Volume will activate and be selected as 2.
- When Warning Volume is selected as 0 while Haptic Warning is selected as 0 or deselected, steering wheel vibration will activate or be selected as 2.

## Reverse Parking Collision-Avoidance Assist Operation

Operating conditions

If Rear Active Assist or Rear Warning Only is set from the Settings menu, Reverse Parking Collision-Avoidance Assist will be in the ready status when the following conditions are satisfied:

- The liftgate is closed
- The gear is shifted to R (Reverse)
- Vehicle speed is below 6 mph (10 km/h)
- Reverse Parking Collision-Avoidance Assist components such as the rear view camera and the rear ultrasonic sensors are in normal conditions.

When Reverse Parking Collision Avoidance Assist activates, a line appears behind the vehicle image in the instrument cluster. Reverse Parking Collision-Avoidance Assist operates only once after the gear is shifted to R (Reverse). To reactivate Reverse Parking Collision-Avoidance Assist, shift the gear from another gear to R (Reverse).



OJKEV071068

#### Rear Active Assist

- If Reverse Parking Collision-Avoidance
   Assist detects a risk of collision with
   a pedestrian or an object, Reverse
   Parking Collision-Avoidance Assist
   will warn the driver with an audible
   warning and warning message on the
   cluster. When Rear View Monitor is
   operating, a warning will appear on
   the infotainment system screen.
- If Reverse Parking Collision-Avoidance
   Assist detects an imminent collision
   with a pedestrian or an object behind
   the vehicle, Reverse Parking Collision
   Avoidance Assist will assist you with
   braking. The driver needs to pay
   attention and apply the brakes as the
   brake assist will last for 5 minutes.
   The driver must immediately depress
   the brake pedal and check vehicle
   surroundings.
- · Brake control will end when:
  - The gear is shifted to P (Park) or D (Drive).
  - The driver depresses the brake pedal with sufficient power
  - Braking assist has lasted for about 5 minutes



Braking control is released after 5 minutes from the initial braking, and Electronic Parking Brake (EPB) is engaged immediately.

## **Reverse Parking Collision-Avoidance Assist Malfunction** and Limitations

Reverse Parking Collision-Avoidance Assist malfunction



OJKEV072254L

When Reverse Parking Collision-Avoidance Assist or other related functions are not working properly, the 'Check Parking Safety system' warning message will appear on the cluster, and Reverse Parking Collision-Avoidance Assist will turn off automatically. Have the vehicle inspected by an authorized retailer of Genesis Branded products.

#### Reverse Parking Collision-Avoidance Assist disabled

**Detecting sensors** 



[A]: Wide-rear view camera

The wide-rear view cameras are used as detecting sensors to detect pedestrians. If the camera lens is covered with foreign material, such as snow or rain, it may adversely affect camera performance and Parking Collision-Avoidance Assist may not operate properly. Always keep the camera lens clean.



[B]: Rear ultrasonic sensor

The ultrasonic sensors detect objects around the vehicle. If the sensors are covered with foreign material, such as snow or rain, it may adversely affect sensor performance and Parking Collision-Avoidance Assist may not operate properly. Always keep the bumper clean.





OJKEV072256L

#### Warning message

The 'Camera error or blockage' or 'Ultrasonic sensor error or blockage' warning message will appear on the cluster if the following situations occur:

- The camera(s) or ultrasonic sensor(s) is covered with foreign material, such as snow or rain, etc.
- There is inclement weather, such as heavy snow, heavy rain, etc.

If this occurs, Parking Collision-Avoidance Assist may turn off or may not operate properly. Check whether the cameras and ultrasonic sensors are clean

#### Limitations of Reverse Parking Collision-Avoidance Assist

Reverse Parking Collision-Avoidance Assist may not assist braking or warn the driver even if there are pedestrians or objects under the following circumstances:

- Problems with vehicle
  - Any non-factory equipment or accessory is installed
  - Your vehicle is unstable due to an accident or other causes.
  - Bumper height or rear ultrasonic sensor installation has been modified
  - Wide-rear view camera(s) or ultrasonic sensor(s) is damaged
  - Wide-rear view camera(s) or the ultrasonic sensor(s) is stained with foreign material, such as snow, dirt, etc.
  - Wide-rear view camera(s) is obscured by a light source or by inclement weather, such as heavy rain, fog, snow, etc.
- Problems with the surroundings
  - The surrounding is very bright or very dark
  - Outside temperature is very high or very low
  - The wind is either strong (above 12 mph (20 km/h)) or blowing perpendicular to the bumper
  - Objects generating excessive noise, such as vehicle horns, loud motorcycle engines or truck air brakes, are near your vehicle
  - An ultrasonic sensor with similar frequency is near your vehicle
  - The road is slippery or inclined
  - The image of the pedestrian in the front view camera is indistinguishable from the background

- Problems with pedestrian or object
  - The pedestrians are difficult to detect
  - There is ground height difference between the vehicle and the pedestrian
  - The pedestrian is near the edge of the vehicle
  - The pedestrian is not standing upright
  - The pedestrian is either very short or very tall to detect
  - The pedestrian is wearing clothing that easily blends into the background, making it difficult to detect
  - The pedestrian is wearing clothing that does not reflect ultrasonic waves well
  - Size, thickness, height, or shape of the object does not reflect ultrasonic waves well (for example, low object, narrow object, circular pillar, small pillar, corners of a square pillar, bush, curbs, carts, edge of a wall, etc.)
  - The pedestrian or the object is moving
  - The pedestrian or the object is very close to the vehicle
  - There is a large object such as a wall is behind the pedestrian or the object
  - The object is not located at the front or rear center of your vehicle
  - The object is not parallel to the rear bumper
  - The sensors cannot detect the pedestrians and objects

- · Problems with driving condition
  - The driver drives the vehicle immediately after shifting to R (Reverse) or D (Drive)
  - The driver accelerates or circles the vehicle

Reverse Parking Collision-Avoidance Assist may unnecessarily warn the driver or assist with braking even if there are no pedestrians or objects under the following circumstances:

- · Problems with vehicle
  - Any non-factory equipment or accessory is installed
  - Your vehicle is unstable due to an accident or other causes
  - Bumper height or rear ultrasonic sensor installation has been modified
  - Your vehicle height is low or high due to heavy loads, abnormal tire pressure, etc.
  - Wide-rear view camera(s) or the rear ultrasonic sensor(s) is stained with foreign material, such as snow, dirt, etc.

- Problems with the surroundings
  - The pattern on the road is mistaken for a pedestrian
  - There is shadow or light reflecting on the ground
  - Pedestrians or objects are around the path of the vehicle
  - Objects generating excessive noise, such as vehicle horns, loud motorcycle vehicles or truck air brakes, are near your vehicle
  - Your vehicle is backing towards a narrow passage or parking space
  - Your vehicle is backing towards an uneven road surface, such as an unpaved road, gravel, bump, gradient, etc.
  - A trailer or carrier is installed on the rear of your vehicle
  - An ultrasonic sensor with similar frequency is near your vehicle
- · Problems with pedestrian or object
  - The pedestrian or the object is moving
- Problems with driving condition
  - The driver accelerates or circles the vehicle
  - The vehicle moves forward and backward repeatedly

### **MARNING**

Take the following precautions when using Parking Collision-Avoidance Assist:

- Always exercise extreme caution while driving. The driver is responsible for braking and safe driving.
- Always pay attention to road and traffic conditions while driving, whether or not there is a warning.
- Always look around your vehicle to make sure there are no pedestrians or objects before moving the vehicle.
- The performance of Reverse Parking Collision-Avoidance Assist may vary under certain conditions. If vehicle speed is above 2 mph (4 km/h), Parking Collision-Avoidance Assist will provide collision avoidance assist only when pedestrians are detected. Always look around and pay attention when driving your vehicle.
- Reverse Parking Collision-Avoidance
   Assist may operate differently under
   certain conditions. If the vehicle
   moves forward and backward
   repeatedly, the Collision-Avoidance
   Assist may fail to assist braking or to
   warn the driver. Always pay attention
   when driving your vehicle.
- Some objects may not be detected by the ultrasonic sensors due to the objects distance, size, shape or material, all of which can limit the effectiveness of the sensor.
- Reverse Parking Collision-Avoidance
   Assist may not operate properly or
   may operate unnecessarily depending
   on the road conditions and the
   surroundings.
- Do not solely rely on Parking Collision-Avoidance Assist. Doing so may lead to vehicle damage or injuries.

#### ! CAUTION

- Noise may be heard when sudden braking occurs to avoid a collision.
- If any other warning sound such as the seat belt warning chime is already generated, Parking Collision-Avoidance Assist warning may not
- Parking Collision-Avoidance Assist may not work properly if the bumper has been damaged, replaced or repaired.
- Parking Collision-Avoidance Assist may not operate properly if interfered by strong electromagnetic waves.
- Playing the vehicle audio system at high volume may prevent passengers from hearing Parking Collision-Avoidance Assist warning sounds.
- Turn off Parking Collision-Avoidance Assist when towing a trailer. If towing and moving in reverse, Parking Collision-Avoidance Assist will activate as it detects the trailer.
- The brake control may not operate properly depending on the status of ESC (Electronic Stability Control).

There will only be a warning when:

- The ESC (Electronic Stability Control) warning light is on
- ESC (Electronic Stability Control) is engaged in a different function



#### **CAUTION**

Take the following precautions to maintain optimal performance of the detecting sensors:

- Always keep the wide-rear view cameras and ultrasonic sensors clean.
- Do not use any cleanser containing acid or alkaline detergents when cleaning the camera lens. Use only a mild soap or neutral detergent, and rinse thoroughly with water.
- · Do not spray the wide-rear view cameras or the rear ultrasonic sensors or their surrounding area directly with a high pressure washer. It may cause the wide angle cameras or the ultrasonic sensors to malfunction.
- Do not apply objects, such as a bumper sticker or a bumper guard, near the wide angle cameras or ultrasonic sensors or apply paint to the bumper. Doing so may adversely affect the performance of Parking Collision-Avoidance Assist.
- Never disassemble or apply impact on the wide angle cameras or the ultrasonic sensors components.
- Do not apply unnecessary force on the wide-rear view cameras or the ultrasonic sensors. Reverse Parking Collision-Avoidance Assist may not operate properly if the wide angle cameras or the ultrasonic sensor(s) is forcibly moved out of proper alignment. Have the vehicle inspected by an authorized retailer of Genesis Branded products.



#### Information

Reverse Parking Collision-Avoidance Assist can detect a pedestrian or an object when:

- A pedestrian is standing behind the vehicle
- A large obstacle, such as a vehicle is parked in the rear center of your vehicle

#### REMOTE SMART PARKING ASSIST (RSPA) (IF EQUIPPED)

Remote Smart Parking Assist uses vehicle sensors to help the driver park and exit parking spaces remotely from outside the vehicle by controlling the steering wheel, vehicle speed, and gearshifts.

gearsiiits.	
Function	Description
Remote Operation	Remotely moving forward or backward
	OJKEV071169
	Perpendicular reverse parking
Smart Parking or Remote Smart Parking	0 0 0 OJKEV071170
	Parallel reverse parking
	OJKEV071171
Smart Exit	Parallel forward exit
	O IVENOTATO

- Remote Smart Parking and Remote Operation function may be operated from outside the vehicle using the smart key.
- Smart Parking and Remote Smart Parking function may be operated from inside the vehicle.
- Smart Parking and Remote Smart Parking function helps the driver with perpendicular reverse parking, diagonal reverse parking and parallel reverse parking.
- Smart Exit function helps the driver with parallel forward exit.
- When Remote Smart Parking Assist operates, Parking Distance Warning and Surround View Monitor will also operate. For more information, refer to the "Parking Distance Warning (PDW)" and "Surround View Monitor (SVM)" sections in this chapter.



O IKEV071172

### **CAUTION**

When a trailer is connected to the tow hitch harness installed to your vehicle, Remote Smart Parking Assist automatically turns off (if equipped). In this case, Remote Smart Parking Assist is not functional. Always have your eyes on the road.

### **Detecting Sensors**

Ultrasonic sensors





- [A]: Front ultrasonic sensors,
- [B]: Front corner ultrasonic sensors,
- [C]: Rear corner ultrasonic sensors,
- [D]: Rear ultrasonic sensors

Refer to the picture above for the detailed location of the detecting sensors.

### ! CAUTION

Take the following precautions to maintain optimal performance of the detecting sensors:

- Never disassemble the detecting sensor or sensor assembly, or cause any damage to it.
- If the detecting sensors need repair, have your vehicle inspected by an authorized retailer of Genesis Branded products.
- Remote Smart Parking Assist may malfunction if the vehicle bumper height or ultrasonic sensor installation has been modified or damaged. Any non-factory installed equipment or accessories may also interfere with the sensor performance.
- When the ultrasonic sensor is frozen or stained with snow, dirt, or water, the sensor may be not operate until the stains are removed using a soft cloth.
- · Do not push, scratch, or strike the ultrasonic sensor. Sensor damage could occur.
- Do not spray the ultrasonic sensors or its surrounding area directly with a high pressure washer.

## Remote Smart Parking Assist Settings

Settings features



OJKEV072320N

#### **Warning Methods**

With the vehicle on, go to **Setup > Vehicle > Driver Assistance > Warning Methods** from the Settings in the infotainment system to select the following:

• Warning Volume: The Warning Volume can be adjusted.

### *i* Information

- If you change the Warning Methods, Warning Methods of other Driver Assistance systems may change.
- If the vehicle is restarted, Warning Methods will maintain the last setting.
- There may be no Settings menu depending on the feature applied to your vehicle.
- Even though 0 is selected for Warning Volume, Warning Volume will not be turned off but Warning Volume will sound as 1.

# Remote Smart Parking Assist Operation Remote Smart Parking Assist button

Parking/Vio Parking Saf		Smart Key	Digital Key
OJKEV071153	OJKEV071168	OJKEV071193	OJKEV072324N

Location	Name	Symbol	Description
Inside vehicle	Parking/View button	ŢP	Press and hold the Parking/View button to turn on Remote Smart Parking Assist. Also, Forward/Reverse Parking Distance warning will automatically turn on. However, functions may differ depending on the situations. Refer to the each function's description for more information in the following pages.
			<ul> <li>Press and hold the Parking/View button while Smart Parking or Smart Exit function is on to operate the function.</li> </ul>
	Parking Safety button	P∥ <u></u>	<ul> <li>Press the Parking Safety button while Remote Smart Parking Assist is operating to end Remote Smart Parking Assist operation.</li> </ul>
Smart key Forw butt	Remote Start	emote Start	Press the Remote Start button after the door is locked with the vehicle off to start the vehicle remotely.
	button	HOLD	<ul> <li>Press the Remote Start button while Remote Smart Parking or Remote Operation function is operating to end function operation.</li> </ul>
	Forward button	<b>₽</b>	When using Remote Smart Parking function, regardless of which direction button is pressed, parking is supported while the button is pressed.
	Backward button	<b>₽</b> P	When using the Remote Operation function, the vehicle moves in the direction of the button while the button is pressed.
	Damata		Press the Remote Smart Parking Assist icon on the smartphone digital key application to activate Remote Smart Parking.
Digital key	Remote Smart Parking Assist icon		When using the Remote Operation function, the vehicle moves in the direction of the icon is pushed and moves while the icon is pushed.
			When using Remote Smart Parking function, regardless of which direction the icon is pushed, parking is supported while the icon is pushed.

#### Remote Operation

Operating order

Remote Operation functions in the following order:

- Getting ready to remotely move forward and backward
- 2. Remotely moving forward and backward

### Getting ready to remotely move forward and backward

There are two ways to operate Remote Operation function.



Method (1) Using the function with vehicle off

- (1) Within a certain range from the vehicle press the door lock (1) button on the smart key and lock all doors.
- (2) Press and hold the Remote Start button ( ) within 4 seconds until the vehicle starts.

For more information on remotely starting the vehicle, refer to the "Remote Start" section in chapter 6.





OJKEV072217L

Method (2) Using the function with vehicle on

- Park the vehicle in front of the space where you want to use Remote Operation function, and shift the gear to P (Park).
- (2) Press and hold the Parking/View (P) button to turn on Smart Parking Assist. A message 'Remote Parking Instructions' will appear on the infotainment system screen.
- (3) Get out of the vehicle with the smart key and close all doors.

- 'Agree' must be selected on the infotainment system screen and the infotainment system has to operate properly to use Remote Operation function.
- Method (2) can be used after the vehicle has been driven above 3 mph (5 km/h).
- If the function is turned on again after parking is completed by Remote Smart Parking Assist, Remote Operation function can be used with Method (2).
- Check that all smart keys are outside the vehicle when using Remote Operation function.

### 2. Remotely moving forward and backward



(1) Press and hold one of the Forward (()) or Backward (()) button on the smart key. Remote Smart Parking Assist will automatically control the steering wheel, vehicle speed and gearshift. The vehicle will move in the direction of the button pressed.

- (2) While Remote Operation function is operating, if you do not hold down the Forward (骨) or Backward (骨) button, the vehicle will stop and function control will pause. The function will start operating again when the button is pressed and held again.
- (3) When the vehicle reaches the target location, release the smart key Forward or Backward button.
- (4) When the driver gets in the vehicle with the smart key, a message will appear informing the driver Remote Operation function is complete on the infotainment system screen and the vehicle will remain on.

In addition, when the Remote Start (\(\infty\)) button is pressed on the smart key from outside the vehicle, a message will appear informing the driver Remote Operation function is complete and the vehicle will turn off.

### *i* Information

- Check that all smart keys are outside the vehicle when using Remote Operation function.
- Remote Operation function will operate only when the smart key is within 13 feet (4 m) from the vehicle. If there is no vehicle movement even when the Forward or Backward button is pressed on the smart key, check the distance to the vehicle and press the button again.
- The detecting range of the smart key may vary depending on the surroundings that are affected by radio waves such as transmission tower, broadcast station, etc.
- When remotely moving forward using method (1), it is recognized as an exit situation, and the vehicle moves 13 feet (4 m) to check for parking lines, pedestrians, animals or objects around the vehicle. After confirmation, the steering wheel is controlled according to the condition ahead.
- When remotely moving forward using method (2), it is recognized as a parking situation, and will immediately control the steering wheel according to the condition ahead to assist with entering the parking space and aligning the vehicle. However, performance may reduce depending on the parking lines pedestrians, animals, shape of objects, location, etc., around the vehicle.
- For moving remotely backward, both method (1) and (2) aligns the steering wheel first, and then will only move the vehicle straight.
- When remotely moving forward or backward is completed, the vehicle will automatically shift to P (Park) and engage EPB (Electronic Parking Brake).

### **A** CAUTION

- When using Remote Operation function, make sure that all passengers have gotten out of the vehicle.
- If the vehicle's battery is discharged or Remote Smart Parking Assist malfunctions when parked in a narrow parking space, Remote Operation function will not operate. Always park your vehicle in a space wide enough for you to get in or out of your vehicle.
- Depending on the parking space, you may not be able to exit from the space you have entered by using Remote Operation function.
- After parking, the surrounding may change due to the movement of surrounding vehicles. If this occurs, Remote Operation function may not operate.
- Before leaving the vehicle, close windows and sunroofs, and make sure the vehicle is off before locking the doors.

### Remote Operation function operation status

Operation Status	Smart Key LED	Hazard Warning Light
Under control	Green LED continuously blinks	-
Pause	Red LED continuously blinks	Blinks
Off	Red LED illuminates for 4 seconds and then turns off	Blinks 3 times and turns off
Complete	Green LED illuminates for 4 seconds and then turns off	Blinks 1 time and turns off

- \* Operation status by the hazard warning light may not be applicable based on the regulation of your state.
- \* If the smart key is not within the operating range from the vehicle (about 13 feet (4 m)), the smart key LED will not illuminate or blink. Use the smart key within the operating range.

### How to turn off Remote Operation function while operating

- Press the Parking/View (戶) button while the infotainment system screen guides the driver using method 2.
- Shift the gear from P (Park) to any other position while the infotainment system screen guides the driver using method 2.
- Press the Parking Safety (Pm) button or select 'Cancel' on the infotainment system screen.
- Press the Remote Start ( ) button
   on the smart key while the vehicle is
   being controlled by Remote Operation
   function. Remote Operation function
   will turn off. At this time, the vehicle
   will turn off.
- Get on the vehicle with the smart key. Remote Operation function will turn off. At this time, the vehicle will remain on.

The function will pause in the following conditions when:

- There is a pedestrian, animal or object in the direction the vehicle is moving
- The door or liftgate is open
- The Forward ( ) or Backward ( ) button is not continuously pressed
- Simultaneously pressing multiple buttons on a smart key
- The smart key is not operated within 13 feet (4 m) from the vehicle
- Button of another smart key is pressed in addition to the operating smart key
- Blind-Spot Collision-Avoidance
   Assist or Rear Cross-Traffic Collision Avoidance Assist operates while the
   vehicle is being controlled in the
   reverse direction.
- The vehicle moves 22 feet (7 m) while the smart key is pressed with Remote Operation function (maximum travel distance per button press)

When Remote operation function is paused, the vehicle will stop. If the condition that made the function to pause disappears, the function may operate again.

The function will cancel in the following conditions when:

- The steering wheel is steered
- The gear is shifted while the vehicle is moving
- Operating EPB while the vehicle is moving
- The hood is open
- The brake pedal or accelerator pedal is depressed when all the doors are closed
- The smart key is outside the vehicle when the brake pedal is depressed while the driver's door is open
- · Rapid acceleration occurs
- · Vehicle skid occurs
- The wheel is stuck by an obstacle and cannot move
- About 3 minutes and 50 seconds have past after Remote Operation function has started to operate
- The slope of the road exceeds the operational range
- The function is paused for more than 1 minute
- The total travel distance of the vehicle has exceeded 45 feet (14 m) after Remote Operation function operation
- The steering wheel, gearshift, braking, and drive controls are not working properly
- There is a problem with the smart key or the smart key battery is low
- ABS, TCS or ESC system operates due to slippery road conditions
- The alarm of the Theft Alarm System sounds
- The charging door is open

When Remote Operation function is canceled, the vehicle will automatically stop, shift the gear to P (Park) and engage EPB (Electronic Parking Brake).

The vehicle will turn off.

#### Smart Parking, Remote Smart Parking

#### Operating order

Parking function operates in the following order:

- 1. Getting ready for parking
- 2. Searching for parking space
- 3. Select parking type and operating mode
- 4. Smart Parking
- 5. Remote Smart Parking

#### 1. Getting ready for parking



- (1) With the vehicle turned on, depress the brake pedal and shift the gear to D (Drive) or N (Neutral).
- (2) Press and hold the Parking/View (児戸) button to turn on Remote Smart Parking Assist.

### *î* Information

- Agree must be selected on the infotainment system screen and the infotainment system has to operate properly to use Parking function.
- If you drive above 3 mph (5 km/h)
  With the vehicle on, you may use the
  Parking function with the gear shifted
  to N (Neutral).

#### 2. Searching for parking space




OJKEV072218L

- Slowly drive forward maintaining the distance of about 40 inches (100 cm) from the parking lines or the parked vehicles.
- (2) When searching for a parking space is complete, a message will appear on the infotainment system screen with an audible sound to notify the search is complete.
- (3) Select Parking Type will be displayed on the infotainment system screen and the selected parking space will appear on Top View screen of Surround View Monitor.

### *i* Information

- Remote Smart Parking Assist searches parking lines or parking spaces that are next to parked vehicles. Remote Smart Parking Assist cannot search parking spaces in front or rear of the vehicle.
- While searching for a parking space, when vehicle speed is above 12 mph (20 km/h), a message will appear on the infotainment system screen informing you to slow down. When vehicle speed is above 18 mph (30 km/h), Parking function will turn off.
- Searching for a parking space will be completed when there is enough space to move the vehicle in addition to the parking space.
- Even if an audible sound is heard to notify that searching for a parking space is complete, search completion can be canceled immediately depending on surroundings.

### *i* Information



- If the distance is below 20 inches (50 cm) or over 59 inches (150 cm), Remote Smart Parking Assist may not be able to search for a parking space.
- If you do not maintain a certain distance from the parked vehicle, the performance to search for a parking space may reduce.
- Due to abnormal performance of the ultrasonic sensor or the influence of the surroundings, Parking function may not be able to search for a parking space even if there is a parking space, or may search for a space that is not suitable for parking.
- If the parking space is on a incline or is diagonal, the parking type displayed may be different from the actual parking type which should be selected. If this occurs, do not select the parking type, and search for another parking space.

#### 3. Select parking type and operating mode



OJKEV072219L

 Parking type – Perpendicular reverse (Left/Right), Parallel reverse (Left/Right)
 With the vehicle stopped by depressing the brake pedal, touch the infotainment system screen or use the central controller to select the desired parking type.

### *i* Information

- If you continue to drive without stopping after the parking type selection screen appears, Remote Smart Parking Assist will return to the previous stage and search for a parking space.
- If Parking function is canceled unintentionally by pressing the Parking/View (戶) button before the parking type is selected, you can return to the parking type selection stage by pressing and holding the button again while the vehicle is stopped.



Before selecting the Parking type, the driver should check whether the parking space is suitable.

If the searched parking space by Remote Smart Parking Assist is narrow or unsuitable for parking, do not select the Parking type and move the vehicle to search for another parking space.



OJKEV072220L

(2) Operating mode – Remote Parking, Smart Parking After selecting a parking type, the infotainment system screen will guide you with Remote Smart Parking function and Smart Parking function. Follow the instructions to operate Remote Smart Parking Assist.



#### Information

- Operating instructions will be displayed on the screen for each desired function you select.
- Do not take your foot off the brake pedal during the Parking function guide. When the vehicle moves, Remote Smart Parking Assist will turn off.

### *i* Information



OJKEV072221L

If Remote Smart Parking Assist cannot activate Remote Smart Parking function, only the Smart Parking guide will be displayed on the infotainment system screen.

#### 4. Smart Parking



- (1) Press the Parking/View
  (() P) button when the vehicle is stopped by depressing the brake pedal. When the brake pedal is released, Remote Smart Parking Assist will automatically control the steering wheel, vehicle speed and gearshift.
- (2) While Smart Parking function is operating, if you do not hold down the Parking/View button, the vehicle will stop and function control will pause. The function will start operating again when the Parking/View button is pressed and held again.
- (3) When the vehicle reaches the target parking position, a message will appear on the infotainment system screen to inform you that parking is complete.
- (4) If you need to change the vehicle's position or location, manually complete parking your vehicle.

### *i* Information

- Smart Parking function will not operate if the door is open or the seat belt is not fastened.
- The parking location indicator is displayed on Surround View Monitor screen and is displayed until the vehicle enters the parking space for the first time by Smart Parking function.
- Vehicle speed can be adjusted by depressing the brake pedal while Smart Parking function is operating. However, the vehicle does not accelerate even when the accelerator pedal is depressed.
- Depending on parking environments, if the vehicle is stopped by a stopper, parking may be completed.
- If you need to change the vehicle's position or location, manually complete parking your vehicle.

#### 5. Remote Smart Parking



OJKEV072222L

- Shift the gear to P (Park), get out of the vehicle with the smart key, and close all doors.
- (2) Press and hold one of the Forward (合) or Backward (合) button on the smart key. Remote Smart Parking Assist will automatically control the steering wheel, vehicle speed and gearshift.
- (3) While Remote Smart Parking function is operating, if you do not hold down the Forward (合物) or Backward (合物) button, the vehicle will stop and function control will pause. The function will start operating again when the button is pressed and held again.
- (4) When the vehicle reaches the target parking position, a message will appear on the infotainment system screen to inform you that parking is complete. The vehicle will automatically shift to P (Park), engage EPB (Electronic Parking Brake) and the vehicle will turn off.
- (5) If you need to change the vehicle's position or location, manually complete parking your vehicle.

### i

#### Information

- When operating Remote Smart Parking function, make sure all smart keys are outside of the vehicle.
- Remote Smart Parking function will operate only when the smart key is within 13 feet (4 m) from the vehicle. If there is no vehicle movement even when the Remote Forward or Backward button is pressed on the smart key, check the distance to the vehicle and press the button again.
- The detecting range of the smart key may vary depending on the surroundings that are affected by radio waves such as transmission tower, broadcast station, etc.
- The parking location indicator is displayed on Surround View Monitor screen and is displayed until the vehicle enters the parking space for the first time by Remote Smart Parking function.
- Depending on parking environments, if the vehicle is stopped by a stopper, parking may be completed.
- If you need to change the vehicle's position or location, manually complete parking your vehicle.



#### **!** CAUTION

- When using Remote Smart Parking function, make sure that all passengers have gotten out of the vehicle.
- After ending or turning off Remote Smart Parking function, before leaving the vehicle, close windows and sunroofs, and make sure the vehicle is off before locking the doors.

#### Parking function operation status

· Smart Parking function

Operation Status	Turn Signal
Under control	The turn signal of the parking direction blinks until the first reverse is complete.

• Remote Smart Parking function

Operation Status	Smart Key LED	Hazard Warning Light	Turn Signal
Under control	Green LED continuously blinks	-	The turn signal of the parking direction blinks until the first reverse is complete.
Pause	Red LED continuously blinks	Blinks	-
Off	Red LED illuminates for 4 seconds and then turns off	Blinks 3 times and turns off	-
Complete	Green LED illuminates for 4 seconds and then turns off	Blinks 1 time and turns off	-

<sup>\*</sup> Operation status by the hazard warning light and turn signal may not be available based on the regulation of your state.

<sup>\*</sup> If the smart key is not within the operating range from the vehicle (about 13 feet (4 m)), the smart key LED will not illuminate or blink. Use the smart key within the operating range.

## The function will pause in the following conditions when:

- · Smart Parking
  - There is a pedestrian, animal or object in the direction the vehicle is moving
  - The door or liftgate is open
  - The driver's seat belt is not fastened
  - Blind-Spot Collision-Avoidance Assist or Rear-Cross Traffic Collision-Avoidance Assist operates while the vehicle is being controlled in the reverse direction
  - The Parking/View (P) button is not continuously pressed
  - The vehicle is stopped by depressing the brake pedal
- Remote Smart Parking
  - There is a pedestrian, animal or object in the direction the vehicle is moving
  - The door or liftgate is open
  - The Forward (p) or Backward (p) button is not continuously pressed
  - Simultaneously pressing multiple buttons on a smart key
  - The smart key is not operated within 13 feet (4 m) from the vehicle
  - Button of another smart key is pressed in addition to the operating smart key
  - Blind-Spot Collision-Avoidance Assist or Rear-Cross Traffic Collision-Avoidance Assist, or Parking Collision-Avoidance Assist operates.

When Parking function is paused, the vehicle will automatically stop. If the condition that made the function to pause disappears, the function may operate again.

## How to turn off Parking function while operating

- Press the Parking/View (P) button in the following stage:
  - Searching for parking space
  - Select parking type
- Shift the gear to R (Reverse) in the following stage:
  - Searching for parking space
  - Select parking type
  - Select operating mode
- Press the Parking Safety (Pm) button or select 'Cancel' on the infotainment system screen to turn off Parking function.
- While Smart Parking function is operating:
  - If the vehicle is stopped by depressing the brake pedal, and the gear is shifted, Parking function will turn off. At this time, EPB (Electronic Parking Brake) will not be engaged.
- While Remote Smart Parking function is operating:
  - Press the Remote Start ( ) button on the smart key. Parking function will turn off.
  - Get on the vehicle with the smart key. Parking function will turn off. At this time, the vehicle will remain on.

## The function will cancel in the following conditions when:

- · Smart Parking
  - The steering wheel is steered
  - The gear is shifted while the vehicle is moving
  - Operating EPB while the vehicle is moving
  - The hood is open
  - The driver opens the door with the seatbelt unfastened
  - Rapid acceleration occurs
  - Vehicle skid occurs
  - The wheel is stuck by an obstacle and cannot move
  - There are pedestrians, animals or objects at the front and rear of the vehicle at the same time
  - About 3 minutes and 50 seconds have past after Smart Parking function has started to operate
  - The slope of the road exceeds the operational range
  - The function is paused for more than 1 minute
  - The steering wheel, gearshift, braking, and drive controls are not working properly
  - ABS, TCS or ESC system operates due to slippery road conditions

When Smart Parking function is canceled, the vehicle will automatically stop, shift the gear to P (Park) and engage EPB (Electronic Parking Brake).

- · Remote Smart Parking
  - The steering wheel is steered
  - The gear is shifted
  - Operating EPB while the vehicle is moving
  - The hood is open
  - The brake pedal or accelerator pedal is depressed when all the doors are closed
  - The smart key is outside the vehicle when the brake pedal is depressed while the driver's door is open.
  - Rapid acceleration occurs
  - Vehicle skid occurs
  - The wheel is stuck by an obstacle and cannot move
  - There are pedestrians, animals or objects at the front and rear of the vehicle at the same time
  - About 3 minutes and 50 seconds have past after Remote Smart Parking function has started to operate
  - The slope of the road exceeds the operational range
  - The function is paused for more than 1 minute
  - The steering wheel, gearshift, braking, and drive controls are not working properly
  - There is a problem with the smart key or the smart key battery is low
  - ABS, TCS or ESC system operates due to slippery road conditions
  - The alarm of the Theft Alarm System sounds
  - The charging door is open

When Remote Smart Parking function is canceled, the vehicle will automatically stop, shift the gear to P (Park) and engage EPB (Electronic Parking Brake). The vehicle will turn off.

#### Smart Exit

#### Operating order

Smart Exit function operates in the following order:

- 1. Getting ready for exit
- 2. Checking space
- 3. Select exit direction
- 4. Smart Exit

#### 1. Getting ready for exit



- With the vehicle turned on, depress the brake pedal and shift the gear to P (Park) or N (Neutral).
- (2) Press and hold the Parking/View (見) button to turn on Remote Smart Parking Assist.

### *i* Information

- Agree must be selected on the infotainment system screen and the infotainment system has to operate properly to use Smart Exit function.
- Drive below 3 mph (5 km/h) with the vehicle on and shift the gear to N (Neutral), Smart Exit function can be used.
- If the function is turned on again after parallel parking is completed by Remote Smart Parking Assist, Smart Exit function can be used.

#### 2. Checking space



OJKEV072223L

- (1) When the vehicle is stopped by depressing the brake pedal, the vehicle sensors will detect the distance from nearby objects and check for space to exit.
- (2) When checking for space is complete, a message will appear on the infotainment system screen with an audible sound to notify the search is complete.

### **!** WARNING

- While checking for space, if there is a risk of collision with pedestrian, animal or object in the direction of vehicle exit, for your safety, Smart Exit function can be turned off.
- Even if check for space is completed, objects in the blind spot area cannot be detected by the sensors. The driver must directly check the blind spot area and continue using the function.

### *i* Information

Due to abnormal performance of the ultrasonic sensor or the influence of the surroundings, Parking function may not be able to search for an exit space even if there is a an exit space, or may search for a space that is not suitable for exiting.

 The parked vehicle has objects attached to the bumper such as bumper guard, trailer hitch, etc.

#### 3. Select exit direction



OJKEV072224L

- With the vehicle stopped by depressing the brake pedal, the infotainment system screen displays the possible directions for parallel exit.
- (2) Touch the infotainment system screen or use the central controller to select the desired exit direction.



#### **!** CAUTION

- Before selecting the Exit Direction, the driver should check whether the space for exit is suitable.
- If the searched exit space by Remote Smart Parking Assist is narrow or unsuitable (surrounding vehicles are parked vertically, etc.), do not use the Smart Exit function.

#### 4. Smart Exit



OJKEV072286L

- (1) Press the Parking/View
  ((ア)) button when the vehicle is stopped by depressing the brake pedal. When the brake pedal is released, Remote Smart Parking Assist will automatically control the steering wheel, vehicle speed and gearshift.
- (2) While Smart Exit function is operating, if you do not hold down the Parking/View button, the vehicle will stop and function control will pause. The function will start operating again when the Parking/View button is pressed and held again.
- (3) When the vehicle reaches the target exit location, a message will appear on the infotainment system screen to inform you that exit is complete.



#### Information

- Smart Exit function will not operate if the door is open or the seat belt is not fastened.
- Vehicle speed can be adjusted by depressing the brake pedal while Smart Exit function is operating. However, the vehicle does not accelerate even when the accelerator pedal is depressed.
- If exit is completed while depressing the brake pedal, Smart Exit function will complete with the gear in D (Drive).
- If exit is completed while depressing the accelerator pedal, you must take your foot off the accelerator pedal once for the accelerator pedal to operate.
- If there is no vehicle operation such as depressing the brake pedal or accelerator pedal within 4 seconds after exit is complete, the vehicle will automatically shift to P (Park) and engage EPB (Electronic Parking Brake).
- After Exit function is complete, always check the surroundings before driving.

#### Smart Exit operation status

Operation Status	Turn Signal
Under control	The turn signal of the exit direction blinks until the exit is complete or Smart Exit is canceled.

### The function will pause in the following conditions when:

- There is a pedestrian, animal or object in the direction the vehicle is moving
- · The door or liftgate is open
- The driver's seat belt is not fastened
- Blind-Spot Collision-Avoidance
   Assist or Rear-Cross Traffic Collision Avoidance Assist operates while the
   vehicle is being controlled in the
   reverse direction
- The Parking/View (P) button is not continuously pressed
- The vehicle is stopped by depressing the brake pedal

When Exit function is paused, the vehicle will stop. If the condition that made the function to pause disappears, the function may operate again.

### How to turn off Smart function while operating

- Press the Parking/View (P) button in the following stage:
  - Checking space
  - Select exit direction
- Shift the gear to R (Reverse) in the following stage:
  - Checking space
  - Select exit direction
- Press the Parking Safety (Pm<sub>A</sub>) button or select Cancel on the infotainment system screen to turn off Exit function.
- While Smart Exit function is operating, if the vehicle is stopped by depressing the brake pedal, and the gear is shifted, Exiting function will turn off. At this time, EPB (Electronic Parking Brake) will not be engaged.

The function will cancel in the following conditions when:

- Smart Exit
  - The steering wheel is steered
  - The gear is shifted while the vehicle is moving
  - Operating EPB while the vehicle is moving
  - The hood is open
  - The driver opens the door with the seatbelt unfastened
  - Rapid acceleration occurs
  - Vehicle skid occurs
  - The wheel is stuck by an obstacle and cannot move
  - There are pedestrians, animals or objects at the front and rear of the vehicle at the same time
  - About 3 minutes and 50 seconds have past after Smart Exit function has started to operate
  - The slope of the road exceeds the operational range
  - The function was paused for more than 1 minute
  - The steering wheel, gearshift, braking, and drive controls are not working properly
  - ABS, TCS or ESC system operates due to slippery road conditions
  - The charging door is open

When Smart Exit function is canceled, the vehicle will automatically stop, shift the gear to P (Park) and engage EPB (Electronic Parking Brake).

#### Remote Smart Parking Assist Malfunction and Limitations

Remote Smart Parking Assist malfunction



OJKEV072275L

Remote Smart Parking Assist check
When Remote Smart Parking Assist is
not working properly, the 'Check Parking
Assist' warning message will appear
on the infotainment system screen.
If the message appears, stop using
Remote Smart Parking Assist, and have
the vehicle inspected by an authorized
retailer of Genesis Branded products.



OJKEV072276L

Remote Smart Parking Assist canceled When Remote Parking Assist is operating, the function can be canceled, and the 'Parking Assist Canceled' warning message may appear regardless of the parking order. Other messages may appear depending on the situations. Follow the instructions provided on the infotainment system screen while parking your vehicle with Remote Parking Assist. Always look around and pay attention when using Remote Smart Parking Assist.



OJKEV072277L

Remote Smart Parking Assist standby 'Parking Assist Conditions Not Met' message appears when Parking/View (P) button has been pressed and held while Remote Smart Parking Assist is in standby.

After a while, press and hold the Parking/ View ( TD) button again to see if Remote Smart Parking Assist works.

The message appears even when the smart key's battery is low. Check the smart key battery level.

It does not work even when the EV mode is in the Utility mode. For related information, refer to the "Setting Utility Mode" section in chapter 1.

#### Limitations of Remote Smart Parking Assist

In the following circumstances, Remote Smart Parking Assist performance to park or exit the vehicle may be limited, there may be a risk of collision, or Remote Smart Parking Assist may turn off. Park or exit the vehicle manually if necessary.

- An object is attached to the steering wheel
- The vehicle is installed with a snow chain, spare tire or different size wheel
- Tire pressure is lower or higher than the standard tire pressure
- Your vehicle is loaded with cargo longer or wider than your vehicle or a trailer is connected to your vehicle
- There is a problem with the wheel alignment
- Your vehicle is leaned severely to one side
- Your vehicle is equipped with a trailer hitch
- The license plate is installed differently from the original location
- There is a person, animal or object above or below the ultrasonic sensor when Remote Smart Parking Assist is activated
- There is an obstacle such as a person, animal or object (trash can, bicycle, motorcycle, shopping cart, narrow pillar, etc.) near the parking space
- There is a circular pillar or narrow pillar, or a pillar surrounded by objects such as fire extinguisher, etc., near the parking space
- The road surface is bumpy (curbstone, speed bump, etc.)
- The road is slippery

- · The parking line is too thin or thick
- The parking line is partially erased or blurred
- The parking line is obscured by people, animals, or objects such as snow, boxes, etc.
- · There is heavy wind
- Operating Remote Smart Parking Assist on uneven roads, gravel roads, bushes, etc.
- The performance of the ultrasonic sensor is affected by extremely hot or cold weather
- The ultrasonic sensor is covered with snow or water
- An object that generates ultrasonic waves is nearby
- A wireless device with a transmission function operates near the ultrasonic sensors
- Your vehicle is affected by another vehicle's Parking Distance Warning
- The sensor is mounted or positioned incorrectly by an impact to the bumper
- The ultrasonic sensor cannot detect the following objects when:
  - Sharp or slim objects, such as ropes, chains or small poles
  - Objects smaller than 40 inches (100 cm) in length and narrower than 6 inches (14 cm) in diameter
  - Objects which tend to absorb sensor frequency, such as clothes, spongy material or snow
  - A narrow object such as a corner of a square pillar
  - Person, animal or object near the ultrasonic sensor

Remote Smart Parking Assist may not operate properly under the following circumstances:

· Parking on inclines



Park manually when parking on inclines.

Parking in snow



Snow may interfere with sensor operation, or Remote Smart Parking Assist may cancel if the road is slippery while parking.

#### · Parking on uneven road



Remote Smart Parking Assist may cancel when the vehicle slips, or the vehicle cannot move due to road conditions such as pebbles or fragmented stones.

· Parking behind a truck




Do not use Remote Smart Parking Assist around vehicles with higher ground clearance, such as a bus, truck, etc. It may lead to an accident.

#### Parking near a pillar



Remote Smart Parking Assist performance may reduce or collision with an obstacle may occur when there is a narrow object, circular pillar, square pillar, or a pillar surrounded by objects such as a fire extinguisher, etc., near the parking space. The driver should park the vehicle properly.

Parking in a parking space with a vehicle on one side only



If Remote Smart Parking Assist is used, when parking in a parking space with a vehicle only on one side, your vehicle may cross the parking line to avoid the parked vehicle.

#### · Parking diagonal



Remote Smart Parking Assist does not provide diagonal parking. Even if your vehicle was able to enter the parking space, do not use Remote Smart Parking Assist because the function cannot operate properly.

 Leaving a parking space near a wall or parking in a narrow space



- Remote Smart Parking Assist may not operate properly when leaving a parking space that is narrow and near a wall. Always check for pedestrians, animals, objects while leaving.
- For your safety, Remote Smart
   Parking Assist does not search for
   parking spaces at areas with narrow
   parking spaces that are narrower
   than the minimum space required
   for parking.

### **MARNING**

Take the following precautions when using Remote Smart Parking Assist:

- The driver is responsible for safe parking and exit when using Remote Smart Parking Assist.
- When using Remote Smart Parking Assist, stay out of the vehicle's path for your safety.
- Always check surroundings when using Remote Smart Parking Assist. You may collide with pedestrians, animals, or objects if they are near the sensor or are in the sensor's blind spot area.
- A collision may occur if a pedestrian, animal, or object suddenly appears while Remote Smart Parking Assist is operating.
- Do not use Remote Smart Parking Assist when under the influence of alcohol.
- Do not let children or other people to use the smart key.
- If Remote Smart Parking Assist is used continuously for a long period, it may adversely affect Remote Smart Parking Assist performance.

- Remote Smart Parking Assist may not operate properly if the vehicle needs wheel alignment adjustment such as when the vehicle tilts to one side. Have the vehicle inspected by an authorized retailer of Genesis Branded Products.
- Noise may be heard when braking occurs by Remote Smart Parking Assist or when the brake pedal is depressed by the driver.
- Remote Smart Parking Assist may suddenly apply the brake to avoid collision.
- Use Remote Smart Parking Assist only in a parking space that is large enough for the vehicle to move safely.

#### NOTICE

- If the 3rd stage warning (continuous beep) of the Forward/Reverse Parking Distance Warning sounds while Remote Smart Parking Assist is operating, it means the obstacle detected is close to your vehicle. At this time, Remote Smart Parking Assist will temporarily stop operating. Make sure there are no pedestrians, animals, or objects around your vehicle.
- Depending on brake operation, the stop lights may come on while the vehicle is moving.
- If the vehicle is remotely started that has been parked in cold weather for a long time, the operation of Remote Smart Parking function may be delayed or canceled depending on the vehicle condition.

#### **DECLARATION OF CONFORMITY (IF EQUIPPED)**

#### **Front Radar**

The radio frequency components complies:

For USA



FCC ID : 2A30Z-LRR25

This device complies with Part 15 of the FCC Rules. Operation is subject to the following

two conditions:
(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION TO USERS

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

OANATEL450

- For Canada

Model: LRR-25 IC: 27992-LRR25

This device complies with Industry Canada licenceexempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference and

(2) this device must accept any interference

including interference that may cause undesired

operation of the device, Le prèsent appareil est conforme aux CNR

d'Industrie Canada applicables aux appareils

radio exempts de licence, L'exploitation est autorisée

aux deux conditions suiventes:
(1) l'appareil ne doit pas produire de

brouillage,

El.

(2) l'utilisateur de l'appareil doit accepter tout

brouillage radioèlectrique subi, même si le brouillage est susceptible d'en

compromettre le fonctionnement

OANATEL451

## Front Corner Radar/Rear Corner Radar

The radio frequency components complies:

For USA



#### FCC ID: LTQJ4TR

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

#### CAUTION TO USERS

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

OANATEL053

#### For Canada

Model: J4TR/J4TRh IC: 3659A-J4TR

This device complies with Industry Canada licenceexempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et


(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

OANATEL054

# 8. Emergency Situations

Hazard Warning Flasher	8-2
In Case of an Emergency while Driving	8-2 8-2
If the Vehicle will not Start  Confirm the EV Battery is not Low on the Charge Gauge	
Jump Starting (12 V Battery)	8-4
Tire Pressure Monitoring System (TPMS)	8-7 8-8 8-9 8-9
If You Have a Flat Tire (with Tire Mobility Kit) Introduction Notes on the Safe Use of the Tire Mobility Kit Components of the Tire Mobility Kit Using the Tire Mobility Kit When a Tire is Flat How to Adjust Tire Pressure	8-12 8-13 8-14 8-15
Towing  Towing Service  Precautions when Moving a Short Distance before Towing a Vehicle	8-19

#### HAZARD WARNING FLASHER



The hazard warning flasher warns other drivers to exercise extreme caution when approaching, overtaking, or passing your vehicle.

It should be used whenever making emergency repairs or when stopped near the edge of a roadway.

To turn on or off the hazard warning flasher, press the hazard warning flasher button with the Start/Stop button in any position. The hazard warning flasher button is located in the center fascia panel. All turn signal lights flash simultaneously.

- The hazard warning flasher operates whether your vehicle is running or not.
- The turn signals do not work when the hazard flasher is on.

## IN CASE OF AN EMERGENCY WHILE DRIVING

#### If the Vehicle Stalls while Driving

- Reduce the vehicle speed gradually, keeping a straight line. Move cautiously off the road to a safe place.
- · Turn on your hazard warning flasher.
- Try to start the vehicle again. If your vehicle does not start, contact an authorized retailer of Genesis Branded products or seek other qualified assistance.

## If the Vehicle Stalls at a Crossroad or Crossing

If the vehicle stalls at a crossroad or intersection, if safe to do so, shift the gear to N (Neutral) and then push the vehicle to a safe location.

## If you have a Flat Tire while Driving

If a tire goes flat while you are driving:

- Take your foot off the accelerator pedal and let the vehicle slow down while driving straight ahead. Do not apply the brakes immediately or attempt to pull off the road because this may cause loss of vehicle control resulting in a collision. When the vehicle has slowed to such a speed that it is safe to do so, brake carefully and pull off the road. Drive off the road as far as possible and park on a firm, level ground. If you are on a divided highway, do not park in the median area between the two traffic lanes.
- When the vehicle is stopped, press the hazard warning flasher button, shift the gear to P (Park), apply the parking brake, and press the Start/Stop button to the OFF position.
- Have all passengers get out of the vehicle. Make sure they all get out on the side of the vehicle that is away from traffic.
- When replacing a flat tire, follow the instructions provided later in this chapter.

## IF THE VEHICLE WILL NOT START

## Confirm the EV Battery is not Low on the Charge Gauge

- Be sure the gear is in P (Park). The vehicle starts only when the gear is in P (Park).
- Check the 12 V battery connections and make sure the battery is clean and tight.
- Turn on the interior light. If the light dims or goes out when you operate the starter, the 12 V battery is drained.

#### NOTICE

Starting the vehicle by pushing or pulling may cause vehicle damage.

#### **JUMP STARTING (12 V BATTERY)**

Jump starting can be dangerous if done incorrectly. Follow the jump starting procedure in this section to avoid serious injury or damage to your vehicle. If in doubt about how to properly jump start your vehicle, have a service technician or towing service do it for you.



#### **WARNING**

To prevent SERIOUS INJURY or DEATH to you or bystanders, always follow these precautions when working near or handling the battery:



Always read and follow instructions carefully when handling a battery.



Wear eye protection designed to protect the eyes from acid splashes.



Keep all flames, sparks, or smoking materials away from the battery.



Hydrogen gas is always present in battery cells. It is highly combustible, and may explode if ignited.



Keep batteries out of reach of children.



Batteries contain sulfuric acid that is highly corrosive. Do not allow acid to contact your eyes, skin, or clothing.

If acid gets into your eyes, flush your eyes with clean water for at least 15 minutes and get immediate medical attention. If acid gets on your skin, thoroughly wash the area. If you feel pain or a burning sensation, get medical attention immediately.

- When lifting a plastic-cased battery, excessive pressure on the case may cause battery acid to leak. Lift with a battery carrier or with your hands on opposite corners.
- Do not attempt to jump start your vehicle if your battery is frozen.
- NEVER attempt to recharge the battery when the vehicle's battery cables are connected to the battery.
- The electrical ignition system works with high voltage.
  - NEVER touch these components with the vehicle on (**READY** indicator on) or when the Start/Stop button is in the ON position.
- The electrical ignition system works with high voltage. NEVER touch these components with the (READY) Start/Stop button in the ON or START position.
- Do not allow the (+) and (-) jumper cables to touch. It may cause sparks.
- The battery may rupture or explode when you jump start with a low or frozen battery.
- Do not directly connect the (-) to the jump cable. Connect the (-) to the one of the metallic parts located far from the jump cable in the vehicle. The direct (-) connection to the jump cable may cause an explosion.

### **WARNING**


- When connecting the supplementary battery and the discharged battery with a jump cable because the jump start does not operate with jump start terminal in the motor compartment, do not directly connect the (-) to the jump cable. Connect the (-) to the one of the metallic parts located far from the jump cable in the vehicle. The direct (-) connection to the jumpcable may cause an explosion.
- The battery contains dilute sulfuric acid, which is highly corrosive. Be careful not to let the battery liquid get on your body, clothes, or car body. If dilute sulfuric acid gets on your body or eyes, immediately rinse the area with clean water for about 15 minutes and then consult a doctor.

#### Jump starting procedure

### *i* Information

Your vehicle has a battery in the cargo area, but when you jump start your vehicle, use the jumper terminal in the motor compartment.

- Position the vehicles close enough that the jumper cables will reach. Do not allow the vehicles to touch.
- 2. Avoid fans or any moving parts in the motor compartment at all times, even when the vehicles are turned off.
- Turn off all electrical devices such as radios, lights, air conditioning, etc. Put the vehicles in P (Park) and apply the parking brake. Turn both vehicles OFF.
- 4. Open the hood.



5. Remove the motor compartment fuse box cover.

### **CAUTION**

Before jump starting, make sure to correctly identify the positive (+) and negative (-) terminals to avoid reverse polarity connections.



- Connect the jumper cables in the exact sequence shown in the illustration. First connect one jumper cable to the red, positive (+) jumper terminal of your vehicle (1).
- Connect the other end of the jumper cable to the red, positive (+) battery/ jumper terminal of the assisting vehicle (2).
- 8. Connect the second jumper cable to the black, negative (-) battery/ jumper terminal of the assisting vehicle (3).
- Connect the other end of the second jumper cable to the black, negative (-) chassis ground of your vehicle (4).
   Do not allow the jumper cables to contact anything except the correct battery or jumper terminals or the correct ground. Do not lean over the battery when making connections.

# **WARNING**

Do not connect the jumper cable to the negative (-) jumper terminal of the discharged battery. A spark could cause the battery to explode and lead to a personal injury or vehicle damage.

 Start the assisting vehicle and let it run for a few minutes. Then start your vehicle. 11. Keep your vehicle operating for at least 30 minutes at idle or driving to assure your battery receives enough charge to be able to start on its own after the vehicle is shut off. A completely discharged battery may require as long as 60 minutes runtime to fully recharge it. If the vehicle is run for less, the vehicle may not restart.

If your vehicle does not start after a few attempts, it probably requires service. Have your vehicle inspected by an authorized retailer of Genesis Branded products.

Disconnect the jumper cables in the exact reverse order you connected them:

- 1. Disconnect the jumper cable from the chassis ground of your vehicle (4).
- Disconnect the other end of the jumper cable from the black, negative (-) battery/chassis ground of the assisting vehicle (3).
- 3. Disconnect the second jumper cable from the red, positive (+) battery/ jumper terminal of the assisting vehicle (2).
- Disconnect the other end of the jumper cable from the red, positive (+) jumper terminal of your vehicle (1).

## *i* Information



An inappropriately disposed battery can be harmful to the environment and human health. Dispose of the battery according to your local law(s) or regulations.

## NOTICE

To prevent damage to your vehicle:

- Only use a 12-volt power supply (battery or jumper system) to jump start your vehicle.
- Do not attempt to jump start your vehicle by push-starting.

## TIRE PRESSURE MONITORING SYSTEM (TPMS)





- (1) Low Tire Pressure Telltale/TPMS
  Malfunction Indicator
- (2) Low Tire Pressure Position Telltale and Tire Pressure Telltale (Shown on the cluster display)

## **Check Tire Pressure**



OJKEV082007N

- You can check the tire pressure in the Utility view on the cluster.
  - Refer to the "View Modes" section in chapter 4.
- Tire pressure is displayed after a few minutes of driving after initial vehicle start up.
- If tire pressure is not displayed when the vehicle is stopped, 'Drive to display' message appears. After driving, check the tire pressure.
- The displayed tire pressure values may differ from those measured with a tire pressure gauge.
- You can change the tire pressure unit from the Settings menu in the infotainment system. Select:
  - Setup > General > Units > Tire Air Pressure > psi/kPa/bar



## Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.

## **Tire Pressure Monitoring System**



## WARNING

Over-inflation or under-inflation can reduce tire life, adversely affect vehicle handling, and lead to sudden tire failure that may cause loss of vehicle control resulting in an accident.

Each tire, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label. (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should determine the proper tire inflation pressure for those tires.)

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure.

Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for about one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists.

When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly.

Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

## NOTICE

If any of the below happens, have the system checked by an authorized retailer of Genesis Branded products.

- The Low Tire Pressure Telltale/ TPMS
   Malfunction Indicator does not
   illuminate for 3 seconds when the
   Start/Stop button is pressed to the
   ON position or when the vehicle is
   running.
- The TPMS Malfunction Indicator remains illuminated after blinking for about 1 minute.
- 3. The Low Tire Pressure Position Telltale remains illuminated.



# Low Tire Pressure Position and Tire Pressure Telltale



When the tire pressure monitoring system warning indicators are illuminated and a warning message displayed on the cluster display, one or more of your tires is significantly under-inflated. The Low Tire Pressure Position Telltale will indicate which tire is significantly underinflated by illuminating the corresponding position light.

If either telltale illuminates, immediately reduce your speed, avoid hard cornering and anticipate increased stopping distances. You should stop and check your tires as soon as possible. Inflate the tires to the proper pressure as indicated on the vehicle's placard or tire inflation pressure label located on the driver's side center pillar outer panel.

If you cannot reach a service station or if the tire cannot hold the newly added air, replace the low pressure tire with the spare tire (if equipped).

The Low Tire Pressure Telltale will remain on and the TPMS Malfunction Indicator may blink for one minute and then remain illuminated (when the vehicle is driven about 10 minutes at speed above 15.5 mph (25 km/h)) until you have the low pressure tire repaired and replaced on the vehicle.



## **CAUTION**

In winter or cold weather, the Low Tire Pressure Telltale may be illuminated if the tire pressure was adjusted to the recommended tire inflation pressure in warm weather. It does not mean your TPMS is malfunctioning because the decreased temperature leads to a proportional lowering of tire pressure.

When you drive your vehicle from a warm area to a cold area or from a cold area to a warm area, or the outside temperature is greatly higher or lower, you should check the tire inflation pressure and adjust the tires to the recommended tire inflation pressure.



## WARNING

Low pressure damage

Significantly low tire pressure makes the vehicle unstable and can contribute to loss of vehicle control and increased braking distances.

Continued driving on low pressure tires can cause the tires to overheat and fail.



## TPMS (Tire Pressure Monitoring System) Malfunction Indicato

The TPMS Malfunction Indicator will illuminate after it blinks for about one minute when there is a problem with the Tire Pressure Monitoring System.

Have the system inspected by an authorized retailer of Genesis Branded products as soon as possible.

## NOTICE

If there is a malfunction with the TPMS, the Low Tire Pressure Position Telltale will not be displayed even though the vehicle has an under-inflated tire.

## NOTICE

The TPMS Malfunction Indicator may illuminate after blinking for one minute if the vehicle is near electric power supply cables or radio transmitters such as police stations, government and public offices, broadcasting stations, military installations, airports, transmitting towers, etc.

Additionally, the TPMS Malfunction Indicator may illuminate if snow chains are used or electronic devices such as computers, chargers, remote starters, navigation, etc. This may interfere with normal operation of the TPMS.

## Changing a Tire with TPMS

If you have a flat tire, the Low Tire Pressure and Position telltales will come on. Have the flat tire be repaired by an authorized retailer of Genesis Branded products as soon as possible or replace the flat tire with the spare tire (if equipped).

## NOTICE

It is recommended that you do not use a puncture-repairing agent not approved by an authorized retailer of Genesis Branded products or the equivalent specified for your vehicle to repair and/ or inflate a low pressure tire. Tire sealant not approved by an authorized retailer of Genesis Branded products or the equivalent specified for your vehicle may damage the tire pressure sensor.

The spare tire (if equipped) does not come with a tire pressure monitoring sensor. When the low pressure tire or the flat tire is replaced with the spare tire, the Low Tire Pressure Telltale will remain on. Also, the TPMS Malfunction Indicator will illuminate after blinking for one minute if the vehicle is driven at speed above 15.5 mph (25 km/h) for about 10 minutes.

Once the original wheel equipped with a tire pressure monitoring sensor is reinflated to the recommended pressure and reinstalled on the vehicle, the Low Tire Pressure Telltale and TPMS Malfunction Indicator will go off within a few minutes of driving.

If the indicators do not extinguish after a few minutes, consult an authorized retailer of Genesis Branded products.

Each wheel is equipped with a tire pressure sensor mounted inside the tire behind the valve stem (except for the spare tire). You must use TPMS specific wheels. Have your tires serviced by an authorized retailer of Genesis Branded products.

You may not be able to identify a tire with low pressure by simply looking at it. Always use a good quality tire pressure gauge to measure. Please note that a tire that is hot (from being driven) will have a higher pressure measurement than a tire that is cold.

A cold tire means the vehicle has been sitting for 3 hours and driven for less than 1 mile (1.6 km) in that 3 hour period. Allow the tire to cool before measuring the inflation pressure. Always be sure the tire is cold before inflating to the recommended pressure.

# **MARNING**

- The TPMS cannot alert you to severe and sudden tire damage caused by external factors such as nails or road dehris
- If you feel any vehicle instability, immediately take your foot off the accelerator pedal, apply the brakes gradually with light force, and slowly move to a safe position off the road.

# A

## WARNING

Tampering with, modifying, or disabling the Tire Pressure Monitoring System (TPMS) components may interfere with the system's ability to warn the driver of low tire pressure conditions and/or TPMS malfunctions and may void the warranty.



## **WARNING**

This device complies with Part 15 of the FCC rules. Operation is subject to the following three conditions:

- 1. This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation of the device.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

## IF YOU HAVE A FLAT TIRE (WITH TIRE MOBILITY KIT)



For safe operation, carefully read and follow the instructions in this manual before use.

- (1) Compressor
- (2) Sealant bottle

The tire mobility kit is a temporary fix to the tire, have the tire inspected by an authorized retailer of Genesis Branded products or the equivalent approved for your vehicle as soon as possible.



## CAUTION

When two or more tires are flat, do not use the tire mobility kit because the sealant provided with the Tire Mobility Kit must be used for only one flat tire.



## **WARNING**

Do not use the Tire Mobility Kit to repair punctures in the tire walls. This can result in an accident due to tire failure.



## WARNING

Have your tire repaired as soon as possible. The tire may lose air pressure at any time after inflating with the Tire Mobility Kit.

## Introduction

With the Tire Mobility Kit you can stay mobile even after experiencing a tire puncture.

The compressor and sealing compound system effectively and comfortably seals most punctures in a passenger car tire caused by nails or similar objects and reinflates the tire.

After you ensure that the tire is properly sealed you can drive cautiously on the tire (distance up to 120 miles (200 km)) at a max. speed of 50 mph (80 km/h) in order to reach a service station or tire dealer for the tire replacement.

It is possible that some tires, especially with larger punctures or damage to the sidewall, cannot be sealed completely.

Air pressure loss in the tire may adversely affect tire performance.

For this reason, you should avoid abrupt steering or other driving maneuvers, especially if the vehicle is heavily loaded or if a trailer is in use.

The Tire Mobility Kit is not designed or intended as a permanent tire repair method and is to be used for one tire only.

This instruction shows you step by step how to temporarily seal the puncture simply and reliably.

Read the section "Notes on the safe use of the Tire Mobility Kit".

# Notes on the Safe Use of the Tire Mobility Kit

- Park your vehicle at the side of the road so that you can work with the Tire Mobility Kit away from moving traffic.
- To be sure your vehicle will not move, even when you're on fairly level ground, always apply your parking brake.
- Only use the Tire Mobility Kit for sealing/inflation passenger car tires.
   Only punctured areas located within the tread region of the tire can be sealed using the tire mobility kit.
- Do not use on motorcycles, bicycles or any other type of tires.
- When the tire and wheel are damaged, do not use Tire Mobility Kit for your safety.
- Use of the Tire Mobility Kit may not be effective for tire damage larger than about 0.16 inch (4 mm).
  - Contact the nearest authorized retailer of Genesis Branded products if the tire cannot be made roadworthy with the Tire Mobility Kit.

- Do not use the Tire Mobility Kit if a tire is severely damaged by driving run flat or with insufficient air pressure.
  - Only punctured areas located within the tread region of the tire can be sealed using the TMK.
- Do not remove any foreign objects such as nails or screws that have penetrated the tire.
- Provided the vehicle is outdoors, leave the vehicle on (READY indicator on).
   Otherwise operating the compressor may eventually drain the car battery.
- Never leave the Tire Mobility Kit unattended while it is being used.
- Do not leave the compressor running for more than 10 minutes at a time or it may overheat.
- Do not use the Tire Mobility Kit if the ambient temperature is below - 22°F (-30°C).
- In case of skin contact with the sealant, wash the area thoroughly with plenty of water. If the irritation persists, seek medical attention.
- In case of eye contact with the sealant, flush your eyes for at least 15 minutes. If the irritation persists, seek medical attention.
- In case of swallowing the sealant, rinse the mouth and drink plenty of water. However, never give anything to an unconscious person and seek medical attention immediately.
- Long time exposure to the sealant may cause damage to bodily tissue such as kidney, etc.

## **Components of the Tire Mobility Kit**



- (1) Speed restriction label
- (2) Sealant bottle and label with speed restriction
- (3) Filling hose from sealant bottle to wheel
- (4) Connectors and cable for power outlet direct connection
- (5) Holder for the sealant bottle
- (6) Compressor

- (7) ON/OFF switch
- (8) Pressure gauge for displaying the tire inflation pressure
- (9) Button for reducing the tire inflation pressure

Strictly follow the specified sequence, otherwise the sealant may escape under high pressure.

# **MARNING**

Do not use the tire sealant after the sealant has expired (the expiration date is pasted on the sealant container). This can increase the risk of tire failure.

# **MARNING**

## Sealant

- · Keep out of reach of children.
- · Avoid contact with eyes.
- · Do not swallow.

# Using the Tire Mobility Kit When a Tire is Flat






Detach the speed restriction label (1) from the sealant bottle (2), and place it in a highly visible place inside the vehicle such as on the steering wheel to remind the driver not to drive too fast.


# **CAUTION**

If only the tire pressure needs to be adjusted, refer to the "How to Adjust Tire Pressure" section in this chapter.

Before using the Tire Mobility Kit, be fully aware of the explanation on the sealant.



1. Shake the sealant bottle (2).



2. Remove the cover (A) of the sealant bottle (2) and compressor (6).



- 3. Connect the sealant bottle (2) and compressor (6).
- Make sure that the valve (9) for reducing tire inflation pressure is closed.



5. Unscrew the valve cap from the valve of the defective wheel and screw the filling hose (3) of the sealant bottle onto the valve.

## CAUTION

Securely install the sealant filling hose to the valve. If not, sealant may flow backward, possibly clogging the filling hose.

6. Make sure the compressor is off by pressing the main switch (7) to the OFF (O) position.



7. Plug the compressor power cord (4) into the vehicle power outlet.

8. With the vehicle on (READY indicator on), switch on the compressor and let it run for about 5-7 minutes to fill the sealant up to proper pressure (Refer to the "Tire and Wheels" section in chapter 2).


Be careful not to overinflate the tire and stay away from the tire when filling it.

## **CAUTION**

Tire pressure

Do not attempt to drive your vehicle if the tire pressure is below 29 psi (200 kPa). This could result in an accident due to sudden tire failure

- 9. Switch off the compressor.
- 10. Detach the hoses from the sealant. bottle connector and from the tire valve.
- 11. Return the Tire Mobility Kit to its storage location in the vehicle.



12. Immediately drive about 4-6 miles (7-10 km or, about 10 minutes) to evenly distribute the sealant in the tire.

Do not exceed a speed of 50 mph (80 km/h). If possible, do not fall below a speed of 12 mph (20 km/h).

While driving, if you experience any unusual vibration, ride disturbance or noise, reduce your speed and drive with caution until you can safely pull off of the side of the road.

Call for road side service or towing.



- After driving about 4-6 miles (7-10 km or about 10 minutes), stop at a safety location.
- 14. Connect the filling hose (3) of the compressor directly to the tire valve.
- 15. Connect cables (4) to the battery.
- 16. Adjust the tire inflation pressure to the recommended tire inflation.

With the vehicle on (**READY** indicator on) proceed as follows:

- To increase the inflation pressure: Switch on the compressor. To check the current tire inflation pressure setting, briefly switch off the compressor.
- To reduce the tire inflation pressure: Press the button (9) on the compressor.



## Information

The pressure gauge may show higher than actual reading when the compressor is running. To get an accurate tire pressure, the compressor needs to be turned off.



## **CAUTION**

If the tire inflation pressure is not maintained, drive the vehicle a second time, refer to step 9.

Then repeat steps 10 to 13.

Use of the TMK may be ineffectual for tire damage larger than about 0.16 in (4 mm).

Contact an authorized retailer of Genesis Branded products if the tire cannot be made roadworthy with the Tire Mobility Kit.



## **WARNING**

The tire inflation pressure must be inflated to the proper pressure (Refer to the "Tire and Wheels" section in chapter 2). If it is not, do not continue driving.

Call for road side service or towing.



## **CAUTION**

Tire pressure sensor

The sealant on the tire pressure sensor and wheel should be removed when you replace the tire with a new one and inspect the tire pressure sensors. Have this done at an authorized retailer of Genesis Branded products.



## Information

When reinstalling the repaired or replaced tire and wheel on the vehicle, tighten the wheel bolt to 101-116 lbf·ft (14-16 kgf·m).

## **How to Adjust Tire Pressure**



- 1. Park your vehicle in a safe location.
- 2. Connect the filling hose (3) of the compressor directly to the tire valve.
- 3. Plug the compressor power cord (4) into the vehicle power outlet.

4. Adjust the tire inflation pressure to the recommended tire inflation.

With the vehicle on (**READY** indicator on), proceed as follows:

- To increase the inflation pressure: Switch on the compressor. To check the current tire inflation pressure setting, briefly switch off the compressor.
- To reduce the tire inflation pressure: Press the button (9) on the compressor.



## Information

- The pressure gauge may show higher than actual reading when the compressor is running. To get an accurate tire reading, the compressor needs to be turned off.
- When reinstalling the repaired or replaced tire and wheel on the vehicle, tighten the wheel bolt to 101-116 lbf-ft (14-16 kgf-m).



## **CAUTION**

Do not use the sealant when the tire pressure only needs to be adjusted.




## WARNING

The tire inflation pressure must be inflated to the proper pressure (Refer to the "Tire and Wheels" section in chapter 2). If it is not, do not continue driving. Call for road side service or towing.

## **TOWING**

## **Towing Service**



[1]: Dollies

If emergency towing is necessary, have it done by an authorized retailer of Genesis Branded products or a commercial tow-truck service.

Proper lifting and towing procedures are necessary to prevent damage to the vehicle. The use of wheel dollies or flatbed is recommended.

**AWD vehicles** must be towed with a wheel lift and dollies or flatbed equipment with all the wheels off the ground.



## CAUTION

Do not tow the vehicle with any wheels on the grounds as this may cause damage to the vehicle.

## Precautions when Moving a Short Distance before Towing a Vehicle

Move short distances within 33 feet (10 m) at a speed of 3 mph (5 km/h) or less only when loading on a tow truck or if the vehicle needs to be repositioned. At this time, the gear must be in N (Neutral) and the parking brake must be released. If it is impossible to operate the gear and parking brake, move the vehicle with the rear wheel lifted.

## NOTICE

To prevent damage when towing:


- Do not lift using the trailer hitch or body and chassis parts.
- Do not tow vehicles with sling-type equipment. Only use wheel lift or flatbed equipment.

# 9. Maintenance

Motor Compartment	9-3
Maintenance Services Owner's Responsibility Owner Maintenance Precautions	9-4
Owner Maintenance Owner Maintenance Schedule	
Scheduled Maintenance Services	9-8
Explanation of Scheduled Maintenance Items	9-11
Coolant	
Brake FluidChecking the Brake Fluid Level	9-14 9-14
Gear Fluid	9-15
Washer FluidChecking the Washer Fluid Level	
Cabin Air Filter Filter Inspection Filter Replacement	9-16
Wiper Blades  Blade Inspection  Blade Replacement	9-18
Battery (12 V)	
Battery Replacement	9-21
12 V Battery Recharging	9-22 9-23

Tires and Wheels	9-24
Tire Care	
Recommended Cold Tire Inflation Pressures	9-24
Check Tire Inflation Pressure	9-25
Tire Rotation	
Wheel Alignment and Tire Balance	9-26
Tire Replacement	
Wheel Replacement	
Tire Traction	
Tire Maintenance	
Tire Sidewall Labeling	9-28
Tire Terminology and Definitions	
All Season Tires	
Summer Tires	
Snow Tires	
Radial-Ply Tires	
Low Aspect Ratio Tires	9-36
Fuses	9-37
Instrument Panel Fuse Replacement	9-38
Motor Compartment Panel Fuse Replacement	9-39
Fuse/Relay Panel Description	9-40
Light Bulbs	9-51
Headlight, Parking Light, Turn Signal Light, Daytime Running Light (DRL)	5 51
Replacement	9-52
Puddle Light Replacement	
Rear Combination Light Replacement	
High Mounted Stop Light Replacement	
License Plate Light Replacement	
Front Trunk Light Replacement	
Interior Light Replacement	
Appearance Care	9-55
Exterior Care	
Interior Care	
California Perchlorate Notice	9-63

## **MOTOR COMPARTMENT**



- (1) Coolant reservoir
- (2) Brake fluid reservoir
- (3) Windshield washer fluid reservoir
- (4) Fuse box

- (5) Cabin air filter
- (6) Front trunk
- (7) Jump-start negative (chassis) terminal

## **MAINTENANCE SERVICES**

You should exercise the utmost care to prevent damage to your vehicle and injury to yourself whenever performing any maintenance or inspection procedures.

Have your vehicle maintained and repaired by an authorized retailer of Genesis Branded products. An authorized retailer of Genesis Branded products meets Genesis Branded Vehicle's high service quality standards and receives technical support from Genesis Branded Vehicle in order to provide you with a high level of service satisfaction.

## **Owner's Responsibility**

Maintenance service and record retention are the owner's responsibility.

You should retain documents that show proper maintenance has been performed on your vehicle in accordance with the scheduled maintenance service charts shown on the following pages. You need this information to establish your compliance with the servicing and maintenance requirements of your vehicle warranties.

Detailed warranty information is provided in your Owner's Handbook & Warranty Information booklet.

Repairs and adjustments required as a result of improper maintenance or a lack of required maintenance are not covered.

## **Owner Maintenance Precautions**

Inadequate, incomplete or insufficient servicing may result in operational problems with your vehicle that could lead to vehicle damage, an accident, or personal injury. This chapter provides instructions only for the maintenance items that are easy to perform.

Your vehicle should not be modified in any way. Such modifications may adversely affect the performance, safety or durability of your vehicle and may, in addition, violate conditions of the limited warranties covering the vehicle.

Certain modifications may also be in violation of regulations established by the U.S. Department of Transportation and other federal or state agencies.

## NOTICE

Improper owner maintenance during the warranty period may affect warranty coverage. For details, read the separate Owner's Handbook & Warranty Information Booklet provided with the vehicle. If you're unsure about any service or maintenance procedure, have it done by an authorized retailer of Genesis Branded products.

## **OWNER MAINTENANCE**



## ♠ WARNING

Performing maintenance work on a vehicle can be dangerous. If you lack sufficient knowledge and experience or the proper tools and equipment to do the work, it should be done by an authorized retailer of Genesis Branded products. ALWAYS follow these precautions for performing maintenance work:

- Park your vehicle on level ground. Shift the vehicle to P (Park), apply the parking brake, and press the Start/ Stop button to the OFF position.
- · Block the tires (front and back) to prevent the vehicle from moving. Remove loose clothing or jewelry that can become entangled in moving parts.
- Keep flames, sparks, or smoking materials away from the battery parts.

The following lists are vehicle checks and inspections that should be performed by the owner or an authorized retailer of Genesis Branded products at the frequencies indicated to help ensure safe, dependable operation of your vehicle.

Any adverse conditions should be brought to the attention of your dealer as soon as possible.

These Owner Maintenance vehicle checks are generally not covered by warranties and you may be charged for labor, parts and lubricants used.

The electric control system in the vehicle may cause malfunction or other negative impact on the artificial heart and the artificial internal organs. Be sure to inquire the impact of the electric control system on the artificial organs from the medical product corporation.



## ! WARNING

Make sure to turn the Start/Stop button to the OFF position to shut down the vehicle before performing maintenance work on the vehicle.

# Owner Maintenance Schedule

## When you stop for charging:

- Check the coolant level in the coolant reservoir.
- Check the windshield washer fluid level.
- Check for low or under-inflated tires.



## **WARNING**



Be careful when checking your coolant level if the motor compartment is hot. This may result in coolant being blown out of the opening and cause serious burns and other injuries.

## While operating your vehicle:

- Check for vibrations in the steering wheel. Notice if there is any increased steering effort or looseness in the steering wheel, or change in its straight-ahead position.
- Notice if your vehicle constantly turns slightly or "pulls" to one side when traveling on smooth, level road.
- When stopping, listen and check for unusual sounds, pulling to one side, increased brake pedal travel or "hardto-push" brake pedal.
- If any slipping or changes in the operation of your gear shift occurs, check the shift gear fluid level.
- · Check the shift gear P (Park) function.
- · Check the parking brake.
- Check for fluid leaks under your vehicle (water dripping from the air conditioning system during or after use is normal).

## At least monthly:

- Check coolant level in the coolant reservoir.
- Check the operation of all exterior lights, including the stoplights, turn signals and hazard warning flashers.
- Check the inflation pressures of all tires including the spare (if equipped) for tires that are worn, show uneven wear, or are damaged.
- · Check for loose wheel bolts.

# At least twice a year: (for example, every Spring and Autumn)

- Check radiator, heater and air conditioning hoses for leaks or damage.
- Check windshield washer spray and wiper operation. Clean wiper blades with a clean cloth dampened with washer fluid.
- · Check headlight alignment.
- Check the seat belts for wear and function.

## At least once a year:

- Clean body and door drain holes.
- Lubricate door hinges and hood hinges.
- Lubricate door and hood locks and latches.
- Lubricate door rubber weather strips.
- Check the air conditioning system.
- Inspect and lubricate shift gear linkage and controls.
- · Clean the battery (12 V) and terminals.
- Check the brake fluid level.

## SCHEDULED MAINTENANCE SERVICES

Follow Normal Maintenance Schedule if the vehicle is usually operated where none of the following conditions apply. If any of the following conditions apply, you must follow the Maintenance Under Severe Usage Conditions.

- Repeatedly driving short distance of less than 5 miles (8 km) in normal temperature or less than 10 miles (16 km) in freezing temperature
- Driving on rough, dusty, muddy, unpaved, graveled or salt spread roads
- · Driving in areas using salt or other corrosive materials or in very cold weather
- · Driving in heavy dust condition
- Driving in heavy traffic area with the ambient temperature higher than 90 °F (32 °C) while consuming more than 50 % of electric energy.
- · Driving on uphill, downhill, or mountain roads repeatedly
- · Towing a trailer or using a camper, or driving with loads on the roof
- · Driving as a patrol car, taxi, other commercial use or vehicle towing
- Frequently driving under high speed or rapid acceleration/deceleration
- · Frequently driving in stop-and-go conditions

If your vehicle is operated under the above conditions, you should inspect, replace or refill more frequently than the following Normal Maintenance Schedule. After the periods or distance shown in the chart, continue to follow the prescribed maintenance intervals.

# Normal Maintenance Schedule

The following maintenance services must be performed to ensure good vehicle performance.

Keep receipts for all vehicle services to protect your warranty. Where both mileage and time are shown, the frequency of service is determined by whichever occurs first.

MAINTENANCE	Months	12	24	36	48	09	72	84	96	108	120	132	144	156
	Miles×1,000	œ	16	24	32	40	48	56	64	72	80	88	96	104
ITEM	Km×1,000	13	26	39	52	65	78	91	104	117	130	143	156	169
Cooling system		_	_	_	_	_	_	_	_	_	_	_	_	_
Rotate Tires (Includes Tire Pressure and Tread Wear Inspection)					Sotate 6	every 8,	m 000	lles (13,	000 km	) or 12	Rotate every 8,000 miles (13,000 km) or 12 months			
Replace Climate Control Air Filter (For Evaporator and Blower Unit)		_	~	_	~	_	~	_	~	_	~	_	~	_
Coolant *1				At first, replace at 120,000 miles (200,000 km) or 120 months. After that, replace every 24,000 miles (40,000 km) or 24 months	t, repla at, repl	se at 12 ace eve	0,000 represented 1	niles (2 00 mile	00,000 es (40,0	km) ol	At first, replace at 120,000 miles (200,000 km) or 120 months. fter that, replace every 24,000 miles (40,000 km) or 24 month	onths. months		
12 V auxiliary battery condition	ion	_	_	_	_	_	_	_	_	_	_	_	_	_
Brake lines, hoses, and connections	nections	_	_	_	_	_	_	_	_	-	_	_	_	_

I: Inspect and if necessary, adjust, correct, clean or replace.

R: Replace or change.

\*: When replacing or adding coolant, have you visited an authorized retailer of Genesis Branded products.

# Normal Maintenance Schedule

MAINTENANCE	Months	12	24	36	48	09	72	84	96	108	120	132	144	156
	Miles×1,000	œ	16	24	32	40	48	56	64	72	80	88	96	104
ITEM	Km×1,000	13	26	39	52	65	78	91	104	117	130	143	156	169
Disc brakes and pads		_	_	_	_	_	_	_	_	_	_	_	_	_
Steering gear rack, linkage, and boots		_	_	_	_	_	_	_	_	_	_	_	_	_
Drive shafts and boots			_		_		_		_		_		_	
Air conditioning compressor, air conditioner		_	_	_	_	_	_	_	_	_	_	_	_	_
Gear fluid					_				-				-	
Brake pedal		_	_	_	_	_	_	_	_	_	_	_	_	_
Brake fluid				ln Re <sub>l</sub>	ispect e place e	Inspect every 8,000 miles (13,000 km) or 12 months, Replace every 48,000 miles (78,000 km) or 48 months	000 m ,000 m	les (13, iles (78	000 km ,000 kı	ı) or 12 m) or 4.	months 8 mont	s, hs		

I: Inspect and if necessary, adjust, correct, clean or replace.

R: Replace or change.

## Maintenance Under Severe Usage and Low Mileage Conditions

The following items must be serviced more frequently on cars mainly used under severe driving conditions.

Refer to the chart below for the appropriate maintenance intervals.

R: Replace I: Inspect and if necessary, adjust, correct, clean or replace

Maintenance item	Maintenance operation	Maintenance intervals	Driving condition
Gear fluid	R	Replace every 80,000 miles (120,000 km)	B, D, G, H
Steering gear rack, linkage and boots	I	Inspect more frequently depending on the condition	B, C, D, E, F
Front suspension ball joints	I	Inspect more frequently depending on the condition	B, C, D, E, F
Disc brakes and pads, calipers and rotors	I	Inspect more frequently depending on the condition	B, C, D, E, F, G, H, I, J
Driveshaft and boots	I	Inspect more frequently depending on the condition	B, C, D, E, F, G, H, I
Climate control air filter	R	Replace more frequently depending on the condition	B, D, F

## Severe driving conditions

- A. Repeatedly driving short distance of less than 5 miles (8 km) in normal temperature or less than 10 miles (16 km) in freezing temperature
- B. Driving on rough, dusty, muddy, unpaved, graveled or salt spread roads
- C. Driving in areas using salt or other corrosive materials or in very cold weather
- D. Driving in heavy dust condition
- E. Driving in heavy traffic area with the ambient temperature higher than 90 °F (32 °C) while consuming more than 50 % of electric energy.
- F. Driving on uphill, downhill, or mountain roads repeatedly
- G. Towing a trailer or using a camper, or driving with loads on the roof
- H. Driving as a patrol car, taxi, other commercial use or vehicle towing
- I. Frequently driving under high speed or rapid acceleration/deceleration
- J. Frequently driving in stop-and-go conditions

## **EXPLANATION OF SCHEDULED MAINTENANCE ITEMS**

## **Cooling System**

Check cooling system components, such as radiator, coolant reservoir, hoses and connections for leakage and damage. Replace any damaged parts.

## Coolant

The coolant should be changed at the intervals specified in the maintenance schedule.

## **Gear Fluid**

The gear fluid should be inspected and replaced according to the intervals specified in the maintenance schedule.

## **Brake Hoses and Lines**

Visually check for proper installation, chafing, cracks, deterioration and any leakage. Replace any deteriorated or damaged parts immediately.

## **Brake Fluid**

Check the brake fluid level in the brake fluid reservoir. The level should be between the MIN and the MAX marks on the side of the reservoir. Use only hydraulic brake fluid conforming to DOT 4 specification.

# **Brake Discs, Pads, Calipers and Rotors**

Check the pads, the disc, and the rotor for any excessive wear-out. Inspect calipers for any fluid leakage.

## **Suspension Mounting Bolts**

Check the suspension connections for looseness or damage. Retighten to the specified torque.

# Steering Gear Box, Linkage & Boots/Lower Arm Ball Joint

With the vehicle stopped and the vehicle off, check for excessive free-play in the steering wheel. Check the linkage for bends or damage. Check the dust boots and ball joints for deterioration, cracks, or damage.

Replace any damaged parts.


## **Drive Shafts and Boots**

Check the drive shafts, boots and clamps for cracks, deterioration, or damage. Replace any damaged parts and, if necessary, repack the grease.

## **Air Conditioning Refrigerant**

Check the air conditioning lines and connections for leakage and damage.

## COOLANT



Check the condition and connections of all cooling system hoses and heater hoses. Replace any swollen or deteriorated hoses.

The coolant level should be filled between the MAX or F and the MIN or L marks on the side of the coolant reservoir when the parts in the motor compartment is cool.

If the coolant level is low, add enough distilled (deionized) water mixed with antifreeze to bring the level to the MAX mark. If frequent additions are required, contact an authorized retailer of Genesis Branded products.

# **MARNING**



Keep hands, clothing, and tools away from the rotating fan blades of the cooling fan.



The cooling fan may continue to operate even though the vehicle is turned off and can cause serious injury.

The electric motor for the cooling fan is controlled by vehicle coolant temperature, refrigerant pressure and vehicle speed. As the vehicle coolant temperature decreases, the electric motor will automatically shut off.

# **MARNING**



Check the coolant level when the motor compartment is cooled. Coolant level is influenced by temperature, and if the coolant reservoir cap is removed when coolant temperature is high, hot coolant and steam may blow out under pressure causing serious injury.

 Make sure the coolant cap is properly closed after refilling coolant.
 Otherwise the motor could be overheated while driving.



 Check if the coolant cap label is straight in front.



Make sure that the tiny protrusions inside the coolant cap are securely interlocked.

## Recommended coolant

- When adding coolant, use only deionized water, distilled water, or soft water for your vehicle and never mix hard water in the coolant filled at the factory.
- An incorrect coolant mixture may result in severe malfunction or motor damage.
- · Do not use alcohol or methanol coolant or mix them with the specified coolant.
- Do not use a solution that contains more than 60 % antifreeze or less than 35 % antifreeze, which could reduce the effectiveness of the solution.

For mixing percentage, refer to the following table:

Ambient	Mixture Po (volu	ercentage ume)
Temperature	Antifreeze	Water
5 °F (-15 °C)	35	65
-13 °F (-25 °C)	40	60
-31 °F (-35 °C)	50	50
-49 °F (-45 °C)	60	40

## *i* Information

If in doubt about the mix ratio, a 50 % water and 50 % antifreeze mix is the easiest to mix together because it is the same quantity for each.

## **Changing Coolant**

Have the coolant changed by an authorized retailer of Genesis Branded product according to the Maintenance Schedule.

## NOTICE

To prevent damage to motor parts, put a thick towel around the coolant cap before refilling the coolant to prevent the coolant from overflowing into motor parts.

## **BRAKE FLUID**

## **Checking the Brake Fluid Level**



Check the fluid level in the reservoir periodically. The fluid level should be between MAX and MIN marks on the side of the reservoir.

Before removing the reservoir cap and adding brake fluid, clean the area around the reservoir cap thoroughly to prevent brake fluid contamination.

If the level is low, add the specified brake fluid to the MAX level. If the fluid level is excessively low or frequent additions are required, have the brake system inspected by an authorized retailer of Genesis Branded products.



## ! WARNING

If brake fluid comes in contact with your eyes, flush your eyes with clean water for at least 15 minutes and get immediate medical attention.

## NOTICE

- Do not allow brake fluid to contact the vehicle's body paint, because paint damage may occur.
- Never use brake fluid that has been exposed to open air for an extended time and dispose of it properly.
- Do not use the wrong type of brake fluid. A few drops of mineral based oil such as engine oil in your brake system may damage the brake system parts.



## Information

Use only the brake fluid specified in the "Recommended Lubricants and Capacities" section in chapter 2.

## **GEAR FLUID**

There is no gear fluid level gauge in the vehicle. Check the gear fluid every 32,000 miles (52,000 km) regularly. If the vehicle is driven under severe condition, check the maintenance under severe usage condition and consult an authorized retailer of Genesis Branded products.

## **WASHER FLUID**

## **Checking the Washer Fluid Level**



Check the fluid level in the washer fluid reservoir and add fluid if necessary. Plain water may be used if washer fluid is not available. However, use washer solvent with antifreeze characteristics in cold climates to prevent freezing.



## WARNING

To prevent serious injury or death, take the following safety precautions when using washer fluid:

- Do not use coolant or antifreeze in the washer fluid reservoir. Coolant can severely obscure visibility when sprayed on the windshield and may cause loss of vehicle control resulting in an accident or damage to paint and body trim.
- Do not allow sparks or flame to contact the washer fluid or the washer fluid reservoir. Washer fluid may contain alcohol and can be flammable.
- Do not drink washer fluid and avoid contact with skin. Washer fluid is harmful to humans and animals.
- Keep washer fluid away from children and animals.

## **CABIN AIR FILTER**

## **Filter Inspection**

The cabin air filter must be replaced according to the Maintenance Schedule. If the vehicle is operated in severely airpolluted cities or on dusty rough roads for a long period, it should be inspected more frequently and replaced sooner. Replace the cabin air filter by following the procedure below and be careful to avoid damaging other components.


## Filter Replacement



(1) Open the glove box and remove the support rod (1).



(2) Remove the stoppers on both sides to allow the glove box to hang open.



- (3) Press and hold the lock (1) on the left side of the cover.
- (4) Pull out (2) the cover.
- (5) Replace the cabin air filter.
- (6) Reassemble in the reverse order of disassembly.

## Motor compartment (if equipped)



- (1) Remove the cover by pushing out the retainer clip with a slim tool.
- (2) Press and hold the lock on the left side of the cover and then pull the cover out.
- (3) Replace the cabin air filter.
- (4) Reassemble in the reverse order of disassembly.

## NOTICE



Install a new cabin air filter with the arrow symbol (4) facing down to improve effectiveness.

## WIPER BLADES

## **Blade Inspection**

Contamination of either the windshield or the wiper blades with foreign matter can reduce the effectiveness of the windshield wipers.

Common sources of contamination are insects, tree sap, and hot wax treatments used by some commercial car washes. If the blades are not wiping properly, clean both the window and the blades with a good cleaner or mild detergent, and rinse thoroughly with clean water. Replace blades as needed.

## NOTICE

To prevent damage to the wiper blades, arms or other components, do not:

- Use gasoline, kerosene, paint thinner, or other solvents on or near them.
- · Attempt to move the wipers manually.

## **Blade Replacement**

When the wipers no longer clean adequately, the blades may be worn or cracked. Replace the wipers with new ones.

## NOTICE

To prevent damage:


- Never use non-specified wiper blades.
- Lift the wiper arms when in the top wiping position.
- Always return the wiper arms to the windshield before driving.

# Front windshield wiper blade replacement



This vehicle has a "hidden" wiper design which means that the wipers cannot be lifted manually when they are in their bottom resting position.

- (1) Within 20 seconds of turning off the vehicle, lift up and hold the wiper lever to the MIST position for about 2 seconds until the wipers move to the top wipe position.
- (2) Lift the wipers off the windshield.



(3) Lift up the wiper blade clip (1). Then lift up the wiper blade (2).



(4) While pushing the lock (3), pull down the wiper blade (4).




- (5) Remove the wiper blade from the wiper arm (5).
- (6)Install the new blade assembly in the reverse order of removal.
- (7) Return the wiper arm on the windshield.
- (8) Turn the wipers to any ON position to return the wiper arms to the bottom resting position.

# Rear window wiper blade replacement



- (1) Raise the wiper arm and then rotate the wiper blade assembly (1).
- (2) Pull out the wiper blade assembly (2).



- (3) Install the new blade assembly by inserting the center part into the slot in the wiper arm until it clicks into place (3).
- (4) Make sure the blade assembly is installed firmly by trying to pull it slightly.
- (5) Rotate back the blade assembly so that it aligns with the wiper arm.

To prevent damage to the wiper arms or other components, have the wiper blades replaced by an authorized retailer of Genesis Branded products.

## **BATTERY (12 V)**



## WARNING

To prevent SERIOUS INJURY or DEATH to you or bystanders, always follow these precautions when working near or handling the battery:



Always read and follow instructions carefully when handling a battery.



Wear eye protection designed to protect the eyes from acid splashes.



Keep all flames, sparks, or smoking materials away from the battery.



Hydrogen gas is always present in battery cells. It is highly combustible, and may explode if ignited.



Keep batteries out of reach of children.

Batteries contain sulfuric acid that is highly corrosive. Do not allow acid to contact your eyes, skin, or clothing.



If acid gets into your eyes, flush your eyes with clean water for at least 15 minutes and get immediate medical attention. If acid gets on your skin, thoroughly wash the area. If you feel pain or a burning sensation, get medical attention immediately.

- Lift a battery with a battery carrier or with your hands on opposite corners. When lifting a plastic-cased battery, excessive pressure on the case may cause battery acid to leak.
- Do not attempt to jump start your vehicle if your battery is frozen.
- NEVER attempt to recharge the battery when the vehicle's battery cables are connected to the battery.

 The electrical ignition switch works with high voltage. NEVER touch these components with the Start/Stop button in the ON or START position.



## WARNING


CALIFORNIA PROPOSITION 65
WARNING Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer, birth defects and reproductive harm. Batteries also contain other chemicals known to the State of California to cause cancer. Wash hands after handling.

## NOTICE

To prevent battery damage:


- When you do not use the vehicle for a long time in a low temperature area, disconnect the battery and keep it indoors.
- Always fully charge the battery to prevent battery case damage in low temperature areas.
- Prevent liquid from wetting the battery terminals.
- Do not tilt the battery.
- Never connect unauthorized devices to the battery.

## **For Best Battery Service**



- Keep the battery securely mounted.
- Keep the battery top clean and dry.
- Keep the terminals and connections clean, tight, and coated with petroleum jelly or terminal grease.
- Rinse any spilled electrolyte from the battery immediately with a solution of water and baking soda.
- If the vehicle is not going to be used for an extended time, disconnect the battery cables.
- Inspect the battery frequently and keep the battery clean at all times.
   Leaving the battery contaminated will shorten battery life.
- Before recharging the battery or performing any inspections, turn off the vehicle and all electrical equipment.

## **Battery Replacement**



When replacing the battery, disconnect negative (-) cable (1) and remove positive (+) battery fuse box (2). Reassemble in the reverse order of disassembly.

## **Battery Capacity Label**



- \* The actual battery label in the vehicle may differ from the illustration.
- (1) AGM60R-DIN(12V): The Genesis Branded Vehicle model name of battery
- (2) 60Ah (20HR): The nominal capacity (in Ampere hours)
- (3) CCA 640A: The cold-test current in amperes by SAE/EN
- (4) RC 100min: The nominal reserve capacity (in min.)

## 12 V Battery Recharging

## By battery charger

Should your vehicle's 12 V battery become discharged either run the motor for at least 60 minutes driving. Alternatively you may connect a fully automatic regulated charger to the battery in the motor compartment.

# **MARNING**

Always follow these instructions when recharging your vehicle's battery to avoid the risk of SERIOUS INJURY or DEATH from explosions or acid burns:

- Before performing maintenance or recharging the battery, turn off all accessories and stop the vehicle.
- Keep all flames, sparks, or smoking materials away from the battery.
- Always work outdoors or in an area with plenty of ventilation.
- Wear eye protection when checking the battery during charging.
- The battery must be removed from the vehicle and placed in a well ventilated area.
- Watch the battery during charging, and stop or reduce the charging rate if the battery cells begin boiling violently.

- Remove the negative battery cable first and install it last when the battery is disconnected. Disconnect the battery charger in the following order:
  - 1. Turn off the battery charger main switch.
  - 2. Unhook the negative clamp from the negative battery terminal.
  - 3. Unhook the positive clamp from the positive battery terminal.

## NOTICE

## AGM battery

Absorbent Glass Mat (AGM) batteries are maintenance-free and have the AGM battery be serviced by an authorized retailer of Genesis Branded products. Only charge using fully automatic battery chargers that are specifically for AGM batteries.

## CAUTION

Do not open or remove the cap on top of the battery. This may cause leaks of internal electrolyte that could result in serious injury.

## By jump starting

After a jump start from a good battery, drive the vehicle for 20-30 minutes before it is shutoff. The vehicle may not restart if you shut it off before the battery had a chance to adequately recharge. Refer to the "Jump Starting" section in chapter 8 for more information on jump starting procedures.





An inappropriately disposed battery can be harmful to the environment and human health. Dispose of the battery according to your local law(s) or regulation.

#### **Reset Items**

The following items may need to be reset after the battery has been discharged or the battery has been disconnected:

- Driving info/After recharging/ Accumulated info (items in Utility view) (refer to chapter 4)
- Integrated memory system (refer to chapter 5)
- Power window (refer to chapter 5)
- Power liftgate (refer to chapter 5)
- Climate control system (refer to chapter 5)
- Clock (refer to the Infotainment system manual)
- Infotainment system (refer to the Infotainment system manual)

#### **TIRES AND WHEELS**

# **MARNING**

Tire failure may cause loss of vehicle control resulting in an accident. To reduce risk of SERIOUS INJURY or DEATH, take the following precautions:

- Inspect your tires monthly for proper inflation as well as wear and damage.
- The recommended cold tire pressure for your vehicle can be found in this manual and on the tire label located on the driver's side center pillar. Always use a tire pressure gauge to measure tire pressure. Tires with too much or too little pressure wear unevenly causing poor handling.
- Check the pressure of the spare(if equipped) every time you check the pressure of the other tires on your vehicle.
- Replace tires that are worn, show uneven wear, or are damaged.
   Worn tires can cause loss of braking effectiveness, steering control, or traction.
- ALWAYS replace tires with the same size, type, construction and tread pattern as each tire that was originally supplied with this vehicle. Using tires and wheels other than the recommended sizes could cause unusual handling characteristics, poor vehicle control, or negatively affect your vehicle's Anti-Lock Brake System (ABS) resulting in a serious accident.

#### **Tire Care**

For proper maintenance, safety, and maximum electric energy economy, you must always maintain recommended tire inflation pressures and stay within the load limits and weight distribution recommended for your vehicle.



All specifications (sizes and pressures) can be found on a label attached to the driver's side center pillar.

# Recommended Cold Tire Inflation Pressures

All tire pressures (including the spare) should be checked when the tires are cold. "Cold tires" means the vehicle has not been driven for at least three hours or driven less than one mile (1.6 km).

Warm tires normally exceed recommended cold tire pressures by 4 to 6 psi (28 to 41 kPa). Do not release air from warm tires to adjust the pressure or the tires will be under-inflated. For recommended inflation pressure, refer to the "Tire and Wheels" section in chapter 2.

# **MARNING**

- Recommended pressures must be maintained for the best ride, vehicle handling, and minimum tire wear.
- Over-inflation or under-inflation can reduce tire life, adversely affect vehicle handling, and lead to sudden tire failure that may result in loss of vehicle control resulting in a collision.
- Severe under-inflation may lead to severe heat build-up, causing blowouts, tread separation, and other tire failures that result in loss of vehicle control resulting in a collision. This risk is much higher on hot days and when driving for a long time at high speeds.
- Under-inflation may cause excessive wear, poor handling, and reduced fuel economy. Wheel deformation is also possible. Keep your tire pressures at the proper levels. If a tire frequently needs refilling, have it inspected by an authorized retailer of Genesis Branded products.
- Over-inflation produces a harsh ride, excessive wear at the center of the tire tread, and a greater possibility of damage from road hazards.

#### **Check Tire Inflation Pressure**

Check your tires, including the spare tire (if equipped), once a month or more.

#### How to check

Use a good quality tire pressure gauge to check tire pressure. You can not tell if your tires are properly inflated simply by looking at them. Radial tires may look properly inflated when they are underinflated.

Remove the valve cap from the tire valve stem. Press the tire gauge firmly onto the valve to get a pressure measurement. If the cold tire inflation pressure matches the recommended pressure on the tire and loading information label, no further adjustment is necessary. If the pressure is low, add air until you reach the recommended pressure. Make sure to put the valve caps back on the valve stems. Without the valve cap, dirt or moisture could get into the valve core and cause air leakage. If a valve cap is missing, install a new one as soon as possible.

If you overfill the tire, release air by pushing on the metal stem in the center of the tire valve. Recheck the tire pressure with the tire gauge. Be sure to put the valve caps back on the valve stems. Without the valve cap, dirt or moisture could get into the valve core and cause air leakage. If a valve cap is missing, install a new one as soon as possible.

#### **Tire Rotation**

To equalize tread wear, Genesis Branded Vehicle recommends that the tires be rotated according to the maintenance schedule or sooner if irregular wear develops.

During rotation, check the tires for correct balance.

When rotating tires, check for uneven wear and damage. Abnormal wear is usually caused by incorrect tire pressure, improper wheel alignment, out-of-balance wheels, severe braking or severe cornering. Look for bumps or bulges in the tread or side of the tire. Replace the tire if you find any of these conditions. Replace the tire if fabric or cord is visible. After rotation, be sure to bring the front and rear tire pressures to specification and check wheel bolt tightness (proper torque is 101-116 lbf.ft [14-16 kgf.m]).



Disc brake pads should be inspected for wear whenever tires are rotated.



# Information

When installing an unsymmetrical tire, install the side marked "outside" facing out.



# WARNING

- Do not use the compact spare tire for tire rotation.
- Do not mix bias ply and radial ply tires under any circumstances.
   This may cause unusual handling characteristics that may cause loss of vehicle control resulting in an collision.

# Wheel Alignment and Tire Balance

The wheels on your vehicle were aligned and balanced carefully at the factory to give you the longest tire life and best overall performance.

In most cases, you will not need to have your wheels aligned again. However, if you notice unusual tire wear or your vehicle pulling one way or the other, the alignment may need to be reset.

If you notice your vehicle vibrating when driving on a smooth road, your wheels may need to be rebalanced.

# NOTICE

Only use approved wheel weights or your vehicle's aluminum wheels may be damaged.

# **Tire Replacement**



[A]: Tread wear indicator

If the tire is worn evenly, a tread wear indicator will appear as a solid band across the tread. This shows there is less than 1/16 inches (1.6 mm) of tread left on the tire. Replace the tire when this happens.

Do not wait for the band to appear across the entire tread before replacing the tire.

# **WARNING**

To reduce the risk of DEATH or SERIOUS INJURY:

- Replace tires that are worn, show uneven wear, or are damaged.
   Worn tires can cause loss of braking effectiveness, steering control, and traction.
- Always replace tires with the same size as each tire that was originally supplied with this vehicle. Using tires and wheels other than the recommended sizes could cause unusual handling characteristics, poor vehicle control, or negatively affect your vehicle's Anti-Lock Brake System (ABS) resulting in a serious accident.

- When replacing tires (or wheels), it is recommended to replace the two front or two rear tires (or wheels) as a pair. Replacing just one tire can seriously affect your vehicle's handling.
- Tires degrade over time, even when they are not being used. Regardless of the remaining tread, Genesis Branded Vehicle recommends that tires be replaced after six (6) years of normal service.
- Heat caused by hot climates or frequent high loading conditions can accelerate the aging process.
   Failure to follow this warning may cause sudden tire failure, which could lead to a loss of vehicle control resulting in an accident.

# Compact spare tire (if equipped) replacement

A compact spare tire has a shorter tread life than a regular size tire. Replace it when you can see the tread wear indicator bars on the tire. The replacement compact spare tire should be the same size and design tire as the one provided with your new vehicle and should be mounted on the same compact spare tire wheel. The compact spare tire is not designed to be mounted on a regular size wheel, and the compact spare tire wheel is not designed for mounting a regular size tire.

# ! WARNING

The original tire should be repaired or replaced as soon as possible to avoid failure of the spare (if equipped) and loss of vehicle control resulting in an accident. The compact spare tire (if equipped) is for emergency use only. Do not operate your vehicle over 50 mph (80 km/h) when using the compact spare tire.

## Wheel Replacement

When replacing the metal wheels for any reason, make sure the new wheels are equivalent to the original factory units in diameter, rim width, and offset.

#### **Tire Traction**

Tire traction can be reduced if you drive on worn tires, tires that are improperly inflated or on slippery road surfaces. Tires should be replaced when tread wear indicators appear. To reduce the possibility of losing control, slow down whenever there is rain, snow or ice on the road.

#### Tire Maintenance

In addition to proper inflation, correct wheel alignment helps to decrease tire wear. If you find a tire is worn unevenly, have your dealer check the wheel alignment.

When you have new tires installed, make sure they are balanced. This will increase vehicle ride comfort and tire life. Additionally, a tire should always be rebalanced if it is removed from the wheel.

# **Tire Sidewall Labeling**

This information identifies and describes the fundamental characteristics of the tire and also provides the tire identification number (TIN) for safety standard certification. The TIN can be used to identify the tire in case of a recall.



# 1. Manufacturer or brand name Manufacturer or brand name is shown.

# 2. Tire size designation

A tire's sidewall is marked with a tire size designation. You will need this information when selecting replacement tires for your car. The following explains what the letters and numbers in the tire size designation mean.

Example tire size designation:

(These numbers are provided as an example only; your tire size designator could vary depending on your vehicle.)

#### 265/45 R20 101H

- 265 Tire width in millimeters.
- 45 Aspect ratio. The tire's section height as a percentage of its width.
- R Tire construction code (Radial).
- 20 Rim diameter in inches.
- 101 Load Index, a numerical code associated with the maximum load the tire can carry.
- H Speed Rating Symbol. See the speed rating chart in this section for additional information.

#### Wheel size designation

Wheels are also marked with important information that you need if you ever have to replace one. The following explains what the letters and numbers in the wheel size designation mean.

Example wheel size designation:

#### 8.5J X 20

- 8.5 Rim width in inches.
- J Rim contour designation.
- 20 Rim diameter in inches.

## Tire speed ratings

The chart below lists many of the different speed ratings currently being used for passenger vehicle tires. The speed rating is part of the tire size designation on the sidewall of the tire. This symbol corresponds to that tire's designed maximum safe operating speed.

Speed Rating Symbol	Maximum Speed
S	112 mph (180 km/h)
Т	118 mph (190 km/h)
Н	130 mph (210 km/h)
V	149 mph (240 km/h)
W	168 mph (270 km/h)
Υ	186 mph (300 km/h)

# 3. Checking tire life (TIN: Tire Identification Number)

Any tires that are over six years old, based on the manufacturing date, (including the spare tire) should be replaced by new ones. You can find the manufacturing date on the tire sidewall (possibly on the inside of the wheel), displaying the DOT Code. The DOT Code is a series of numbers on a tire consisting of numbers and English letters. The manufacturing date is designated by the last four digits (characters) of the DOT code.

#### DOT: XXXX XXXX OOOO

The front part of the DOT shows a plant code number, tire size and tread pattern and the last four numbers indicate week and year manufactured.

## For example:

DOT XXXX XXXX 5222 represents that the tire was produced in the 52nd week of 2022.

#### 4. Genesis exclusive tire

Genesis Branded Vehicle recommends that tires designed specifically for Genesis vehicles be used. You may find the marking "GOE" (Genesis Original Equipment) embossed on the tire sidewall.

# 5. Tire ply composition and material

The number of layers or plies of rubber-coated fabric in the tire. Tire manufacturers also must indicate the materials in the tire, which include steel, nylon, polyester, and others. The letter "R" means radial ply construction; the letter "D" means diagonal or bias ply construction; and the letter "B" means belted-bias ply construction.

# 6. Maximum permissible inflation pressure

This number is the greatest amount of air pressure that should be put in the tire. Do not exceed the maximum permissible inflation pressure. Refer to the Tire and Loading Information label for recommended inflation pressure.

#### 7. Maximum load rating

This number indicates the maximum load in kilograms and pounds that can be carried by the tire. When replacing the tires on the vehicle, always use a tire that has the same load rating as the factory installed tire.

# 8. DOT Tire Quality Grading (U.S Vehicles)

The tires on your vehicle meet all U.S. Federal Safety Requirements. All tires are also graded for treadwear, traction, and temperature performance according to Department of Transportation (DOT) standards.

#### Uniform tire quality grading

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

For example:

TREADWEAR 200 TRACTION AA TEMPERATURE A

#### Tread wear

The tread wear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. For example, a tire graded 150 would wear one-and-a-half times (1½) as well on the government course as a tire graded 100.

The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

These grades are molded on the sidewalls of passenger vehicle tires. The tires available as standard or optional equipment on your vehicle may vary with respect to grade.

#### Traction - AA, A, B & C

The traction grades, from highest to lowest, are AA, A, B and C. Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.



#### WARNING

The traction grade assigned to this tire is based on straight ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

#### Temperature - A, B & C

The temperature grades are A (the highest), B and C representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel.

Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.



# WARNING

The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, under-inflation, over-inflation, or excessive loading, either separately or in combination, can cause heat build-up and possible sudden tire failure. This may cause loss of vehicle control resulting in an accident.

# Tire Terminology and Definitions

#### Air pressure

The amount of air inside the tire pressing outward on the tire. Air pressure is expressed in pounds per square inch (psi) or kilopascal (kPa).

## Accessory weight

This means the combined weight of optional accessories. Some examples of optional accessories are automatic transmission, power seats, and air conditioning.

## Aspect ratio

The relationship of a tire's height to its width.

#### Belt

A rubber coated layer of cords that is located between the plies and the tread. Cords may be made from steel or other reinforcing materials.

#### Bead

The tire bead contains steel wires wrapped by steel cords that hold the tire onto the rim.

# Bias ply tire

A pneumatic tire in which the plies are laid at alternate angles less than 90 degrees to the centerline of the tread.

# Cold tire pressure

The amount of air pressure in a tire, measured in pounds per square inch (psi) or kilopascals (kPa) before a tire has built up heat from driving.

#### **Curb** weight

This means the weight of a motor vehicle with standard and optional equipment including the maximum capacity of fuel, oil and coolant, but without passengers and cargo.

## **DOT** markings

A code molded into the sidewall of a tire signifying that the tire is in compliance with the U.S. Department of Transportation motor vehicle safety standards. The DOT code includes the Tire Identification Number (TIN), an alphanumeric designator which can also identify the tire manufacturer, production plant, brand and date of production.

#### **GVWR**

Gross Vehicle Weight Rating

#### **GAWR FRT**

Gross Axle Weight Rating for the Front Axle.

#### **GAWR RR**

Gross Axle Weight Rating for the Rear axle.

#### Intended outboard sidewall

The side of an asymmetrical tire, that must always face outward when mounted on a vehicle.

#### Kilopascal (kPa)

The metric unit for air pressure.

## Light Truck (LT) tire

A tire designated by its manufacturer as primarily intended for use on lightweight trucks or multipurpose passenger vehicles.

#### Load ratings

The maximum load that a tire is rated to carry for a given inflation pressure.

#### Load index

An assigned number ranging from 1 to 279 that corresponds to the load carrying capacity of a tire.

## Maximum inflation pressure

The maximum air pressure to which a cold tire may be inflated. The maximum air pressure is molded onto the sidewall.

# Maximum load rating

The load rating for a tire at the maximum permissible inflation pressure for that tire.

## Maximum loaded vehicle weight

The sum of curb weight; accessory weight; vehicle capacity weight; and production options weight.

# Normal occupant weight

The number of occupants a vehicle is designed to seat multiplied by 150 lbs. (68 kg).

# Occupant distribution

Designated seating positions.

# Outward facing sidewall

An asymmetrical tire has a particular side that faces outward when mounted on a vehicle. The outward facing sidewall bears white lettering or bears manufacturer, brand, and/or model name molding that is higher or deeper than the same moldings on the inner facing sidewall.

# Passenger (P-Metric) tire

A tire used on passenger cars and some light duty trucks and multipurpose vehicles.

#### Ply

A layer of rubber-coated parallel cords.

#### Pneumatic tire

A mechanical device made of rubber, chemicals, fabric and steel or other materials, that, when mounted on an automotive wheel provides the traction and contains the gas or fluid that sustains the load.

## Pneumatic options weight

The combined weight of installed regular production options weighing over 5 lbs. (2.3 kg) in excess of the standard items which they replace, not previously considered in curb weight or accessory weight, including heavy duty breaks, ride levelers, roof rack, heavy duty battery, and special trim.

#### Recommended inflation pressure

Vehicle manufacturer's recommended tire inflation pressure as shown on the tire placard.

# Radial ply tire

A pneumatic tire in which the ply cords that extend to the beads are laid at 90 degrees to the centerline of the tread.

#### Rim

A metal support for a tire and upon which the tire beads are seated.

#### Sidewall

The portion of a tire between the tread and the bead.

# Speed rating

An alphanumeric code assigned to a tire indicating the maximum speed at which a tire can operate.

#### **Traction**

The friction between the tire and the road surface. The amount of grip provided.

#### Tread

The portion of a tire that comes into contact with the road.

#### Treadwear indicators

Narrow bands, sometimes called "wear bars", that show across the tread of a tire when only 1/16 inch of tread remains.

#### **UTQGS**

Uniform Tire Quality Grading Standards is a tire information system that provides consumers with ratings for a tire's traction, temperature and treadwear. Ratings are determined by tire manufacturers using government testing procedures. The ratings are molded into the sidewall of the tire.

## Vehicle capacity weight

The number of designated seating positions multiplied by 150 lbs. (68 kg) plus the rated cargo and luggage load.

Vehicle maximum load on the tire Load on an individual tire due to curb and accessory weight plus maximum occupant and cargo weight.

Vehicle normal load on the tire
Load on an individual tire that is
determined by distributing to each
axle its share of the curb weight,
accessory weight, and normal
occupant weight and dividing by 2.

#### Vehicle placard

A label permanently attached to a vehicle showing the original equipment tire size and recommended inflation pressure.

#### **All Season Tires**

Genesis Branded Vehicle specifies all season tires on some models to provide good performance for use all year round, including snowy and icy road conditions. All season tires are identified by ALL SEASON and/ or M+S (Mud and Snow) on the tire sidewall. Snow tires have better snow traction than all season tires and may be more appropriate in some areas.

#### **Summer Tires**

Genesis Branded Vehicle specifies summer tires on some models to provide superior performance on dry roads. Summer tire performance is substantially reduced in snow and ice. Summer tires do not have the tire traction rating M+S (Mud and Snow) on the tire side wall. If you plan to operate your vehicle in snowy or icy conditions, Genesis Branded Vehicle recommends the use of snow tires or all season tires on all four wheels.

#### **Snow Tires**

If you equip your car with snow tires, they should be the same size and have the same load capacity as the original tires. Snow tires should be installed on all four wheels: otherwise, poor handling may result. Snow tires should carry 4 psi (28 kPa) more air pressure than the pressure recommended for the standard tires on the tire label on the driver's side of the center pillar, or up to the maximum pressure shown on the tire sidewall, whichever is less. Do not drive faster than 75 mph (120 km/h) when your vehicle is equipped with snow tires.

## **Radial-Ply Tires**

Radial-ply tires provide improved tread life, road hazard resistance and smoother high speed ride. The radial-ply tires used on this vehicle are of belted construction, and are selected to complement the ride and handling characteristics of your vehicle. Radial-ply tires have the same load carrying capacity, as bias-ply or bias belted tires of the same size, and use the same recommended inflation pressure. Mixing of radial-ply tires with bias-ply or bias belted tires is not recommended. Any combinations of radial-ply and bias-ply or bias belted tires when used on the same vehicle will seriously deteriorate vehicle handling. The best rule to follow is: Identical pairs of radial-ply tires should always be used as a set for the front tires and a set for the rear tires.

Longer wearing tires can be more susceptible to irregular tread wear. It is very important to follow the tire rotation interval in this chapter to achieve the tread life potential of these tires. Cuts and punctures in radial-ply tires are repairable only in the tread area, because of sidewall flexing. Consult your tire dealer for radial-ply tire repairs.

# **MARNING**

Do not mix bias ply and radial ply tires under any circumstances. This may cause unusual handling characteristics that may cause loss of vehicle control resulting in an accident.

# Low Aspect Ratio Tires (if equipped)

The aspect ratio is lower than 50 on low aspect ratio tires.


Because low aspect ratio tires are optimized for handling and braking, their sidewall is a little stiffer than a standard tire. Also low aspect ratio tires tend to be wider and consequently have increased contact with the road surface. In some instances, low aspect ratio tires may generate more road noise compared with standard tires.

## NOTICE

Low-aspect wheels and tires are easily damaged. To reduce the risk of damage:

- When driving on rough roads, passing over a pothole, speed bump, manhole, or curb stone, drive the vehicle slowly not to damage the tires and wheels. Damage is not covered by your vehicle warranty.
- Inspect the tire condition and pressure every 8,000 miles (13,000 km).
- It is difficult to visually inspect for tire damage with your eyes. If any damage is found, contact your authorized retailer of Genesis Branded products to replace the tire

#### **FUSES**



[A]: Blade type, [B]: Cartridge type,

[C]: Multi type, [D]: Midi type

O: Normal, X: Blown

A vehicle's electrical system is protected from electrical overload damage by fuses.

This vehicle has 4 fuse panels, one located in the driver's side panel bolster, the other in the vehicle compartment.

If any of your vehicle's lights, accessories, or controls do not work, check the appropriate circuit fuse. If a fuse has blown, the element inside the fuse will be melted or broken.

If the electrical system does not work, first check the driver's side fuse panel. Before replacing a blown fuse, turn the vehicle and all switches off, and then disconnect the negative battery cable. Always replace a blown fuse with one of the same rating.

If the replacement fuse blows, this indicates an electrical problem. Avoid using the system involved. Consult an authorized retailer of Genesis Branded products.

# A

# WARNING

NEVER replace a fuse with anything but another fuse of the same rating.

- A higher capacity fuse may cause damage and possibly cause a fire.
- Do not install a wire or aluminum foil instead of the proper fuse - even as a temporary repair. It may cause extensive wiring damage and possibly a fire.

# NOTICE

Do not use a screwdriver or any other metal object to remove fuses because it may cause a short circuit and damage the system.

# Instrument Panel Fuse Replacement



[A]: Driver's side

- (1) Turn off the vehicle.
- (2) Turn off all other switches.
- (3) Open the fuse panel cover.
- (4) Refer to the label on the inside of the fuse panel cover to locate the suspected fuse location.



[B]: Motor compartment

(5) Pull the suspected fuse straight out. Use the removal tool (1) provided in the motor compartment fuses panel cover.

- (6) Check the removed fuse and replace it if it is blown. Spare fuses are provided in the instrument panel fuse panels (or in the motor compartment fuse panel).
- (7) Push in a new fuse of the same rating, and make sure it fits tightly in the clips. If it is not tight, contact an authorized retailer of Genesis Branded products.

In an emergency, if you do not have a spare fuse, use a fuse of the same rating from a circuit you may not need for operating the vehicle.

If the headlights or other electrical components do not work and the fuses are undamaged, check the fuse panel in the motor compartment.

# **Motor Compartment Panel Fuse** Replacement

Blade fuse/Cartridge fuse



OJKEV091015

[A]: Blade type fuse, [B]: Cartridge type fuse

- (1) Turn off the vehicle.
- (2) Turn off all other switches.
- (3) Remove the fuse panel cover by pressing the tap and pulling up.
- (4) Check the removed fuse and replace it if it is blown. To remove or insert the fuse, use the fuse puller in the motor compartment fuse panel.
- (5) Push in a new fuse of the same rating, and make sure it fits tightly in the clips. If it is not tight, contact an authorized retailer of Genesis Branded products.

# NOTICE

Always securely install the fuse panel cover. Water may contact the fuse and cause an electrical failure.

#### Multi fuse





[C]: Multi type, [D]: Midi type

If the multi fuse or midi fuse is blown, contact an authorized retailer of Genesis Branded products.


# Fuse/Relay Panel Description Instrument panel fuse panel



Inside the fuse panel cover, you can find the fuse label describing fuse names and ratings.



Not all fuse panel descriptions in this manual may be applicable to your vehicle. When you inspect the fuse panel on your vehicle, refer to the fuse panel label.



# Instrument panel fuse panel

Fuse name	Fuse rating	Circuit protected	
MODULE9	10 A	Overhead Console, Electro Chromic Mirror, Inverter (Rear) Driver/Passenger Power Seat Module, Smartphone Wireless Charger, Rear Seat Warmer Control Module, Fingerprint Recognition Device, Rear Air Ventilation Seat Control Module, AMP, A/V & Navigation Head Unit	
MODULE11	10 A	Head Light LH, Head Light RH, Multifunction Switch, ADAS Unit (Parking), Rear Junction Block (Rear Wiper Relay)	
MODULE12	10 A	IAU, IBU	
A/C2	10 A	A/C Control Module, Front/Rear A/C Controller	
A/BAG IND	10 A	Instrument Cluster, Overhead Console	
E-SHIFTER4	10 A	Electronic Shift Dial	
SPARE(IG2)	15 A	Spare	
MODULE10	10 A	ICU Junction Block (ESU)	
MODULE7	10 A	Driver Door Module, Stop Light Switch, IBU, IAU, Multifunction Switch	
MULTIMEDIA	15 A	A/V & Navigation Head Unit	
MODULE13	10 A	Head-Up Display, Garnish Mood Light RH, Fingerprint Recognition Device, A/V & Navigation Keyboard, Security Indicator, Instrument Cluster, A/C Control Module, Front/ Rear A/C Controller, Front Console Switch, Crash Pad Switch, Console Mood Light, ICU Junction Block (ESU) Mood Light Unit, Driver/Passenger Mood Light #1/#2, Rear Door Mood Light LH/RH #1/#2	

# Instrument panel fuse panel

Fuse name	Fuse rating	Circuit protected
CLUSTER	10 A	Head-Up Display, Instrument Cluster
IBU2	10 A	IBU
A/BAG2	15 A	SRS Control Module
PRESAFETY SEAT BELT3	10 A	Pre-Active Seat Belt Unit
MODULE8	10 A	Rear Corner Radar LH/RH, ECS Unit, Crash Pad Switch, Front View Camera ADAS Unit (Driving/Parking), Steering Tilt & Telescopic Unit,
MODULE5	10 A	UIP Sensor, UIP Siren, Rain Sensor, Data Link Connector, Multifunction Switch, Electro Chromic Mirror
MODULE3	10 A	Active Air Flap Module, Front Console Keyboard, VESS Unit, Steering Tilt & Telescopic Unit, Rear Occupant Alert Sensor, Clock Spring, Front/Rear Corner Radar LH/RH, NEMS Unit Smartphone Wireless Charger
P/WIN LH	30 A	Driver Safety Power Window Module (LHD), Passenger Safety Power Window Module (RHD), Rear Power Window Module LH
P/SEAT	10 A	Driver Lumbar Support Unit, Passenger Lumbar Support Unit
P/SEAT PASS2	25 A	Passenger Power Seat Switch, Passenger Power Seat Module
A/BAG1	15 A	SRS Control Module
E-SHIFTER3	10 A	Electronic Shift Dial
A/C1	10 A	P/R Junction Block (RLY.4), A/C Control Module

# Instrument panel fuse panel

Fuse name	Fuse rating	Circuit protected
S/ROOF	25 A	Sunroof Control Unit (Master)
P/SEAT DRV1	25 A	Driver Power Seat Module, Driver Power Seat Switch
MODULE2	10 A	Driver Door Module, Driver/Passenger Power Outside Mirror, Power Liftgate Module, Driver/Passenger Power Seat Switch, Driver/Passenger Lumbar Support Unit, Driver/Passenger Power Seat Module, Front radar
P/HANDLE	15 A	Steering Tilt & Telescopic Unit
SPARE(B+)	10 A	Spare
IBU1	10 A	BLE Unit, IAU, IBU, Driver/Passenger Door Outside Handle
P/SEAT DRV2	25 A	Driver Power Seat Module, Driver Power Seat Switch
P/SEAT PASS1	25 A	Passenger Power Seat Module, Passenger Power Seat Switch
S/HTR DRV	15 A	Driver Power Seat Module
S/HTR PASS1	15 A	Passenger Power Seat Module
Door Lock	20 A	ICU Junction Block (Center Door Lock Relay, Center Door Unlock Relay, Dead Lock Relay)
BATT Management	10 A	вми
MODULE4	10 A	CDM
MODULE6	10 A	Rear USB Charger, Armrest Light, Front Console Keyboard, AMP, IBU, Electronic Shift Dial, ADAS Unit (Parking), IAU, A/V & Navigation Head Unit, ICU Junction Block (ESU) P/R Junction Block (RLY.6)
BRAKE SWITCH	10 A	IBU, Stop Light Switch


# Motor compartment fuse panel



Inside the fuse panel cover, you can find the fuse label describing fuse names and ratings.

# *i* Information

Not all fuse panel descriptions in this manual may be applicable to your vehicle. When you inspect the fuse panel in your vehicle, refer to the fuse panel label.



# Motor compartment fuse panel

Туре	Fuse name	Fuse rating	Circuit protected
	MDPS1	100 A	MDPS Unit
MINE	LDC	255 A	ICCU
	B+7	150 A	P/R Junction Block (Fuse - S1, S2, S3, S4, F1, F2, F3, F4, F5), PCB Block (Fuse - S1, S2, S3, S4)
	FR WIPER	30 A	Front Wiper Motor
	VCU3	40 A	VCU
	P/OUTLET1	40 A	RLY.6
	E-SHIFTER1	40 A	RLY.2, Fuse (F11)
MULTI	RR HTD	40 A	RLY.1
	IEB3	60 A	IEB Unit
	IEB2	60 A	IEB Unit
	IEB1	60 A	IEB Unit
	C/FAN	100 A	Cooling Fan Motor
	H/LP LH	30 A	Head Light LH
SB	EOP1	40 A	Electronic Traction Motor Oil Pump (Front)
	EOP2	40 A	Electronic Traction Motor Oil Pump (Rear)
	BLOWER	40 A	RLY.4
	H/LP RH	30 A	Head Light RH

# Motor compartment fuse panel

Туре	Fuse name	Fuse rating	Circuit protected
	EWP1	20 A	Electronic Water Pump (BSA #1)
	OBC	10 A	ICCU, VCMS
	VCU1	20 A	VCU
	VCU2	20 A	VCU
	EWP2	20 A	Electronic Water Pump (BSA #2)
	HORN	15 A	PCB Block (Horn Relay)
MICRO	EPCU1	10 A	Inverter (Front)
MIORO	B/ALARM	15 A	RLY.5
	IG3 8	20 A	PCB Block (IG3 #2 Relay)
	E-SHIFTER2	10 A	SCU
	MIRR HTD	10 A	Front A/C Controller, Driver/Passenger Power Outside Mirror
	P/OUTLET2	20 A	Luggage Power Outlet
	P/OUTLET3	20 A	Front Power Outlet


# Cargo area fuse panel (Rear sub junction block)



Inside the fuse panel cover, you can find the fuse label describing fuse names and ratings.



Not all fuse panel descriptions in this manual may be applicable to your vehicle. When you inspect the fuse panel in your vehicle, refer to the fuse panel label.



# Rear junction block

Fuse name	Fuse rating	Circuit protected	
B+2	30 A	ICU Junction Block(IPS2, IPS5, IPS6, Fuse: F22, F29, F30, F37, F38, F46, F47)	
CHILD LOCK	15 A	Child Lock/Unlock Relay	
P/WIN RH	30 A	Passenger Safety Power Window Module (LHD), Driver Safety Power Window Module (RHD), Rear Power Window Module RH	
AMP	25 A	AMP	
PRESAFETY S/ BELT1	30 A	Pre-active Seat Belt Unit	
ECS	15 A	ECS Unit	
WIPER RR	15 A	Rear Wiper Relay, Rear Wiper Motor	
EPCU2	10 A	Inverter (Rear)	
S/HTR PASS2	15 A	Passenger Power Seat Module	
PRESAFETY S/ BELT2	30 A	Pre-active Seat Belt Unit	
CHARGER	15 A	Charging Connector Lock/Unlock Relay	
S/HTR RR1	20 A	Rear Air Ventilation Seat Control Module, Rear Seat Warmer Control Module	
PTGM	30 A	Power Liftgate Module	
S/HTR RR2	20 A	Rear Air Ventilation Seat Control Module, Rear Seat Warmer Control Module	


# Cargo area fuse panel (Battery junction block)



Inside the fuse panel cover, you can find the fuse label describing fuse names and ratings.



Not all fuse panel descriptions in this manual may be applicable to your vehicle. When you inspect the fuse panel in your vehicle, refer to the fuse panel label.



# **Battery junction block**

Fuse name	Fuse rating	Circuit protected	
TRAILER	50 A	Trailer Connector	
B+1	50 A	ICU Junction Block (IPS1, IPS3, IPS4, IPS7, Short/Long Term Load Latch Relay, Fuse: F50)	
B+3	50 A	ICU Junction Block (Fuse: F26, F33, F36, F34, F41, F42, F43, F44)	
B+4	50 A	ICU Junction Block (Fuse: F27, F31, F45)	
B+6	100 A	Rear Junction Block (Fuse: F3, F6, F9, F12, F14, F16, F17, F19, F20, F22, F24, F25, F26, S1)	
AMS	10 A	12 V Battery Sensor	

#### LIGHT BULBS

Consult an authorized retailer of Genesis Branded products to replace most vehicle light bulbs. It is difficult to replace vehicle light bulbs because other parts of the vehicle must be removed before you can get to the bulb. This is especially true for removing the headlight assembly to get to the bulb(s). Removing/installing the headlight assembly can result in damage to the vehicle.



- Prior to replacing a light bulb, depress
  the brake pedal, shift to P (Park),
  apply the parking brake, press the
  Start/Stop button to the OFF position,
  and take the key with you when
  leaving the vehicle to avoid sudden
  movement of the vehicle and to
  prevent possible electric shock.
- Be aware the bulbs may be hot and may burn your fingers.

# NOTICE

Be sure to replace the burned-out bulb with one of the same wattage to prevent damage to the fuse or electrical wiring system.

# NOTICE

To prevent damage, do not clean the headlight lens with chemical solvents or strong detergents.

# i Information - Headlight desiccant

This vehicle is equipped with desiccant to reduce fogging inside the headlight due to moisture. The desiccant is consumable and its performance may change based on the used period or environment. If fogging inside the headlight due to moisture continues for a long time, contact an authorized retailer of Genesis Branded products.



## Information

The headlight and tail light lenses could appear to have condensation inside if the vehicle is washed after driving or if the vehicle is driven in wet weather. This condition is caused by a higher temperature inside the light and a cooler outside temperature. Moisture that condenses in the light is removed after driving with the light on. If the moisture is not removed, contact an authorized retailer of Genesis Branded products.



## Information

- A normally functioning light may flicker momentarily to stabilize the vehicle's electrical control system. However, if the light goes out after flickering momentarily, or continues to flicker, have the system inspected by an authorized retailer of Genesis Branded products.
- The parking light may not turn on when the parking light switch is turned on, but the parking light and headlight switch may turn on when the headlight switch is turned on. This may be caused by network failure or vehicle electrical control system malfunction. If this occurs, contact an authorized retailer of Genesis Branded products.



# Information

Adjust the headlight aim after an accident or the headlight is replaced.

# Headlight, Parking Light, Turn Signal Light, Daytime Running Light (DRL) Replacement



- (1) Headlight (Low)
- (2) Headlight (High/Sub low)
- (3) Parking light/Daytime running light/ Turn signal light
- (4) Front side marker

If the LED light does not operate, contact an authorized retailer of Genesis Branded products for replacement.

The LED light cannot be replaced as a single unit. A skilled technician should check or repair the LED light, for it may damage related parts of the vehicle.

# **Puddle Light Replacement**



If the LED light (1) does not operate, contact an authorized retailer of Genesis Branded products for replacement.

The LED light cannot be replaced as a single unit. A skilled technician should check or repair the LED light, for it may damage related parts of the vehicle.

# Rear Combination Light Replacement



- (1) Stop light/Turn signal light
- (2) Tail light/Stop light/Turn signal light
- (3) Rear side marker
- (4) Reverse light

If the LED light does not operate, contact an authorized retailer of Genesis Branded products for replacement.

The LED light cannot be replaced as a single unit. A skilled technician should check or repair the LED light, for it may damage related parts of the vehicle.


# High Mounted Stop Light Replacement



If the LED light (1) does not operate, contact an authorized retailer of Genesis Branded products for replacement.

The LED light cannot be replaced as a single unit. A skilled technician should check or repair the LED light, for it may damage related parts of the vehicle.

# **License Plate Light Replacement**



If the LED light (1) does not operate, contact an authorized retailer of Genesis Branded products for replacement.

The LED light cannot be replaced as a single unit. A skilled technician should check or repair the LED light, for it may damage related parts of the vehicle.

# **Front Trunk Light Replacement**



If the LED light (1) does not operate, contact an authorized retailer of Genesis Branded products for replacement.

The LED light cannot be replaced as a single unit. A skilled technician should check or repair the LED light, for it may damage related parts of the vehicle.


# **Interior Light Replacement**







- [A]: Front lights,
- [B]: Room lights (without sunroof),
- [C]: Personal lights (with sunroof)



- [D]: Vanity mirror light,
- [E]: Glove box light,
- [F]: Inner door handle lamp (A)/Mood lamp (B)/ Door courtesy lamp (C) (if equipped)



[G]: Cargo area light

If the LED light does not operate, contact an authorized retailer of Genesis Branded products for replacement.

The LED light cannot be replaced as a single unit. A skilled technician should check or repair the LED light, for it may damage related parts of the vehicle.

#### APPEARANCE CARE

#### **Exterior Care**

# NOTICE

If you park your vehicle near a stainless steel sign or glass facade building, the vehicle's exterior plastic parts such as a bumper, spoiler, garnish, light or Outer side view mirror might be damaged due to sunlight reflected from the sign or building. To prevent damage of the exterior plastic parts, you should avoid parking in areas where light may be reflected or use a car cover. (The exterior plastic parts applied to your vehicle may vary.)

## Exterior general caution

It is very important to follow the label directions when using any chemical cleaner or polish. Read all warning and caution statements that appear on the label.

#### Finish maintenance

#### Washing

To help protect your vehicle's finish from rust and deterioration, wash it thoroughly and frequently at least once a month with lukewarm or cold water.

If you use your vehicle for off-road driving, you should wash it after each off-road trip. Pay special attention to the removal of any accumulation of salt, dirt, mud, and other foreign materials. Make sure the drain holes in the lower edges of the doors and rocker panels are kept clear and clean.

Insects, tar, tree sap, bird droppings, industrial pollution and similar deposits can damage your vehicle's finish if not removed immediately.

Even prompt washing with plain water may not completely remove all these deposits. A mild soap, safe for use on painted surfaces, should be used.

After washing, rinse the vehicle thoroughly with lukewarm or cold water. Do not allow soap to dry on the finish.

#### **High-pressure** washing

- When using high-pressure washers, make sure to maintain sufficient distance from the vehicle.
  - Insufficient clearance or excessive pressure can lead to component damage or water penetration.
- Do not spray the camera, sensors or its surrounding area directly with a high pressure washer. Shock applied from high pressure water may cause the device to not operate normally.
- Do not bring the nozzle tip close to boots (rubber or plastic covers) or connectors as they may be damaged if they come into contact with high pressure water.

# **WARNING**

After washing the vehicle, test the brakes while driving slowly to see if they have been affected by water before getting on the road. If braking performance is impaired, dry the brakes by applying them lightly while maintaining a slow forward speed.

# NOTICE

- Do not use strong soap, chemical detergents or hot water, and do not wash the vehicle in direct sunlight or when the body of the vehicle is warm.
- Be careful when washing the side windows of your vehicle.
- Especially, with high-pressure water, water may leak through the windows and wet the interior.
- To prevent damage to the plastic parts, do not clean with chemical solvents or strong detergents.

# NOTICE



- Water washing in the motor compartment including high pressure water washing may cause the failure of electrical circuits located in the vehicle compartment.
- Never allow water or other liquids to come in contact with electrical/ electronic components inside the vehicle as water or other liquids may flow in to the motor compartment through the front trunk and damage electrical/electronic components.

# NOTICE

Matte paint finish vehicle (if equipped)
Automatic car wash which uses rotating brushes should not be used as this can damage the surface of your vehicle. A steam cleaner which washes the vehicle surface at high temperature may result the oil to adhere and leave stains that is difficult to remove.

Use a soft cloth (for example, microfiber towel or sponge) when washing your vehicle and dry with a microfiber towel. When you hand wash your vehicle, you should not use a cleaner that finishes with wax. If the vehicle surface is too dirty (sand, dirt, dust, contaminant, etc.), clean the surface with water before washing the car.

#### Waxing

A good coat of wax is a barrier between your paint and contaminate. Keeping a good coat of wax on your vehicle will help protect it.

Wax the vehicle when water will no longer bead on the paint.

Always wash and dry the vehicle before waxing. Use a good quality liquid or paste wax, and follow the manufacturer's instructions. Wax all metal trim to protect it and to maintain its luster.

Removing oil, tar, and similar materials with a spot remover will usually strip the wax from the finish. Be sure to re-wax these areas even if the rest of the vehicle does not yet need waxing.

## NOTICE

- Wiping dust or dirt off the body with a dry cloth will scratch the finish.
- Do not use steel wool, abrasive cleaners, or strong detergents containing highly alkaline or caustic agents on chrome-plated or anodized aluminum parts. This may result in damage to the protective coating and cause discoloration or paint deterioration.

# NOTICE

Matte paint finish vehicle (if equipped)
Do not use any polish protector such as a detergent, an abrasive and a polish. In case wax is applied, remove the wax immediately using a silicon remover and if any tar or tar contaminant is on the surface use a tar remover to clean. However, be careful not to apply too much pressure on the painted area.

# Finish damage repair

Deep scratches or stone chips in the painted surface must be repaired promptly. Exposed metal will quickly rust and may develop into a major repair expense.

# NOTICE

If your vehicle is damaged and requires any metal repair or replacement, be sure the body shop applies anti-corrosion materials to the parts repaired or replaced.

# NOTICE

Matte paint finish vehicle (if equipped) In case of matte paint finish vehicles, it is impossible to modify only the damaged area and repair of the whole part is necessary. If the vehicle is damaged and painting is required, have your vehicle maintained and repaired by an authorized retailer of Genesis Branded products. Take extreme care, as it is difficult to restore the quality after the repair.

## Bright-metal maintenance

- To remove road tar and insects, use a tar remover, not a scraper or other sharp object.
- To protect the surfaces of brightmetal parts from corrosion, apply a coating of wax or chrome preservative and rub to a high luster.
- During winter weather or in coastal areas, cover the bright metal parts with a heavier coating of wax or preservative. If necessary, coat the parts with non-corrosive petroleum jelly or other protective compound.

#### Underbody maintenance

Corrosive materials used for ice and snow removal and dust control may collect on the underbody. If these materials are not removed, accelerated rusting can occur on underbody parts such as the frame and floor pan, even though they have been treated with rust protection.

Thoroughly flush the vehicle underbody and wheel openings with lukewarm or cold water once a month, after off-road driving and at the end of each winter. Pay special attention to these areas because it is difficult to see all the mud and dirt. It will do more harm than good to wet down the road grime without removing it. The lower edges of doors, rocker panels, and frame members have drain holes that should not be allowed to clog with dirt; trapped water in these areas can cause rusting.



# **WARNING**

After washing the vehicle, test the brakes while driving slowly to see if they have been affected by water. If braking performance is impaired, dry the brakes by applying them lightly while maintaining a slow forward speed.

#### Aluminum wheel maintenance

The aluminum wheels are coated with a clear protective finish.

- Do not use abrasive cleaner, polishing compound, solvent, or wire brushes on aluminum wheels.
- · Clean the wheel when it has cooled.
- Use only a mild soap or neutral detergent, and rinse thoroughly with water. Also, clean the wheels after driving on salted roads.
- Do not wash the wheels with highspeed car wash brushes.
- Do not use any cleaners containing acid or alkaline detergents.

#### Corrosion protection

Protecting your vehicle from corrosion
By using the most advanced design
and construction practices to combat
corrosion, GENESIS produces vehicles of
the highest quality. However, this is only
part of the job. To achieve the long-term
corrosion resistance your vehicle can
deliver, the owner's cooperation and
assistance is also required.

#### Common causes of corrosion

The most common causes of corrosion on your vehicle are:

- Road salt, dirt and moisture that is allowed to accumulate underneath the vehicle.
- Removal of paint or protective coatings by stones, gravel, abrasion or minor scrapes and dents which leave unprotected metal exposed to corrosion.

#### **High-corrosion areas**

If you live in an area where your vehicle is regularly exposed to corrosive materials, corrosion protection is particularly important. Some of the common causes of accelerated corrosion are road salts, dust control chemicals, ocean air and industrial pollution.

#### Moisture breeds corrosion

Moisture creates the conditions in which corrosion is most likely to occur. For example, corrosion is accelerated by high humidity, particularly when temperatures are just above freezing. In such conditions, the corrosive material is kept in contact with the vehicle surfaces by moisture that is slow to evaporate.

Mud is particularly corrosive because it is slow to dry and holds moisture in contact with the vehicle. Although the mud appears to be dry, it can still retain moisture and promote corrosion.

High temperatures can also accelerate corrosion of parts that are not properly ventilated so the moisture can be dispersed. For all these reasons, it is particularly important to keep your vehicle clean and free of mud or accumulations of other materials. This applies not only to the visible surfaces but particularly to the underside of the vehicle.

#### To help prevent corrosion Keep your vehicle clean

The best way to prevent corrosion is to keep your vehicle clean and free of corrosive materials. Attention to the underside of the vehicle is particularly important.

- If you live in a high-corrosion area —
   where road salts are used, near the
   ocean, areas with industrial pollution,
   acid rain, etc., —, you should take
   extra care to prevent corrosion. In
   winter, hose off the underside of
   your vehicle at least once a month
   and be sure to clean the underside
   thoroughly when winter is over.
- When cleaning underneath the vehicle, pay particular attention to the components under the fenders and other areas that are hidden from view. Do a thorough job; just dampening the accumulated mud rather than washing it away will accelerate corrosion rather than prevent it. Water under high pressure and steam are particularly effective in removing accumulated mud and corrosive materials.
- When cleaning lower door panels, rocker panels and frame members, be sure that drain holes are kept open so that moisture can escape and not be trapped inside to accelerate corrosion.

#### Keep your garage dry

Don't park your vehicle in a damp, poorly ventilated garage. This creates a favorable environment for corrosion. This is particularly true if you wash your vehicle in the garage or drive it into the garage when it is still wet or covered with snow, ice or mud. Even a heated garage can contribute to corrosion unless it is well ventilated so moisture is dispersed.

Keep paint and trim in good condition Scratches or chips in the finish should be covered with "touch-up" paint as soon as possible to reduce the possibility of corrosion. If bare metal is showing through, the attention of a qualified body and paint shop is recommended.

Bird droppings are highly corrosive and may damage painted surfaces in just a few hours. Always remove bird droppings as soon as possible.

#### **Interior Care**

#### Interior general precautions

Prevent caustic solutions such as perfume and cosmetic oil, from contacting the interior parts because they may cause damage or discoloration. If they do contact the interior parts, wipe them off immediately. See the instructions for the proper way to clean vehicle interior surfaces.

### **NOTICE**

- Never allow water or other liquids to come in contact with electrical/ electronic components inside the vehicle as this may damage them.
- When cleaning leather products (steering wheel, seats etc.), use neutral detergents or low alcohol content solutions. If you use high alcohol content solutions or acid/ alkaline detergents, the color of the leather may fade or the surface may get stripped off.

# Cleaning the upholstery and interior trim

Vehicle interior surfaces (if equipped)
Remove dust and loose dirt from interior surfaces with a whisk broom or a vacuum cleaner

If necessary, clean interior surfaces with a mixture of warm water and mild nondetergent cleaner (test all cleaners on a concealed area before use).

#### Fabric (if equipped)

Remove dust and loose dirt from fabric with a whisk broom or vacuum cleaner. Clean with a mild soap solution recommended for upholstery or carpets. Remove fresh spots immediately with a fabric spot cleaner. If fresh spots do not receive immediate attention, the fabric can be stained and its color can be affected. Also, its fire-resistant properties can be reduced if the material is not properly maintained.

## NOTICE

Using anything but recommended cleaners and procedures may affect the fabric's appearance and fire-resistant properties.

#### Leather (if equipped)

- · Features of seat leather
  - Leather is made from the outer skin of an animal, which goes through a special process to be available for use. Since it is a natural product, each part differs in thickness or density.

Wrinkles may appear as a natural result of stretching and shrinking depending on the temperature and humidity.

- The seat is made of stretchable fabric to improve comfort.
- The parts contacting the body are curved and the side supporting area is high which provides driving comfort and stability.
- Wrinkles may appear naturally from usage. It is not a fault of the products.

### NOTICE

- Wrinkles or abrasions which appear naturally from usage are not covered by warranty.
- Belts with metallic accessories, zippers or keys inside the back pocket may damage the seat fabric.
- Make sure not to wet the seat. It may change the nature of natural leather.
- Jeans or clothes which could bleach may contaminate the surface of the seat covering fabric.

- Caring for the leather seats
  - Vacuum the seat periodically to remove dust and sand on the seat. It will prevent abrasion or damage of the leather and maintain its quality.
  - Wipe the natural leather seat cover often with dry or soft cloth.
  - Use of proper leather protector may prevent abrasion of the cover and helps maintain the color. Be sure to read the instructions and consult a specialist when using leather coating or protective agent.
  - Light colored (beige, cream beige) leather is easily contaminated and the stain is noticeable. Clean the seats frequently.
  - Avoid wiping with wet cloth. It may cause the surface to crack.
- · Cleaning the leather seats
  - Remove all contaminations instantly. Refer to instructions below for removal of each contaminant.
  - Cosmetic products (sunscreen, foundation, etc.)
    - Apply cleansing cream on a cloth and wipe the contaminated spot. Wipe off the cream with a wet cloth and remove water with a dry cloth.
  - Beverages (coffee, soft drink, etc.)
     Apply a small amount of neutral detergent and wipe until contaminations do not smear.
  - OII
     Remove oil instantly with absorbable cloth and wipe with stain remover used only for natural
  - Chewing gum
     Harden the gum with ice and remove gradually.

leather.

#### Interior wooden trim

- Use a wooden furniture protector (for example, wax, coating compound) to clean the interior wooden trim.
- Often wipe the interior wooden trim with a lint-free, clean cloth to maintain the unique wooden textures for a longer period of time.
- If you spill beverage (for example, water, coffee) over the interior wooden trim, immediately wipe it with clean, dry cloth.
- Sharp objects (for example, driver, knife), adhesive materials, or tapes may damage the interior wooden trim.
- Any strong impacts may damage the interior wooden trim.
- If the coating finish over the interior wooden trim is removed, moisture may damage or change wood traits.
- If the interior wooden trim is damaged, you may get a splinter from the wood surface. Therefore, you should immediately have replaced the damaged interior wooden trim. Contact an authorized Retailer of Genesis Branded Products.
- Forged wood is an eco-friendly wooden trim made from recycled wood chips. Due to these material characteristics, the grain direction is not constant and small dots or natural cracks may occur. These are natural appearance characteristics of real wood from the manufacturing method and are not appearance defects.

#### Cleaning the seat belt webbing

Clean the belt webbing with any mild soap solution recommended for cleaning upholstery or carpet. Follow the instructions provided with the soap. Do not bleach or re-dye the webbing because this may weaken the seat belt.

#### Cleaning the interior window glass

If the interior glass surfaces of the vehicle become fogged (that is, covered with an oily, greasy or waxy film), they should be cleaned with glass cleaner. Follow the directions on the glass cleaner container.

## NOTICE

Do not scrape or scratch the inside of the rear window. This may result in damage to the rear window defroster grid.

# CALIFORNIA PERCHLORATE NOTICE

Perchlorate Material-special handling may apply, See: www.dtsc.ca.gov/perchlorate.Notice to California Vehicle Dismantlers: Perchlorate containing materials, such as airbag inflators, seatbelt pretensioners and keyless remote entry batteries, must be disposed of according to Title 22 California Code of Regulations Section 67384.10 (a).

# Index

# Α

Accessing Your Vehicle	5-5
Immobilizer System	5-11
Using Smart Key	5-5
Active Noise Control-road	6-56
System Malfunction	6-56
Active Sound Design	6-56
Advanced Rear Occupant Alert (ROA)	5-37
Advanced Rear Occupant Alert Operation	5-37
Advanced Rear Occupant Alert Precautions	5-38
Advanced Rear Occupant Alert Settings	5-37
Declaration of Conformity	5-39
Air Conditioner Compressor Label	2-13
Air Conditioning System	2-11
Air Ventilation Seats	3-23
Front Air Ventilation Seats	3-23
Operating Rear Air Ventilation Seat from Front Seat	3-24
Rear Air Ventilation Seats	3-23
Airbag - Supplemental Restraint System	3-46
Additional Safety Precautions	3-67
Airbag Warning Labels	3-67
How Does the Airbag System Operate?	3-51
Occupant Classification System (OCS)	3-55
SRS Care	3-66
What to Expect After an Airbag Inflates	3-54
Where are the Airbags?	3-48
Why Didn't My Airbag Go Off In a Collision?	3-61
All Wheel Drive (AWD)	6-47
All Wheel Drive (AWD) Operation	6-47
Emergency Precautions	6-49
Appearance Care	9-55
Exterior Care	9-55
Interior Care	9-60
Automatic Climate Control System	5-96
Automatic Temperature Control Mode	5-98
Manual Temperature Control Mode	5-99
System Maintenance	5-109
System Operation	5-108

# В

Battery (12 V)	9-20
12 V Battery Recharging	9-22
Battery Capacity Label	9-21
Battery Replacement	9-21
For Best Battery Service	9-21
Reset Items	9-23
Before Driving	6-4
Before Entering the Vehicle	6-4
Before Starting	6-4
Blind-Spot Collision-Avoidance Assist (BCA)	7-35
Blind-Spot Collision-Avoidance Assist Malfunction and Limitations	7-43
Blind-Spot Collision-Avoidance Assist Operation	7-40
Blind-Spot Collision-Avoidance Assist Settings	7-37
Blind-Spot View Monitor (BVM)	7-74
Blind-Spot View Monitor Malfunction	7-75
Blind-Spot View Monitor Operation	7-74
Blind-Spot View Monitor Settings	7-74
Boost Mode	6-55
Boost Mode Limitations	6-55
Using Boost Mode	6-55
Brake Fluid	
Checking the Brake Fluid Level	9-14
Braking System	6-29
Anti-lock Brake System (ABS)	6-38
Auto Hold	6-34
Brake Assistant System (BAS)	6-44
Brake Disc Cleaning	6-37
Disc Brakes Wear Indicator	6-30
Downhill Brake Control (DBC)	6-44
Electronic Parking Brake (EPB)	6-30
Electronic Stability Control (ESC)	6-39
Good Braking Practices	6-46
High Performance Brake	6-30
Hill-Start Assist Control (HAC)	
Power-assist Brakes	
Trailer Stability Assist (TSA)	
Vehicle Stability Management (VSM)	6-42
Bulb Wattage	2-9

Cabin Air Filter	9-16
Filter Inspection.	9-16
Filter Replacement	9-16
California Perchlorate Notice	9-63
Center Console Overview	2-5
Charging Door	5-79
Closing the Charging Door	5-79
Opening the Charging Door	5-79
Charging Your Electric Vehicle	1-26
Checking Basic Information on Charging Your Electric Vehicle	1-26
Checklist when Charging Does Not Start	1-48
Safety Precautions for Charging Your Electric Vehicle	1-31
Using a DC Charger	
Using a Portable Charger (ICCB: In-Cable Control Box)	1-38
Using an AC Charger	1-34
Using the Scheduled Charging Function	1-47
Child Restraint System (CRS)	3-38
Installing a Child Restraint System (CRS)	3-40
Our Recommendation: Children Always In the Rear	3-38
Selecting a Child Restraint System (CRS)	3-39
Climate Control Additional Features	5-115
A/C Automatic Drying	5-116
Auto Defogging System	5-115
Auto Dehumidify	5-117
Automatic Controls Linked to Climate Control Settings (for driver's s	eat)5-118
Recirculating Air when Washer Fluid is Used	5-118
Cluster Display	4-26
3D Instrument Cluster (for 12.3-inch 3D Cluster)	4-32
Cluster Display Control	4-26
Option Menu	4-30
View Modes	4-26
Consumer Information	2-14
Coolant	9-12
Changing Coolant	9-13
Countermeasures for Accidents or Fire	1-60
If an Accident Occurs	1-60
Other Precautions for Electric Vehicle	1-61
Turning off the High Voltage Battery	1-61

Declaration of Conformity	7-178
Front Corner Radar/Rear Corner Radar	7-179
Front Radar	7-178
Dimensions	2-8
Door Locks	5-30
Automatic Door Lock and Unlock Features	5-33
Child-protector Rear Door Locks	5-33
Electronic Child Safety Lock	5-34
Operating Door Locks from Inside the Vehicle	5-31
Operating Door Locks from Outside the Vehicle	5-30
Drive Mode Integrated Control System	6-53
Drive Modes Characteristic	6-54
ECO, COMFORT, SPORT, SNOW Mode Features	6-53
Selecting Drive Mode	6-53
Driver Attention Warning (DAW)	7-64
Driver Attention Warning Malfunction and Limitations	7-67
Driver Attention Warning Operation	7-65
Driver Attention Warning Settings	7-64
Driving Your Electric Vehicle	1-49
Checking Electric Vehicle Driving Information	1-50
Checking the Warning and Indicator Lights (related to electric vehicle	)1-53
Cluster Display Messages	1-55
Starting Your Vehicle	1-49
Stopping Your Vehicle	1-49
Virtual Engine Sound System	1-50
E	
Electric Vehicle Specifications	2-8
Electronic Control Suspension	
System Malfunction	6-51
Electronically Controlled Suspension with Road Preview	
Limitations of the System	
System Malfunction	
Explanation of Scheduled Maintenance Items	
Exterior Features	
Roof Side Rails	5-131

Exterior Lights	5-82
Battery Saver Function	5-84
Headlight Delay Function	5-85
Headlight Leveling Device	5-85
Headlight Moisture Removal Function	5-85
High Beam Operation	5-83
Lighting Control	5-82
Reverse Guide Light	
Turn Signals and Lane Change Signals	5-84
Exterior Overview (Front View)	2-2
Exterior Overview (Rear View)	2-3
F	
Fingerprint Authentication System	5-26
Fingerprint Authentication System Operation	5-27
Fingerprint Authentication System Settings	5-26
Limitations of the System	5-28
Remotely Starting the Vehicle	5-29
When Purchasing a Used Vehicle	5-29
Forward Attention Warning (FAW)	7-70
Forward Attention Warning Malfunction and Limitations	7-71
Forward Attention Warning Operation	7-71
Forward Attention Warning Settings	7-70
Forward Collision-Avoidance Assist (FCA)	7-2
Forward Collision-Avoidance Assist Malfunction and Limitations	7-18
Forward Collision-Avoidance Assist Operation	7-8
Forward Collision-Avoidance Assist Settings	7-6
Forward/Reverse Parking Distance Warning (PDW)	7-138
Parking Distance Warning Malfunction and Limitations	7-141
Parking Distance Warning Operation	7-139
Parking Distance Warning Settings	7-138
Front Trunk	5-69
Closing the Front Trunk	5-69
Opening the Front Trunk	5-69
Fuses	9-37
Fuse/Relay Panel Description	9-40
Instrument Panel Fuse Replacement	9-38
Motor Compartment Panel Fuse Replacement	9-39

G
Gear Fluid9-1Genesis Digital Key5-1Digital Key (Card Key)5-1Digital Key (Smartphone)5-1Limitations of the System5-2Personalized Profile and Vehicle Settings5-2Used Vehicle/Digital Key Maintenance5-2
Н
Hazard Warning Flasher8-Head-up Display5-8Head-up Display Information5-8Head-up Display Settings5-8Precautions while Using the Head-up Display5-8High Beam Assist (HBA)5-9High Beam Assist Malfunction and Limitations5-9High Beam Assist Operation5-9High Beam Assist Setting5-9Highway Driving Assist (HDA)7-10Highway Driving Assist Malfunction and Limitations7-11Highway Driving Assist Operation7-10Highway Driving Assist Settings7-10Hood5-6Closing the Hood5-6Opening the Hood5-6
If the Vehicle will not Start

Important Safety Precautions	3-2
Airbag Hazards	3-2
Always Wear Your Seat Belt	3-2
Control Your Speed	3-2
Driver Distraction	3-2
Keep Your Vehicle In Safe Condition	3-2
Restrain All Children	3-2
In Case of an Emergency while Driving	8-2
If the Vehicle Stalls at a Crossroad or Crossing	8-2
If the Vehicle Stalls while Driving	8-2
If you have a Flat Tire while Driving	8-3
Infotainment System	5-132
Antenna	5-132
Bluetooth® Wireless Technology	5-134
Infotainment System	5-133
Lexicon Premium Sound System	5-134
Steering Wheel Remote Controls	5-132
USB Port	5-132
Voice Recognition	5-133
Instrument Cluster	4-4
Cluster Display Messages	4-19
Gauges and Meters	4-5
Instrument Cluster Control	4-5
Power/Charge Gauge	4-6
State of Charge (SOC) Gauge for High Voltage Battery	4-6
Warning and Indicator Lights	4-10
Integrated Memory System	5-40
Recalling Memory Positions	5-41
Resetting the System	5-41
Seat Easy Access	5-42
Storing Memory Positions	5-40
Intelligent Speed Limit Assist (ISLA)	7-58
Intelligent Speed Limit Assist Malfunction and Limitations	7-61
Intelligent Speed Limit Assist Operation	7-59
Intelligent Speed Limit Assist Settings	7-58

Interior Features 5-121
Cargo Net Holder5-129
Cargo Security Screen5-129
Clock5-127
Coat Hook5-127
Cup Holder5-121
Floor Mat Anchor(s)5-128
Power Outlet5-122
Rear Side Window Sunshades5-128
Sunvisor
USB Charger5-123
Vehicle to Load (V2L)5-127
Wireless Smartphone Charging System5-124
Interior Lights5-86
Cargo Area Lamp5-88
Door Handle Lamp/Mood Lamp/Door Courtesy Lamp5-88
Front Lamps5-86
Glove Box Lamp5-87
Interior Light AUTO Cut5-86
Puddle Light5-88
Rear Lamps5-87
Vanity Mirror Lamp5-87
Welcome System5-89
Interior Overview2-4
J
Jump Starting (12 V Battery)8-4
L
Lane Following Assist (LFA)7-101
Lane Following Assist Malfunction and Limitations
Lane Following Assist Operation 7-102
Lane Following Assist Settings
Lane Keeping Assist (LKA)
Keeping Assist Operation
Lane Keeping Assist Malfunction and Limitations
Lane Keeping Assist Settings

Light Bulbs9-51
Front Trunk Light Replacement9-53
Headlight, Parking Light, Turn Signal Light, Daytime Running Light (DRL) Replacement
High Mounted Stop Light Replacement9-53
Interior Light Replacement9-54
License Plate Light Replacement9-53
Puddle Light Replacement9-52
Rear Combination Light Replacement 9-52
Total Communion Digite replacement
M
Maintenance Services
Owner Maintenance Precautions9-4
Owner's Responsibility
Manual Speed Limit Assist (MSLA)
Manual Speed Limit Assist Operation
Mirrors
Inside Rearview Mirror
Reverse Parking Aid
Side View Mirrors
Motor Compartment
Motor Compartment Overview
Motor Number
Motor Number
N
Navigation-based Smart Cruise Control (NSCC)
Limitations of Navigation-based Smart Cruise Control
Navigation-based Smart Cruise Control Operation
Navigation-based Smart Cruise Control Settings
Navigation-based Smart Cruise Control Settings/-94
0
Open Source Software Notice
Owner Maintenance 9-5
Owner Maintenance Schedule. 9-6

Reporting Safety Defects	2-15
Reverse Parking Collision-Avoidance Assist (PCA)	7-143
Parking Collision-Avoidance Assist Settings	
Reverse Parking Collision-Avoidance Assist Malfunction and Limita	tions7-146
Reverse Parking Collision-Avoidance Assist Operation	7-145
s	
Safe Exit Assist (SEA)	7-49
Safe Exit Assist Malfunction and Limitations	
Safe Exit Assist Operation.	
Safe Exit Assist Settings.	
Scheduled Maintenance Services	
Maintenance Under Severe Usage and Low Mileage Conditions	
Normal Maintenance Schedule	
Seat Belts	
Additional Seat Belt Safety Precautions	
Care of Seat Belts	
Pre-Active Seat Belt (PSB)	
Seat Belt Restraint System	
Seat Belt Safety Precautions	
Seat Belt Warning Light	
Seat Warmers	3-20
Front Seat Warmers	3-20
Operating Rear Seat Warmer from the Front Seat	3-21
Rear Seat Warmers	3-21
Seats	3-3
Front Seats	3-7
Head Restraint	3-16
Rear Seats	3-13
Safety Precautions	3-6
Shift By Wire	6-10
Cluster Display Message Information	6-15
Good Driving Practices	6-16
Shift By Wire Operation	6-10
Smart Cruise Control (SCC)	
Smart Cruise Control Malfunction and Limitations	
Smart Cruise Control Operation	7-79
Smart Cruise Control Settings	7-77

S	Smart Liftgate	5-77
	Deactivating Smart Liftgate	5-78
	Detecting Area	5-78
	Using Smart Liftgate	5-77
S	Smart Posture Care System	5-43
S	Smart Regeneration System	6-22
	Front Sensor	6-24
	Pausing Smart Regeneration System	6-24
	Smart Regeneration Level Settings	6-23
	Smart Regeneration System On/Off	6-22
	Smart Regeneration System Operating Condition	6-23
	Smart Regeneration System Precautions	6-25
	System Check Message	6-25
S	Special Driving Conditions	6-57
	Driving at Night	6-58
	Driving in Flooded Areas	6-58
	Driving in the Rain	6-58
	Hazardous Driving Conditions	6-57
	Highway Driving	6-58
	Reducing the Risk of a Rollover	6-59
	Rocking the Vehicle	6-57
	Smooth Cornering	6-57
S	Start/Stop Button	6-5
	Remote Start	6-9
	Start/Stop Button Positions	6-6
	Starting the Vehicle	6-7
	Turning Off the Vehicle	6-8
S	Steering Wheel	5-44
	Heated Steering Wheel	5-46
	Horn	5-46
	MDPS (Motor Driven Power Steering)	5-44
	Tilt/Telescopic Steering	
S	Steering Wheel Control Overview	
	Storage Compartment	
	Center Console Storage	
	Glove Box	
	Mobile Phone Holder	
	Sunglass Holder	

Surround View Monitor (SVM)	7-121
Surround View Monitor Malfunction and Limitations	7-125
Surround View Monitor Operation	
Surround View Monitor Settings	
т	
Theft-alarm System	
Tire Pressure Monitoring System (TPMS)	
Changing a Tire with TPMS	8-10
Check Tire Pressure	
Low Tire Pressure Position and Tire Pressure Telltale	8-9
Low Tire Pressure Warning Light	8-9
Tire Pressure Monitoring System	8-8
TPMS (Tire Pressure Monitoring System) Malfunction Indicator	8-10
Tire Specification and Pressure Label	2-12
Tires and Wheels	. 2-10, 9-24
All Season Tires	9-35
Check Tire Inflation Pressure	9-25
Low Aspect Ratio Tires	9-36
Radial-Ply Tires	9-36
Recommended Cold Tire Inflation Pressures	9-24
Snow Tires	9-35
Summer Tires	9-35
Tire Care	9-24
Tire Maintenance	
Tire Replacement	
Tire Rotation	
Tire Sidewall Labeling	
Tire Terminology and Definitions	
Tire Traction	
Wheel Alignment and Tire Balance	
Wheel Replacement	
Towing	
Precautions when Moving a Short Distance before Towing a Vehicle.	
Towing Service	
10111115 501 1100	17

Trailer Towing	6-63
Driving with a Trailer	6-68
If You Decide to Pull a Trailer?	6-64
Maintenance When Towing a Trailer	6-71
Trailer Towing Equipment	
U	
Understanding Your Electric Vehicle	1-7
Characteristics of Your Electric Vehicles	1-7
Precautions when Using the High Voltage Battery	1-8
Using Aux. Battery Saver+	1-25
Using EV Mode Functions	1-9
Checking Energy Information	
Checking the EV Mode Screen Configuration	1-9
Setting Battery Discharging Limit when Using Vehicle to Load (V2L).	1-15
Setting Electric Vehicle Specialized Functions	1-15
Setting Scheduled Charging and Climate	1-13
Setting the Next Departure Time	1-12
Using V2L Function	1-19
Safety Precautions when Using the V2L	1-19
Solving V2L Problems	1-24
Using Electricity Inside the Vehicle	1-22
Using Electricity Outside the Vehicle	1-21
V	
Vehicle Certification Label	2-12
Vehicle Identification Number (VIN)	
Vehicle Load Limit	
The Loading Information Label	
Vehicle Settings (Infotainment System)	
Setting Your Vehicle	
Vehicle Weight and Luggage Volume	

## W

Washer Fluid	9-15
Checking the Washer Fluid Level	9-15
Windows	5-60
Power Windows	5-61
Windshield Defrosting and Defogging	5-112
Defogging Logic	
Rear Window Defroster	5-114
To Defog Inside Windshield	5-112
To Defrost Outside Windshield	5-113
Winter Driving	6-60
Snow or Icy Conditions	
Winter Precautions	
Wiper Blades	9-18
Blade Inspection	9-18
Blade Replacement	9-18
Wipers and Washers	5-93
Front Windshield Washers	5-94
Front Windshield Wipers	
Rear Window Wiper and Washer	