

VOICE RECOGNITION TIPS

BLUETOOTH®

Command **Example**
 Dial <Phone #> — “Dial
 7-1-4-0-0-0-8-8-8-8”
 Call <Name> — “Call John Smith”

Improving how you store your contacts can optimize your Bluetooth® Voice Recognition performance:

- Use full names instead of short or single-syllable names (“John or Dad”)
- Avoid using special characters/emojis or abbreviations (“Dr.”) when saving contacts

NAVIGATION

Command **Example**
 Find Address — “1-2-3-4-5 1st Street,
 <House #, Street, Fountain Valley”
 City, State>
 Find <POI Name> — “Find McDonald’s”

Located on Rearview Mirror
DESTINATION SEARCH BY VOICE 
Command **Example**
 Find <POI Name> — “Find Lowe’s® near me”
 <POI Name> — “Starbucks®”

DEMONSTRATE AUTOMATIC CLIMATE CONTROL - page 15


HOW TO DEFROST

- 1 Press the front defrost button.
- 2 Set to warmest temperature setting.
- 3 Set to highest fan speed.

TIRE PRESSURE MONITORING SYSTEM (TPMS)- page 40

Low tire pressure indicator /
 TPMS malfunction indicator



NOTE: Tire pressure may vary in colder temperatures causing the low tire pressure indicator  to illuminate. Inflate tires according to the Tire Pressure Label located on the driver’s side door pillar.

INTRODUCTION AND LOCATION OF THE SERVICE DEPARTMENT

SET FIRST SERVICE VALET APPOINTMENT

REVIEW FACTORY RECOMMENDED MAINTENANCE SCHEDULE

WAS THE CONDITION OF YOUR VEHICLE (AT DELIVERY) TO YOUR SATISFACTION?

GENESIS CONNECTED SERVICES

- Assist with creating a Genesis Owners account
- Assist with Genesis Connected Services enrollment
- Show Genesis Connected Services Users Manual
- Encourage customer to download the Genesis Intelligent Assistant App

MAINTENANCE

Scheduled Maintenance (Normal Usage)		2.0T / 3.3T
Engine Oil And Filter	Replace	6,000 or 12 mos.
Fuel Additives	Add	6,000 or 12 mos.
Tire Rotation	Perform	6,000 or 12 mos.
Vacuum Hose		
Air Conditioning Refrigerant		
Brake Hoses & Lines		
Drive Shafts & Boots		
Exhaust Pipe & Muffler		
Front Brake Disc/Pads, Calipers	Inspect	6,000 or 12 mos.
Rear Brake Disc/Pads		
Steering Gear Box, Linkage & Boots/ Lower Arm Ball Joint, Upper Arm Ball Joint		
Suspension Mounting Bolts		
Propeller Shaft		
Air Cleaner Filer	Inspect	6,000 or 12 mos.
	Replace	18,000 or 36 mos.
Climate Control Air Filter (For Evaporator And Blower Unit)	Replace	Every 12 mos.
Fuel Lines, Fuel Hoses And Connections		
Front(AWD)/Rear Differential Oil	Inspect	24,000 or 48 mos.
Valve Clearance (3.3T and 3.8L)	Inspect	60,000 or 72 mos.
Drive Belt	Inspect	First 60,000 or 72 mos.
	Inspect	Subsequent, every 12,000 or 24 mos.
Spark Plugs (Iridium Coated)	Replace	42,000
Coolant	Replace	First 120,000 or 120 mos. Subsequent, every 30,000 or 24 mos.
Automatic Transmission Fluid	No checks or services required for Normal Usage driving.	
*Check the engine oil regularly between recommended oil change. Genesis Branded Vehicle recommend Quaker State oil.		
*See Owner’s Manual for details.		

Looking For more detailed information? This Quick Reference Guide does not replace your vehicle’s Owner’s Manual. If you require additional information or are unsure of a specific issue, we recommend that you always refer to the vehicle’s Owner’s Manual or contact your authorized retailer of Genesis Branded Products. The information contained in this Quick Reference Guide is correct at the time of printing; however, specifications and equipment can change without notice. No warranty or guarantee is being extended in this Quick Reference Guide, and Genesis Brand reserves the right to change product specifications and equipment at any time without incurring obligations. Some vehicles are shown with optional equipment.

Sales Consultant Date Sales Manager Date

New Owner Date

Email @

GENESIS G70

QUICK REFERENCE GUIDE

GENESIS BRANDED VEHICLE OWNER PRIVACY POLICY

Your Genesis Branded Vehicle may be equipped with technologies and services that use information collected, generated, recorded or stored by the vehicle. Genesis Branded Vehicle has created a Vehicle Owner Privacy Policy to explain how these technologies and services collect, use, and share this information.

You may read our Vehicle Owner Privacy Policy on the GenesisMotorsUSA.com website at <https://www.genesis.com/us/en/privacy-policy.html>
If you would like to receive a hard copy of our Vehicle Owner Privacy Policy, please contact Customer Care at:

Genesis Customer Care
P.O. Box 20850
Fountain Valley, CA 92728
844-340-9741
CustomerCare@genesismotorsusa.com

Genesis Customer Care representatives are available Monday through Friday, between the hours of 5:00 AM and 7:00 PM PST and Saturday and Sunday between 6:30 AM and 3:00 PM PST (English).
For Customer Care assistance in Spanish or Korean, representatives are available Monday through Friday between 6:30 AM and 3:00 PM PST.

Roadside Assistance: **1-844-340-9742**
SiriusXM® Radio: **1-800-967-2346**
Genesis Customer Care &
Connected Services: **1-844-340-9741**
www.MyGenesisusa.com



Instrument cluster

Page 11




Smart cruise control

Page 35



Navigation

Page 19




Wiper and washer

Page 09




USB port

Page 17



Climate control system

Page 15



FEATURES AND CONTROLS

Climate control system	15
Driver's main controls	07
Fuel filler door	06
Head up display	14
Instrument cluster	11
Interior lights	08
LCD display control	13
LCD display modes	13
Occupant Classification System (OCS)	03
Seat-Climate control system seat	04
Seat-Driver position memory system	04
Seat-Front seat adjustment	02
Seat-Headrest adjustment	02
Smart key	01
Smart trunk	06
Sunroof	08
Trunk operation	05
Warning and indicators	14
Wiper blades	10
Wipers and washer	09

INFOTAINMENT

Android Auto™	25
Apple CarPlay™	27
Bluetooth Phone Pairing	17
Genesis Connected Services	20
Homelink wireless garage control system	23
Navigation	19
Power outlet	18
Radio mode	19
USB Port	17
Wireless cellular phone charging system	18

DRIVING

Auto hold	41
Blind-Spot Collision Avoidance Assist (BCA)	37
Digital key pairing	42
Driver Attention Warning (DAW)	32
Electric parking brake (EPB)	41
Electronic stability control (ESC)	32
Forward Collision-Avoidance Assist (FCA)	39
Forward/Reverse Parking Distance Warning (PDW)	38
Highway Driving Assist (HDA)	34
Lane Following Assist (LFA)	33
Lane Keeping Assist (LKA)	33
Near Field Communication (NFC)	43
Rear View monitor	38
Shift by Wire [Electronic type shifter]	31
Smart cruise control	35
Tire Pressure Monitoring System (TPMS)	40

WARNING!

To reduce the risk of serious injury to yourself and others, read and understand the important SAFETY INFORMATION in your Owner's Manual.


Use this Quick Reference Guide to learn about the features that will enhance your enjoyment of your Genesis Branded Vehicle. More detailed information about these features are available in your Owner's Manual.

*Some vehicles may not be equipped with all the listed features.


This QRG provides instructional videos that are accessible by scanning the QR Codes found throughout the QRG with your smartphone/tablet.

In order to scan a QR Code, you will need to use a QR Code Reader App on your mobile device. You can download the app onto your device through an app store or marketplace.


SMART KEY




- Door lock
- Door unlock
- Trunk open
- Panic
- Remote start
- Lamp ON



Driver's door Lock / Unlock
Smart key must be within 20~40 in. from the outside door handle.
Press: One time – Unlock driver door
Two times – Unlock all doors
Three times – Lock all doors



Remove mechanical key.
If the Smart Key does not operate normally, you can lock or unlock the driver's door by using the mechanical key.




1. Place a soft cloth over the groove **A** and pry open the smart key cover.
2. Press the mechanical key and remove it from the smart key FOB.
3. After use, reinstall the mechanical key and smart key cover in the reverse order of removal.

FRONT SEAT ADJUSTMENT



- Forward and backward** **1**
- Seat cushion length** (if equipped) **2**
- Seatback angle** **3**
- Seat cushion height and tilt** **1**
- Lumbar support** **4**
- Seat bolster adjustment** (if equipped) **5**

HEADREST ADJUSTMENT



- To Raise Headrest:**
Pull headrest up.
- To Lower Headrest:**
Press lock button while pressing down on headrest.
- To adjust headrest forward (front seats only):**
Pull forward to 1 of 3 positions.
- To adjust headrest rearward (front seats only):**
Pull it fully forward to the farthest position and release it.

Easy Access Function (Driver's Seat)


Entering the vehicle

The driver's seat and steering wheel will move back to its original position when the Engine Start/Stop button is in the OFF position and the driver's door is closed with the smart key in possession.

Exiting the vehicle

The driver's seat will move rearward and the steering wheel will move upward when the driver's door is opened and the Engine Start/Stop button is in the OFF position with the gear in P (Park).

NOTE: The driver's seat may not move rearward if there is not enough space between the driver's seat and the rear seat.

You can activate/deactivate this function from the  User Settings mode in the cluster LCD display:


Seat Easy Access:

Convenience > Seat Easy Access > Off/Normal/Extended

Steering Easy Access:

Convenience > Steering Easy Access > On/Off

OCCUPANT CLASSIFICATION SYSTEM (OCS)




Your vehicle is equipped with an Occupant Classification System

(OCS) in the front passenger's seat that detects whether the passenger air bag system should be activated or deactivated.

The following items may affect the OCS operation:

- Car seat accessories such as thick blankets and cushions which cover up the car seat surface
- Placing materials such as water bottles on the seat
- Using electronic devices such as laptops and satellite radios which use inverter chargers
- Wet towels or liquid that has been spilled on the seat. Make sure the seat has been completely dried before driving the vehicle

DRIVER POSITION MEMORY SYSTEM



Storing

1. Adjust the driver's seat, outside rearview mirrors, steering wheel, instrument panel illumination and head up display.
2. Press the SET button. The system will beep once.
3. Press one of the memory buttons (1 or 2) within 5 seconds. The system will beep twice.


NOTE: Transmission must be in P(Park).

Recalling

Press the desired memory button (1 or 2). The system will beep once.

NOTE: For resetting, please see Owner's Manual for procedure.

CLIMATE CONTROL SYSTEM SEAT




 - Heat  - Air Ventilation

Each time you push the button, the setting is changed as follows:


OFF → HIGH → MEDIUM → LOW



TRUNK OPERATION



Power trunk open button




Press to open.
Smart key needs to be within the range.


Power trunk open button on the smart key




Press and hold.



Trunk Open button



Press to open.




Closing the trunk

Use the trunk pull handle located inside the trunk lid to close.

NOTES: Trunk opening height adjustment is available in the Vehicle setup options. Please refer to your Owner's Manual for further information.

SMART TRUNK



Smart Trunk

When smart key is within range for 3 seconds, the trunk will automatically open.



To enable Smart Trunk function:

Vehicle must be in P (Park) to adjust the settings located in the setup menu in the AVN system screen.

1. Select Setup > Vehicle > Door/Trunk
2. Check "Smart Trunk".

NOTE: Function is active after 15 seconds when all doors are closed and locked. The vehicle will also provide an audible and visual alarm while activating. Please refer to your Owner's Manual for further information.


FUEL FILLER DOOR



Opening the fuel filler door:

1. Turn the engine off.
2. Push the fuel filler door opener button.
3. Pull the fuel filler door ① outward to access the fuel tank cap.
4. To remove the fuel tank cap ②, turn it counterclockwise.
5. Place the cap on the fuel filler door.

DRIVER'S MAIN CONTROLS



Outside Rearview Mirror

- Press switch left/right to unfold/fold mirrors. Press the lock or unlock button on the smart key, and the mirrors will be folded or unfolded when AUTO is set.
- Press the L or R button to adjust the mirror by using the directional switch. If L or R button is still selected, both mirrors will tilt downward when reversing. Deselect L or R will disable the auto tilt down feature.

Power window lock button

Disables the power window switches on the rear passenger doors.


Door Lock

Locks/unlocks all doors.

Window Switches

- Front power window switches.
- Rear power window switches.

SUNROOF



Sunshade



To open the sunshade, pull the sunroof control lever lightly backward to the first detent position. Push the sunroof control lever forward to close.

Sliding the sunroof




Pull the sunroof control lever backward past the first detent to slide open the sunroof control lever forward to the second detent position to close sunroof glass with the sunshade.

Tilting the sunroof



Push the sunroof control lever upward to tilt open the sunroof. Push again the sunroof control lever upward to tilt the sunroof glass closed.

INTERIOR LIGHTS



Front map lamp ①

Press the button to turn the map lamp on or off.

Front door lamp (🚪) ②

Lights will turn on when any door is open.


Front room lamp (🏠) ③

Push the switch to turn the room lamp on.


Front room lamp (🏠) ④

Push the switch to turn the room lamp off.

WIPERS AND WASHER




- **MIST** - Single wipe
- **OFF**
- **AUTO** - Auto control wipe
- **LO** - Low wiper speed
- **HI** - High wiper speed



Auto control wiper interval adjustment

Adjust the control knob.

- Fastest wiper speed
- Slowest wiper speed




PULL


Windshield washer

Pull the lever gently toward you to spray washer fluid on the windshield and to run the wipers 1-3 cycles.

WIPER BLADES



MIST
OFF



This vehicle has a “hidden” wiper design which means they cannot be lifted in their bottom resting position

Wiper Blade Removal

1. Within 20 seconds of turning off the engine, lift and hold the wiper lever up to the MIST **A** position for about 2 seconds until the wipers move to the top wipe position.
2. At this position, you are able to lift the wipers off the windshield.
3. Gently put wipers back down onto windshield.
4. Turn the wipers to any ON position to return to resting position.

NOTE: To prevent damage to the hood and wiper arms, the wiper arms should only be lifted when in the top wiping position.

INSTRUMENT CLUSTER

7" LCD Display



- 1 Tachometer
- 2 Speedometer
- 3 Engine coolant temperature gauge




- 4 Fuel gauge
- 5 Warning and indicator lights
- 6 LCD display

LCD DISPLAY MODES

Modes	Symbol	Explanation
Trip Computer		This mode displays driving information like the tripmeter, fuel economy, and so on.
Turn By Turn (TBT) (if equipped)		This mode displays the navigation turn by turn guidance.
Assist (if equipped)		This mode displays the state of the Driver Attention Warning (DAW) and Tire Pressure Monitoring System (TPMS).
Warning		Display service internal warning messages and tire pressures.

LCD DISPLAY CONTROL




- 1 : MODE button for changing modes
- 2 : MOVE switch for changing items
- OK (Press) : SELECT/RESET button for setting or resetting the selected item
- 3 : BACK button for moving to upper level menu (if equipped)

WARNINGS AND INDICATORS

Air bag warning light	Seat belt warning	Parking brake & Brake fluid warning light
Anti-lock Brake System (ABS) warning light	Electronic Brake Force Distribution (EBD) system warning light	
Electric Power Steering (EPS) warning light	Malfunction Indicator Lamp (MIL)	Charging system warning light
Engine coolant temperature warning light	Engine oil pressure warning light	Low fuel level warning light
ECO indicator	Door open warning light	Trunk open warning light
AWD warning light	Electric Parking Brake (EPB) warning light	Forward Collision-Avoidance Assist (FCA)
Master warning light	Electronic Stability Control (ESC) indicator	Electronic Stability Control (ESC) OFF indicator
Immobilizer indicator	Turn signal indicator	Low beam indicator
High beam indicator	Light ON indicator	High Beam Assist
Front fog light indicator	Cruise indicator	Adaptive Front Lighting System
AUTO HOLD indicator	SPORT mode indicator	Lane Keeping Assist (LKA)
Low Tire Pressure Warning Indicator/TPMS Malfunction Lamp		LED Headlight warning indicator

HEAD UP DISPLAY




The head up display is a transparent display which projects an image of selected information from the instrument cluster and navigation on the windshield glass.

To activate the head up display, select the Setup Hard key → Vehicle → Head-up Display in the headunit. Adjust "Head-up Display" height until in view.

NOTE: If you wear polarizing-filter sunglasses, it may be difficult to read the Head Up Display information.


CLIMATE CONTROL SYSTEM

Front



- 1 Driver's temperature control knob
- 2 Fan speed control button
- 3 OFF button
- 4 AUTO (automatic control) button
- 5 Mode selection button
- 6 Air conditioning button
- 7 Front windshield defrost button
- 8 Rear window defrost button
- 9 Passenger's temperature control knob
- 10 SYNC button (sync driver and passenger front air temperature)
- 11 Air intake control button (Outside air)
- 12 Air intake control button (Recirculated air)
- 13 Climate information screen selection button

DEFOGGING/DEFROSTING




1. Press the front defrost button.

NOTE: Outside (fresh) air position will be selected when front defrost button is selected.




2. Select warmest temperature.




3. Set the fan speed to the highest speed.

NOTE: To reduce the glass fogging and improve visibility, keep the interior surface of the windshield clean by wiping it with a clean cloth and glass cleaner. In addition, select air intake control to the outside (fresh) air position whenever possible while operating the vehicle.


MODE SELECTION



Changing the direction of the air flow as follow.




Rear



- 10 SYNC button (sync driver and passenger front air temperature)
- 11 Air intake control button (Outside air)
- 12 Air intake control button (Recirculated air)
- 13 Climate information screen selection button
- 14 Rear vent ON/OFF thumbwheel

AIR INTAKE CONTROL



AUTO DEFOGGING SYSTEM (ADS)


Auto defogging helps reduce the possibility of fogging up the inside windshield automatically. This system operates when the heater or A/C is on.

SMART VENT

If the cabin humidity increases while Climate Control is off, fresh air will automatically be circulated into the cabin. This feature control is located in the climate control information screen.

Please refer to the Owner's Manual for more information.

AUTOMATIC HEATING / AIR CONDITIONING




Automatically controls the modes, fan speeds, air intake and air-conditioning functions.




For your convenience and to improve the effectiveness of the climate control, use the AUTO button and set the temperature to 72°F (22°C).

BLUETOOTH PHONE PAIRING


Pairing a new device

NOTE: Vehicle must be in (P) Park to complete pairing process.

1. Press the PHONE button in the head unit (or DIS navigation system) or  button in the steering wheel remote control.




2. Search for the device name as displayed on your mobile phone and pair.



3. Confirm that the 6-digit passkey displayed on the audio screen and the Bluetooth device are identical.
4. Press OK in your Bluetooth device.
5. Pairing is complete.

USB PORT




When using wireless Android Auto® or Apple CarPlay®, note that the USB port will operate as a charging port.


For vehicles equipped with navigation, use the USB port to access features on your smartphone using Apple CarPlay® or Android Auto® phone projection.

Or use either USB port to charge an external device such as a cell phone.


WIRELESS CELLULAR PHONE CHARGING SYSTEM



The system operates when all doors are closed, and the Engine Start/Stop button is in the ACC/ON position. When the charging process is completed, the indicator light changes from orange to green. If there is a malfunction, the indicator light turns orange and blinks for 10 seconds. In this case, remove the phone from the charging pad and then placing it back onto the pad. The wireless charging function can be turned ON or OFF.

NOTE: The wireless cellular phone charging system supports only the Qi-enabled cellular phones (.


POWER OUTLET



The power outlet is designed to provide power for mobile telephones or other devices designed to operate with vehicle electrical systems. The devices should draw less than 180 watts with the engine running.

RADIO MODE


How to set Preset



1. Press the **A** RADIO button.
2. Rotate **B** TUNE knob to select desired station from FM/AM/SiriusXM.
3. Press the STAR **C** on screen to save preset.

NAVIGATION


Map position



- | | |
|--|--|
| <ul style="list-style-type: none"> 1 Displays the Home screen. 2 Used to change the map display mode 3 You can adjust the volume of navigation or GPS warning sound 4 Zooms in the map 5 The scale of the map automatically changes 6 Zooms out the map 7 Displays the rest areas on the route 8 Displays the point to change the driving direction 9 Displays the next point to change the driving direction | <ul style="list-style-type: none"> 10 Displays the lanes in different colors 11 Displays quick menu items that can be used during guidance 12 Cancel the route guidance 13 Displays the remaining distance to the destination and the estimated time of arrival 14 Displays or hides the detailed guidance 15 Displays the system information on the map |
|--|--|

NOTE: Map view can be changed by selecting Map view mode button.

GENESIS CONNECTED SERVICES



Genesis Connected Services subscription is required. To enroll, please visit your dealership or MyGenesisUSA.com.

Press the **∞** button for access to the voice-response menu of services.

- You can say:
- Roadside Assistance
- Service Link
- Account Assistance

Press the **📍** button for Destination Search by Voice.

Press the **SOS** button for SOS Emergency Assistance.

Visit MyGenesisUSA.com for more information or refer to your Genesis Connected Services User's Manual for detailed information on system operation.

For immediate assistance with subscription services, please call 1-844-340-9741.

Genesis Intelligent Assistant App




You can download the Genesis Intelligent Assistant App to your compatible smart phone from the following sites:

- iPhone® — Apple® App Store
- Android™ — Google Play™

Remote Start

Remote Start enables you to remotely start your vehicle virtually from anywhere. For vehicles equipped with full-automatic temperature control, you can also enable climate control remotely and turn on the front window defroster, ensuring a warm or cool car is ready to go when you are.

-  To use this feature, you must have a Genesis Connected Services Personal Identification Number (PIN). To create or change your PIN, log in to MyGenesisUSA.com.

Remember:

- Remote Start will automatically shut off after 10 minutes or after selected engine timer runs out in navigation vehicles.
- While this feature is active, the parking lights will blink until the vehicle is turned off or when vehicle is in operation.
- To continue to operate the vehicle, the proximity key must be inside the vehicle with the driver, prior to pressing the brake and being able to move the gearshift from the P (Park) position.

NOTE: Remote Start is only available for push button start equipped vehicles with an Automatic Transmission or a Dual Clutch Transmission (DCT).

Preconditions:

- Ignition is OFF
- Alarm is armed (i.e., vehicle locked by key fob or Remote Door Lock)
- Gearshift level is in the P (Park) position
- Brake pedal is not depressed
- Engine hood is securely closed
- All the doors are closed and locked
- The tailgate or trunk lid is closed
- The security / panic system is not activated
- The battery power is not low
- Vehicle is located in an open area
- It has been less than 4 days since last vehicle ignition off
- Vehicle located in area with good cell reception

Remote Start will terminate:

- After 10 minutes or after selected engine timer runs out in navigation vehicles
- Brake is pressed without the proximity key inside the vehicle
- Alarm is triggered without the proximity key inside the vehicle
- Door / trunk is opened from inside the vehicle

Notice: Laws in some communities may restrict the use of the features that remotely start the engine. For example, some laws may require a person using the remote start feature to have the vehicle in view when doing so, or limit the length of time a vehicle engine may idle. Please check local and state regulations for any requirements and restrictions on remote starting of vehicles and engine idling time.


WARNING!

Do not remote start vehicle in an enclosed environment (i.e., closed garage). Prolonged operation of a motor vehicle in an enclosed environment can cause a harmful build-up of carbon monoxide. Carbon monoxide is harmful to your health. Exposure to high levels of carbon monoxide can cause headaches, dizziness or in extreme cases unconsciousness and / or death. Do not leave children or animals unattended in a vehicle while using the remote start function.

CAUTION!

If the vehicle's windshield wipers are left on when the vehicle was last driven, then the wipers will turn on if the remote start function is activated. To avoid damage to the wiper blades (i.e., due to heavy ice or snow accumulated on the windshield), please always turn the vehicle's windshield wipers off when parking the vehicle.

HOMELINK WIRELESS GARAGE CONTROL SYSTEM



1. Press and release **1**, **2** or **3** button.
 - If the indicator **7** is turned ON in Orange, go to Step 3 (programming mode)
 - If the indicator **7** is continuously turned ON or flashes in Green rapidly several times, go to Step 2 (erasing mode)
2. Press and hold the button you wish to program for approximately 15- 25 seconds until the LED flashes in Orange for several times.
3. Hold the Garage Door Opener Original Transmitter near the HomeLink Mirror.
4. Press the Original Transmitter button until the indicator **7** is turned continuously ON or flashes in Green for approximately 10 seconds and it indicates the programming is completed.

NOTE: If the indicator **7** flashes in Green continuously, but if the garage door opener does not operate, please continue to follow Rolling Code Programming steps below.

Two Way Communication

Some new garage door openers come equipped with a two-way communication feature. If your garage door opener has this feature, please also continue to follow the Rolling Code Programming steps below. For more information and programming tips on two-way communication please visit [www. homelink.com/compatible/two-waycommunication](http://www.homelink.com/compatible/two-waycommunication) or call (800)-355-3515.



Indicator **4** & **6**:


Flashes in orange → “Closing” & “Opening”
Solid Green → “Closed” & “Opened”

NOTE: If 2-way communication (TWC) is not initially programmed properly it can lose programming after 10 operations. If so, contact Homelink customer support or go to www.HomeLink.com

Rolling Code Programming

- You may need a ladder to access your garage door opener.
- You may need help from a second person.
- Be prepared some of the steps are time sensitive.

1. Firmly press and release the “Learn”, Smart”, or “ Program” button of garage door opener on the ceiling while the indicator **7** flashes in Green. Once the button is pressed, you have approximately 30 seconds to initiate the next step.



2. Return to the vehicle and firmly press the HomeLink button, hold for two seconds and release the button up to three times. Do not press the HomeLink button rapidly. At this point programming is complete and your device should operate.

For more detailed information, please refer to your Owner’s manual or visit www.homelink.com or call (800) 355-3515



ANDROID AUTO™

REQUIREMENTS:

- USB cable
- OS Android™ 5.0 or higher
- Compatible Android Phone
- Data and wireless plan for applicable features

BEFORE YOU BEGIN:

- Android Auto features may operate differently than on your phone.
- Message and data charges may apply when using Android Auto.
- Android Auto relies on the performance of your phone. If you experience performance issues:
 - Close all apps and then restart them or
 - Disconnect and then reconnect your phone
- Using the USB cable that was provided with your phone is recommended.

ANDROID AUTO SUPPORT



<https://support.google.com/androidauto/>

NOTE - Dual Voice Recognition:

1. Pressing Voice Recognition button once will use vehicle onboard for requests.
2. Pressing and Holding Voice Recognition button will use Android Auto for requests.

PHONE SETUP

Turn on Bluetooth® on your phone and connect the USB cable to your phone and the USB port on the vehicle.


Phone will prompt you to download the Android Auto app and update other needed apps (i.e. Google Maps™, Google Play Music™, Google Now™).

NOTE: Vehicle must be parked.

- Location mode setting should be set to High accuracy.
- Car and phone setup should be completed in one sitting. If phone setup needs to be resumed, recommend to Force Stop the Android Auto app on the Phone then reopen the app and accept the Disclaimer notifications.

CAR SETUP

1. Press the SETUP button.
2. Touch the “Phone Projection” icon on screen.
3. Select “On” for Android Auto.
4. Connect your Android phone to the vehicle USB port. Agree to the notification and disclaimers on your phone then the “Android Auto” icon will appear confirming the setup.



For more detailed information on how to operate Android Auto, please refer to your navigation manual.

For additional Android Auto support, please refer to the Android Auto Support Website
<https://support.google.com/androidauto/>

Android Auto, Google Play, Android, and other marks are trademarks of Google Inc.

APPLE CARPLAY™

REQUIREMENTS

- Apple Lightning® cable
- Latest iOS
- iPhone® 5 or above
- Data and wireless plan for applicable features


BEFORE YOU BEGIN

- Apple® CarPlay features may operate differently than on your phone.
- Message and data charges may apply when using Apple CarPlay.
- Apple CarPlay relies on the performance of your phone. If you experience performance issues:
 - Close all apps and then restart them or
 - Disconnect and then reconnect your phone
- Using the Apple Lightning cable that was provided with your phone is recommended.

PHONE SETUP



On your phone, go to Settings > General > CarPlay to allow CarPlay access.

On your phone, go to Settings > Siri and ensure Siri is turned ON.



CAR SETUP

1. Press the SETUP button.
2. Touch the “Phone Projection” icon on the screen.
3. Touch “Apple CarPlay” on the Connectivity Settings screen. Then touch “On” to enable Apple CarPlay.
4. Connect your Apple iPhone to the vehicle USB port then touch ‘OK’ when the pop-up message appears. The Apple CarPlay icon will now appear on the vehicle Home screen confirming the setup.



Apple CarPlay, Apple, and other marks are trademarks of Apple Inc.

NOTE - Dual Voice Recognition:

1. Pressing Voice Recognition button once will use vehicle onboard for requests.
2. Pressing and Holding Voice Recognition button will use Android Auto for requests.

CarPlay Home Screen



- | | |
|-------------------------|----------------------------------|
| 1 HOME ICON | 8 MESSAGES |
| 2 WIRELESS CONNECTIVITY | 9 3RD PARTY APPS |
| 3 CELLULAR SIGNAL | 10 SCREEN PAGE INDICATOR |
| 4 PHONE TIME | 11 EXIT TO HOME SCREEN |
| 5 PHONE | 12 CURRENT CARPLAY AUDIO PLAYING |
| 6 APPLE MUSIC™ | 13 VOICE RECOGNITION |
| 7 APPLE MAPS | |

SIRI

Apple CarPlay uses Siri to perform many actions like sending messages, placing calls, and looking up/setting POI/Destinations. A Siri session can be initiated on any screen by:

1. Touch and hold the HOME icon 1 on the CarPlay screen or
2. Press and hold the steering wheel VOICE RECOGNITION 13 button.

NOTE: Ensure Siri feature is set to ON in your phone (Go to Settings > General > Siri).

3. Say any of the following commands;
 - “Text <John Smith> ‘Call you later’” to send a text message.
 - “Read text messages” to read available text message.
 - “Call <John Smith>” to make a phone call.
 - “Find <POI/Destination>” to locate a POI/Destination.

PHONE

Touch the PHONE 5 icon to access the Phone screen. Siri will automatically asks ‘Who you would like to call’ when the PHONE 5 icon is selected.

NOTE: Phone call sound quality is dependent on the wired connection. Using the Lightning cable that came with the phone is recommended.

APPLE MUSIC

Touch the APPLE MUSIC 6 icon to access the Apple Music screen.

APPLE MAPS

Touch the APPLE MAPS 7 icon to access the Apple Map screen.

MESSAGES

Touch the MESSAGES 8 icon to access the Message screen. Siri will automatically asks ‘To hear unread messages or create a new one’ when the MESSAGE icon is selected.


3rd PARTY APPS

Supported CarPlay apps that are downloaded on your phone will appear on the CarPlay screen. Touch the apps icons to access those supported apps.


NOTE: A list of the supported CarPlay supported apps can be found at <http://www.apple.com/ios/carplay/>

Ensure phone has latest version of the 3rd Party Apps.

SHIFT BY WIRE (Electronic type shifter)




P (Park)
Always stop completely before pressing P (Park) button. To shift the gear from R (Reverse), N (Neutral), D (Drive) or Manual mode to P (Park), press the [P] button while depressing the brake pedal.





R (Reverse) / N (Neutral) / D (Drive)
To select gear, press the [UNLOCK] button **A** while depressing the brake pedal and then move the shift lever forward (R side) or backward (D side).

Paddle Shifter (Manual Shift Mode)



Press (-) to downshift



Press (+) to upshift


The Paddle shifter is available when the shift lever is in the D position.

Press the [+] or [-] paddle shifter once to shift up or down one gear.

NOTE: To exit manual shift mode, pull and hold (+) paddle shifter for more than 3sec.

DRIVER ATTENTION WARNING (DAW)

Driver Attention Warning will help determine the driver's attention level by analyzing driving pattern, driving time, etc. while vehicle is being driven. Driver Attention Warning will recommend a break when the driver's attention level falls below a certain level.




- With the engine on, select or deselect 'Driver Assistance → Driver Attention Warning' from the Settings menu to set whether or not to use each function.

Inattentive Driving Warning - If this is selected, Driver Attention Warning will inform the driver the driver's attention level and will recommend taking a break when the level falls below a certain level.

Leading Vehicle Departure Alert - If this is selected, the function will inform the driver when the front vehicle departs from a stop.


ELECTRONIC STABILITY CONTROL (ESC)



The ESC system is an electronic system designed to help the driver maintain vehicle control under adverse conditions.


Press  to turn ESC on or off.

LANE KEEPING ASSIST (LKA)



Lane Keeping Assist detects lane markers on the road, and helps prevent the vehicle from departing the lane while driving.

- To turn LKA ON/OFF, short press button.
- To turn LFA ON/OFF, press and hold button more than 3 seconds.


LKA operates only when the vehicle speed is above 37 mph and when the  in the instrument cluster is green. LKA will not operate properly if the following conditions are present:

- the lane line is not clear
- on sharp bend in a road
- heavy fog

Refer to the Owner's Manual for more detailed information.


NOTE: During operation, you may feel the sensation of steering wheel movement. Depending on the road condition (gradient), the deflection driving may occur. LKA mode can be adjusted in the User Settings page of the infotainment system.

LANE FOLLOWING ASSIST (LFA)




Lane Following Assist is designed to help detect lane markings and/or vehicles on the road, and assists the driver's steering to help center the vehicle in the lane. The front view camera is used as a detecting sensor to help detect lane markings and vehicles in front.

To activate LFA:

With the engine on, shortly press the Lane Driving Assist button located on the steering wheel to turn on Lane Following Assist. The white or green  indicator light will illuminate on the cluster. Press the button again to turn off.

HIGHWAY DRIVING ASSIST (HDA)




Highway Driving Assist helps maintain a set distance and speed from the vehicle ahead when driving on a highway and helps center the vehicle in the lane while driving, even through a curve.

With the Engine Start/Stop button in the ON position, select or deselect 'Driver Assistance → Driving Convenience' from the setting menu to activate this setting.


NOTE: If the engine is turned off then on again, the system maintains the last setting.

Operation :

- Driving on the highway main road.
 - Vehicle speed is under 120 mph (200 km/h).
- Press the Smart Cruise Control button  on the steering wheel.
 - If entering the main road of highways while SCC and LFA is operating, HDA will be automatically activated.

If HDA is operating, the indicator on the cluster will illuminate green.

SMART CRUISE CONTROL



The cruise control system allows you to program the vehicle to maintain a constant speed without holding the accelerator pedal.

- 1 To turn On/Off cruise control.
- 2 Toggle switch UP to Resume or Increase the cruise control speed.
- 3 Toggle switch DOWN to Set or Decrease the cruise control speed.
- 4 To temporary cancel the Cruise Control
- 5 To set the vehicle distance

Setting Cruise Control

1. Press the “CRUISE” button 1 to turn on Cruise Control. The icon will illuminate in the instrument cluster.
2. Toggle “-SET” switch 3 DOWN to set cruising speed.


Adjusting the vehicle speed

1. Toggle “+RES” switch 2 UP to increase cruising speed.
2. Toggle “-SET” switch 3 DOWN to decrease cruising speed.

NOTE: Quick toggle up/down will change speed by 1 mph. Holding switch up/down will change speed by 5 mph.

To Cancel Cruise Control

Press the “PAUSE II” button 4 to temporarily cancel SCC. To turn off Smart Cruise Control, press the Driving Assist 5 button and SCC will turn off.



Each time the vehicle distance set button is pressed, the vehicle to vehicle distance changes as follows:



Setting vehicle distance (SMART CRUISE CONTROL only)

This system assist you in setting the distance from the vehicle ahead and will maintain the selected distance without you depressing the accelerator or the brake pedal. However, in stop and go traffic if the vehicle stops for more than 3 seconds, you must depress the accelerator pedal or push the toggle switch to start driving.

The vehicle to vehicle distance will automatically activate when you set the cruise speed.



BLIND-SPOT COLLISION AVOIDANCE ASSIST (BCA)



The BCA (Blind-Spot Collision Avoidance Assist) system uses radar sensors to alert the driver while driving. It senses the rear side territory of the vehicle and provides information to the driver.

- 1 Blind-Spot Collision Warning
- 2 Lane change assist
- 3 Rear Cross-Traffic Collision Warning (RCCW)

- To turn the BCA on, select 'Driver Assistance → Blind-Spot Safety' from the Settings menu to set each function.
- To turn the BCA off, go to 'Driver Assistance → Blind-Spot Safety' and deselect the feature in the Settings menu.



The BCA system will activate once vehicle speed exceeds 20 mph.

The RCCW (Rear Cross-Traffic Collision Warning) alert will activate, if vehicle is in reverse at speeds below 6 mph and BCA is activated.

NOTE: The RCCW system will only activate on the first reverse application from park.

Please refer to your Owner's Manual for further information.

REAR VIEW MONITOR




The rearview camera will activate when the engine is running and the shift lever is in the R (Reverse) position.

NOTE: Rearview display is selectable, see Owner's Manual for further details.

The image displayed on the screen may become difficult to see under the following conditions:

- In the dark or at night.
 - When it is raining, or when water droplets are on the camera.
 - When the sun or the beam of headlights are shining into the camera lens.
- Use care to keep the camera lens clean and avoid applying any type of solvents, car wax, or window cleaners to the camera lens. If the lens becomes dirty, wipe the lens with a clean, soft cloth.

FORWARD/REVERSE PARKING DISTANCE WARNING (PDW)



Forward/Reverse Parking Distance Warning will help warn the driver if an obstacle is detected within a certain distance when the vehicle is moving forward or in reverse at low speeds.

Press button to turn ON/OFF:


- ON – indicator light on
- OFF – indicator light off

If the PDW is OFF, the system will turn ON automatically when the shift lever is in R (reverse).

NOTE: Front parking sensor will not operate if the PDW is OFF.

The system will automatically turn OFF when vehicle is driven forward at speed above 6 mph.

FORWARD COLLISION-AVOIDANCE ASSIST (FCA)




The Forward Collision Avoidance (FCA) system is designed to help detect and monitor the vehicle ahead and warn the driver if a collision is imminent. On vehicles equipped with both camera and radar sensor, pedestrian detection is also available.

To operate the system, select 'Driver Assistance → Forward Safety' from the Settings menu to set whether or not to use each function. Please refer to your Owner's Manual for further information.

"Early, Normal, & Late" are NOT the available choices in head unit under "Driver Assistance → Forward Safety"

Driver Assistance -> Forward Safety -> (choices) Active Assist/Warning Only/Off




Driver Assistance -> Warning Timing -> (choices) Standard/Late



Driver Assistance -> Warning Volume -> (choices) High/Medium/Low/Off



TIRE PRESSURE MONITORING SYSTEM (TPMS)



Low Tire Pressure Indicator / TPMS Malfunction Indicator



NOTE: Vehicle must be driven for accurate tire pressure reading.

Low Tire Pressure Position Telltale and Tire Pressure Telltale (Shown on the LCD display)


LOW TIRE PRESSURE INDICATOR

Illuminates if one or more of your tires are significantly under-inflated.

TPMS MALFUNCTION INDICATOR

Blinks for approximately one minute, then remains illuminated when there is a malfunction with the TPMS. Inspect all tires and adjust tire pressure to specification. If the lamp remains illuminated, have the system checked by an authorized retailer of Genesis Brand Products as soon as possible.


LOW TIRE PRESSURE POSITION INDICATOR AND TIRE PRESSURE INDICATOR (LCD DISPLAY)



To access the TPMS menu within the LCD display, press the Assist mode button on the steering wheel to display tire pressure.

Tire pressures will display after driving a short distance. If a tire pressure drops lower than predetermined specification, the Low Tire Pressure Indicator (⚠️) will illuminate and the LCD (📺) display will indicate tire(s) requiring air.

ELECTRIC PARKING BRAKE (EPB)



To apply EPB (Electronic Parking Brake)


1. Depress and hold the brake pedal.
2. Pull up the EPB switch. Make sure the Parking Brake warning light comes on.

To release EPB (Electronic Parking Brake)

1. Press the Engine Start/Stop button to the ON or START position.
2. Press the EPB switch while depressing the brake pedal. Make sure the Parking Brake warning light goes off.

NOTE: If necessary, emergency braking is possible by pulling and holding the EPB switch.

AUTO HOLD



The Auto Hold feature assists in steep hill areas. It holds the brake until the accelerator pedal is pressed.

**WHITE
AUTO
HOLD**

1. Press the AUTO HOLD switch.

**GREEN
AUTO
HOLD**



2. Stop the vehicle by pressing the brake pedal. The brakes will remain engaged even if the brake pedal is released.

**WHITE
AUTO
HOLD**

3. The brakes will release when the accelerator pedal is pressed with transmission in D, R or manual mode.

To cancel the AUTO HOLD operation, press the AUTO HOLD switch again.

DIGITAL KEY PAIRING (if equipped)



Genesis Digital Key allows drivers to start the engine of their car using a smartphone app and Near-Field Communication (NFC). Genesis Digital Key provides many of the same functions as your physical key. To pair your smartphone, complete the following steps:

1. Login to the Genesis Digital Key Application using your MyHyundai username and password
2. Start the vehicle with the proximity key
3. Pair the phone to the vehicle as follows:
 - Navigation Vehicles: Settings -> Vehicle -> Digital Key -> Smartphone Key -> Save
 - Display Audio: Instrument Cluster User Settings Mode -> Digital Key -> Smartphone Key -> Save
4. Open the Genesis Digital Key Application on the primary user's smartphone. Select the + Icon on the main screen of the smartphone app.
5. Place the smartphone on the Wireless Phone Charger in the vehicle and the process will begin automatically
6. Once the screen in the vehicle says saved, your Digital Key is ready to use.

NOTE: This application is only available for Android users.

If the NFC card is lost or stolen, please contact your local Genesis dealer for replacement.


NEAR FIELD COMMUNICATION (NFC)



Pair Card Key authentication

Authenticate using NFC

Authenticate using BLE



To lock/unlock your vehicle using the NFC key card, hold the key card up to the center of the door handle **A**.

If you try to lock your vehicle with the NFC card under the following conditions, it will not work:

- The Smart Key is in the vehicle.
- The POWER button is in ACC or ON position.
- Any of the doors, hood and trunk are open.

NOTE: If you overlap and use the key card with other NFC-enabled cards such as a transportation card or credit card, it will not work.

*For security reasons, the vehicle can only have one NFC key card paired to it at one time. Any time that a new Key card is paired to the car it will disable the previously paired Key Card .

GENESIS SERVICE VALET PROGRAM TERMS AND CONDITIONS

Program Coverage Summary

Genesis Service Valet is included for the first 3 years or 36,000 miles, whichever comes first, of ownership.			
Complimentary Services	Service Valet	Complimentary Loaner Vehicle	Maintenance
Original Owner or Lessee	Yes	Yes	Yes
Subsequent Owner or Lessee	Warranty Only	Warranty Only	No

See below for program terms and conditions.

SERVICE VALET

Service Valet is available while your vehicle is receiving complimentary maintenance, wear items, or warranty repairs by an authorized Genesis retailer. Simply contact your authorized Genesis retailer's Service Experience Manager or contact the Customer Care Center at 844-340-9741 to make your appointment. The retailer will work with you to arrange your pickup and delivery time and location.

- Valet appointments must be made at least 2 business days in advance.
- Valet area of coverage is valid only within an estimated 1 hour drive time distance (based on traffic, weather, and road conditions) from the participating retailer location to the pickup/delivery location.
- Valet pickup and delivery must occur during normal business hours. After-hours pickup and delivery are at the discretion of your participating retailer.
- You must notify your Genesis Service Experience Manager 1 business day in advance if location or time of valet services changes. If a change or cancellation is not made at least 1 business day in advance, you may be charged a fee, or Service Valet may be cancelled.
- You will be charged a fee if you elect to extend the use of the courtesy replacement vehicle or delay the delivery of your vehicle.
- Prior to or at the time of your vehicle pickup, you will need to provide your valet with the following information if a courtesy replacement vehicle is needed:
 - Insurance company name, policy number, and expiration date
 - Driver's license number, state, expiration, and date of birth
 - Credit card number and expiration date (standard requirement for rental car use)
 - The above information for any additional drivers

Genesis brand vehicle owner must provide the valet with the Genesis brand vehicle that is currently registered in compliance with local and state laws. Road tolls incurred during the Service Valet may be charged to the vehicle owner.

COMPLIMENTARY LOANER VEHICLE

We come to you and provide you with alternative transportation. While your vehicle is being serviced under this program, qualified drivers will be provided a courtesy replacement Genesis brand vehicle at no additional cost. You must be at least 25 years of age (in most states) with a valid driver's license to drive a loaner vehicle. Please provide your Service Advocate with the following information:

- Insurance company name, policy number, and expiration date
- Driver's license number, state, expiration and birth date
- Credit card number and expiration date (standard requirement for rental car use)
- The above information for any additional drivers

COMPLIMENTARY MAINTENANCE COVERAGE

Vehicle Eligibility

For original retail owners of the Genesis vehicle, all factory-recommended scheduled maintenance are covered for the first 3 years or 36,000 miles, whichever comes first. The Service Valet Program is applicable to all 2017 - 2019 model year Genesis brand vehicle United States specification vehicles purchased in the United States from authorized Genesis retailers. The program is not in effect outside of the United States.

- Vehicle coverage begins on the date of first retail sale. Fleet vehicles are excluded from this program.
- If the vehicle becomes damaged (such as by accident, fire, act of nature, etc.) and is subsequently titled salvaged, flooded, or reconstructed, it is no longer eligible for the benefits of the Genesis G80 complimentary maintenance Program.

Guidelines for Scheduling Maintenance

The Service Valet Program covers factory-recommended scheduled maintenance for the first 3 years or 36,000 miles, whichever comes first. Covered maintenance costs include all labor and parts necessary to complete the factory recommended service. Having your vehicle serviced at the specified time/mile intervals is critical in maintaining long-term durability. Failure to have your vehicle serviced at the specified interval may invalidate the warranty under certain circumstances.

If for any reason a service is missed, the authorized Genesis retailer will perform the next or missed major service.

Some owners may wish to have their oil changed more frequently. The customer must pay for any additional services performed on the vehicle. Service procedures not specifically referenced in the Genesis Customer Care Quick Reference Guide must be preauthorized by a Genesis District Parts and Service Manager.

COMPLIMENTARY MAINTENANCE COVERAGE (continued)

Exclusions from Coverage

The following items, without limitations, are not covered :

- Gasoline and gasoline additives
- State inspections
- Wear and tear of soft trim, including seats, carpets, door casings, wood veneer, headliner, and all chrome trim
- Wear and tear or damage to exterior body panels, trim, and glass
- Damage due to poor fuel quality, misuse, abuse, neglect, fire, accident, flood, or installation of unapproved parts and accessories
- Vehicles used in competitive events
- Vehicles with an unreadable/tampered VIN, or where true mileage cannot be determined
- Repairs and maintenance not performed at an Authorized retailer of Genesis.
- Repairs covered under the New Vehicle Limited Warranty
- Required maintenance and covered wear parts replacement on United States specification vehicles operating outside the United States

Transfer of Coverage

The described coverage only applies to the original retail purchaser or original lessee of a Genesis Brand vehicle. The coverage is not transferable to subsequent owners, with the exception of immediate family members. Immediate family members include the following:

- Spouses or registered domestic partners
- Parents
- Children or stepchildren

Dealerships will verify that the owner/customer is the original owner/lessee. Certain limitations and exclusions apply to this program. Please refer to your New Vehicle Limited Warranty guide for warranty details.

 Guest Date

GENESIS GUEST DELIVERY CHECKLIST

GENESIS BRAND OWNER	RETAILER NAME
SALES CONSULTANT	DATE
VIN	PREVIOUS VEHICLE

BEFORE DELIVERY

- SET TIRE PRESSURE LF ___ RF ___ RR ___ LR ___
- VERIFY VEHICLE IS CLEAN, IN GOOD CONDITION, FREE OF CHIPS AND SCRATCHES · CLEAN WINDSHIELD AND BACK WINDOW
- ENSURE FLOORMATS ARE SNAPPED INTO PLACE

WALK THE CUSTOMER THROUGH EACH OF THE FOLLOWING KEY DELIVERY FEATURES

- REVIEW QUICK REFERENCE GUIDE
- PAIR CUSTOMER'S PHONE TO THE BLUETOOTH SYSTEM
- OPERATION OF THE NAVIGATION SYSTEM - page 19
- REVIEW AND TEAR OFF VOICE COMMAND / QUICK TIP CARD
- OPERATION OF THE AUDIO SYSTEM

BLUETOOTH® HANDS-FREE



CONNECTING YOUR PHONE

- On the radio:**
1. Select **All Menus**.
 2. Select **Setup**.
 3. Select **Bluetooth -> Bluetooth Connection**.
- **Alternately, you can also press the green colored answer button on the steering wheel OR the PHONE hard key located on the center stack to initiate Bluetooth Pairing.**
4. Select **Add New Device**.
- In your phone's Bluetooth settings:**
5. Select the <Vehicle Name> on your phone
 6. Enter the passkey from the radio or accept the authorization pop-up on your phone.

SWITCHING BETWEEN PAIRED PHONES

- Using Voice Command:**
 "Change Bluetooth device"
- On the radio:**
1. Select **All Menus**.
 2. Select **Setup**.
 3. Select **Bluetooth -> Bluetooth Connection**.
 4. Select **Connect** next to the desired phone.